



# EBERLINE SERVICES

006499'7

February 22, 2005

Mr. Steve Trent  
Fluor Hanford Inc.  
825 Jadwin Avenue  
Richland, WA 99352

Reference: P.O. #630  
Eberline Services R4-12-175-7191, SDG H2905  
R4-12-214-7197, SDG H2905  
R4-12-280-7209, SDG H2905

Dear Mr. Trent:

Enclosed is data for eight solid samples all designated under SAF No. F04-015. Three samples were received on December 16, three received December 20, and two received December 23, 2004; all the samples were placed in sample delivery group H2905. The samples were analyzed according to the accompanying chain-of-custody documents.


Please call if you have any questions concerning this report.

Sincerely,

Melissa C. Mannion  
Senior Program Manager

MCM/njv

Enclosure: Data Package



RECEIVED  
MAY 12 2005  
EDMC

Analytical Services  
2030 Wright Avenue  
P.O. Box 4040  
Richmond, California 94804-0040  
(510) 235-2633 Fax (510) 235-0438  
Toll Free (800) 841-5487  
[www.eberlineservices.com](http://www.eberlineservices.com)

000000001

## 1.0 GENERAL

Fluor Hanford Inc. (FH) Sample Delivery Group H2905 was composed of eight solid (soil) samples designated under SAF No. F04-015 with a Project Designation of: 200-MW-1 Characterization Sampling and Analysis-Soil.

The samples were received as stated on the Chain-of-Custody documents. Any discrepancies are noted on the Eberline Services Sample Receipt Checklist. The three samples received on December 16 and the three received December 20 were analyzed together in preparation batches with common QC samples. The two samples received December 23 were analyzed with their own QC samples.

## 2.0 ANALYSIS NOTES

### 2.2 Tritium Analyses

No problems were encountered during the course of the analyses.

### 2.6 Total Strontium Analyses

Required for samples B19960 and B19961 only. No problems were encountered during the course of the analyses.

### 2.7 Technetium-99 Analyses

No problems were encountered during the course of the analyses.

### 2.8 Iodine-129 Analyses

No problems were encountered during the course of the analyses.

### 2.9 Isotopic Uranium Analyses

Required for samples B19960 and B19961 only. No problems were encountered during the course of the analyses.

### 2.10 Total Uranium Analyses

Required for samples B19960 and B19961 only. No problems were encountered during the course of the analyses.

### 2.14 Isotopic Plutonium Analyses

Required for samples B19960 and B19961 only. No problems were encountered during the course of the analyses.

Eberline Services  
W.O. No. R4-12-175-7191  
R4-12-214-7197  
R4-12-280-7209

Fluor Hanford Inc.  
SDG H2905

**Case Narrative**

**Page 2 of 2**

**2.15 Americium-241 Analyses**

Required for samples B19960 and B19961 only. No problems were encountered during the course of the analyses.


**2.16 Gamma Spectroscopy**

Required for samples B19960 and B19961 only. No problems were encountered during the course of the analyses.

**Case Narrative Certification Statement**

"I certify that this data package is in compliance with the SOW, both technically and for completeness, for other than the conditions detailed above. Release of the data obtained in this hard copy data package has been authorized by the Laboratory Manager or a designee, as verified by the following signature."

  
\_\_\_\_\_  
Melissa C. Mannion  
Senior Program Manager

  
\_\_\_\_\_  
Date

00000003


EBERLINE SERVICES / RICHMOND  
SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

S U M M A R Y   D A T A   S E C T I O N

T A B L E   O F   C O N T E N T S					
About this section	.	.	.	.	1
Sample Summaries	.	.	.	.	3
Prep Batch Summary	.	.	.	.	5
Work Summary	.	.	.	.	6
Method Blanks	.	.	.	.	7
Lab Control Samples	.	.	.	.	8
Duplicates	.	.	.	.	9
Matrix Spikes	.	.	.	.	10
Data Sheets	.	.	.	.	11
Method Summaries	.	.	.	.	13
Report Guides	.	.	.	.	16
End of Section	.	.	.	.	30

  
Prepared by

  
Reviewed by

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-TOC  
Version 3.06  
Report date 02/21/05

00000004

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

### ABOUT THE DATA SUMMARY SECTION

The Data Summary Section of a Data Package has all data, in several useful orders, necessary for first level, routine review of the data package for a Sample Delivery Group (SDG). This section follows the Data Package Narrative, which has an overview of the data package and a discussion of special problems. It is followed by the Raw Data Section, which has full details.

The Data Summary Section has several groups of reports:

#### SAMPLE SUMMARIES

The Sample and QC Summary Reports show all samples, including QC samples, reported in one SDG. These reports cross-reference client and lab sample identifiers.

#### PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches (lab groupings reflecting how work was organized) relevant to the reported SDG with information necessary to check the completeness and consistency of the SDG.

#### WORK SUMMARY

The Work Summary Report shows all samples and work done on them relevant to the reported SDG.

#### METHOD BLANKS

The Method Blank Reports, one for each Method Blank relevant to the SDG, show all results and primary supporting information for the blanks.

#### LAB CONTROL SAMPLES

The Lab Control Sample Reports, one for each Lab Control Sample relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

#### REPORT GUIDES

Page 1

#### SUMMARY DATA SECTION

Page 1

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000005

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

ABOUT THE DATA SUMMARY SECTION

DUPLICATES

The Duplicate Reports, one for each Duplicate and Original sample pair relevant to the SDG, show all results, differences and primary supporting information for these QC samples.

MATRIX SPIKES

The Matrix Spike Reports, one for each Spiked and Original sample pair relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

DATA SHEETS

The Data Sheet Reports, one for each client sample in the SDG, show all results and primary supporting information for these samples.

METHOD SUMMARIES

The Method Summary Reports, one for each test used in the SDG, show all results, QC and method performance data for one analyte on one or two pages. (A test is a short code for the method used to do certain work to the client's specification.)

REPORT GUIDES

The Report Guides, one for each of the above groups of reports, have documentation on how to read the associated reports.

REPORT GUIDES

Page 2

SUMMARY DATA SECTION

Page 2

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000006

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191

Contact Melissa C. Mannion

## SAMPLE SUMMARY

Client Hanford

Contract No. 630

Case no SDG H2905

CLIENT SAMPLE ID	LOCATION	MATRIX	LEVEL	LAB SAMPLE ID	SAF NO	CHAIN OF CUSTODY	COLLECTED
B19960	216-U-3; 17.5-20ft	SOLID		R412175-01	F04-015	F04-015-065	12/10/04 10:50
B19961	216-U-3; 17.5-20ft	SOLID		R412175-02	F04-015	F04-015-065	12/10/04 10:50
Method Blank		SOLID		R412175-04	F04-015		
Lab Control Sample		SOLID		R412175-03	F04-015		
Duplicate (R412175-01)	216-U-3; 17.5-20ft	SOLID		R412175-05	F04-015		12/10/04 10:50
Spike (R412175-02)	216-U-3; 17.5-20ft	SOLID		R412175-06	F04-015		12/10/04 10:50

SAMPLE SUMMARY

Page 1

SUMMARY DATA SECTION

Page 3

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-CS

Version 3.06

Report date 02/21/05

00000007

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

## QC SUMMARY

SDG 7191  
Contact Melissa C. Mannion

Client Hanford  
Contract No. 630  
Case no SDG H2905

K BATCH	CHAIN OF CUSTODY	CLIENT SAMPLE ID	MATRIX	% SOLIDS	SAMPLE AMOUNT	BASIS AMOUNT	DAYS SINCE RECEIVED	LAB COLL	LAB SAMPLE ID	DEPARTMENT SAMPLE ID
191	F04-015-065	B19960	SOLID	96.5	99.1 g		12/16/04	6	R412175-01	7191-001
		B19961	SOLID	93.1	100.6 g		12/16/04	6	R412175-02	7191-002
		Method Blank	SOLID						R412175-04	7191-004
		Lab Control Sample	SOLID						R412175-03	7191-003
		Duplicate (R412175-01)	SOLID	96.5	99.1 g		12/16/04	6	R412175-05	7191-005
		Spike (R412175-02)	SOLID	93.1	100.6 g		12/16/04	6	R412175-06	7191-006

QC SUMMARY

Page 1

SUMMARY DATA SECTION

Page 4

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-QS  
Version 3.06  
Report date 02/21/05

00000008



# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191

Contact Melissa C. Mannion

## PREP BATCH SUMMARY

Client Hanford

Contract No. 630

Case no SDG H2905

TEST	MATRIX	METHOD	PREPARATION ERROR		PLANCHETS ANALYZED					QUALI-	
			BATCH	2σ %	CLIENT	MORE	RE	BLANK	LCS	DUP/ORIG	MS/ORIG
Beta Counting											
TC	SOLID	Technetium 99 in Solids	7121-061	10.0	2			1	1	1/1	
Gamma Spectroscopy											
I	SOLID	Iodine 129 in Solids	7121-061	10.0	2			1	1	1/1	
Liquid Scintillation Counting											
H	SOLID	Tritium in Solids	7121-061	10.0	2			1	1	1/1	1/1 X

Duplicates and Matrix Spikes are those with original (Client) sample in this Sample Delivery Group.

Blank and LCS planchets are those in the same preparation batch as some Client, Duplicate or Spike sample.

PREP BATCH SUMMARY

Page 1

SUMMARY DATA SECTION

Page 5

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-PBS

Version 3.06

Report date 02/21/05

00000000

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191

Contact Melissa C. Mannion

## WORK SUMMARY

Client Hanford

Contract No. 630

Case no SDG H2905

CLIENT SAMPLE ID	MATRIX	LAB SAMPLE ID	TEST	SUF-	ANALYZED	REVIEWED	BY	METHOD
LOCATION	SAF No	COLLECTED	PLANCHET	FIX				
USTODY		RECEIVED						
19960		R412175-01	7191-001	H	02/03/05	02/09/05	MWT	Tritium in Solids
16-U-3; 17.5-20ft	SOLID	12/10/04	7191-001	I	02/09/05	02/16/05	MWT	Iodine 129 in Solids
04-015-065	F04-015	12/16/04	7191-001	TC	01/31/05	02/03/05	MWT	Technetium 99 in Solids
19961		R412175-02	7191-002	H	02/04/05	02/09/05	MWT	Tritium in Solids
16-U-3; 17.5-20ft	SOLID	12/10/04	7191-002	I	02/09/05	02/16/05	MWT	Iodine 129 in Solids
04-015-065	F04-015	12/16/04	7191-002	TC	01/31/05	02/03/05	MWT	Technetium 99 in Solids
Method Blank		R412175-04	7191-004	H	02/04/05	02/09/05	MWT	Tritium in Solids
	SOLID		7191-004	I	02/09/05	02/11/05	MWT	Iodine 129 in Solids
	F04-015		7191-004	TC	02/01/05	02/03/05	MWT	Technetium 99 in Solids
Lab Control Sample		R412175-03	7191-003	H	02/04/05	02/09/05	MWT	Tritium in Solids
	SOLID		7191-003	I	02/09/05	02/10/05	MWT	Iodine 129 in Solids
	F04-015		7191-003	TC	01/31/05	02/03/05	MWT	Technetium 99 in Solids
Duplicate (R412175-01)		R412175-05	7191-005	H	02/04/05	02/09/05	MWT	Tritium in Solids
16-U-3; 17.5-20ft	SOLID	12/10/04	7191-005	I	02/09/05	02/11/05	MWT	Iodine 129 in Solids
	F04-015	12/16/04	7191-005	TC	02/02/05	02/03/05	MWT	Technetium 99 in Solids
Pike (R412175-02)		R412175-06	7191-006	H	02/04/05	02/09/05	MWT	Tritium in Solids
16-U-3; 17.5-20ft	SOLID	12/10/04						
	F04-015	12/16/04						

## COUNTS OF TESTS BY SAMPLE TYPE

TEST	SAF No	METHOD	REFERENCE	CLIENT	MORE	RE	BLANK	LCS	DUP	SPIKE	TOTAL
H	F04-015	Tritium in Solids	906.0_H3_LSC	2			1	1	1	1	6
I	F04-015	Iodine 129 in Solids	I129_SEP_LEPS_GS	2			1	1	1		5
TC	F04-015	Technetium 99 in Solids	TC99_TR_SEP_LSC	2			1	1	1		5
TOTALS				6			3	3	3	1	16

WORK SUMMARY

Page 1

SUMMARY DATA SECTION

Page 6

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-CWS

Version 3.06

Report date 02/21/05

00000010

**METHOD BLANK**

~~AAA-AAA-1-1~~

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

R412175-03

Lab Control Sample

## LAB CONTROL SAMPLE

SDG <u>7191</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412175-03</u>	Client sample id <u>Lab Control Sample</u>	
Dept sample id <u>7191-003</u>	Material/Matrix <u>SOLID</u>	
	SAF No <u>F04-015</u>	

ANALYTE	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS TEST	ADDED pCi/g	2σ ERR pCi/g	REC %	3σ LMTS (TOTAL)	PROTOCOL LIMITS
Tritium	11.8	0.55	0.38	400	H	11.8	0.47	100	82-118	80-120
Technetium 99	111	3.0	0.85	15	TC	109	4.4	102	83-117	80-120
Iodine 129	125	2.8	<u>5.0</u>	2.0	I	116	4.6	108	82-118	80-120

200-MW-1 Charatrizatn.Samp.&Ana-Soil

QC-LCS 51221

LAB CONTROL SAMPLES

Page 1

SUMMARY DATA SECTION

Page 8

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LCS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000012

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

R412175-05

B19960

## DUPLICATE

SDG <u>7191</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
DUPLICATE	ORIGINAL	
Lab sample id <u>R412175-05</u>	Lab sample id <u>R412175-01</u>	Client sample id <u>B19960</u>
Dept sample id <u>7191-005</u>	Dept sample id <u>7191-001</u>	Location/Matrix <u>216-U-3; 17.5-20ft</u>
	Received <u>12/16/04</u>	Collected/Weight <u>12/10/04 10:50 99.1 g</u>
% solids <u>96.5</u>	% solids <u>96.5</u>	Custody/SAF No <u>F04-015-065</u> <u>F04-015</u>

ANALYTE	DUPLICATE pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ORIGINAL pCi/g	2σ ERR (COUNT)	MDA pCi/g	QUALI- FIERS	RPD %	3σ PROT TOT LIMIT
Tritium	0.419	0.15	0.23	400		H	0.362	0.15	0.23		15	84
Technetium 99	-0.010	0.31	0.93	15	U	TC	0.080	0.28	0.47	U	-	
Iodine 129	-1.04	2.7	<u>6.1</u>	2.0	U	I	-0.336	0.85	1.9	U	-	

200-MW-1 Charatrizatn.Samp.&Ana-Soil

QC-DUP#1 51223

DUPLICATES

Page 1

SUMMARY DATA SECTION

Page 9

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DUP</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000013

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

R412175-06

B19961

## MATRIX SPIKE

SDG <u>7191</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract <u>No. 630</u>	
<b>MATRIX SPIKE</b>	<b>ORIGINAL</b>	
Lab sample id <u>R412175-06</u>	Lab sample id <u>R412175-02</u>	Client sample id <u>B19961</u>
Dept sample id <u>7191-006</u>	Dept sample id <u>7191-002</u>	Location/Matrix <u>216-U-3; 17.5-20ft</u> <b>SOLID</b>
	Received <u>12/16/04</u>	Collected/Weight <u>12/10/04 10:50</u> <u>100.6 g</u>
% solids <u>93.1</u>	% solids <u>93.1</u>	Custody/SAF No <u>F04-015-065</u> <u>P04-015</u>

ANALYTE	SPIKE pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ADDED pCi/g	2σ ERR pCi/g	ORIGINAL pCi/g	2σ ERR (COUNT)	REC 3σ % (TOTAL)	LMTS LIMITS	PROTOCOL
Tritium	57.3	2.4	0.83	400	X	H	58.2	2.3	0.417	0.15	98	83-117	60-140

200-MW-1 Charatrizatn.Samp.&Ana-Soil

QC-MS#2 51224

MATRIX SPIKES

Page 1

SUMMARY DATA SECTION

Page 10

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-MS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

000000014

**EBERLINE SERVICES / RICHMOND**  
**SAMPLE DELIVERY GROUP H2905**

R412175-01

B19960

**DATA SHEET**

SDG <u>7191</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412175-01</u>	Client sample id <u>B19960</u>	
Dept sample id <u>7191-001</u>	Location/Matrix <u>216-U-3; 17.5-20ft</u>	<u>SOLID</u>
Received <u>12/16/04</u>	Collected/Weight <u>12/10/04 10:50</u>	<u>99.1 g</u>
% solids <u>96.5</u>	Custody/SAF No <u>F04-015-065</u>	<u>F04-015</u>

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	0.362	0.15	0.23	400		H
Technetium 99	14133-76-7	0.080	0.28	0.47	15	U	TC
Iodine 129	15046-84-1	-0.336	0.85	1.9	2.0	U	I

200-MW-1 Charatrizatn.Samp.&Ana-Soil

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000015

**EBERLINE SERVICES / RICHMOND**  
**SAMPLE DELIVERY GROUP H2905**

R412175-02

B19961

**DATA SHEET**

SDG <u>7191</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412175-02</u>	Client sample id <u>B19961</u>	
Dept sample id <u>7191-002</u>	Location/Matrix <u>216-U-3; 17.5-20ft</u>	<u>SOLID</u>
Received <u>12/16/04</u>	Collected/Weight <u>12/10/04 10:50</u>	<u>100.6 g</u>
% solids <u>93.1</u>	Custody/SAF No <u>F04-015-065</u>	<u>F04-015</u>

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	0.417	0.15	0.23	400		H
Technetium 99	14133-76-7	0.126	0.36	0.56	15	U	TC
Iodine 129	15046-84-1	0.527	0.54	1.2	2.0	U	I

200-MW-1 Charatrizatn.Samp.&Ana-Soil

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000016



# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

## METHOD SUMMARY

TECHNETIUM 99 IN SOLIDS

BETA COUNTING

Test TC Matrix SOLID

SDG 7191

Contact Melissa C. Mannion

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Technetium 99
reparation batch 7121-061				
19960	R412175-01		7191-001	U
19961	R412175-02		7191-002	U
LK (QC ID=51222)	R412175-04		7191-004	U
CS (QC ID=51221)	R412175-03		7191-003	ok
uplicate (R412175-01)	R412175-05		7191-005	- U

ominal values and limits from method RDLs (pCi/g) 15  
00-MW-1 Charatrizatn.Samp.&Ana-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT keV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
reparation batch 7121-061 2σ prep error 10.0 % Reference Lab Notebook 7121 pg. 061																
19960	R412175-01		0.47	1.00				85		104			52	01/28/05	01/31	GRB-231
19961	R412175-02		0.56	1.00				63		104			52	01/28/05	01/31	GRB-232
LK (QC ID=51222)	R412175-04		0.76	1.00				66		50				01/28/05	02/01	GRB-203
CS (QC ID=51221)	R412175-03		0.85	1.00				65		50				01/28/05	01/31	GRB-225
uplicate (R412175-01) (QC ID=51223)	R412175-05		0.93	1.00				54		50			54	01/28/05	02/02	GRB-224

ominal values and limits from method 15 1.00 20-105 50 180

PROCEDURES REFERENCE TC99\_TR\_SEP\_LSC  
CP-431 Technetium-99 Purification of Soil or Resin by  
Extraction Chromatography, rev 2  
CP-008 Heavy Element Electroplating, rev 9

AVERAGES ± 2 SD MDA 0.71 ± 0.39  
FOR 5 SAMPLES YIELD 67 ± 23

METHOD SUMMARIES

Page 1

SUMMARY DATA SECTION

Page 13

Lab id EBRLINE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-CMS  
Version 3.06  
Report date 02/21/05

00000017

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test I Matrix SOLID

SDG 7191

Contact Melissa C. Mannion

## METHOD SUMMARY

IODINE 129 IN SOLIDS

GAMMA SPECTROSCOPY

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Iodine 129
reparation batch 7121-061				
19960	R412175-01	7191-001		U
19961	R412175-02	7191-002		U
LK (QC ID=51222)	R412175-04	7191-004		U
CS (QC ID=51221)	R412175-03	7191-003		ok
uplicate (R412175-01)	R412175-05	7191-005		- U

ominal values and limits from method RDLs (pCi/g) 2.0  
00-MW-1 Charatrizatn.Samp.&Ana-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA g	ALIQ FAC	PREP TION	DILU- %	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
reparation batch 7121-061 2σ prep error 10.0 % Reference Lab Notebook 7121 pg. 061																
19960	R412175-01		1.9	1.00			44	607		61	02/07/05	02/09	XSPEC-004			
19961	R412175-02		1.2	1.00			49	607		61	02/07/05	02/09	XSPEC-002			
LK (QC ID=51222)	R412175-04		0.72	1.00			87	926			02/07/05	02/09	XSPEC-004			
CS (QC ID=51221)	R412175-03		5.0	1.00			52	608			02/07/05	02/09	XSPEC-016			
uplicate (R412175-01) (QC ID=51223)	R412175-05		6.1	1.00			26	927		61	02/07/05	02/09	XSPEC-016			

ominal values and limits from method 2.0 1.00 20-105 300 180

PROCEDURES REFERENCE I129\_SEP\_LEPS\_GS  
CP-024 Iodine-129, Sample Dissolution, rev 5  
CP-530 Iodine-129 Purification, rev 1

AVERAGES ± 2 SD MDA 3.0 ± 4.8  
FOR 5 SAMPLES YIELD 52 ± 44

METHOD SUMMARIES

Page 2

SUMMARY DATA SECTION

Page 14

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-CMS  
Version 3.06  
Report date 02/21/05

00000018

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test H Matrix SOLID  
SDG 7191  
Contact Melissa C. Marnion

## METHOD SUMMARY

TRITIUM IN SOLIDS  
LIQUID SCINTILLATION COUNTING

Client Hanford  
Contract No. 630  
Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Tritium
reparation batch 7121-061				
19960	R412175-01		7191-001	0.362
19961	R412175-02		7191-002	0.417
LK (QC ID=51222)	R412175-04		7191-004	U
CS (QC ID=51221)	R412175-03		7191-003	ok
uplicate (R412175-01)	R412175-05		7191-005	ok
pike (R412175-02)	R412175-06		7191-006	ok X

ominal values and limits from method RDLs (pCi/g) 400  
00-MW-1 Charatrizatn.Samp.&Ana-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT keV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
reparation batch 7121-061 2σ prep error 10.0 % Reference Lab Notebook 7121 pg. 061																
19960	R412175-01		0.23	20.2				33		120			55	02/03/05	02/03	LSC-004
19961	R412175-02		0.23	20.5				33		120			56	02/03/05	02/04	LSC-004
LK (QC ID=51222)	R412175-04		0.23	20.0				33		120				02/03/05	02/04	LSC-004
CS (QC ID=51221)	R412175-03		0.38	20.0				33		45				02/03/05	02/04	LSC-004
uplicate (R412175-01)	R412175-05		0.23	20.0				34		120			56	02/03/05	02/04	LSC-004
(QC ID=51223)																
pike (R412175-02)	R412175-06		0.83	20.5				33		10			56	02/03/05	02/04	LSC-004
(QC ID=51224)																

ominal values and limits from method 400 20.0 25 180

PROCEDURES REFERENCE 906.0\_H3\_LSC  
CP-218 Tritium in Soil Samples by Azeotropic  
Distillation, rev 3

AVERAGES ± 2 SD MDA 0.36 ± 0.48  
FOR 6 SAMPLES YIELD 33 ± 1

## METHOD SUMMARIES

Page 3

## SUMMARY DATA SECTION

Page 15

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-CMS  
Version 3.06  
Report date 02/21/05

00000019

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

## SAMPLE SUMMARY

The Sample and QC Summary Reports show all samples, including QC samples, reported in one Sample Delivery Group (SDG).

The Sample Summary Report fully identifies client samples and gives the corresponding lab sample identification. The QC Summary Report shows at the sample level how the lab organized the samples into batches and generated QC samples. The Preparation Batch and Method Summary Reports show this at the analysis level.

The following notes apply to these reports:

- \* LAB SAMPLE ID is the lab's primary identification for a sample.
- \* DEPARTMENT SAMPLE ID is an alternate lab id, for example one assigned by a radiochemistry department in a lab.
- \* CLIENT SAMPLE ID is the client's primary identification for a sample. It includes any sample preparation done by the client that is necessary to identify the sample.
- \* QC BATCH is a lab assigned code that groups samples to be processed and QCed together. These samples should have similar matrices.

QC BATCH is not necessarily the same as SDG, which reflects samples received and reported together.

- \* All Lab Control Samples, Method Blanks, Duplicates and Matrix Spikes are shown that QC any of the samples. Due to possible reanalyses, not all results for all these QC samples may be relevant to the SDG. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.

### REPORT GUIDES

Page 1

### SUMMARY DATA SECTION

Page 16

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000020

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

### PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches in one Sample Delivery Group (SDG) with information necessary to check the completeness and consistency of the SDG.

The following notes apply to this report:

- \* The preparation batches are shown in the same order as the Method Summary Reports are printed.
- \* Only analyses of planchets relevant to the SDG are included.
- \* Each preparation batch should have at least one Method Blank and LCS in it to validate client sample results.
- \* The QUALIFIERS shown are all qualifiers other than U, J, B, L and H that occur on any analysis in the preparation batch. The Method Summary Report has these qualifiers on a per sample basis.

These qualifiers should be reviewed as follows:

- X Some data has been manually entered or modified. Transcription errors are possible.
- P One or more results are 'preliminary'. The data is not ready for final reporting.
- 2 There were two or more results for one analyte on one planchet imported at one time. The results in DVD may not be the same as on the raw data sheets.

Other lab defined qualifiers may occur. In general, these should be addressed in the SDG narrative.

#### REPORT GUIDES

Page 2

#### SUMMARY DATA SECTION

Page 17

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000021

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

## WORK SUMMARY

The Work Summary Report shows all samples, including QC samples, and all relevant analyses in one Sample Delivery Group (SDG). This report is often useful as supporting documentation for an invoice.

The following notes apply to this report:

- \* TEST is a code for the method used to measure associated analytes. Results and related information for each analyte are on the Data Sheet Report. In special cases, a test code used in the summary data section is not the same as in associated raw data. In this case, both codes are shown on the Work Summary.
- \* SUFFIX is the lab's code to distinguish multiple analyses (recounts, reworks, reanalyses) of a fraction of the sample. The suffix indicates which result is being reported. An empty suffix normally identifies the first attempt to analyze the sample.
- \* The LAB SAMPLE ID, TEST and SUFFIX uniquely identify all supporting data for a result. The Method Summary Report for each TEST has method performance data, such as yield, for each lab sample id and suffix and procedures used in the method.
- \* PLANCHET is an alternate lab identifier for work done for one test. It, combined with the TEST and SUFFIX, may be the best link to raw data.
- \* For QC samples, only analyses that directly QC some regular sample are shown. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.
- \* The SAS (Special Analytical Services) Number is a client or lab assigned code that reflects special processing for samples, such as rapid turn around. Counts of tests done are lists by SAS number since it is likely to affect prices.

### REPORT GUIDES

Page 3

### SUMMARY DATA SECTION

Page 18

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000022

EBERLINE SERVICES / RICHMOND  
SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

DATA SHEET

The Data Sheet Report shows all results and primary supporting information for one client sample or Method Blank. This report corresponds to both the CLP Inorganics and Organics Data Sheet.

The following notes apply to this report:

- \* TEST is a code for the method used to measure an analyte. If the TEST is empty, no data is available; the analyte was not analyzed for.
- \* The LAB SAMPLE ID and TEST uniquely identify work within the Summary Data Section of a Data Package. The Work Summary and Method Summary Reports further identify raw data that underlies this work.

The Method Summary Report for each TEST has method performance data, such as yield, for each Lab Sample ID and a list of procedures used in the method.

- \* ERRORS can be labeled TOTAL or COUNT. TOTAL implies a preparation (non-counting method) error has been added, as square root of sum of squares, to the counting error denoted by COUNT. The preparation errors, which may vary by preparation batch, are shown on the Method Summary Report.
- \* A RESULT can be 'N.R.' (Not Reported). This means the lab did this work but chooses not to report it now, possibly because it was reported at another time.
- \* When reporting a Method Blank, a RESULT can be 'N.A.' (Not Applicable). This means there is no reported client sample work in the same preparation batch as the Blank's result. This is likely to occur when the Method Blank is associated with reanalyses of selected work for a few samples in the SDG.

The following qualifiers are defined by the DVD system:

- U The RESULT is less than the MDA (Minimum Detectable Activity).

REPORT GUIDES

Page 4

SUMMARY DATA SECTION

Page 19

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000023

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

DATA SHEET

If the MDA is blank, the ERROR is used as the limit.

- J The RESULT is less than the RDL (Required Detection Limit) and no U qualifier is assigned.
- B A Method Blank associated with this sample had a result without a U flag and, after correcting for possibly different aliquots, that result is greater than or equal to the MDA for this sample.

Normally, B is not assigned if U is. When method blank subtraction is shown on this report, B flags are assigned based on the unsubtracted values while U's are assigned based on the subtracted ones. Both flags can be assigned in this case.

For each sample result, all Method Blank results in the same preparation batch are compared. The Method Summary Report documents this and other QC relationships.

- L Some Lab Control Sample that QC's this sample had a low recovery. The lab can disable assignment of this qualifier.
- H Similar to 'L' except the recovery was high.
- P The RESULT is 'preliminary'.
- X Some data necessary to compute the RESULT, ERROR or MDA was manually entered or modified.
- 2 There were two or more results available for this analyte. The reported result may not be the same as in the raw data.

Other qualifiers are lab defined. Definitions should be in the SDG narrative.

The following values are underlined to indicate possible problems:

- \* An MDA is underlined if it is bigger than its RDL.

REPORT GUIDES

Page 5

SUMMARY DATA SECTION

Page 20

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000024



# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## DATA SHEET

- \* An ERROR is underlined if the 1.645 sigma counting error is bigger than both the MDA and the RESULT, implying that the MDA may not be a good estimate of the 'real' minimum detectable activity.
- \* A negative RESULT is underlined if it is less than the negative of its 2 sigma counting ERROR.
- \* When reporting a Method Blank, a RESULT is underlined if greater than its MDA. If the MDA is blank, the 2 sigma counting error is used in the comparison.

REPORT GUIDES

Page 6

SUMMARY DATA SECTION

Page 21

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000025

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

### LAB CONTROL SAMPLE

The Lab Control Sample Report shows all results, recoveries and primary supporting information for one Lab Control Sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. Refer to its Report Guide for details.
- \* An amount ADDED is the lab's value for the actual amount spiked into this sample with its ERROR an estimate of the error of this amount.

An amount added is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- \* REC (Recovery) is RESULT divided by ADDED expressed as a percent.
- \* The first, computed limits for the recovery reflect:
  1. The error of RESULT, including that introduced by rounding the result prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.

  2. The error of ADDED.
  3. A lab specified, per analyte bias. The bias changes the center of the computed limits.
- \* The second limits are protocol defined upper and lower QC limits for the recovery.
- \* The recovery is underlined if it is outside either of these ranges.

#### REPORT GUIDES

Page 7

#### SUMMARY DATA SECTION

Page 22

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000026

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

### DUPLICATE

The Duplicate Report shows all results, differences and primary supporting information for one Duplicate and associated Original sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. This applies both to the Duplicate and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Duplicate has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- \* The RPD (Relative Percent Difference) is the absolute value of the difference of the RESULTS divided by their average expressed as a percent.

If both RESULTS are less than their MDAs, no RPD is computed and a '-' is printed.

For an analyte, if the lab did work for both samples but has data for only one, the MDA from the sample with data is used as the other's result in the RPD.

- \* The first, computed limit is the sum, as square root of sum of squares, of the errors of the results divided by the average result as a percent, hence the relative error of the difference rather than the error of the relative difference. The errors include those introduced by rounding the RESULTS prior to printing.

If this limit is labeled TOT, it includes the preparation error in the RESULTS. If labeled CNT, it does not.

This value reported for this limit is at most 999.

- \* The second limit for the RPD is the larger of:

1. A fixed percentage specified in the protocol.

#### REPORT GUIDES

Page 8

#### SUMMARY DATA SECTION

Page 23

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000027

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## DUPLICATE

2. A protocol factor (typically 2) times the average MDA as a percent of the average result. This limit applies when the results are close to the MDAs.

- \* The RPD is underlined if it is greater than either limit.
- \* If specified by the lab, the second limit column is replaced by the Difference Error Ratio (DER), which is the absolute value of the difference of the results divided by the quadratic sum of their one sigma errors, the same errors as used in the first limit.

Except for differences due to rounding, the DER is the same as the RPD divided by the first RPD limit with the limit scaled to 1 sigma.

- \* The DER is underlined if it is greater than the sigma factor, typically 2 or 3, shown in the header for the first RPD limit.

### REPORT GUIDES

Page 9

### SUMMARY DATA SECTION

Page 24

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000028

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

## MATRIX SPIKE

The Matrix Spike Report shows all results, recoveries and primary supporting information for one Matrix Spike and associated Original sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. This applies both to the Spiked and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Spike has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- \* An amount ADDED is the lab's value for the actual amount spiked into the Spike sample with its ERROR an estimate of the error of this amount.

An amount is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- \* REC (Recovery) is the Spike RESULT minus the Original RESULT divided by ADDED expressed as a percent.

- \* The first, computed limits for the recovery reflect:

1. The errors of the two RESULTS, including those introduced by rounding them prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.

2. The error of ADDED.

3. A lab specified, per analyte bias. The bias changes the center of the computed limits.

- \* The second limits are protocol defined upper and lower QC limits

### REPORT GUIDES

Page 10

### SUMMARY DATA SECTION

Page 25

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000029

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

## MATRIX SPIKE

for the recovery.

These limits are left blank if the Original RESULT is more than a protocol defined factor (typically 4) times ADDED. This is a way of accounting for that when the spike is small compared to the amount in the original sample, the recovery is unreliable.

- \* The recovery is underlined (out of spec) if it is outside either of these ranges.

### REPORT GUIDES

Page 11

### SUMMARY DATA SECTION

Page 26

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000030

EBERLINE SERVICES / RICHMOND  
SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

METHOD SUMMARY

The Method Summary Report has two tables. One shows up to five results measured using one method. The other has performance data for the method. There is one report for each TEST, as used on the Data Sheet Report.

The following notes apply to this report:

- \* Each table is subdivided into sections, one for each preparation batch. A preparation batch is a group of aliquots prepared at roughly the same time in one work area of the lab using the same method.

There should be Lab Control Sample and Method Blank results in each preparation batch since this close correspondence makes the QC meaningful. Depending on lab policy, Duplicates need not occur in each batch since they QC sample dependencies such as matrix effects.

- \* The RAW TEST column shows the test code used in the raw data to identify a particular analysis if it is different than the test code in the header of the report. This occurs in special cases due to method specific details about how the lab labels work.

The Lab Sample or Planchet ID combined with the (Raw) Test Code and Suffix uniquely identify the raw data for each analysis.

- \* If a result is less than both its MDA and RDL, it is replaced by just 'U' on this report. If it is greater than or equal to the RDL but less than the MDA, the result is shown with a 'U' flag.

The J and X flags are as on the data sheet.

- \* Non-U results for Method Blanks are underlined to indicate possible contamination of other samples in the preparation batch. The Method Blank Report has supporting data.
- \* Lab Control Sample and Matrix Spike results are shown as: ok, No data, LOW or HIGH, with the last two underlined. 'No data'

REPORT GUIDES

Page 12

SUMMARY DATA SECTION

Page 27

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000031

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## METHOD SUMMARY

means no amount ADDED was specified. 'LOW' and 'HIGH' correspond to when the recovery is underlined on the Lab Control Sample or Matrix Spike Report. See these reports for supporting data.

- \* Duplicate sample results are shown as: ok, No data, or OUT, with the last two underlined. 'No data' means there was no original sample data found for this duplicate. 'OUT' corresponds to when the RPD is underlined on the Duplicate Report. See this report for supporting data.
- \* If the MDA column is labeled 'MAX MDA', there was more than one result measured by the reported method and the MDA shown is the largest MDA. If not all these results have the same RDL, the MAX MDA reflects only those results with RDL equal to the smallest one.

MDAs are underlined if greater than the printed RDL.

- \* Aliquots are underlined if less than the nominal value specified for the method.
- \* Preparation factors are underlined if greater than the nominal value specified for the method.
- \* Dilution factors are underlined if greater than the nominal value specified for the method.
- \* Residues are underlined if outside the range specified for the method. Residues are not printed if yields are.
- \* Yields, which may be gravimetric, radiometric or some type of recovery depending on the method, are underlined if outside the range specified for the method.
- \* Efficiencies are underlined if outside the range specified for the method. Efficiencies are detector and geometry dependent so this test is only approximate.

### REPORT GUIDES

Page 13

### SUMMARY DATA SECTION

Page 28

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 02/21/05

00000032



# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

## METHOD SUMMARY

- \* Count times are underlined if less than the nominal value specified for the method.
- \* Resolutions (as FWHM; Full Width at Half Max) are underlined if greater than the method specified limit.
- \* Tracer drifts are underlined if their absolute values are greater than the method specified limit. Tracer drifts are not printed if percent moistures are.
- \* Days Held are underlined if greater than the holding time specified in the protocol.
- \* Analysis dates are underlined if before their planchet's preparation date or, if a limit is specified, too far after it.

For some methods, ratios as percentages and error estimates for them are computed for pairs of results. A ratio column header like '1+3' means the ratio of the first result column and the third result column.

Ratios are not computed for Lab Control Sample, Method Blank or Matrix Spike results since their matrices are not necessarily similar to client samples'.

The error estimate for a ratio of results from one planchet reflects only counting errors since other errors should be correlated. For a ratio involving different planchets, if QC limits are computed based on total errors, the error for the ratio allows for the preparation errors for the planchets.

The ratio is underlined (out of spec) if the absolute value of its difference from the nominal value is greater than its error estimate. If no nominal value is specified, this test is not done.

For Gross Alpha or Gross Beta results, there may be a column showing the sum of other Alpha or Beta emitters. This sum includes all relevant

### REPORT GUIDES

Page 14

### SUMMARY DATA SECTION

Page 29

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000033

## EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7191  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## METHOD SUMMARY

results in the DVD database, whether reported or not. Results in the sum are weighted by a particles/decay value specified by the lab for each relevant analyte. Results less than their MDA are not included. No sums are computed for Lab Control, Method Blank or Matrix Spike samples since their various planchets may not be physically related.

If a ratio of total isotopic to Gross Alpha or Beta is shown, the error for the ratio reflects both the error in the Gross result and the sum, as square root of sum of squares, of the errors in the isotopic results.

For total elemental uranium or thorium results, there may be a column showing the total weight computed from associated isotopic results. Ignoring results less than their MDAs, this is a weighted sum of the isotopic results. The weights depend on the molecular weight and half-life of each isotope so as to convert activities (decays) to weight (atoms).

If a ratio of total computed to measured elemental uranium or thorium is shown, the error for the ratio reflects the errors in all the measurements.

## REPORT GUIDES

Page 15

## SUMMARY DATA SECTION

Page 30

Lab id EBRINE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000034

FLUOR Hanford Inc.		CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST						F04-015-065		PAGE 1 OF 1	
COLLECTOR Pope/Pfister/Tyra/Wiberg		COMPANY CONTACT CS Clearlock		TELEPHONE NO. 372-9638		PROJECT COORDINATOR TRENT, SJ		PRICE CODE 8N		DATA TURNAROUND 45 Days / 45 Days	
SAMPLING LOCATION 216-U-3; 12.5 FT - 17.5 - 20 ft LF 14704		PROJECT DESIGNATION H2905 (7/91) 200-MW-1 Characterization Sampling and Analysis - Soil		SAF NO. F04-015		AIR QUALITY <input type="checkbox"/>					
ICE CHEST NO. GRP-03-019		FIELD LOGBOOK NO. HNF-N-386 1		COA 119144ES10		METHOD OF SHIPMENT Federal Express					
SHIPPED TO Eberline Services		OFFSITE PROPERTY NO. Su PTL 14590		BILL OF LADING/AIR BILL NO. Su PTL 14590							
MATRIX* A=Air DL=Drum Liquids DS=Drum Solids L=Liquid O=Oil S=Soil SE=Sediment T=Tissue V=Vegetation W=Water WI=Wipe X=Other	POSSIBLE SAMPLE HAZARDS/ REMARKS N/A		PRESERVATION Cool 4C	None							
			TYPE OF CONTAINER aG	aG							
			NO. OF CONTAINER(S) 1	1							
			VOLUME 120mL	60mL							
SPECIAL HANDLING AND/OR STORAGE Radioactive Tie To: B19951			SAMPLE ANALYSIS SEE FORM (I) IN SPEC. INSTRUCTIONS		Iodine-129; Technetium-99; Tritium - H3;						
SAMPLE NO.	MATRIX*	SAMPLE DATE	SAMPLE TIME								
B19960	SOIL	12/10/04	1050	X							
B19961	SOIL	12/10/04	1050	X							
CHAIN OF POSSESSION				SIGN/ PRINT NAMES		SPECIAL INSTRUCTIONS <del>(1) NO2/NOS - 353.2; Oil &amp; Grease - 413.1; Chromium Hex - 7196;</del> M08-12-04					
RELINQUISHED BY/REMOVED FROM Dana Wilkerson	DATE/TIME 12/14/04 1330	RECEIVED BY/STORED IN S. Frise #1	DATE/TIME 12/10/04 1330								
RELINQUISHED BY/REMOVED FROM M. Brinkley	DATE/TIME 12/15/04 0725	RECEIVED BY/STORED IN M. Brinkley	DATE/TIME 12/15/04 0725								
RELINQUISHED BY/REMOVED FROM M. Brinkley	DATE/TIME 12/16/04 0725	RECEIVED BY/STORED IN J. Jones	DATE/TIME 12/16/04 0725								
RELINQUISHED BY/REMOVED FROM Fred	DATE/TIME 12/16/04 9:40	RECEIVED BY/STORED IN J. Jones	DATE/TIME 12/16/04 0725								
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME								
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME								
LABORATORY SECTION	RECEIVED BY	TITLE		DATE/TIME							
FINAL SAMPLE DISPOSITION	DISPOSAL METHOD	DISPOSED BY		DATE/TIME							



## RICHMOND, CA LABORATORY

## SAMPLE RECEIPT CHECKLIST

Client: Fluor Hanford City: Richland State: WA

Date/Time received: 12/16/04 9:40 CoC No. FOF-015-065

Container I.D. No. GRP 03-019 Requested TAT (Days) 45 P.O. Received Yes [ ] No [ ]

**INSPECTION**

1. Custody seals on shipping container intact? Yes [X] No [ ] N/A [ ]

2. Custody seals on shipping container dated & signed? Yes [X] No [ ] N/A [ ]

3. Custody seals on sample containers intact? Yes [X] No [ ] N/A [ ]

4. Custody seals on sample containers dated & signed? Yes [X] No [ ] N/A [ ]

5. Packing material is: Wet [ ] Dry [X]

6. Number of samples in shipping container: 2 Sample Matrix: S.S.

7. Number of containers per sample: 1 (Or see CoC \_\_\_\_\_)

8. Samples are in correct container Yes [X] No [ ]

9. Paperwork agrees with samples? Yes [X] No [ ]

10. Samples have: Tape [ ] Hazard labels [ ] Rad labels [ ] Appropriate sample labels [X]

11. Samples are: In good condition [X] Leaking [ ] Broken Container [ ] Missing [ ]

12. Samples are: Preserved [ ] Not preserved [ ] pH \_\_\_\_\_ Preservative \_\_\_\_\_

13. Describe any anomalies: \_\_\_\_\_

14. Was P.M. notified of any anomalies? Yes [ ] No [ ] Date \_\_\_\_\_

15. Inspected by: [Signature] Date: 12/16/04 Time: 12:45

Customer Sample  
No.

cpm

mR/hr

wipe

Customer Sample  
No.

cpm

mR/hr

wipe

Ion Chamber Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

Alpha Meter Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

Beta/Gamma Meter Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_




EBERLINE SERVICES / RICHMOND  
SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

S U M M A R Y   D A T A   S E C T I O N

T A B L E   O F   C O N T E N T S					
About this section	.	.	.	.	1
Sample Summaries	.	.	.	.	3
Prep Batch Summary	.	.	.	.	5
Work Summary	.	.	.	.	6
Method Blanks	.	.	.	.	7
Lab Control Samples	.	.	.	.	8
Duplicates	.	.	.	.	9
Data Sheets	.	.	.	.	10
Method Summaries	.	.	.	.	13
Report Guides	.	.	.	.	16
End of Section	.	.	.	.	30

  
Prepared by

Melissa Mannion  
Reviewed by

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-TOC  
Version 3.06  
Report date 02/21/05

00000037

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

ABOUT THE DATA SUMMARY SECTION

The Data Summary Section of a Data Package has all data, in several useful orders, necessary for first level, routine review of the data package for a Sample Delivery Group (SDG). This section follows the Data Package Narrative, which has an overview of the data package and a discussion of special problems. It is followed by the Raw Data Section, which has full details.

The Data Summary Section has several groups of reports:

SAMPLE SUMMARIES

The Sample and QC Summary Reports show all samples, including QC samples, reported in one SDG. These reports cross-reference client and lab sample identifiers.

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches (lab groupings reflecting how work was organized) relevant to the reported SDG with information necessary to check the completeness and consistency of the SDG.

WORK SUMMARY

The Work Summary Report shows all samples and work done on them relevant to the reported SDG.

METHOD BLANKS

The Method Blank Reports, one for each Method Blank relevant to the SDG, show all results and primary supporting information for the blanks.

LAB CONTROL SAMPLES

The Lab Control Sample Reports, one for each Lab Control Sample relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 1

Lab id EBRINE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000038

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

GUIDE , c o n t .

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

## ABOUT THE DATA SUMMARY SECTION

### DUPLICATES

The Duplicate Reports, one for each Duplicate and Original sample pair relevant to the SDG, show all results, differences and primary supporting information for these QC samples.

### MATRIX SPIKES

The Matrix Spike Reports, one for each Spiked and Original sample pair relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

### DATA SHEETS

The Data Sheet Reports, one for each client sample in the SDG, show all results and primary supporting information for these samples.

### METHOD SUMMARIES

The Method Summary Reports, one for each test used in the SDG, show all results, QC and method performance data for one analyte on one or two pages. (A test is a short code for the method used to do certain work to the client's specification.)

### REPORT GUIDES

The Report Guides, one for each of the above groups of reports, have documentation on how to read the associated reports.

### REPORT GUIDES

Page 2

### SUMMARY DATA SECTION

Page 2

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000039



# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197

Contact Melissa C. Mannion

## SAMPLE SUMMARY

Client Hanford

Contract No. 630

Case no SDG H2905

CLIENT SAMPLE ID	LOCATION	MATRIX	LEVEL	LAB		CHAIN OF	
				SAMPLE ID	SAF NO	CUSTODY	COLLECTED
B19963	216-U-3; 35ft-37.5ft	SOLID		R412214-01	F04-015	F04-015-067	12/14/04 07:00
B19964	216-U-3; 47ft-49.5ft	SOLID		R412214-02	F04-015	F04-015-068	12/15/04 07:00
B19965	216-U-3; 97.5ft-100ft	SOLID		R412214-03	F04-015	F04-015-069	12/16/04 09:00
Method Blank		SOLID		R412175-04	F04-015		
Lab Control Sample		SOLID		R412175-03	F04-015		
Duplicate (R412214-01)	216-U-3; 35ft-37.5ft	SOLID		R412214-06	F04-015		12/14/04 07:00

SAMPLE SUMMARY

Page 1

SUMMARY DATA SECTION

Page 3

Lab id EBRINE

Protocol Hanford

Version Ver 1.0

Form DVD-CS

Version 3.06

Report date 02/21/05

00000040

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

## QC SUMMARY

Client Hanford  
Contract No. 630  
Case no SDG H2905

C BATCH	CHAIN OF CUSTODY	CLIENT SAMPLE ID	MATRIX	SOLIDS	SAMPLE AMOUNT	BASIS AMOUNT	DAYS SINCE RECEIVED	LAB COLL SAMPLE ID	DEPARTMENT SAMPLE ID
191		Method Blank	SOLID					R412175-04	7191-004
		Lab Control Sample	SOLID					R412175-03	7191-003
197	F04-015-067	B19963	SOLID	96.0	60.1 g		12/20/04 6	R412214-01	7197-001
	F04-015-068	B19964	SOLID	98.2	88.4 g		12/20/04 5	R412214-02	7197-002
	F04-015-069	B19965	SOLID	92.0	56.4 g		12/20/04 4	R412214-03	7197-003
		Duplicate (R412214-01)	SOLID	96.0	60.1 g		12/20/04 6	R412214-06	7197-006

QC SUMMARY

Page 1

SUMMARY DATA SECTION

Page 4

Lab id EBRINE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-QS  
Version 3.06  
Report date 02/21/05

00000041

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197

Contact Melissa C. Mannion

## PREP BATCH SUMMARY

Client Hanford

Contract No. 630

Case no SDG H2905

TEST	MATRIX	METHOD	PREPARATION ERROR		PLANCHETS ANALYZED						QUALI-
			BATCH	2σ %	CLIENT	MORE	RE	BLANK	LCS	DUP/ORIG	MS/ORIG
Beta Counting											
TC	SOLID	Technetium 99 in Solids	7121-061	10.0	3			1	1	1/1	
Gamma Spectroscopy											
I	SOLID	Iodine 129 in Solids	7121-061	10.0	3			1	1	1/1	
Liquid Scintillation Counting											
H	SOLID	Tritium in Solids	7121-061	10.0	3			1	1	1/1	

Duplicates and Matrix Spikes are those with original (Client) sample in this Sample Delivery Group.

Blank and LCS planchets are those in the same preparation batch as some Client, Duplicate or Spike sample.

PREP BATCH SUMMARY

Page 1

SUMMARY DATA SECTION

Page 5

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-FBS

Version 3.06

Report date 02/21/05

00000042

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197

Contact Melissa C. Mannion

## WORK SUMMARY

Client Hanford

Contract No. 630

Case no SDG H2905

CLIENT SAMPLE ID	LAB SAMPLE ID									
LOCATION	MATRIX	COLLECTED		SUF-						
USTODY	SAF No	RECEIVED	PLANCHET	TEST	FIX	ANALYZED	REVIEWED	BY	METHOD	
19963		R412214-01	7197-001	H		02/04/05	02/11/05	MWT	Tritium in Solids	
16-U-3; 35ft-37.5ft	SOLID	12/14/04	7197-001	I		02/08/05	02/09/05	MWT	Iodine 129 in Solids	
04-015-067	F04-015	12/20/04	7197-001	TC		01/31/05	02/03/05	MWT	Technetium 99 in Solids	
19964		R412214-02	7197-002	H		02/04/05	02/11/05	MWT	Tritium in Solids	
16-U-3; 47ft-49.5ft	SOLID	12/15/04	7197-002	I		02/08/05	02/09/05	MWT	Iodine 129 in Solids	
04-015-068	F04-015	12/20/04	7197-002	TC		02/01/05	02/03/05	MWT	Technetium 99 in Solids	
19965		R412214-03	7197-003	H		02/04/05	02/11/05	MWT	Tritium in Solids	
16-U-3; 97.5ft-100ft	SOLID	12/16/04	7197-003	I		02/09/05	02/11/05	MWT	Iodine 129 in Solids	
04-015-069	F04-015	12/20/04	7197-003	TC		02/01/05	02/03/05	MWT	Technetium 99 in Solids	
ethod Blank		R412175-04	7191-004	H		02/04/05	02/09/05	MWT	Tritium in Solids	
	SOLID		7191-004	I		02/09/05	02/11/05	MWT	Iodine 129 in Solids	
	F04-015		7191-004	TC		02/01/05	02/03/05	MWT	Technetium 99 in Solids	
ab Control Sample		R412175-03	7191-003	H		02/04/05	02/09/05	MWT	Tritium in Solids	
	SOLID		7191-003	I		02/09/05	02/10/05	MWT	Iodine 129 in Solids	
	F04-015		7191-003	TC		01/31/05	02/03/05	MWT	Technetium 99 in Solids	
uplicate (R412214-01)		R412214-06	7197-006	H		02/04/05	02/18/05	MWT	Tritium in Solids	
16-U-3; 35ft-37.5ft	SOLID	12/14/04	7197-006	I		02/10/05	02/11/05	MWT	Iodine 129 in Solids	
	F04-015	12/20/04	7197-006	TC		01/31/05	02/03/05	MWT	Technetium 99 in Solids	

## COUNTS OF TESTS BY SAMPLE TYPE

TEST	SAF No	METHOD	REFERENCE	CLIENT	MORE	RE	BLANK	LCS	DUP	SPIKE	TOTAL
H	F04-015	Tritium in Solids	906.0_H3_LSC		3		1	1	1		6
I	F04-015	Iodine 129 in Solids	I129_SEP_LEPS_GS		3		1	1	1		6
TC	F04-015	Technetium 99 in Solids	TC99_TR_SEP_LSC		3		1	1	1		6
TOTALS					9		3	3	3		18

WORK SUMMARY

Page 1

SUMMARY DATA SECTION

Page 6

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-CWS

Version 3.06

Report date 02/21/05

00000043

**EBERLINE SERVICES / RICHMOND**

**SAMPLE DELIVERY GROUP H2905**

**R412175-04**

**Method Blank**

**METHOD BLANK**

SDG <u>7197</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412175-04</u>	Client sample id <u>Method Blank</u>	
Dept sample id <u>7191-004</u>	Material/Matrix <u>SOLID</u>	
	SAF No <u>F04-015</u>	

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	0.090	0.14	0.23	400	U	H
Technetium 99	14133-76-7	0.052	0.21	0.76	15	U	TC
Iodine 129	15046-84-1	0.060	0.32	0.72	2.0	U	I

200-MW-1 Charac.Samp.& Analysis-Soil

QC-BLANK 51222

Lab id EBRLNE  
 Protocol Hanford  
 Version Ver 1.0  
 Form DVD-DS  
 Version 3.06  
 Report date 02/21/05

00000044

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

R412175-03

Lab Control Sample

## LAB CONTROL SAMPLE

SDG <u>7197</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412175-03</u>	Client sample id <u>Lab Control Sample</u>	
Dept sample id <u>7191-003</u>	Material/Matrix <u>SOLID</u>	
	SAP No <u>F04-015</u>	

ANALYTE	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ADDED pCi/g	2σ ERR pCi/g	REC %	3σ LMTS (TOTAL)	PROTOCOL LIMITS
Tritium	11.8	0.55	0.38	400		H	11.8	0.47	100	82-118	80-120
Technetium 99	111	3.0	0.85	15		TC	109	4.4	102	83-117	80-120
Iodine 129	125	2.8	<u>5.0</u>	2.0		I	116	4.6	108	82-118	80-120

200-MW-1 Charac.Samp.& Analysis-Soil

QC-LCS 51221

LAB CONTROL SAMPLES

Page 1

SUMMARY DATA SECTION

Page 8

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LCS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000045

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

R412214-06

B19963

## DUPLICATE

SDG <u>7197</u>		Client/Case no <u>Hanford</u>		SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>		Contract No. <u>630</u>		
DUPLICATE		ORIGINAL		
Lab sample id <u>R412214-06</u>	Lab sample id <u>R412214-01</u>	Client sample id <u>B19963</u>		
Dept sample id <u>7197-006</u>	Dept sample id <u>7197-001</u>	Location/Matrix <u>216-U-3; 35ft-37.5ft</u> <u>SOLID</u>		
	Received <u>12/20/04</u>	Collected/Weight <u>12/14/04 07:00</u> <u>60.1 g</u>		
% solids <u>96.0</u>	% solids <u>96.0</u>	Custody/SAF No <u>F04-015-067</u> <u>F04-015</u>		

ANALYTE	DUPLICATE pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ORIGINAL pCi/g	2σ ERR (COUNT)	MDA pCi/g	QUALI- FIERS	RPD %	3σ TOT	PROT LIMIT
Tritium	0.087	0.14	0.23	400	U	H	0.105	0.14	0.22	U	-		
Technetium 99	-0.078	0.39	1.1	15	U	TC	0.252	0.29	1.0	U	-		
Iodine 129	0.154	0.45	1.0	2.0	U	I	0.034	0.47	1.0	U	-		

200-MW-1 Charac.Samp.& Analysis-Soil

QC-DUP#1 51314

DUPLICATES

Page 1

SUMMARY DATA SECTION

Page 9

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DUP</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

000000046

**EBERLINE SERVICES / RICHMOND**  
**SAMPLE DELIVERY GROUP H2905**

R412214-01

B19963

**DATA SHEET**

SDG <u>7197</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412214-01</u>	Client sample id <u>B19963</u>	
Dept sample id <u>7197-001</u>	Location/Matrix <u>216-U-3; 35ft-37.5ft</u>	<u>SOLID</u>
Received <u>12/20/04</u>	Collected/Weight <u>12/14/04 07:00</u>	<u>60.1 g</u>
% solids <u>96.0</u>	Custody/SAF No <u>F04-015-067</u>	<u>F04-015</u>

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	0.105	0.14	0.22	400	U	H
Technetium 99	14133-76-7	0.252	0.29	1.0	15	U	TC
Iodine 129	15046-84-1	0.034	0.47	1.0	2.0	U	I

200-MW-1 Charac.Samp.& Analysis-Soil

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000047



**EBERLINE SERVICES / RICHMOND**  
**SAMPLE DELIVERY GROUP H2905**

R412214-02

B19964

**DATA SHEET**

SDG <u>7197</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412214-02</u>	Client sample id <u>B19964</u>	
Dept sample id <u>7197-002</u>	Location/Matrix <u>216-U-3; 47ft-49.5ft</u>	<u>SOLID</u>
Received <u>12/20/04</u>	Collected/Weight <u>12/15/04 07:00</u>	<u>88.4 g</u>
% solids <u>98.2</u>	Custody/SAF No <u>F04-015-068</u>	<u>F04-015</u>

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	0.175	0.14	0.22	400	U	H
Technetium 99	14133-76-7	-0.183	0.24	0.85	15	U	TC
Iodine 129	15046-84-1	0.533	1.4	<u>3.3</u>	2.0	U	I

200-MW-1 Charac.Samp.& Analysis-Soil

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000048

**EBERLINE SERVICES / RICHMOND**  
**SAMPLE DELIVERY GROUP H2905**

R412214-03

B19965

**DATA SHEET**

SDG <u>7197</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412214-03</u>	Client sample id <u>B19965</u>	
Dept sample id <u>7197-003</u>	Location/Matrix <u>216-U-3; 97.5ft-100ft</u>	<u>SOLID</u>
Received <u>12/20/04</u>	Collected/Weight <u>12/16/04 09:00</u>	<u>56.4 g</u>
% solids <u>92.0</u>	Custody/SAP No <u>F04-015-069</u>	<u>F04-015</u>

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	1.78	0.18	0.23	400		H
Technetium 99	14133-76-7	-0.119	0.20	0.67	15	U	TC
Iodine 129	15046-84-1	-0.146	1.0	<u>2.3</u>	2.0	U	I

200-MW-1 Charac.Samp.& Analysis-Soil

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000049

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test TC Matrix SOLID

SDG 7197

Contact Melissa C. Mannion

## METHOD SUMMARY

TECHNETIUM 99 IN SOLIDS

BETA COUNTING

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW SUP- TEST FIX	PLANCHET	Technetium 99
reparation batch 7121-061				
19963	R412214-01		7197-001	U
19964	R412214-02		7197-002	U
19965	R412214-03		7197-003	U
LK (QC ID=51222)	R412175-04		7191-004	U
CS (QC ID=51221)	R412175-03		7191-003	ok
uplicate (R412214-01)	R412214-06		7197-006	- U

ominal values and limits from method RDLs (pCi/g) 15  
00-MW-1 Charac.Samp.& Analysis-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW SUP- TEST FIX	MDA pCi/g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
reparation batch 7121-061 2σ prep error 10.0 % Reference Lab Notebook 7121 pg. 061															
19963	R412214-01		1.0	1.00			50	50			48	01/28/05	01/31	GRB-228	
19964	R412214-02		0.85	1.01			59	50			48	01/28/05	02/01	GRB-202	
19965	R412214-03		0.67	1.00			75	50			47	01/28/05	02/01	GRB-203	
LK (QC ID=51222)	R412175-04		0.76	1.00			66	50				01/28/05	02/01	GRB-203	
CS (QC ID=51221)	R412175-03		0.85	1.00			65	50				01/28/05	01/31	GRB-225	
uplicate (R412214-01) (QC ID=51314)	R412214-06		1.1	1.00			44	55			48	01/28/05	01/31	GRB-227	
ominal values and limits from method			15	1.00			20-105	50			180				

PROCEDURES REFERENCE TC99\_TR\_SEP\_LSC  
CP-431 Technetium-99 Purification of Soil or Resin by  
Extraction Chromatography, rev 2  
CP-008 Heavy Element Electroplating, rev 9

AVERAGES ± 2 SD MDA 0.87 ± 0.31  
FOR 6 SAMPLES YIELD 60 ± 23

METHOD SUMMARIES

Page 1

SUMMARY DATA SECTION

Page 13

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-CMS

Version 3.06

Report date 02/21/05

00000050

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test I Matrix SOLID

SDG 7197

Contact Melissa C. Mannion

## METHOD SUMMARY

IODINE 129 IN SOLIDS

GAMMA SPECTROSCOPY

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Iodine 129
------------------	---------------	--------------	---------------	------------

reparation batch 7121-061

19963	R412214-01	7197-001	U
19964	R412214-02	7197-002	U
19965	R412214-03	7197-003	U
LK (QC ID-51222)	R412175-04	7191-004	U
CS (QC ID-51221)	R412175-03	7191-003	ok
uplicate (R412214-01)	R412214-06	7197-006	- U

ominal values and limits from method RDLs (pCi/g) 2.0  
00-MW-1 Charac.Samp.& Analysis-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT keV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
------------------	---------------	--------------	------------	-----	--------	----------	------------	---------	-------	-----------	----------	-----------	-----------	----------------	------	----------

reparation batch 7121-061 2σ prep error 10.0 % Reference Lab Notebook 7121 pg. 061

19963	R412214-01	1.0	1.00	62	733	56	02/07/05	02/08	XSPEC-002
19964	R412214-02	3.3	1.00	48	733	55	02/07/05	02/08	XSPEC-016
19965	R412214-03	2.3	1.00	28	926	55	02/07/05	02/09	XSPEC-002
LK (QC ID-51222)	R412175-04	0.72	1.00	87	926		02/07/05	02/09	XSPEC-004
CS (QC ID-51221)	R412175-03	5.0	1.00	52	608		02/07/05	02/09	XSPEC-016
uplicate (R412214-01) (QC ID-51314)	R412214-06	1.0	1.00	64	604	58	02/07/05	02/10	XSPEC-004

ominal values and limits from method 2.0 1.00 20-105 300 180

PROCEDURES	REFERENCE	I129_SEP_LEPS_GS
CP-024	Iodine-129, Sample Dissolution, rev 5	
CP-530	Iodine-129 Purification, rev 1	

AVERAGES ± 2 SD	MDA 2.2 ± 3.4
FOR 6 SAMPLES	YIELD 57 ± 39

## METHOD SUMMARIES

Page 2

## SUMMARY DATA SECTION

Page 14

Lab id	EBERLINE
Protocol	Hanford
Version	Ver 1.0
Form	DVD-CMS
Version	3.06
Report date	02/21/05

00000051

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test H Matrix SOLID  
SDG 7197  
Contact Melissa C. Mannion

## METHOD SUMMARY

TRITIUM IN SOLIDS

LIQUID SCINTILLATION COUNTING

Client Hanford  
Contract No. 630  
Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Tritium
reparation batch 7121-061				
19963	R412214-01	7197-001		U
19964	R412214-02	7197-002		U
19965	R412214-03	7197-003		1.78
LK (QC ID=51222)	R412175-04	7191-004		U
CS (QC ID=51221)	R412175-03	7191-003		ok
uplicate (R412214-01)	R412214-06	7197-006		- U

ominal values and limits from method RDLs (pCi/g) 400  
00-MW-1 Charac.Samp.& Analysis-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA g	ALIQ FAC	PREP TION	DILU- %	YIELD %	BFF min	COUNT keV	FWHM keV	DRIFT HELD	DAYS PREPARED	ANAL- YZED	DETECTOR
reparation batch 7121-061 2σ prep error 10.0 % Reference Lab Notebook 7121 pg. 061															
19963	R412214-01		0.22	20.2			34	120				52	02/03/05	02/04	LSC-004
19964	R412214-02		0.22	20.8			34	120				51	02/03/05	02/04	LSC-004
19965	R412214-03		0.23	20.8			33	120				50	02/03/05	02/04	LSC-004
LK (QC ID=51222)	R412175-04		0.23	20.0			33	120					02/03/05	02/04	LSC-004
CS (QC ID=51221)	R412175-03		0.38	20.0			33	45					02/03/05	02/04	LSC-004
uplicate (R412214-01) (QC ID=51314)	R412214-06		0.23	20.1			33	120				52	02/03/05	02/04	LSC-004

ominal values and limits from method 400 15.0 25 180

PROCEDURES REFERENCE 906.0\_H3\_LSC  
CP-218 Tritium in Soil Samples by Azeotropic  
Distillation, rev 3

AVERAGES ± 2 SD MDA 0.25 ± 0.13  
FOR 6 SAMPLES YIELD 33 ± 1

METHOD SUMMARIES

Page 3

SUMMARY DATA SECTION

Page 15

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-CMS  
Version 3.06  
Report date 02/21/05

00000052

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

## SAMPLE SUMMARY

The Sample and QC Summary Reports show all samples, including QC samples, reported in one Sample Delivery Group (SDG).

The Sample Summary Report fully identifies client samples and gives the corresponding lab sample identification. The QC Summary Report shows at the sample level how the lab organized the samples into batches and generated QC samples. The Preparation Batch and Method Summary Reports show this at the analysis level.

The following notes apply to these reports:

- \* LAB SAMPLE ID is the lab's primary identification for a sample.
- \* DEPARTMENT SAMPLE ID is an alternate lab id, for example one assigned by a radiochemistry department in a lab.
- \* CLIENT SAMPLE ID is the client's primary identification for a sample. It includes any sample preparation done by the client that is necessary to identify the sample.
- \* QC BATCH is a lab assigned code that groups samples to be processed and QCed together. These samples should have similar matrices.

QC BATCH is not necessarily the same as SDG, which reflects samples received and reported together.

- \* All Lab Control Samples, Method Blanks, Duplicates and Matrix Spikes are shown that QC any of the samples. Due to possible reanalyses, not all results for all these QC samples may be relevant to the SDG. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.

### REPORT GUIDES

Page 1

### SUMMARY DATA SECTION

Page 16

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000053

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

### PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches in one Sample Delivery Group (SDG) with information necessary to check the completeness and consistency of the SDG.

The following notes apply to this report:

- \* The preparation batches are shown in the same order as the Method Summary Reports are printed.
- \* Only analyses of planchets relevant to the SDG are included.
- \* Each preparation batch should have at least one Method Blank and LCS in it to validate client sample results.
- \* The QUALIFIERS shown are all qualifiers other than U, J, B, L and H that occur on any analysis in the preparation batch. The Method Summary Report has these qualifiers on a per sample basis.

These qualifiers should be reviewed as follows:

- X Some data has been manually entered or modified. Transcription errors are possible.
- P One or more results are 'preliminary'. The data is not ready for final reporting.
- 2 There were two or more results for one analyte on one planchet imported at one time. The results in DVD may not be the same as on the raw data sheets.

Other lab defined qualifiers may occur. In general, these should be addressed in the SDG narrative.

#### REPORT GUIDES

Page 2

#### SUMMARY DATA SECTION

Page 17

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000054

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

## WORK SUMMARY

The Work Summary Report shows all samples, including QC samples, and all relevant analyses in one Sample Delivery Group (SDG). This report is often useful as supporting documentation for an invoice.

The following notes apply to this report:

- \* TEST is a code for the method used to measure associated analytes. Results and related information for each analyte are on the Data Sheet Report. In special cases, a test code used in the summary data section is not the same as in associated raw data. In this case, both codes are shown on the Work Summary.
- \* SUFFIX is the lab's code to distinguish multiple analyses (recounts, reworks, reanalyses) of a fraction of the sample. The suffix indicates which result is being reported. An empty suffix normally identifies the first attempt to analyze the sample.
- \* The LAB SAMPLE ID, TEST and SUFFIX uniquely identify all supporting data for a result. The Method Summary Report for each TEST has method performance data, such as yield, for each lab sample id and suffix and procedures used in the method.
- \* PLANCHET is an alternate lab identifier for work done for one test. It, combined with the TEST and SUFFIX, may be the best link to raw data.
- \* For QC samples, only analyses that directly QC some regular sample are shown. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.
- \* The SAS (Special Analytical Services) Number is a client or lab assigned code that reflects special processing for samples, such as rapid turn around. Counts of tests done are lists by SAS number since it is likely to affect prices.

### REPORT GUIDES

Page 3

### SUMMARY DATA SECTION

Page 18

Lab id EBRLINE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000055



# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

## DATA SHEET

The Data Sheet Report shows all results and primary supporting information for one client sample or Method Blank. This report corresponds to both the CLP Inorganics and Organics Data Sheet.

The following notes apply to this report:

- \* TEST is a code for the method used to measure an analyte. If the TEST is empty, no data is available; the analyte was not analyzed for.
- \* The LAB SAMPLE ID and TEST uniquely identify work within the Summary Data Section of a Data Package. The Work Summary and Method Summary Reports further identify raw data that underlies this work.

The Method Summary Report for each TEST has method performance data, such as yield, for each Lab Sample ID and a list of procedures used in the method.

- \* ERRORS can be labeled TOTAL or COUNT. TOTAL implies a preparation (non-counting method) error has been added, as square root of sum of squares, to the counting error denoted by COUNT. The preparation errors, which may vary by preparation batch, are shown on the Method Summary Report.
- \* A RESULT can be 'N.R.' (Not Reported). This means the lab did this work but chooses not to report it now, possibly because it was reported at another time.
- \* When reporting a Method Blank, a RESULT can be 'N.A.' (Not Applicable). This means there is no reported client sample work in the same preparation batch as the Blank's result. This is likely to occur when the Method Blank is associated with reanalyses of selected work for a few samples in the SDG.

The following qualifiers are defined by the DVD system:

U The RESULT is less than the MDA (Minimum Detectable Activity).

### REPORT GUIDES

Page 4

### SUMMARY DATA SECTION

Page 19

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000056

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## DATA SHEET

If the MDA is blank, the ERROR is used as the limit.

- J The RESULT is less than the RDL (Required Detection Limit) and no U qualifier is assigned.
- B A Method Blank associated with this sample had a result without a U flag and, after correcting for possibly different aliquots, that result is greater than or equal to the MDA for this sample.

Normally, B is not assigned if U is. When method blank subtraction is shown on this report, B flags are assigned based on the unsubtracted values while U's are assigned based on the subtracted ones. Both flags can be assigned in this case.

For each sample result, all Method Blank results in the same preparation batch are compared. The Method Summary Report documents this and other QC relationships.

- L Some Lab Control Sample that QC's this sample had a low recovery. The lab can disable assignment of this qualifier.
- H Similar to 'L' except the recovery was high.
- P The RESULT is 'preliminary'.
- X Some data necessary to compute the RESULT, ERROR or MDA was manually entered or modified.
- 2 There were two or more results available for this analyte. The reported result may not be the same as in the raw data.

Other qualifiers are lab defined. Definitions should be in the SDG narrative.

The following values are underlined to indicate possible problems:

- \* An MDA is underlined if it is bigger than its RDL.

### REPORT GUIDES

Page 5

### SUMMARY DATA SECTION

Page 20

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000057

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## DATA SHEET

- \* An ERROR is underlined if the 1.645 sigma counting error is bigger than both the MDA and the RESULT, implying that the MDA may not be a good estimate of the 'real' minimum detectable activity.
- \* A negative RESULT is underlined if it is less than the negative of its 2 sigma counting ERROR.
- \* When reporting a Method Blank, a RESULT is underlined if greater than its MDA. If the MDA is blank, the 2 sigma counting error is used in the comparison.

### REPORT GUIDES

Page 6

### SUMMARY DATA SECTION

Page 21

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000058

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

### LAB CONTROL SAMPLE

The Lab Control Sample Report shows all results, recoveries and primary supporting information for one Lab Control Sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. Refer to its Report Guide for details.
- \* An amount ADDED is the lab's value for the actual amount spiked into this sample with its ERROR an estimate of the error of this amount.

An amount added is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- \* REC (Recovery) is RESULT divided by ADDED expressed as a percent.
- \* The first, computed limits for the recovery reflect:
  1. The error of RESULT, including that introduced by rounding the result prior to printing.
 

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.
  2. The error of ADDED.
  3. A lab specified, per analyte bias. The bias changes the center of the computed limits.
- \* The second limits are protocol defined upper and lower QC limits for the recovery.
- \* The recovery is underlined if it is outside either of these ranges.

#### REPORT GUIDES

Page 7

#### SUMMARY DATA SECTION

Page 22

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000059

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

### DUPLICATE

The Duplicate Report shows all results, differences and primary supporting information for one Duplicate and associated Original sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. This applies both to the Duplicate and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Duplicate has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- \* The RPD (Relative Percent Difference) is the absolute value of the difference of the RESULTS divided by their average expressed as a percent.

If both RESULTS are less than their MDAs, no RPD is computed and a '-' is printed.

For an analyte, if the lab did work for both samples but has data for only one, the MDA from the sample with data is used as the other's result in the RPD.

- \* The first, computed limit is the sum, as square root of sum of squares, of the errors of the results divided by the average result as a percent, hence the relative error of the difference rather than the error of the relative difference. The errors include those introduced by rounding the RESULTS prior to printing.

If this limit is labeled TOT, it includes the preparation error in the RESULTS. If labeled CNT, it does not.

This value reported for this limit is at most 999.

- \* The second limit for the RPD is the larger of:

1. A fixed percentage specified in the protocol.

#### REPORT GUIDES

Page 8

#### SUMMARY DATA SECTION

Page 23

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000060

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## DUPLICATE

2. A protocol factor (typically 2) times the average MDA as a percent of the average result. This limit applies when the results are close to the MDAs.

- \* The RPD is underlined if it is greater than either limit.
- \* If specified by the lab, the second limit column is replaced by the Difference Error Ratio (DER), which is the absolute value of the difference of the results divided by the quadratic sum of their one sigma errors, the same errors as used in the first limit.

Except for differences due to rounding, the DER is the same as the RPD divided by the first RPD limit with the limit scaled to 1 sigma.

- \* The DER is underlined if it is greater than the sigma factor, typically 2 or 3, shown in the header for the first RPD limit.

### REPORT GUIDES

Page 9

### SUMMARY DATA SECTION

Page 24

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000061

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

### MATRIX SPIKE

The Matrix Spike Report shows all results, recoveries and primary supporting information for one Matrix Spike and associated Original sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. This applies both to the Spiked and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Spike has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- \* An amount ADDED is the lab's value for the actual amount spiked into the Spike sample with its ERROR an estimate of the error of this amount.

An amount is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- \* REC (Recovery) is the Spike RESULT minus the Original RESULT divided by ADDED expressed as a percent.

- \* The first, computed limits for the recovery reflect:

1. The errors of the two RESULTS, including those introduced by rounding them prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.

2. The error of ADDED.

3. A lab specified, per analyte bias. The bias changes the center of the computed limits.

- \* The second limits are protocol defined upper and lower QC limits

#### REPORT GUIDES

Page 10

#### SUMMARY DATA SECTION

Page 25

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000062

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

MATRIX SPIKE

for the recovery.

These limits are left blank if the Original RESULT is more than a protocol defined factor (typically 4) times ADDED. This is a way of accounting for that when the spike is small compared to the amount in the original sample, the recovery is unreliable.

- \* The recovery is underlined (out of spec) if it is outside either of these ranges.

REPORT GUIDES

Page 11

SUMMARY DATA SECTION

Page 26

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000063



# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

## METHOD SUMMARY

The Method Summary Report has two tables. One shows up to five results measured using one method. The other has performance data for the method. There is one report for each TEST, as used on the Data Sheet Report.

The following notes apply to this report:

- \* Each table is subdivided into sections, one for each preparation batch. A preparation batch is a group of aliquots prepared at roughly the same time in one work area of the lab using the same method.

There should be Lab Control Sample and Method Blank results in each preparation batch since this close correspondence makes the QC meaningful. Depending on lab policy, Duplicates need not occur in each batch since they QC sample dependencies such as matrix effects.

- \* The RAW TEST column shows the test code used in the raw data to identify a particular analysis if it is different than the test code in the header of the report. This occurs in special cases due to method specific details about how the lab labels work.

The Lab Sample or Planchet ID combined with the (Raw) Test Code and Suffix uniquely identify the raw data for each analysis.

- \* If a result is less than both its MDA and RDL, it is replaced by just 'U' on this report. If it is greater than or equal to the RDL but less than the MDA, the result is shown with a 'U' flag.

The J and X flags are as on the data sheet.

- \* Non-U results for Method Blanks are underlined to indicate possible contamination of other samples in the preparation batch. The Method Blank Report has supporting data.
- \* Lab Control Sample and Matrix Spike results are shown as: ok, No data, LOW or HIGH, with the last two underlined. 'No data'

### REPORT GUIDES

Page 12

### SUMMARY DATA SECTION

Page 27

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000064

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

METHOD SUMMARY

means no amount ADDED was specified. 'LOW' and 'HIGH' correspond to when the recovery is underlined on the Lab Control Sample or Matrix Spike Report. See these reports for supporting data.

- \* Duplicate sample results are shown as: ok, No data, or OUT, with the last two underlined. 'No data' means there was no original sample data found for this duplicate. 'OUT' corresponds to when the RPD is underlined on the Duplicate Report. See this report for supporting data.
- \* If the MDA column is labeled 'MAX MDA', there was more than one result measured by the reported method and the MDA shown is the largest MDA. If not all these results have the same RDL, the MAX MDA reflects only those results with RDL equal to the smallest one.

MDAs are underlined if greater than the printed RDL.

- \* Aliquots are underlined if less than the nominal value specified for the method.
- \* Preparation factors are underlined if greater than the nominal value specified for the method.
- \* Dilution factors are underlined if greater than the nominal value specified for the method.
- \* Residues are underlined if outside the range specified for the method. Residues are not printed if yields are.
- \* Yields, which may be gravimetric, radiometric or some type of recovery depending on the method, are underlined if outside the range specified for the method.
- \* Efficiencies are underlined if outside the range specified for the method. Efficiencies are detector and geometry dependent so this test is only approximate.

REPORT GUIDES

Page 13

SUMMARY DATA SECTION

Page 28

Lab id EBRLINE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000065

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## METHOD SUMMARY

- \* Count times are underlined if less than the nominal value specified for the method.
- \* Resolutions (as FWHM; Full Width at Half Max) are underlined if greater than the method specified limit.
- \* Tracer drifts are underlined if their absolute values are greater than the method specified limit. Tracer drifts are not printed if percent moistures are.
- \* Days Held are underlined if greater than the holding time specified in the protocol.
- \* Analysis dates are underlined if before their planchet's preparation date or, if a limit is specified, too far after it.

For some methods, ratios as percentages and error estimates for them are computed for pairs of results. A ratio column header like '1+3' means the ratio of the first result column and the third result column.

Ratios are not computed for Lab Control Sample, Method Blank or Matrix Spike results since their matrices are not necessarily similar to client samples'.

The error estimate for a ratio of results from one planchet reflects only counting errors since other errors should be correlated. For a ratio involving different planchets, if QC limits are computed based on total errors, the error for the ratio allows for the preparation errors for the planchets.

The ratio is underlined (out of spec) if the absolute value of its difference from the nominal value is greater than its error estimate. If no nominal value is specified, this test is not done.

For Gross Alpha or Gross Beta results, there may be a column showing the sum of other Alpha or Beta emitters. This sum includes all relevant

### REPORT GUIDES

Page 14

### SUMMARY DATA SECTION

Page 29

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000066

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7197  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## METHOD SUMMARY

results in the DVD database, whether reported or not. Results in the sum are weighted by a particles/decay value specified by the lab for each relevant analyte. Results less than their MDA are not included. No sums are computed for Lab Control, Method Blank or Matrix Spike samples since their various planchets may not be physically related.

If a ratio of total isotopic to Gross Alpha or Beta is shown, the error for the ratio reflects both the error in the Gross result and the sum, as square root of sum of squares, of the errors in the isotopic results.

For total elemental uranium or thorium results, there may be a column showing the total weight computed from associated isotopic results. Ignoring results less than their MDAs, this is a weighted sum of the isotopic results. The weights depend on the molecular weight and half-life of each isotope so as to convert activities (decays) to weight (atoms).

If a ratio of total computed to measured elemental uranium or thorium is shown, the error for the ratio reflects the errors in all the measurements.

### REPORT GUIDES

Page 15

### SUMMARY DATA SECTION

Page 30

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000067

FLUOR Hanford Inc.		CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST				F04-015-067		PAGE 1 OF 1	
COLLECTOR Pope/Pfister/Tyra/Wiberg		COMPANY CONTACT CS Clearlock		TELEPHONE NO. 372-9638		PROJECT COORDINATOR TRENT, SJ		PRICE CODE 8N	
SAMPLING LOCATION 216-U-3; 35FT-37.5FT		PROJECT DESIGNATION 200-MW-1 Characterization Sampling and Analysis - Soil		SAF NO. F04-015		AIR QUALITY <input type="checkbox"/>		DATA TURNAROUND 45 Days / 45 Days	
ICE CHEST NO. <b>GRP-03-009</b>		FIELD LOGBOOK NO. HNF-N-386 1		COA 119144ES10		METHOD OF SHIPMENT Federal Express			
SHIPPED TO Eberline Services		OFFSITE PROPERTY NO. <b>PTR 14598</b>				BILL OF LADING/AIR BILL NO. <b>PTR 14598</b>			
MATRIX* A=Air DL=Drum Liquids DS=Drum Solids L=Liquid O=Oil S=Soil SE=Sediment T=Tissue V=Vegetation W=Water WI=Wipe X=Other	POSSIBLE SAMPLE HAZARDS/ REMARKS N/A	PRESERVATION		Cool 4C	None				
		TYPE OF CONTAINER		aG	aG				
		NO. OF CONTAINER(S)		1	1				
		VOLUME		120ml	60ml				
SPECIAL HANDLING AND/OR STORAGE Radioactive Tie To: B19953		SAMPLE ANALYSIS		SEE ITEM (1) IN SPECIAL INSTRUCTIONS		Iodine-129; Technetium-99; Tritium - H3;			
SAMPLE NO.	MATRIX*	SAMPLE DATE	SAMPLE TIME						
B19963	SOIL	12/14/04	0700		X				
CHAIN OF POSSESSION		SIGN/ PRINT NAMES				SPECIAL INSTRUCTIONS			
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME	(1) NO2/NO3 - 353.2; Oil & Grease - 413.1; Chromium Hex - 7196; <b>msg 12 24</b>			
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
LABORATORY SECTION		RECEIVED BY				TITLE			
FINAL SAMPLE DISPOSITION		DISPOSAL METHOD				DISPOSED BY			
						DATE/TIME			

FLUOR Hanford Inc.		CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST				F04-015-068		PAGE 1 OF 1		
COLLECTOR Pope/Pfister/Tyra/Wiberg		COMPANY CONTACT CS Clearlock		TELEPHONE NO. 372-9638		PROJECT COORDINATOR TRENT, SJ		PRICE CODE 8N DATA TURNAROUND 45 Days / 45 Days		
SAMPLING LOCATION 216-U-3; 47FT-49.5FT		PROJECT DESIGNATION 200-MW-1 Characterization Sampling and Analysis - Soil <b>H2912 (7197)</b>				SAF NO. F04-015		AIR QUALITY <input type="checkbox"/>		
ICE CHEST NO. <b>ERC-02-406</b>		FIELD LOGBOOK NO. HNF-N-386 1		COA 119144ES10		METHOD OF SHIPMENT Federal Express				
SHIPPED TO Eberline Services		OFFSITE PROPERTY NO. <b>See PTR 14598</b>				BILL OF LADING/AIR BILL NO. <b>See PTR 14598</b>				
MATRIX* A=Air DL=Drum Liquids DS=Drum Solids L=Liquid O=Oil S=Soil SE=Sediment T=Tissue V=Vegetation W=Water WI=Wipe X=Other	POSSIBLE SAMPLE HAZARDS/ REMARKS N/A	PRESERVATION	Coal 4C	None						
		TYPE OF CONTAINER	8G	8G						
		NO. OF CONTAINER(S)	1	1						
	VOLUME	120mL	60mL							
SPECIAL HANDLING AND/OR STORAGE Radioactive Tie To: B19954		SAMPLE ANALYSIS		SEE ITEM (1) IN SPECIAL INSTRUCTIONS	Iodine-129; Technetium-99; Tritium - H3;					
SAMPLE NO.	MATRIX*	SAMPLE DATE	SAMPLE TIME							
B19964	SOIL	12-15-04	0700		X					
CHAIN OF POSSESSION				SIGN/ PRINT NAMES		SPECIAL INSTRUCTIONS				
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME		(1)NO2/NO3 - 353.2; Oil & Grease - 413.1; Chromium Hex - 7196;		
J.S. Pope		12-15-04 1330		M.H. Baughman		12-05-04 1330				
M.H. Baughman		12-16-04 1130		M.H. Baughman		12-16-04 1130				
M.H. Baughman		12-16-04 1130		M.H. Baughman		12-16-04 1130				
Fed Ex		12-20-04 10:00		Fed Ex		12-20-04 9:00				
Fed Ex		12-20-04 10:00		Fed Ex		12-20-04 9:00				
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME				
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME				
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME				
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME				
LABORATORY SECTION		RECEIVED BY				TITLE				
FINAL SAMPLE DISPOSITION		DISPOSAL METHOD				DISPOSED BY				
						DATE/TIME				
						DATE/TIME				

FLUOR Hanford Inc.		CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST				F04-015-069		PAGE 1 OF 1	
COLLECTOR Pope/Pfister/Tyra/Wiberg		COMPANY CONTACT CS Clearlock		TELEPHONE NO. 372-9638		PROJECT COORDINATOR TRENT, SJ		PRICE CODE 8N DATA TURNAROUND 45 Days / 45 Days	
SAMPLING LOCATION 216-U-3; 97.5FT-100FT		PROJECT DESIGNATION 200-MW-1 Characterization Sampling and Analysis - Soil <b>H2912 (7197)</b>				SAF NO. F04-015		AIR QUALITY <input type="checkbox"/>	
ICE CHEST NO. <b>ERC-6118-02-406</b>		FIELD LOGBOOK NO. HNF-N-386 1		COA 119144ES10		METHOD OF SHIPMENT Federal Express			
SHIPPED TO Eberline Services		OFFSITE PROPERTY NO. <b>Suprk 14598</b>				BILL OF LADING/AIR BILL NO. <b>2u PTH 14598</b>			
MATRIX* A=Air DL=Drum Liquids DS=Drum Solids L=Liquid O=Oil S=Soil SE=Sediment T=Tissue V=Vegetation W=Water WI=Wipe X=Other	POSSIBLE SAMPLE HAZARDS/ REMARKS N/A	PRESERVATION		Cool 4C	None				
		TYPE OF CONTAINER		gG	gG				
		NO. OF CONTAINER(S)		1	1				
	SPECIAL HANDLING AND/OR STORAGE Radioactive Tie To: B19953 <b>B19954 12/16/04</b>		VOLUME		120mL	60mL			
		SAMPLE ANALYSIS		SEE ITEM (1) IN SPECIAL INSTRUCTIONS	Iodine-129; Technetium-99; Tritium - H3;				
SAMPLE NO.		MATRIX*		SAMPLE DATE	SAMPLE TIME				
B19965		SOIL		12.6.04	0910				
CHAIN OF POSSESSION				SIGN/ PRINT NAMES		SPECIAL INSTRUCTIONS			
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME		<del>(1) NO2/NO3 - 353 2; Oil &amp; Grease - 413.1; Chromium Hex - 7196;</del> <b>12-04</b>	
R. P. 10732/Robert		12/16/04 1030		MO-026 ER16 #1		12/16/04 1030			
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME			
MO-026 RTH		12/16/04 1105		M.A. Baiker M.A. Baiker		12/16/04 1105			
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME			
M.A. Baiker		12/16/04 1105		Red 9					
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME			
Ted S		12/20/04 1040		Fred S		12/21/04 09:00			
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME			
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME			
RELINQUISHED BY/REMOVED FROM		DATE/TIME		RECEIVED BY/STORED IN		DATE/TIME			
LABORATORY SECTION		RECEIVED BY		TITLE		DATE/TIME			
FINAL SAMPLE DISPOSITION		DISPOSAL METHOD		DISPOSED BY		DATE/TIME			

**EBERLINE**  
SERVICES**RICHMOND, CA LABORATORY****SAMPLE RECEIPT CHECKLIST**

Client Fluor Hanford City Richland State WA  
Date/Time received 12/20/08 10:00 CoC No. F 04-05-067,074

Container I.D. No. GRP-03-009 Requested TAT (Days) 45 P.O. Received Yes [ ] No [ ]

**INSPECTION**

1. Custody seals on shipping container intact? Yes [x] No [ ] N/A [ ]
2. Custody seals on shipping container dated & signed? Yes [x] No [ ] N/A [ ]
3. Custody seals on sample containers intact? Yes [x] No [ ] N/A [ ]
4. Custody seals on sample containers dated & signed? Yes [x] No [ ] N/A [ ]
5. Packing material is: Wet [ ] Dry [x]
6. Number of samples in shipping container: 2 Sample Matrix Soil
7. Number of containers per sample: \_\_\_\_\_ (Or see CoC ✓)
8. Samples are in correct container Yes [x] No [ ]
9. Paperwork agrees with samples? Yes [x] No [ ]
10. Samples have: Tape [ ] Hazard labels [ ] Rad labels [ ] Appropriate sample labels [x]
11. Samples are: In good condition [x] Leaking [ ] Broken Container [ ] Missing [ ]
12. Samples are: Preserved [ ] Not preserved [ ] pH \_\_\_\_\_ Preservative \_\_\_\_\_
13. Describe any anomalies: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_
14. Was P.M. notified of any anomalies? Yes [ ] No [ ] Date \_\_\_\_\_
15. Inspected by James Date: 12/21/08 Time: 8:00

Customer Sample No.	cpm	mR/hr	wipe	Customer Sample No.	cpm	mR/hr	wipe
<u>B19963</u>	<u>— (6000)</u>	<u>for</u>	<u>Chem.</u>				
<u>B19970</u>	<u>— (comp. line)</u>	<u>for Shaw.</u>					

Ion Chamber Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

Alpha Meter Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

Beta/Gamma Meter Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_





## RICHMOND, CA LABORATORY

## SAMPLE RECEIPT CHECKLIST

Client Fluor Hanford City Richland State WA  
Date/Time received 12/21/04 12:00 CoC No. F04-015-060, 069, 075

Container I.D. No. ERC 02-406 Requested TAT (Days) 45 P.D. Received Yes ☐ No ☐

INSPECTION

1. Custody seals on shipping container intact? Yes ☒ No ☐ N/A ☐  
2. Custody seals on shipping container dated & signed? Yes ☒ No ☐ N/A ☐  
3. Custody seals on sample containers intact? Yes ☒ No ☐ N/A ☐  
4. Custody seals on sample containers dated & signed? Yes ☒ No ☐ N/A ☐  
5. Packing material is: Wet ☐ Dry ☒  
6. Number of samples in shipping container: 3 Sample Matrix Soil  
7. Number of containers per sample: \_\_\_\_\_ (Or see CoC 1)  
8. Samples are in correct container Yes ☒ No ☐  
9. Paperwork agrees with samples? Yes ☒ No ☐  
10. Samples have: Tape ☐ Hazard labels ☐ Rad labels ☐ Appropriate sample labels ☒  
11. Samples are: In good condition ☒ Leaking ☐ Broken Container ☐ Missing ☐  
12. Samples are: Preserved ☐ Not preserved ☐ pH \_\_\_\_\_ Preservative \_\_\_\_\_  
13. Describe any anomalies: \_\_\_\_\_  
14. Was P.M. notified of any anomalies? Yes ☐ No ☐ Date \_\_\_\_\_  
15. Inspected by [Signature] Date: 12/21/04 Time: 9:00

Customer Sample				Customer Sample			
No.	cpm	mR/hr	wipe	No.	cpm	mR/hr	wipe
B19964	(60ml)		for chem				
B19965	(60ml)		for chem				
B19971	(can / spoon liner)		for show				

Ion Chamber Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

Alpha Meter Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

Beta/Gamma Meter Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

EBRLINE SERVICES / RICHMOND  
SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

S U M M A R Y   D A T A   S E C T I O N

T A B L E   O F   C O N T E N T S				
About this section	.	.	.	1
Sample Summaries	.	.	.	3
Prep Batch Summary	.	.	.	5
Work Summary	.	.	.	6
Method Blanks	.	.	.	8
Lab Control Samples	.	.	.	9
Duplicates	.	.	.	10
Matrix Spikes	.	.	.	12
Data Sheets	.	.	.	13
Method Summaries	.	.	.	16
Report Guides	.	.	.	25
End of Section	.	.	.	39

Prepared by



Reviewed by

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-TOC  
Version 3.06  
Report date 02/21/05

00000073

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG\_H2905

### ABOUT THE DATA SUMMARY SECTION

The Data Summary Section of a Data Package has all data, in several useful orders, necessary for first level, routine review of the data package for a Sample Delivery Group (SDG). This section follows the Data Package Narrative, which has an overview of the data package and a discussion of special problems. It is followed by the Raw Data Section, which has full details.

The Data Summary Section has several groups of reports:

#### SAMPLE SUMMARIES

The Sample and QC Summary Reports show all samples, including QC samples, reported in one SDG. These reports cross-reference client and lab sample identifiers.

#### PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches (lab groupings reflecting how work was organized) relevant to the reported SDG with information necessary to check the completeness and consistency of the SDG.

#### WORK SUMMARY

The Work Summary Report shows all samples and work done on them relevant to the reported SDG.

#### METHOD BLANKS

The Method Blank Reports, one for each Method Blank relevant to the SDG, show all results and primary supporting information for the blanks.

#### LAB CONTROL SAMPLES

The Lab Control Sample Reports, one for each Lab Control Sample relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

#### REPORT GUIDES

Page 1

#### SUMMARY DATA SECTION

Page 1

Lab id EBRINE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000074

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## ABOUT THE DATA SUMMARY SECTION

### DUPLICATES

The Duplicate Reports, one for each Duplicate and Original sample pair relevant to the SDG, show all results, differences and primary supporting information for these QC samples.

### MATRIX SPIKES

The Matrix Spike Reports, one for each Spiked and Original sample pair relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

### DATA SHEETS

The Data Sheet Reports, one for each client sample in the SDG, show all results and primary supporting information for these samples.

### METHOD SUMMARIES

The Method Summary Reports, one for each test used in the SDG, show all results, QC and method performance data for one analyte on one or two pages. (A test is a short code for the method used to do certain work to the client's specification.)

### REPORT GUIDES

The Report Guides, one for each of the above groups of reports, have documentation on how to read the associated reports.

### REPORT GUIDES

Page 2

### SUMMARY DATA SECTION

Page 2

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000075

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

## SAMPLE SUMMARY

SDG 7209

Contact Melissa C. Mannion

Client Hanford

Contract No. 630

Case no SDG H2905

CLIENT SAMPLE ID	LOCATION	MATRIX	LEVEL	LAB SAMPLE ID	SAF NO	CHAIN OF CUSTODY	COLLECTED
B19962	216-U-3; 22.5ft-25ft	SOLID		R412280-01	F04-015	F04-015-120	12/13/04 07:50
B19966	216-U-3; 1275ft-129.5ft	SOLID		R412280-02	F04-015	F04-015-070	12/20/04 07:40
B19PT5	216-U-3; 22.5ft-25ft	SOLID		R412280-03	F04-015	F04-015-118	12/13/04 07:50
Method Blank		SOLID		R412280-05	F04-015		
Lab Control Sample		SOLID		R412280-04	F04-015		
Duplicate (R412280-01)	216-U-3; 22.5ft-25ft	SOLID		R412280-06	F04-015		12/13/04 07:50
Duplicate (R412280-03)	216-U-3; 22.5ft-25ft	SOLID		R412280-07	F04-015		12/13/04 07:50
Spike (R412280-01)	216-U-3; 22.5ft-25ft	SOLID		R412280-08	F04-015		12/13/04 07:50

SAMPLE SUMMARY

Page 1

UNMARY DATA SECTION

Page 3

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-CS

Version 3.06

Report date 02/21/05

00000076

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## QC SUMMARY

Client Hanford  
Contract No. 630  
Case no SDG H2905

2 BATCH	CHAIN OF CUSTODY	CLIENT SAMPLE ID	MATRIX	% SOLIDS	SAMPLE AMOUNT	BASIS AMOUNT	DAYS SINCE RECEIVED	LAB COLL	LAB SAMPLE ID	DEPARTMENT SAMPLE ID
209	F04-015-070	B19966	SOLID	91.8	70.5 g		12/23/04 3		R412280-02	7209-002
	F04-015-118	B19PT5	SOLID	95.7	681.6 g		12/23/04 10		R412280-03	7209-003
	F04-015-120	B19962	SOLID	94.3	82.7 g		12/23/04 10		R412280-01	7209-001
		Method Blank	SOLID						R412280-05	7209-005
		Lab Control Sample	SOLID						R412280-04	7209-004
		Duplicate (R412280-01)	SOLID	94.3	82.7 g		12/23/04 10		R412280-06	7209-006
		Duplicate (R412280-03)	SOLID	95.7	681.6 g		12/23/04 10		R412280-07	7209-007
		Spike (R412280-01)	SOLID	94.3	82.7 g		12/23/04 10		R412280-08	7209-008

QC SUMMARY

Page 1

SUMMARY DATA SECTION

Page 4

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-QS  
Version 3.06  
Report date 02/21/05

00000077

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209

Contact Melissa C. Mannion

## PREP BATCH SUMMARY

Client Hanford

Contract No. 630

Case no SDG H2905

TEST	MATRIX	METHOD	PREPARATION ERROR		PLANCHETS ANALYZED				QUALI-			
			BATCH	2σ %	CLIENT	MORE	RE	BLANK	LCS	DUP/ORIG	MS/ORIG	FIERS
Alpha Spectroscopy												
AM	SOLID	Americium 241 in Solids	7113-102	5.0	1			1	1	1/1		
PU	SOLID	Plutonium, Isotopic in Solids	7113-102	5.0	1			1	1	1/1		
U	SOLID	Uranium, Isotopic in Solids	7113-102	5.0	1			1	1	1/1		
Beta Counting												
SR	SOLID	Total Strontium in Solids	7113-102	10.0	1			1	1	1/1		
TC	SOLID	Technetium 99 in Solids	7113-102	10.0	2			1	1	1/1		
Gamma Spectroscopy												
GAM	SOLID	Gamma Scan	7113-102	15.0	1			1	1	1/1		
I	SOLID	Iodine 129 in Solids	7113-102	10.0	2			1	1	1/1		
Kinetic Phosphorimetry (KPA)												
U_T	SOLID	Uranium, Total in Solids	7113-102	9.0	1			1	1	1/1		
Liquid Scintillation Counting												
H	SOLID	Tritium in Solids	7113-102	10.0	2			1	1	1/1	1/1	X

Duplicates and Matrix Spikes are those with original (Client) sample in this Sample Delivery Group.

Blank and LCS planchets are those in the same preparation batch as some Client, Duplicate or Spike sample.

PREP BATCH SUMMARY

Page 1

SUMMARY DATA SECTION

Page 5

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-PBS

Version 3.06

Report date 02/21/05

00000078

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## WORK SUMMARY

Client Hanford  
Contract No. 630  
Case no SDG H2905

CLIENT SAMPLE ID		LAB SAMPLE ID													
LOCATION	MATRIX	COLLECTED	PLANCHET	TEST	SUF-	ANALYZED	REVIEWED	BY	METHOD						
USTODY	SAF No	RECEIVED			FIX										
19962		R412280-01	7209-001	H		02/08/05	02/13/05	MWT	Tritium in Solids						
16-U-3; 22.5ft-25ft	SOLID	12/13/04	7209-001	I		02/15/05	02/18/05	MWT	Iodine 129 in Solids						
04-015-120	F04-015	12/23/04	7209-001	TC		02/17/05	02/18/05	MWT	Technetium 99 in Solids						
19966		R412280-02	7209-002	H		02/08/05	02/13/05	MWT	Tritium in Solids						
16-U-3; 1275ft-129.5ft	SOLID	12/20/04	7209-002	I		02/15/05	02/18/05	MWT	Iodine 129 in Solids						
04-015-070	F04-015	12/23/04	7209-002	TC		02/14/05	02/16/05	MWT	Technetium 99 in Solids						
19PT5		R412280-03	7209-003	AM		01/29/05	01/31/05	MWT	Americium 241 in Solids						
16-U-3; 22.5ft-25ft	SOLID	12/13/04	7209-003	GAM		02/10/05	02/14/05	CSS	Gamma Scan						
04-015-118	F04-015	12/23/04	7209-003	PU		02/02/05	02/03/05	MWT	Plutonium, Isotopic in Solids						
			7209-003	SR		01/14/05	01/19/05	MWT	Total Strontium in Solids						
			7209-003	U		01/15/05	01/17/05	MWT	Uranium, Isotopic in Solids						
			7209-003	U_T		02/11/05	02/14/05	MWT	Uranium, Total in Solids						
ethod Blank		R412280-05	7209-005	AM		01/31/05	02/01/05	MWT	Americium 241 in Solids						
	SOLID		7209-005	GAM		01/12/05	02/14/05	CSS	Gamma Scan						
	F04-015		7209-005	H		02/08/05	02/13/05	MWT	Tritium in Solids						
			7209-005	I		02/17/05	02/18/05	MWT	Iodine 129 in Solids						
			7209-005	PU		02/02/05	02/05/05	MWT	Plutonium, Isotopic in Solids						
			7209-005	SR		01/14/05	01/19/05	MWT	Total Strontium in Solids						
			7209-005	TC		02/14/05	02/18/05	MWT	Technetium 99 in Solids						
			7209-005	U		01/15/05	01/17/05	MWT	Uranium, Isotopic in Solids						
			7209-005	U_T		02/11/05	02/14/05	MWT	Uranium, Total in Solids						
ab Control Sample		R412280-04	7209-004	AM		01/29/05	01/31/05	MWT	Americium 241 in Solids						
	SOLID		7209-004	GAM		02/11/05	02/14/05	CSS	Gamma Scan						
	F04-015		7209-004	H		02/08/05	02/13/05	MWT	Tritium in Solids						
			7209-004	I		02/18/05	02/18/05	MWT	Iodine 129 in Solids						
			7209-004	PU		02/02/05	02/04/05	MWT	Plutonium, Isotopic in Solids						
			7209-004	SR		01/14/05	01/19/05	MWT	Total Strontium in Solids						
			7209-004	TC		02/17/05	02/18/05	MWT	Technetium 99 in Solids						
			7209-004	U		01/15/05	01/17/05	MWT	Uranium, Isotopic in Solids						
			7209-004	U_T		02/11/05	02/14/05	MWT	Uranium, Total in Solids						
uplicate (R412280-01)		R412280-06	7209-006	H		02/08/05	02/13/05	MWT	Tritium in Solids						
16-U-3; 22.5ft-25ft	SOLID	12/13/04	7209-006	I		02/17/05	02/18/05	MWT	Iodine 129 in Solids						
	F04-015	12/23/04	7209-006	TC		02/15/05	02/18/05	MWT	Technetium 99 in Solids						

WORK SUMMARY

Page 1

SUMMARY DATA SECTION

Page 6

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-CWS  
Version 3.06  
Report date 02/21/05

00000079



# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

## WORK SUMMARY, cont.

SDG 7209

Contact Melissa C. Mannion

Client Hanford

Contract No. 630

Case no SDG H2905

CLIENT SAMPLE ID	MATRIX	LAB SAMPLE ID	COLLECTED	TEST	SUF-	ANALYZED	REVIEWED	BY	METHOD
LOCATION	SAF No	RECEIVED	PLANCHET	TEST	FIX	ANALYZED	REVIEWED	BY	METHOD
uplicate (R412280-03)		R412280-07	7209-007	AM		01/31/05	02/01/05	MWT	Americium 241 in Solids
16-U-3; 22.5ft-25ft	SOLID	12/13/04	7209-007	GAM		02/12/05	02/14/05	CSS	Gamma Scan
	F04-015	12/23/04	7209-007	PU		02/02/05	02/04/05	MWT	Plutonium, Isotopic in Solids
			7209-007	SR		01/14/05	01/19/05	MWT	Total Strontium in Solids
			7209-007	U		01/15/05	01/17/05	MWT	Uranium, Isotopic in Solids
			7209-007	U_T		02/11/05	02/14/05	MWT	Uranium, Total in Solids
pike (R412280-01)		R412280-08	7209-008	H		02/08/05	02/13/05	MWT	Tritium in Solids
16-U-3; 22.5ft-25ft	SOLID	12/13/04							
	F04-015	12/23/04							

## COUNTS OF TESTS BY SAMPLE TYPE

TEST	SAF No	METHOD	REFERENCE	CLIENT	MORE	RE	BLANK	LCS	DUP SPIKE	TOTAL
AM	F04-015	Americium 241 in Solids	AMCMISO_IE_PLATE_AEA	1			1	1	1	4
GAM	F04-015	Gamma Scan	GAMMA_GS	1			1	1	1	4
H	F04-015	Tritium in Solids	906.0_H3_LSC	2			1	1	1	6
I	F04-015	Iodine 129 in Solids	I129_SEP_LEPS_GS	2			1	1	1	5
PU	F04-015	Plutonium, Isotopic in Solids	PUIISO_PLATE_AEA	1			1	1	1	4
SR	F04-015	Total Strontium in Solids	SRTOT_SEP_PRECIP_GPC	1			1	1	1	4
TC	F04-015	Technetium 99 in Solids	TC99_TR_SEP_LSC	2			1	1	1	5
U	F04-015	Uranium, Isotopic in Solids	UIISO_PLATE_AEA	1			1	1	1	4
U_T	F04-015	Uranium, Total in Solids	UTOT_KPA	1			1	1	1	4
TOTALS				12			9	9	9	40

WORK SUMMARY

Page 2

SUMMARY DATA SECTION

Page 7

Lab id EBERLINE

Protocol Hanford

Version Ver 1.0

Form DVD-CWS

Version 3.06

Report date 02/21/05

00000080

**EBERLINE SERVICES / RICHMOND**

**SAMPLE DELIVERY GROUP H2905**

**R412280-05**

**Method Blank**

**METHOD BLANK**

SDG <u>7209</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412280-05</u>	Client sample id <u>Method Blank</u>	
Dept sample id <u>7209-005</u>	Material/Matrix <u>SOLID</u>	
	SAF No <u>F04-015</u>	

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	0.096	0.20	0.33	400	U	H
Total Strontium	SR-RAD	0.018	0.12	0.25	1.0	U	SR
Technetium 99	14133-76-7	0.205	0.28	0.50	15	U	TC
Total Uranium (ug/g)	7440-61-1	0	0.004	0.008	1.0	U	U_T
Uranium 233/234	U-233/234	0	0.052	0.20	1.0	U	U
Uranium 235	15117-96-1	0.031	0.063	0.24	1.0	U	U
Uranium 238	U-238	0.078	0.10	0.20	1.0	U	U
Plutonium 238	13981-16-3	0.015	0.030	0.12	1.0	U	PU
Plutonium 239/240	PU-239/240	0	0.030	0.12	1.0	U	PU
Americium 241	14596-10-2	0.070	0.14	0.18	1.0	U	AM
Iodine 129	15046-84-1	-0.130	0.29	0.66	2.0	U	I
Potassium 40	13966-00-2	U		0.23		U	GAM
Cobalt 60	10198-40-0	U		0.026	0.050	U	GAM
Cesium 137	10045-97-3	U		0.023	0.10	U	GAM
Radium 226	13982-63-3	U		0.041	0.10	U	GAM
Radium 228	15262-20-1	U		0.086	0.20	U	GAM
Europium 152	14683-23-9	U		0.057	0.10	U	GAM
Europium 154	15585-10-1	U		0.068	0.10	U	GAM
Europium 155	14391-16-3	U		0.034	0.10	U	GAM
Thorium 228	14274-82-9	U		0.026		U	GAM
Thorium 232	TH-232	U		0.086		U	GAM
Uranium 235	15117-96-1	U		0.059		U	GAM
Uranium 238	U-238	U		2.8		U	GAM
Americium 241	14596-10-2	U		0.019		U	GAM

200-MW-1 Charac. Sampling& Ana.-Soil

QC-BLANK 51384

**METHOD BLANKS**

Page 1

**SUMMARY DATA SECTION**

Page 8

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000081

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

R412280-04

Lab Control Sample

## LAB CONTROL SAMPLE

SDG <u>7209</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract <u>No. 630</u>	
Lab sample id <u>R412280-04</u>	Client sample id <u>Lab Control Sample</u>	
Dept sample id <u>7209-004</u>	Material/Matrix <u>SOLID</u>	
	SAF No <u>F04-015</u>	

ANALYTE	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ADDED pCi/g	2σ ERR pCi/g	REC %	3σ LMTS (TOTAL)	PROTOCOL LIMITS
Tritium	17.0	0.54	0.34	400		H	17.3	0.69	98	83-117	80-120
Total Strontium	11.4	0.62	0.25	1.0		SR	11.1	0.44	103	81-119	80-120
Technetium 99	114	2.2	0.53	15		TC	120	4.8	95	84-116	80-120
Total Uranium (ug/g)	36.2	4.4	0.084	1.0		U_T	36.2	1.4	100	77-123	80-120
Uranium 233/234	19.1	1.6	0.72	1.0		U	19.3	0.77	99	84-116	80-120
Uranium 235	14.8	1.4	0.15	1.0		U	15.7	0.63	94	84-116	80-120
Uranium 238	20.5	1.7	0.69	1.0		U	21.0	0.84	98	85-115	80-120
Plutonium 238	24.5	1.8	0.11	1.0		PU	26.4	1.1	93	86-114	80-120
Plutonium 239/240	28.4	2.0	0.11	1.0		PU	29.0	1.2	98	86-114	80-120
Americium 241	23.7	3.1	0.39	1.0		AM	22.4	0.90	106	77-123	80-120
Iodine 129	124	2.4	<u>3.5</u>	2.0		I	127	5.1	98	84-116	80-120
Cobalt 60	1.22	0.049	0.024	0.050		GAM	1.17	0.047	104	75-125	80-120
Cesium 137	1.23	0.043	0.031	0.10		GAM	1.18	0.047	104	75-125	80-120

200-MW-1 Charac. Sampling& Ana.-Soil

QC-LCS 51383

LAB CONTROL SAMPLES

Page 1

SUMMARY DATA SECTION

Page 9

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LCS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000082

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

R412280-06

B19962

## DUPLICATE

SDG <u>7209</u>		Client/Case no <u>Hanford</u> <u>SDG H2905</u>	
Contact <u>Melissa C. Mannion</u>		Contract <u>No. 630</u>	
DUPLICATE		ORIGINAL	
Lab sample id <u>R412280-06</u>	Lab sample id <u>R412280-01</u>	Client sample id <u>B19962</u>	
Dept sample id <u>7209-006</u>	Dept sample id <u>7209-001</u>	Location/Matrix <u>216-U-3; 22.5ft-25ft</u> <u>SOLID</u>	
	Received <u>12/23/04</u>	Collected/Weight <u>12/13/04 07:50</u> <u>82.7 g</u>	
% solids <u>94.3</u>	% solids <u>94.3</u>	Custody/SAF No <u>F04-015-120</u> <u>F04-015</u>	

ANALYTE	DUPLICATE pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ORIGINAL pCi/g	2σ ERR (COUNT)	MDA pCi/g	QUALI- FIERS	RPD %	3σ TOT	PROT LIMIT
Tritium	0.830	0.22	0.33	400		H	0.955	0.23	0.33		14	58	
Technetium 99	0.028	0.18	0.56	15	U	TC	0.115	0.17	0.52	U	-		
Iodine 129	0.150	0.42	0.94	2.0	U	I	-0.258	0.62	1.4	U	-		

200-MW-1 Charac. Sampling& Ana.-Soil

QC-DUP#1 51385

DUPLICATES

Page 1

SUMMARY DATA SECTION

Page 10

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DUP</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000083

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

R412280-07

B19PT5

## DUPLICATE

SDG <u>7209</u>		Client/Case no <u>Hanford</u>		SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>		Contract No. <u>630</u>		
<b>DUPLICATE</b>		<b>ORIGINAL</b>		
Lab sample id <u>R412280-07</u>	Lab sample id <u>R412280-03</u>	Client sample id <u>B19PT5</u>		
Dept sample id <u>7209-007</u>	Dept sample id <u>7209-003</u>	Location/Matrix <u>216-U-3; 22.5ft-25ft</u> <b>SOLID</b>		
	Received <u>12/23/04</u>	Collected/Weight <u>12/13/04 07:50</u> <u>681.6 g</u>		
% solids <u>95.7</u>	% solids <u>95.7</u>	Custody/SAF No <u>F04-015-118</u> <u>F04-015</u>		

ANALYTE	DUPLICATE pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ORIGINAL pCi/g	2σ ERR (COUNT)	MDA pCi/g	QUALI- FIERS	RPD %	3σ PROT TOT LIMIT
Total Strontium	-0.053	0.11	0.24	1.0	U	SR	0.017	0.12	0.24	U	-	
Total Uranium (ug/g)	1.41	0.17	0.008	1.0		U_T	1.47	0.17	0.008		4	31
Uranium 233/234	0.632	0.23	0.15	1.0		U	0.592	0.21	0.16		7	77
Uranium 235	0.093	0.093	0.18	1.0	U	U	0.025	0.049	0.19	U	-	
Uranium 238	0.536	0.19	0.15	1.0		U	0.551	0.21	0.16		3	79
Plutonium 238	-0.018	0.036	0.14	1.0	U	PU	0	0.070	0.27	U	-	
Plutonium 239/240	0.036	0.036	0.14	1.0	U	PU	0.035	0.070	0.27	U	-	
Americium 241	0.047	0.070	0.090	1.0	U	AM	0	0.054	0.21	U	-	
Potassium 40	10.6	0.46	0.24			GAM	10.4	0.54	0.25		2	33
Cobalt 60	U		0.022	0.050	U	GAM	U		0.027	U	-	
Cesium 137	U		0.021	0.10	U	GAM	U		0.026	U	-	
Radium 226	0.435	0.038	0.038	0.10		GAM	0.430	0.054	0.053		1	39
Radium 228	0.650	0.096	0.093	0.20		GAM	0.634	0.10	0.098		2	45
Europium 152	U		0.055	0.10	U	GAM	U		0.068	U	-	
Europium 154	U		0.070	0.10	U	GAM	U		0.083	U	-	
Europium 155	U		0.061	0.10	U	GAM	U		0.075	U	-	
Thorium 228	0.541	0.027	0.025			GAM	0.553	0.032	0.030		2	34
Thorium 232	0.650	0.096	0.093			GAM	0.634	0.10	0.098		2	45
Uranium 235	U		0.084		U	GAM	U		0.10	U	-	
Uranium 238	U		2.6		U	GAM	U		3.3	U	-	
Americium 241	U		0.099		U	GAM	U		0.12	U	-	

200-MW-1 Charac. Sampling& Ana.-Soil

QC-DUP#3 51386

DUPLICATES

Page 2

SUMMARY DATA SECTION

Page 11

Lab id EBRLNE  
 Protocol Hanford  
 Version Ver 1.0  
 Form DVD-DUP  
 Version 3.06  
 Report date 02/21/05

00000084

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

R412280-08

B19962

## MATRIX SPIKE

SDG <u>7209</u>		Client/Case no <u>Hanford</u> SDG <u>H2905</u>	
Contact <u>Melissa C. Mannion</u>		Contract No. <u>630</u>	
MATRIX SPIKE		ORIGINAL	
Lab sample id <u>R412280-08</u>	Lab sample id <u>R412280-01</u>	Client sample id <u>B19962</u>	
Dept sample id <u>7209-008</u>	Dept sample id <u>7209-001</u>	Location/Matrix <u>216-U-3; 22.5ft-25ft</u> <u>SOLID</u>	
	Received <u>12/23/04</u>	Collected/Weight <u>12/13/04 07:50</u> <u>82.7 g</u>	
% solids <u>94.3</u>	% solids <u>94.3</u>	Custody/SAF No <u>F04-015-120</u> <u>F04-015</u>	

ANALYTE	SPIKE pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ADDED pCi/g	2σ ERR pCi/g	ORIGINAL pCi/g	2σ ERR (COUNT)	REC 3σ % (TOTAL)	LMTS (TOTAL)	PROTOCOL LIMITS
Tritium	86.0	1.2	0.34	400	X	H	88.7	3.5	0.955	0.23	96	84-116	60-140

200-MW-1 Charac. Sampling& Ana.-Soil

QC-MS#1 51387

MATRIX SPIKES

Page 1

SUMMARY DATA SECTION

Page 12

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-MS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000085

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

R412280-01

B19962

## DATA SHEET

SDG <u>7209</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412280-01</u>	Client sample id <u>B19962</u>	
Dept sample id <u>7209-001</u>	Location/Matrix <u>216-U-3; 22.5ft-25ft</u>	<u>SOLID</u>
Received <u>12/23/04</u>	Collected/Weight <u>12/13/04 07:50</u>	<u>82.7 g</u>
% solids <u>94.3</u>	Custody/SAF No <u>F04-015-120</u>	<u>F04-015</u>

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	0.955	0.23	0.33	400		H
Technetium 99	14133-76-7	0.115	0.17	0.52	15	U	TC
Iodine 129	15046-84-1	-0.258	0.62	1.4	2.0	U	I

200-MW-1 Charac. Sampling& Ana.-Soil

DATA SHEETS

Page 1

SUMMARY DATA SECTION

Page 13

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>

00000086

## EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

R412280-02

B19966

## DATA SHEET

SDG <u>7209</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R412280-02</u>	Client sample id <u>B19966</u>	
Dept sample id <u>7209-002</u>	Location/Matrix <u>216-U-3; 1275ft-129.5ft</u>	<u>SOLID</u>
Received <u>12/23/04</u>	Collected/Weight <u>12/20/04 07:40</u>	<u>70.5 g</u>
% solids <u>91.8</u>	Custody/SAF No <u>F04-015-070</u>	<u>F04-015</u>

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	0.142	0.16	0.26	400	U	H
Technetium 99	14133-76-7	0.090	0.23	0.55	15	U	TC
Iodine 129	15046-84-1	-0.099	0.48	1.1	2.0	U	I

200-MW-1 Charac. Sampling&amp; Ana.-Soil

DATA SHEETS

Page 2

SUMMARY DATA SECTION

Page 14

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>02/21/05</u>
<u>00000087</u>



**EBERLINE SERVICES / RICHMOND**  
**SAMPLE DELIVERY GROUP H2905**

R412280-03

B19PT5

**DATA SHEET**

SDG <u>7209</u>	Client/Case no <u>Hanford</u>	SDG <u>H2905</u>
Contact <u>Melissa C. Mannion</u>	Contract <u>No. 630</u>	
Lab sample id <u>R412280-03</u>	Client sample id <u>B19PT5</u>	
Dept sample id <u>7209-003</u>	Location/Matrix <u>216-U-3; 22.5ft-25ft</u>	<u>SOLID</u>
Received <u>12/23/04</u>	Collected/Weight <u>12/13/04 07:50</u>	<u>681.6 g</u>
% solids <u>95.7</u>	Custody/SAF No <u>F04-015-118</u>	<u>F04-015</u>

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Total Strontium	SR-RAD	0.017	0.12	0.24	1.0	U	SR
Total Uranium (ug/g)	7440-61-1	1.47	0.17	0.008	1.0		U_T
Uranium 233/234	U-233/234	0.592	0.21	0.16	1.0		U
Uranium 235	15117-96-1	0.025	0.049	0.19	1.0	U	U
Uranium 238	U-238	0.551	0.21	0.16	1.0		U
Plutonium 238	13981-16-3	0	0.070	0.27	1.0	U	PU
Plutonium 239/240	PU-239/240	0.035	0.070	0.27	1.0	U	PU
Americium 241	14596-10-2	0	0.054	0.21	1.0	U	AM
Potassium 40	13966-00-2	10.4	0.54	0.25			GAM
Cobalt 60	10198-40-0	U		0.027	0.050	U	GAM
Cesium 137	10045-97-3	U		0.026	0.10	U	GAM
Radium 226	13982-63-3	0.430	0.054	0.053	0.10		GAM
Radium 228	15262-20-1	0.634	0.10	0.098	0.20		GAM
Europium 152	14683-23-9	U		0.068	0.10	U	GAM
Europium 154	15585-10-1	U		0.083	0.10	U	GAM
Europium 155	14391-16-3	U		0.075	0.10	U	GAM
Thorium 228	14274-82-9	0.553	0.032	0.030			GAM
Thorium 232	TH-232	0.634	0.10	0.098			GAM
Uranium 235	15117-96-1	U		0.10		U	GAM
Uranium 238	U-238	U		3.3		U	GAM
Americium 241	14596-10-2	U		0.12		U	GAM

200-MW-1 Charac. Sampling& Ana.-Soil

00000088

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test AM Matrix SOLID

SDG 7209

Contact Melissa C. Mannion

## METHOD SUMMARY

AMERICIUM 241 IN SOLIDS

ALPHA SPECTROSCOPY

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW SUP- TEST FIX	PLANCHET	Americium 241
------------------	------------------	----------------------	----------	------------------

Preparation batch 7113-102

19PTS	R412280-03	7209-003	U
LK (QC ID=51384)	R412280-05	7209-005	U
CS (QC ID=51383)	R412280-04	7209-004	ok
Duplicate (R412280-03)	R412280-07	7209-007	- U

Minimal values and limits from method RDLs (pCi/g) 1.0

00-MW-1 Charac. Sampling & Ana.-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW SUP- TEST FIX	MDA pCi/g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT keV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
------------------	------------------	----------------------	--------------	-----------	-------------	---------------	------------	----------	--------------	-------------	--------------	--------------	-------------------	------	----------

Preparation batch 7113-102 2σ prep error 5.0 % Reference Lab Notebook 7113 pg. 102

19PTS	R412280-03	0.21	0.500	74	133	47	01/29/05	01/29	SS-036
LK (QC ID=51384)	R412280-05	0.18	0.500	42	268	01/29/05	01/31	SS-061	
CS (QC ID=51383)	R412280-04	0.39	0.500	40	133	01/29/05	01/29	SS-042	
Duplicate (R412280-03)	R412280-07	0.090	0.500	84	269	49	01/29/05	01/31	SS-062
(QC ID=51386)									

Minimal values and limits from method 1.0 0.500 20-105 100 100 180

PROCEDURES	REFERENCE	AMCMISO_IE_PLATE_AEA
CP-060	Soil Preparation, rev 7	
CP-071	Soil Dissolution, > 1.0g Aliquot, rev 5	
CP-963	Americium and Curium in Water and Dissolved Samples by Extraction Chromatography, rev 6	
CP-008	Heavy Element Electroplating, rev 9	

AVERAGES ± 2 SD	MDA	0.22 ± 0.25
FOR 4 SAMPLES	YIELD	60 ± 45

## METHOD SUMMARIES

Page 1

## SUMMARY DATA SECTION

Page 16

Lab id	<u>EBERLINE</u>
Protocol	<u>Hanford</u>
Version	<u>Ver 1.0</u>
Form	<u>DVD-CMS</u>
Version	<u>3.06</u>
Report date	<u>02/21/05</u>

000000089

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test PU Matrix SOLID

SDG 7209

Contact Melissa C. Mannion

## METHOD SUMMARY

PLUTONIUM, ISOTOPIC IN SOLIDS

ALPHA SPECTROSCOPY

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST	SUF- FIX	Plutonium 238	Plutonium 239/240
------------------	---------------	----------	----------	---------------	-------------------

Preparation batch 7113-102

19PT5	R412280-03	7209-003	U	U
LK (QC ID=51384)	R412280-05	7209-005	U	U
TS (QC ID=51383)	R412280-04	7209-004	ok	ok
uplicate (R412280-03)	R412280-07	7209-007	- U	- U

ominal values and limits from method RDLs (pCi/g) 1.0 1.0  
00-MM-1 Charac. Sampling& Ana.-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST	SUF- FIX	MAX MDA pCi/g	ALIQ g	PREP FAC	DILU- TION	YIELD %	BFF %	COUNT min	FWHM keV	DRIFT keV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
------------------	---------------	----------	----------	---------------	--------	----------	------------	---------	-------	-----------	----------	-----------	-----------	----------------	------	----------

Preparation batch 7113-102 2σ prep error 5.0 % Reference Lab Notebook 7113 pg. 102

19PT5	R412280-03	0.27	0.500	76	102	51	01/31/05	02/02	SS-058
LK (QC ID=51384)	R412280-05	0.12	0.500	74	226		01/31/05	02/02	SS-060
TS (QC ID=51383)	R412280-04	0.11	0.500	82	226		01/31/05	02/02	SS-059
uplicate (R412280-03)	R412280-07	0.14	0.500	64	226	51	01/31/05	02/02	SS-061

ominal values and limits from method 1.0 0.500 20-105 100 100 180

PROCEDURES	REFERENCE	PUISO_PLATE_AEA
CP-060	Soil Preparation, rev 7	
CP-071	Soil Dissolution, > 1.0g Aliquot, rev 5	
CP-941	Plutonium in Water and Dissolved Samples by Extraction Chromatography, rev 3	
CP-008	Heavy Element Electroplating, rev 9	

AVERAGES ± 2 SD	MDA 0.16 ± 0.15
FOR 4 SAMPLES	YIELD 74 ± 15

## METHOD SUMMARIES

Page 2

## SUMMARY DATA SECTION

Page 17

Lab id EBRINE

Protocol Hanford

Version Ver 1.0

Form DVD-CMS

Version 3.06

Report date 02/21/05

00000090

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

## METHOD SUMMARY

URANIUM, ISOTOPIC IN SOLIDS

ALPHA SPECTROSCOPY

Test U Matrix SOLID

SDG 7209

Contact Melissa C. Mannion

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW SUP- TEST FIX PLANCHET	1: Uranium 233/234	2: Uranium 235	3: Uranium 238	RESULT RATIOS (%)			
						1+3	2σ	2+3	2σ
Preparation batch 7113-102									
19PT5	R412280-03	7209-003	0.592	U	0.551	107	56	5	9
LK (QC ID=51384)	R412280-05	7209-005	U	U	U				
CS (QC ID=51383)	R412280-04	7209-004	ok	ok	ok				
uplicate (R412280-03)	R412280-07	7209-007	ok	- U	ok	118	60	17	18
Minimal values and limits from method									
		RDLs (pCi/g)	1.0	1.0	1.0	100		4	
00-MW-1 Charac. Sampling& Ana.-Soil						Averages 113		11	

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW SUP- TEST FIX	MAX MDA pCi/g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- PREPARED	ANAL- YZED	DETECTOR
Preparation batch 7113-102 2σ prep error 5.0 % Reference Lab Notebook 7113 pg. 102															
19PT5	R412280-03		0.19	0.500			58	223				33	01/14/05	01/15	SS-055
LK (QC ID=51384)	R412280-05		0.24	0.500			47	223					01/14/05	01/15	SS-057
CS (QC ID=51383)	R412280-04		0.72	0.500			74	223					01/14/05	01/15	SS-056
uplicate (R412280-03)	R412280-07		0.18	0.500			64	223				33	01/14/05	01/15	SS-058
(QC ID=51386)															
Minimal values and limits from method															
			1.0	0.500			20-105	100	100		180				

PROCEDURES	REFERENCE	UIISO_PLATE_AEA
CP-060		Soil Preparation, rev 7
CP-071		Soil Dissolution, > 1.0g Aliquot, rev 5
CP-921		Uranium in Water and Dissolved Samples by Extraction Chromatography, rev 1
CP-008		Heavy Element Electroplating, rev 9

AVERAGES ± 2 SD	MDA 0.33 ± 0.52
FOR 4 SAMPLES	YIELD 61 ± 23

## METHOD SUMMARIES

Page 3

## SUMMARY DATA SECTION

Page 18

Lab id EBERLINE
Protocol Hanford
Version Ver 1.0
Form DVD-CMS
Version 3.06
Report date 02/21/05

00000091

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test SR Matrix SOLID

SDG 7209

Contact Melissa C. Mannion

## METHOD SUMMARY

TOTAL STRONTIUM IN SOLIDS

BETA COUNTING

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Total Strontium
------------------	---------------	--------------	---------------	-----------------

Preparation batch 7113-102

19PTS	R412280-03	7209-003	U
LK (QC ID=51384)	R412280-05	7209-005	U
CS (QC ID=51383)	R412280-04	7209-004	ok
uplicate (R412280-03)	R412280-07	7209-007	- U

Minimal values and limits from method RDLs (pCi/g) 1.0  
00-MW-1 Charac. Sampling& Ana.-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT keV	DAYS HELD	PREPARED	ANAL- YZED	DETECTOR
------------------	---------------	--------------	------------	-------	--------	----------	------------	---------	-------	-----------	----------	-----------	-----------	----------	------------	----------

Preparation batch 7113-102 2σ prep error 10.0 % Reference Lab Notebook 7113 pg. 102

19PTS	R412280-03	0.24	1.00	89	100	32	01/14/05	01/14	GRB-232
LK (QC ID=51384)	R412280-05	0.25	1.00	81	100	01/14/05	01/14	GRB-203	
CS (QC ID=51383)	R412280-04	0.25	1.00	81	92	01/14/05	01/14	GRB-220	
uplicate (R412280-03)	R412280-07	0.24	1.00	90	100	32	01/14/05	01/14	GRB-204
(QC ID=51386)									

Minimal values and limits from method 1.0 1.00 30-105 100 180

PROCEDURES	REFERENCE	SRTOT_SEP_PRECIP_GPC
CP-060	Soil Preparation, rev 7	
CP-071	Soil Dissolution, > 1.0g Aliquot, rev 5	
CP-380	Strontium in Water Samples, rev 2	

AVERAGES ± 2 SD	MDA 0.24 ± 0.012
FOR 4 SAMPLES	YIELD 85 ± 10

METHOD SUMMARIES

Page 4

SUMMARY DATA SECTION

Page 19

Lab id EBRLINE

Protocol Hanford

Version Ver 1.0

Form DVD-CMS

Version 3.06

Report date 02/21/05

00000092

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test TC Matrix SOLID

SDG 7209

Contact Melissa C. Mannion

## METHOD SUMMARY

TECHNETIUM 99 IN SOLIDS

BETA COUNTING

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Technetium 99
------------------	------------------	-----------------	------------------	------------------

Preparation batch 7113-102

9962	R412280-01		7209-001	U
9966	R412280-02		7209-002	U
AK (QC ID=51384)	R412280-05		7209-005	U
AS (QC ID=51383)	R412280-04		7209-004	ok
uplicate (R412280-01)	R412280-06		7209-006	- U

Minimal values and limits from method RDLs (pCi/g) 15

10-MW-1 Charac. Sampling & Ana.-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
------------------	------------------	-----------------	---------------	----------	-----------	-------------	---------------	------------	----------	--------------	-------------	--------------	--------------	-------------------	------	----------

Preparation batch 7113-102 2σ prep error 10.0 % Reference Lab Notebook 7113 pg. 102

9962	R412280-01		0.52	1.00			100	50		66	02/11/05	02/17	GRB-230
9966	R412280-02		0.55	1.00			98	50		56	02/11/05	02/14	GRB-204
AK (QC ID=51384)	R412280-05		0.50	1.00			100	50			02/11/05	02/14	GRB-222
AS (QC ID=51383)	R412280-04		0.53	1.00			97	50			02/11/05	02/17	GRB-218
uplicate (R412280-01)	R412280-06		0.56	1.00			94	50		64	02/11/05	02/15	GRB-227
(QC ID=51385)													

Minimal values and limits from method 15 1.00 20-105 50 180

PROCEDURES	REFERENCE	TC99_TR_SEP_LSC
CP-431		Technetium-99 Purification of Soil or Resin by Extraction Chromatography, rev 2
CP-008		Heavy Element Electroplating, rev 9

AVERAGES ± 2 SD	MDA	0.53 ± 0.048
FOR 5 SAMPLES	YIELD	98 ± 5

## METHOD SUMMARIES

Page 5

## SUMMARY DATA SECTION

Page 20

Lab id	EBRLNE
Protocol	Hanford
Version	Ver 1.0
Form	DVD-CMS
Version	3.06
Report date	02/21/05

00000093

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

## METHOD SUMMARY

GAMMA SCAN

GAMMA SPECTROSCOPY

Test GAM Matrix SOLID

SDG 7209

Contact Melissa C. Mannion

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Cobalt 60	Cesium 137
reparation batch 7113-102					
19PT5	R412280-03	7209-003		U	U
LK (QC ID=51384)	R412280-05	7209-005		U	U
CS (QC ID=51383)	R412280-04	7209-004		ok	ok
uplicate (R412280-03)	R412280-07	7209-007		- U	- U

ominal values and limits from method RDLs (pCi/g) 0.050 0.10  
00-MW-1 Charac. Sampling& Ana.-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA g	ALIQ FAC	PREP TION	DILU- %	YIELD %	EFF min	COUNT keV	FWHM keV	DRIFT HELD	DAYS PREPARED	ANAL- YZED	DETECTOR
reparation batch 7113-102 2σ prep error 15.0 % Reference Lab Notebook 7113 pg. 102															
19PT5	R412280-03		0.24	228						735		59	01/05/05	02/10	JR,05,00
LK (QC ID=51384)	R412280-05		0.19	228						966			01/05/05	01/12	JR,07,00
CS (QC ID=51383)	R412280-04		0.024	228						848			01/05/05	02/11	JR,05,00
uplicate (R412280-03)	R412280-07		0.19	228						1131		61	01/05/05	02/12	JR,05,00
(QC ID=51386)															

ominal values and limits from method 0.050 228 100 180

PROCEDURES REFERENCE GAMMA\_GS  
CP-060 Soil Preparation, rev 7  
CP-100 Ge(Li) Preparation for Commercial Samples, rev 7

AVERAGES ± 2 SD MDA 0.16 ± 0.19  
FOR 4 SAMPLES YIELD ±

## METHOD SUMMARIES

Page 6

## SUMMARY DATA SECTION

Page 21

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-CMS

Version 3.06

Report date 02/21/05

00000094

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test I Matrix SOLID  
SDG 7209  
Contact Melissa C. Mannion

## METHOD SUMMARY

IODINE 129 IN SOLIDS  
GAMMA SPECTROSCOPY

Client Hanford  
Contract No. 530  
Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Iodine 129
reparation batch 7113-102				
19962	R412280-01	7209-001		U
19966	R412280-02	7209-002		U
LK (QC ID=51384)	R412280-05	7209-005		U
CS (QC ID=51383)	R412280-04	7209-004		ok
uplicate (R412280-01)	R412280-06	7209-006		- U

ominal values and limits from method RDLs (pCi/g) 2.0  
00-MW-1 Charac. Sampling& Ana.-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
reparation batch 7113-102 2σ prep error 10.0 % Reference Lab Notebook 7113 pg. 102																
19962	R412280-01		1.4	1.00				57		790			64	02/12/05	02/15	XSPEC-004
19966	R412280-02		1.1	1.01				64		791			57	02/12/05	02/15	XSPEC-002
LK (QC ID=51384)	R412280-05		0.66	1.00				96		1110				02/12/05	02/17	XSPEC-002
CS (QC ID=51383)	R412280-04		3.5	1.00				99		302				02/12/05	02/18	XSPEC-002
uplicate (R412280-01) (QC ID=51385)	R412280-06		0.94	1.00				57		1111			66	02/12/05	02/17	XSPEC-004

ominal values and limits from method 2.0 1.00 20-105 300 180

PROCEDURES REFERENCE I129\_SEP\_LEPS\_GS  
CP-024 Iodine-129, Sample Dissolution, rev 5  
CP-530 Iodine-129 Purification, rev 1

AVERAGES ± 2 SD MDA 1.5 ± 2.3  
FOR 5 SAMPLES YIELD 75 ± 42

## METHOD SUMMARIES

Page 7

## SUMMARY DATA SECTION

Page 22

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-CMS  
Version 3.06  
Report date 02/21/05

00000095



# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test U T Matrix SOLID

SDG 7209

Contact Melissa C. Mannion

## METHOD SUMMARY

URANIUM, TOTAL IN SOLIDS

KINETIC PHOSPHORIMETRY (KPA)

Client Hanford

Contract No. 630

Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Total Uranium
reparation batch 7113-102				
19PT5	R412280-03		7209-003	1.47
LK (QC ID=51384)	R412280-05		7209-005	U
CS (QC ID=51383)	R412280-04		7209-004	ok
uplicate (R412280-03)	R412280-07		7209-007	ok

ominal values and limits from method RDLs (ug/g) 1.0  
00-MW-1 Charac. Sampling& Ana.-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	MDA ug/g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT keV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
reparation batch 7113-102 2σ prep error 9.0 % Reference Lab Notebook 7113 pg. 102																
19PT5	R412280-03			0.008	0.0500								60	02/11/05	02/11	KPA-001
LK (QC ID=51384)	R412280-05			0.008	0.0500									02/11/05	02/11	KPA-001
CS (QC ID=51383)	R412280-04			0.084	0.0500									02/11/05	02/11	KPA-001
uplicate (R412280-03)	R412280-07			0.008	0.0500								60	02/11/05	02/11	KPA-001
(QC ID=51386)																

ominal values and limits from method 1.0 0.0500 180

PROCEDURES	REFERENCE	UTOT_KPA
CP-062		Sample Aliquoting, rev 2
CP-071		Soil Dissolution, > 1.0g Aliquot, rev 5
CP-928		Total Uranium by Kinetic Phosphorimetry, rev 8
CP-929		Calibration of the Kinetic Phosphorimeter, rev 9

AVERAGES ± 2 SD MDA 0.027 ± 0.076  
FOR 4 SAMPLES YIELD \_\_\_\_\_ ± \_\_\_\_\_

## METHOD SUMMARIES

Page 8

## SUMMARY DATA SECTION

Page 23

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-CMS  
Version 3.06  
Report date 02/21/05

00000096

# EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H2905

Test H Matrix SOLID  
SDG 7209  
Contact Melissa C. Mannion

## METHOD SUMMARY

TRITIUM IN SOLIDS

LIQUID SCINTILLATION COUNTING

Client Hanford  
Contract No. 630  
Contract SDG H2905

## RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Tritium
reparation batch 7113-102				
19962	R412280-01		7209-001	0.955
19966	R412280-02		7209-002	U
LK (QC ID=51384)	R412280-05		7209-005	U
CS (QC ID=51383)	R412280-04		7209-004	ok
uplicate (R412280-01)	R412280-06		7209-006	ok
pike (R412280-01)	R412280-08		7209-008	ok X

ominal values and limits from method RDLs (pCi/g) 400  
00-MW-1 Charac. Sampling& Ana.-Soil

## METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT keV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
reparation batch 7113-102 2σ prep error 10.0 % Reference Lab Notebook 7113 pg. 102																
19962	R412280-01		0.33	15.1				34		120		57	02/08/05	02/08		LSC-005
19966	R412280-02		0.26	20.4				33		120		50	02/08/05	02/08		LSC-005
LK (QC ID=51384)	R412280-05		0.33	15.0				33		120			02/08/05	02/08		LSC-005
CS (QC ID=51383)	R412280-04		0.34	15.0				33		120			02/08/05	02/08		LSC-005
uplicate (R412280-01)	R412280-06		0.33	15.1				34		120		57	02/08/05	02/08		LSC-005
(QC ID=51385)																
pike (R412280-01)	R412280-08		0.34	15.1				33		120		57	02/08/05	02/08		LSC-005
(QC ID=51387)																

ominal values and limits from method 400 15.0 25 180

PROCEDURES REFERENCE 906.0\_H3\_LSC  
CP-218 Tritium in Soil Samples by Azeotropic  
Distillation, rev 3

AVERAGES ± 2 SD MDA 0.32 ± 0.061  
FOR 6 SAMPLES YIELD 33 ± 1

## METHOD SUMMARIES

Page 9

## SUMMARY DATA SECTION

Page 24

Lab id EBRINE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-CMS  
Version 3.06  
Report date 02/21/05

00000097

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

## SAMPLE SUMMARY

The Sample and QC Summary Reports show all samples, including QC samples, reported in one Sample Delivery Group (SDG).

The Sample Summary Report fully identifies client samples and gives the corresponding lab sample identification. The QC Summary Report shows at the sample level how the lab organized the samples into batches and generated QC samples. The Preparation Batch and Method Summary Reports show this at the analysis level.

The following notes apply to these reports:

- \* LAB SAMPLE ID is the lab's primary identification for a sample.
- \* DEPARTMENT SAMPLE ID is an alternate lab id, for example one assigned by a radiochemistry department in a lab.
- \* CLIENT SAMPLE ID is the client's primary identification for a sample. It includes any sample preparation done by the client that is necessary to identify the sample.
- \* QC BATCH is a lab assigned code that groups samples to be processed and QCed together. These samples should have similar matrices.

QC BATCH is not necessarily the same as SDG, which reflects samples received and reported together.

- \* All Lab Control Samples, Method Blanks, Duplicates and Matrix Spikes are shown that QC any of the samples. Due to possible reanalyses, not all results for all these QC samples may be relevant to the SDG. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.

### REPORT GUIDES

Page 1

### SUMMARY DATA SECTION

Page 25

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000098

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

### PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches in one Sample Delivery Group (SDG) with information necessary to check the completeness and consistency of the SDG.

The following notes apply to this report:

- \* The preparation batches are shown in the same order as the Method Summary Reports are printed.
- \* Only analyses of planchets relevant to the SDG are included.
- \* Each preparation batch should have at least one Method Blank and LCS in it to validate client sample results.
- \* The QUALIFIERS shown are all qualifiers other than U, J, B, L and H that occur on any analysis in the preparation batch. The Method Summary Report has these qualifiers on a per sample basis.

These qualifiers should be reviewed as follows:

- X Some data has been manually entered or modified. Transcription errors are possible.
- P One or more results are 'preliminary'. The data is not ready for final reporting.
- 2 There were two or more results for one analyte on one planchet imported at one time. The results in DVD may not be the same as on the raw data sheets.

Other lab defined qualifiers may occur. In general, these should be addressed in the SDG narrative.

#### REPORT GUIDES

Page 2

#### SUMMARY DATA SECTION

Page 26

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000099

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

## WORK SUMMARY

The Work Summary Report shows all samples, including QC samples, and all relevant analyses in one Sample Delivery Group (SDG). This report is often useful as supporting documentation for an invoice.

The following notes apply to this report:

- \* TEST is a code for the method used to measure associated analytes. Results and related information for each analyte are on the Data Sheet Report. In special cases, a test code used in the summary data section is not the same as in associated raw data. In this case, both codes are shown on the Work Summary.
- \* SUFFIX is the lab's code to distinguish multiple analyses (recounts, reworks, reanalyses) of a fraction of the sample. The suffix indicates which result is being reported. An empty suffix normally identifies the first attempt to analyze the sample.
- \* The LAB SAMPLE ID, TEST and SUFFIX uniquely identify all supporting data for a result. The Method Summary Report for each TEST has method performance data, such as yield, for each lab sample id and suffix and procedures used in the method.
- \* PLANCHET is an alternate lab identifier for work done for one test. It, combined with the TEST and SUFFIX, may be the best link to raw data.
- \* For QC samples, only analyses that directly QC some regular sample are shown. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.
- \* The SAS (Special Analytical Services) Number is a client or lab assigned code that reflects special processing for samples, such as rapid turn around. Counts of tests done are lists by SAS number since it is likely to affect prices.

### REPORT GUIDES

Page 3

### SUMMARY DATA SECTION

Page 27

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000100

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

## DATA SHEET

The Data Sheet Report shows all results and primary supporting information for one client sample or Method Blank. This report corresponds to both the CLP Inorganics and Organics Data Sheet.

The following notes apply to this report:

- \* TEST is a code for the method used to measure an analyte. If the TEST is empty, no data is available; the analyte was not analyzed for.
- \* The LAB SAMPLE ID and TEST uniquely identify work within the Summary Data Section of a Data Package. The Work Summary and Method Summary Reports further identify raw data that underlies this work.

The Method Summary Report for each TEST has method performance data, such as yield, for each Lab Sample ID and a list of procedures used in the method.

- \* ERRORS can be labeled TOTAL or COUNT. TOTAL implies a preparation (non-counting method) error has been added, as square root of sum of squares, to the counting error denoted by COUNT. The preparation errors, which may vary by preparation batch, are shown on the Method Summary Report.
- \* A RESULT can be 'N.R.' (Not Reported). This means the lab did this work but chooses not to report it now, possibly because it was reported at another time.
- \* When reporting a Method Blank, a RESULT can be 'N.A.' (Not Applicable). This means there is no reported client sample work in the same preparation batch as the Blank's result. This is likely to occur when the Method Blank is associated with reanalyses of selected work for a few samples in the SDG.

The following qualifiers are defined by the DVD system:

U The RESULT is less than the MDA (Minimum Detectable Activity).

### REPORT GUIDES

Page 4

### SUMMARY DATA SECTION

Page 28

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000101

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## DATA SHEET

If the MDA is blank, the ERROR is used as the limit.

- J The RESULT is less than the RDL (Required Detection Limit) and no U qualifier is assigned.
  - B A Method Blank associated with this sample had a result without a U flag and, after correcting for possibly different aliquots, that result is greater than or equal to the MDA for this sample.
- Normally, B is not assigned if U is. When method blank subtraction is shown on this report, B flags are assigned based on the unsubtracted values while U's are assigned based on the subtracted ones. Both flags can be assigned in this case..
- For each sample result, all Method Blank results in the same preparation batch are compared. The Method Summary Report documents this and other QC relationships.
- L Some Lab Control Sample that QC's this sample had a low recovery. The lab can disable assignment of this qualifier.
  - H Similar to 'L' except the recovery was high.
  - P The RESULT is 'preliminary'.
  - X Some data necessary to compute the RESULT, ERROR or MDA was manually entered or modified.
  - 2 There were two or more results available for this analyte. The reported result may not be the same as in the raw data.

Other qualifiers are lab defined. Definitions should be in the SDG narrative.

The following values are underlined to indicate possible problems:

- \* An MDA is underlined if it is bigger than its RDL.

### REPORT GUIDES

Page 5

### SUMMARY DATA SECTION

Page 29

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000102

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## DATA SHEET

- \* An ERROR is underlined if the 1.645 sigma counting error is bigger than both the MDA and the RESULT, implying that the MDA may not be a good estimate of the 'real' minimum detectable activity.
- \* A negative RESULT is underlined if it is less than the negative of its 2 sigma counting ERROR.
- \* When reporting a Method Blank, a RESULT is underlined if greater than its MDA. If the MDA is blank, the 2 sigma counting error is used in the comparison.

### REPORT GUIDES

Page 6

### SUMMARY DATA SECTION

Page 30

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

00000103



# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

### LAB CONTROL SAMPLE

The Lab Control Sample Report shows all results, recoveries and primary supporting information for one Lab Control Sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. Refer to its Report Guide for details.
- \* An amount ADDED is the lab's value for the actual amount spiked into this sample with its ERROR an estimate of the error of this amount.

An amount added is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- \* REC (Recovery) is RESULT divided by ADDED expressed as a percent.
- \* The first, computed limits for the recovery reflect:
  1. The error of RESULT, including that introduced by rounding the result prior to printing.
 

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.
  2. The error of ADDED.
  3. A lab specified, per analyte bias. The bias changes the center of the computed limits.
- \* The second limits are protocol defined upper and lower QC limits for the recovery.
- \* The recovery is underlined if it is outside either of these ranges.

#### REPORT GUIDES

Page 7

#### SUMMARY DATA SECTION

Page 31

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

0000000000  
pc/  
2-24-

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

### DUPLICATE

The Duplicate Report shows all results, differences and primary supporting information for one Duplicate and associated Original sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. This applies both to the Duplicate and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Duplicate has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- \* The RPD (Relative Percent Difference) is the absolute value of the difference of the RESULTS divided by their average expressed as a percent.

If both RESULTS are less than their MDAs, no RPD is computed and a '-' is printed.

For an analyte, if the lab did work for both samples but has data for only one, the MDA from the sample with data is used as the other's result in the RPD.

- \* The first, computed limit is the sum, as square root of sum of squares, of the errors of the results divided by the average result as a percent, hence the relative error of the difference rather than the error of the relative difference. The errors include those introduced by rounding the RESULTS prior to printing.

If this limit is labeled TOT, it includes the preparation error in the RESULTS. If labeled CNT, it does not.

This value reported for this limit is at most 999.

- \* The second limit for the RPD is the larger of:

1. A fixed percentage specified in the protocol.

#### REPORT GUIDES

Page 8

#### SUMMARY DATA SECTION

Page 32

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

000105

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## DUPLICATE

2. A protocol factor (typically 2) times the average MDA as a percent of the average result. This limit applies when the results are close to the MDAs.

- \* The RPD is underlined if it is greater than either limit.
- \* If specified by the lab, the second limit column is replaced by the Difference Error Ratio (DER), which is the absolute value of the difference of the results divided by the quadratic sum of their one sigma errors, the same errors as used in the first limit.

Except for differences due to rounding, the DER is the same as the RPD divided by the first RPD limit with the limit scaled to 1 sigma.

- \* The DER is underlined if it is greater than the sigma factor, typically 2 or 3, shown in the header for the first RPD limit.

### REPORT GUIDES

Page 9

### SUMMARY DATA SECTION

Page 33

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

000106

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

## MATRIX SPIKE

The Matrix Spike Report shows all results, recoveries and primary supporting information for one Matrix Spike and associated Original sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. This applies both to the Spiked and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Spike has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- \* An amount ADDED is the lab's value for the actual amount spiked into the Spike sample with its ERROR an estimate of the error of this amount.

An amount is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- \* REC (Recovery) is the Spike RESULT minus the Original RESULT divided by ADDED expressed as a percent.
- \* The first, computed limits for the recovery reflect:
  1. The errors of the two RESULTS, including those introduced by rounding them prior to printing.
 

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.
  2. The error of ADDED.
  3. A lab specified, per analyte bias. The bias changes the center of the computed limits.
- \* The second limits are protocol defined upper and lower QC limits

### REPORT GUIDES

Page 10

### SUMMARY DATA SECTION

Page 34

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

000107

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## MATRIX SPIKE

for the recovery.

These limits are left blank if the Original RESULT is more than a protocol defined factor (typically 4) times ADDED. This is a way of accounting for that when the spike is small compared to the amount in the original sample, the recovery is unreliable.

- \* The recovery is underlined (out of spec) if it is outside either of these ranges.

### REPORT GUIDES

Page 11

### SUMMARY DATA SECTION

Page 35

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

000108

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

## REPORT GUIDE

Client Hanford  
Contract No. 630  
Case no SDG H2905

## METHOD SUMMARY

The Method Summary Report has two tables. One shows up to five results measured using one method. The other has performance data for the method. There is one report for each TEST, as used on the Data Sheet Report.

The following notes apply to this report:

- \* Each table is subdivided into sections, one for each preparation batch. A preparation batch is a group of aliquots prepared at roughly the same time in one work area of the lab using the same method.

There should be Lab Control Sample and Method Blank results in each preparation batch since this close correspondence makes the QC meaningful. Depending on lab policy, Duplicates need not occur in each batch since they QC sample dependencies such as matrix effects.

- \* The RAW TEST column shows the test code used in the raw data to identify a particular analysis if it is different than the test code in the header of the report. This occurs in special cases due to method specific details about how the lab labels work.

The Lab Sample or Planchet ID combined with the (Raw) Test Code and Suffix uniquely identify the raw data for each analysis.

- \* If a result is less than both its MDA and RDL, it is replaced by just 'U' on this report. If it is greater than or equal to the RDL but less than the MDA, the result is shown with a 'U' flag.

The J and X flags are as on the data sheet.

- \* Non-U results for Method Blanks are underlined to indicate possible contamination of other samples in the preparation batch. The Method Blank Report has supporting data.
- \* Lab Control Sample and Matrix Spike results are shown as: ok, No data, LOW or HIGH, with the last two underlined. 'No data'

### REPORT GUIDES

Page 12

### SUMMARY DATA SECTION

Page 36

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

000109

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## METHOD SUMMARY

means no amount ADDED was specified. 'LOW' and 'HIGH' correspond to when the recovery is underlined on the Lab Control Sample or Matrix Spike Report. See these reports for supporting data.

- \* Duplicate sample results are shown as: ok, No data, or OUT, with the last two underlined. 'No data' means there was no original sample data found for this duplicate. 'OUT' corresponds to when the RPD is underlined on the Duplicate Report. See this report for supporting data.
- \* If the MDA column is labeled 'MAX MDA', there was more than one result measured by the reported method and the MDA shown is the largest MDA. If not all these results have the same RDL, the MAX MDA reflects only those results with RDL equal to the smallest one.

MDAs are underlined if greater than the printed RDL.

- \* Aliquots are underlined if less than the nominal value specified for the method.
- \* Preparation factors are underlined if greater than the nominal value specified for the method.
- \* Dilution factors are underlined if greater than the nominal value specified for the method.
- \* Residues are underlined if outside the range specified for the method. Residues are not printed if yields are.
- \* Yields, which may be gravimetric, radiometric or some type of recovery depending on the method, are underlined if outside the range specified for the method.
- \* Efficiencies are underlined if outside the range specified for the method. Efficiencies are detector and geometry dependent so this test is only approximate.

### REPORT GUIDES

Page 13

### SUMMARY DATA SECTION

Page 37

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

000110

# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## METHOD SUMMARY

- \* Count times are underlined if less than the nominal value specified for the method.
- \* Resolutions (as FWHM; Full Width at Half Max) are underlined if greater than the method specified limit.
- \* Tracer drifts are underlined if their absolute values are greater than the method specified limit. Tracer drifts are not printed if percent moistures are.
- \* Days Held are underlined if greater than the holding time specified in the protocol.
- \* Analysis dates are underlined if before their planchet's preparation date or, if a limit is specified, too far after it.

For some methods, ratios as percentages and error estimates for them are computed for pairs of results. A ratio column header like '1+3' means the ratio of the first result column and the third result column.

Ratios are not computed for Lab Control Sample, Method Blank or Matrix Spike results since their matrices are not necessarily similar to client samples'.

The error estimate for a ratio of results from one planchet reflects only counting errors since other errors should be correlated. For a ratio involving different planchets, if QC limits are computed based on total errors, the error for the ratio allows for the preparation errors for the planchets.

The ratio is underlined (out of spec) if the absolute value of its difference from the nominal value is greater than its error estimate. If no nominal value is specified, this test is not done.

For Gross Alpha or Gross Beta results, there may be a column showing the sum of other Alpha or Beta emitters. This sum includes all relevant

### REPORT GUIDES

Page 14

### SUMMARY DATA SECTION

Page 38

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

000111



# EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H2905

SDG 7209  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 630  
Case no SDG H2905

## METHOD SUMMARY

results in the DVD database, whether reported or not. Results in the sum are weighted by a particles/decay value specified by the lab for each relevant analyte. Results less than their MDA are not included. No sums are computed for Lab Control, Method Blank or Matrix Spike samples since their various planchets may not be physically related.

If a ratio of total isotopic to Gross Alpha or Beta is shown, the error for the ratio reflects both the error in the Gross result and the sum, as square root of sum of squares, of the errors in the isotopic results.

For total elemental uranium or thorium results, there may be a column showing the total weight computed from associated isotopic results. Ignoring results less than their MDAs, this is a weighted sum of the isotopic results. The weights depend on the molecular weight and half-life of each isotope so as to convert activities (decays) to weight (atoms).

If a ratio of total computed to measured elemental uranium or thorium is shown, the error for the ratio reflects the errors in all the measurements.

### REPORT GUIDES

Page 15

### SUMMARY DATA SECTION

Page 39

Lab id EBRLNE  
Protocol Hanford  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 02/21/05

000112

[illegible]

FLUOR Hanford Inc.		CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST						F04-015-070	PAGE 1	OF 1
COLLECTOR Pope/Pfister/Tyra/Wiberg		COMPANY CONTACT CS Clearlock		TELEPHONE NO. 372-9638		PROJECT COORDINATOR TRENT, SJ		PRICE CODE 8N	DATA TURNAROUND 45 Days / 45 Days	
SAMPLING LOCATION 216-U-3; 127FT-129.5FT		PROJECT DESIGNATION <i>H2923 (7209)</i> 200-MW-1 Characterization Sampling and Analysis - Soil		SAF NO. F04-015		AIR QUALITY <input type="checkbox"/>				
ICE CHEST NO. <i>GRRP-03-003</i>		FIELD LOGBOOK NO. HNF-N-386 1		COA 119144ES10		METHOD OF SHIPMENT Federal Express				
SHIPPED TO Eberline Services		OFFSITE PROPERTY NO. <i>SUPPL 14601</i>		BILL OF LADING/AIR B/L NO. <i>SUPPL 14601</i>						
MATRIX* A=Air DL=Drum Liquids DS=Drum Solids L=Liquid O=Oil S=Soil SE=Sediment T=Tissue V=Vegetation W=Water WI=Wipe X=Other	POSSIBLE SAMPLE HAZARDS/ REMARKS N/A		PRESERVATION Cool 4C	None						
			TYPE OF CONTAINER	aG	aG					
			NO. OF CONTAINER(S)	1	1					
			VOLUME	120mL	60mL					
	SPECIAL HANDLING AND/OR STORAGE Radioactive Tie To: <i>B19955 12/21/04</i>		SAMPLE ANALYSIS SEE FORM (I) IN SPECIAL INSTRUCTIONS		Iodine-129; Technetium-99; Tritium - H3;					
SAMPLE NO.	MATRIX*	SAMPLE DATE	SAMPLE TIME							
B19966	SOIL	12/20/04	0740		X					
CHAIN OF POSSESSION		SIGN/ PRINT NAMES				SPECIAL INSTRUCTIONS <i>mms812-04</i> (1)NO2/NO3 - 353.2; Oil & Grease - 413.1; Chromium Hex - 7196;				
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME							
<i>D. J. Pope</i>	<i>12/20/04 0910</i>	<i>M. D. Pope</i>	<i>12/20/04 0910</i>							
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME							
<i>M. D. Pope</i>	<i>12/21/04 0910</i>	<i>M. G. Brown</i>	<i>12/21/04 0910</i>							
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME							
<i>M. G. Brown</i>	<i>12/21/04 0910</i>	<i>L. A. Pope</i>	<i>12/21/04 0910</i>							
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME							
<i>J. D. Pope</i>	<i>12/23/04 12:00</i>	<i>J. D. Pope</i>	<i>12/23/04 12:00</i>							
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME							
LABORATORY SECTION	RECEIVED BY	TITLE								DATE/TIME
FINAL SAMPLE DISPOSITION	DISPOSAL METHOD	DISPOSED BY								DATE/TIME

[illegible]

7209



## RICHMOND, CA LABORATORY

## SAMPLE RECEIPT CHECKLIST

Client Flux Hanford City Richland State WA

Date/Time received 12/23/04 12:00 CoC No. F04-015-070, 076, 118, 120

Container I.D. No. GRPO3-003 Requested TAT (Days) 45 P.O. Received Yes [ ] No [ ]

**INSPECTION**

- Custody seals on shipping container intact? Yes [X] No [ ] N/A [ ]
- Custody seals on shipping container dated & signed? Yes [X] No [ ] N/A [ ]
- Custody seals on sample containers intact? Yes [X] No [ ] N/A [ ]
- Custody seals on sample containers dated & signed? Yes [X] No [ ] N/A [ ]
- Packing material is: Wet [ ] Dry [X]
- Number of samples in shipping container: 4 Sample Matrix Soil
- Number of containers per sample: \_\_\_\_\_ (Or see CoC \_\_\_\_\_)
- Samples are in correct container Yes [X] No [ ]
- Paperwork agrees with samples? Yes [X] No [ ]
- Samples have: Tape [ ] Hazard labels [ ] Rad labels [ ] Appropriate sample labels [X]
- Samples are: In good condition [X] Leaking [ ] Broken Container [ ] Missing [ ]
- Samples are: Preserved [ ] Not preserved [ ] pH \_\_\_\_\_ Preservative \_\_\_\_\_
- Describe any anomalies: \_\_\_\_\_

14. Was P.M. notified of any anomalies? Yes [ ] No [ ] Date \_\_\_\_\_

15. Inspected by [Signature] Date: 12/23/04 Time: 12:00

Customer Sample No.	cpm	mR/hr	wipe	Customer Sample No.	cpm	mR/hr	wipe
<u>B19972</u>			<u>(can / spec (min)) - for Shaw</u>				
<u>B19966</u>							
<u>B19962</u>			<u>for chem</u>				
<u>B19975</u>							

Ion Chamber Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

Alpha Meter Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

Beta/Gamma Meter Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

**CHEMICAL RESULTS**  
**200-MW-1 Characterization Sampling and**  
**Analysis - Soil**

**SDG NUMBER: H2905-A**

**SAF NUMBER: F04-015**

**DISTRIBUTE TO: Mary Todd**  
**Greg Thomas**

**SAVE AS: H2905 C**

**IDMS DOCUMENT TYPE: PARTIAL**

**GENERAL DESCRIPTION: F04-015, CHEM**

**LOCATION: BOREHOLE C4559, 216-U-3**



Mr. Steve Trent  
Fluor Hanford Inc.  
825 Jadwin Ave.  
Richland, WA 99352

**Subject: Contract No. 630  
Analytical Data Package**

Dear Mr. Trent:


Enclosed are the hard copy analytical reports for the batch number/fraction indicated (marked X) in the following table:

LvLI Batch #	0412L484
SDG #	H2905
SAF #	F03-025
Date Received	12-18-04
# Samples	7
Matrix	Soil
Volatiles	X
Semivolatiles	X
Pest/PCB	X
DRO/GRO/KRO	X
Herbicides	
GC Alcohol	X
Metals	X
Inorganics	X

The electronic data deliverable (EDD) will be emailed shortly. If you have any questions, please don't hesitate to contact me at (610) 280-3012.

Sincerely,  
Lionville Laboratory Incorporated

Orlette S. Johnson  
Project Manager



r:\group\pm\orlette\tnu-hanford\data\fc\_ltrs.doc

Lionville Laboratory, Inc.  
VOA ANALYTICAL DATA PACKAGE FOR  
TNUHANFORD F04-015 H2905


DATE RECEIVED: 12/18/04

LVL LOT # :0412L484

CLIENT ID	LVL #	MTX	PREP #	COLLECTION	EXTR/PREP	ANALYSIS
B19PT5	004	S	04LVG398	12/13/04	N/A	12/22/04
B19PT5	004 MS	S	04LVG398	12/13/04	N/A	12/22/04
B19PT5	004 MSD	S	04LVG398	12/13/04	N/A	12/22/04

LAB QC:

VBLKIO	MB1	S	04LVG398	N/A	N/A	12/22/04
VBLKIO	MB1 BS	S	04LVG398	N/A	N/A	12/22/04



00000002

88888881





## Case Narrative

Client: TNU HANFORD F04-015  
LVL#: 0412L484  
SDG/SAF#: H2905/F04-015

W.O.#: 11343-606-001-9999-00  
Date Received: 12-18-2004


### GC/MS VOLATILE

One (1) soil sample was collected on 12-13-2004.

The sample and its associated QC samples were analyzed according to criteria set forth in Lionville Laboratory SOPs based on SW 846 Method 8260B for TCL volatile target compounds on 12-22-2004.

The following is a summary of the QC results accompanying these sample results and a description of any problems encountered during their analyses:

1. All results presented in this report are derived from a sample that met LvLI's sample acceptance policy.
2. The sample was analyzed within required holding time.
3. Non-target compounds were detected in the sample.
4. All surrogate recoveries were within acceptance criteria.
5. All matrix spike recoveries were within acceptance criteria.
6. All blank spike recoveries were within acceptance criteria.
7. The method blank contained the common laboratory contaminant Methylene Chloride at a level less than the CRQL.
8. Internal standard area and retention time criteria were met.
9. Manual integrations are performed according to SOP QA-125 to produce quality data with the utmost integrity. All manual integrations are required to be technically valid and properly documented. Appropriate technical flags are defined in the Glossary ("Technical Flags For Manual Integration").
10. "I certify that this sample data package is in compliance with SOW requirements, both technically and for completeness, other than the conditions detailed above. Release of the data contained in this hard-copy data package has been authorized by the Laboratory Manager or a designee, as verified by the following signature."

  
Ian Daniels  
Laboratory Manager  
Lionville Laboratory Incorporated

2/1/05  
Date

son\group\data\voa\tnu-hanford\0411-484.doc

The results presented in this report relate only to the analytical testing and conditions of the samples at receipt and during storage. All pages of this report are integral parts of the analytical data. Therefore, this report should only be reproduced in its entirety of 17 pages.

00000003

## GLOSSARY

### DATA QUALIFIERS

- U** = Compound was analyzed for but not detected. The associated numerical value is the estimated sample quantitation limit which is included and corrected for dilution and percent moisture.
- J** = Indicates an estimated value. This flag is used under the following circumstances: 1) when estimating a concentration for tentatively identified compounds (TICs) where a 1:1 response is assumed; or 2) when the mass spectral data indicate the presence of a compound that meets the identification criteria but the result is less than the specified detection limit but greater than zero. For example, if the limit of detection is 10 ug/L and a concentration of 3 ug/L is calculated, it is reported as 3J.
- B** = This flag is used when the analyte is found in the associated blank as well as in the sample. It indicates possible/probable blank contamination. This flag is also used for a TIC as well as for a positively identified TCL compound.
- E** = Indicates that the compound was detected beyond the calibration range and was subsequently analyzed at a dilution.
- D** = Identifies all compounds identified in an analysis at a secondary dilution factor.
- I** = Interference.
- NQ** = Result qualitatively confirmed but not able to quantify.
- N** = Indicates presumptive evidence of a compound. This flag is only used for tentatively identified compounds (TICs), where the identification is based on a mass spectral library search. It is applied to all TIC results. For generic characterization of a TIC, such as chlorinated hydrocarbon, the N code is not used.
- X** = This flag is used for a TIC compound which is quantified relative to a response factor generated from a daily calibration standard (rather than quantified relative to the closest internal standard).
- Y** = Additional qualifiers used as required are explained in the case narrative.

## GLOSSARY

### ABBREVIATIONS



Mr. Steve Trent  
Fluor Hanford Inc.  
825 Jadwin Ave.  
Richland, WA 99352

**Subject: Contract No. 630  
Analytical Data Package**

Dear Mr. Trent:


Enclosed are the hard copy analytical reports for the batch number/fraction indicated (marked X) in the following table:

LvLI Batch #	0412L505
SDG #	H2923-05 <i>Dayes 2/23/05</i>
SAF #	F04-015
Date Received	12-23-04
# Samples	1
Matrix	Soil
Volatiles	
Semivolatiles	
Pest/PCB	
DRO/GRO/KRO	
Herbicides	
GC Alcohol	
Metals	
Inorganics	X

The electronic data deliverable (EDD) will be emailed shortly. If you have any questions, please don't hesitate to contact me at (610) 280-3012.

Sincerely,  
Lionville Laboratory Incorporated

*[Signature]*  
Oriette S. Johnson  
Project Manager



Lionville Laboratory, Inc.  
INORGANIC ANALYTICAL DATA PACKAGE FOR  
TNUHANFORD F04-015 H2923


DATE RECEIVED: 12/23/04

LVL LOT # :0412L505

CLIENT ID /ANALYSIS	LVL #	MTX	PREP #	COLLECTION	EXTR/PREP	ANALYSIS
B19966						
% SOLIDS	001	S	04L&S206	12/20/04	12/27/04	12/28/04
% SOLIDS	001 REP	S	04L&S206	12/20/04	12/27/04	12/28/04
CHROMIUM VI	001	S	04LVI048	12/20/04	12/28/04	12/28/04
CHROMIUM VI	001 REP	S	04LVI048	12/20/04	12/28/04	12/28/04
CHROMIUM VI	001 MS	S	04LVI048	12/20/04	12/28/04	12/28/04
CHROMIUM VI	001 MSD	S	04LVI048	12/20/04	12/28/04	12/28/04
NITRATE NITRITE	001	S	05LN3B04	12/20/04	01/19/05	01/19/05
NITRATE NITRITE	001 REP	S	05LN3B04	12/20/04	01/19/05	01/19/05
NITRATE NITRITE	001 MS	S	05LN3B04	12/20/04	01/19/05	01/19/05
OIL & GREASE BY GRAV	001	S	04LOG047	12/20/04	12/30/04	12/31/04
OIL AND GREASE BY GR	001 REP	S	04LOG047	12/20/04	12/30/04	12/31/04
OIL AND GREASE BY GR	001 MS	S	04LOG047	12/20/04	12/30/04	12/31/04

LAB QC:

CHROMIUM VI	MB1	S	04LVI048	N/A	12/28/04	12/28/04
CHROMIUM VI	MB1 BS	S	04LVI048	N/A	12/28/04	12/28/04
CHROMIUM VI	MB1 BSD	S	04LVI048	N/A	12/28/04	12/28/04
NITRATE NITRITE	MB1	S	05LN3B04	N/A	01/19/05	01/19/05
NITRATE NITRITE	MB1 BS	S	05LN3B04	N/A	01/19/05	01/19/05
OIL & GREASE BY GRAV	MB1	S	04LOG047	N/A	12/30/04	12/31/04
OIL AND GREASE BY GR	MB1 BS	S	04LOG047	N/A	12/30/04	12/31/04






## Analytical Report

Client: TNU-HANFORD F04-015 H2923  
LVL#: 0412L505

W.O.#: 11343-606-001-9999-00  
Date Received: 12-23-04

### INORGANIC NARRATIVE

1. This narrative covers the analyses of 1 soil sample.
2. The sample was prepared and analyzed in accordance with the methods indicated on the attached glossary.
3. Sample holding times as required by the method and/or contract were met.
4. The results presented in this report are derived from samples that met LvLI's sample acceptance policy.
5. The method blanks were within the method criteria.
6. The Laboratory Control Samples (LCS) were within the laboratory control limits.
7. The matrix spike recoveries for Chromium VI, Nitrate Nitrite and Oil and Grease were within the 75-125% control limits.
8. The replicate analyses Percent Solids and Oil and Grease were within the 20% Relative Percent Difference (RPD) control limit however replicate analyses for Chromium VI and Nitrate Nitrite were outside the control limit that may be attributed to sample inhomogeneity.
9. Results for solid samples are reported on a dry weight basis.
10. I certify that this sample data package is in compliance with SOW requirements, both technically and for completeness, other than the conditions detailed above. Release of the data contained in this hard copy package has been authorized by the Laboratory Manager or a designee, as verified by the following signature.

  
Iain Daniels  
Laboratory Manager  
Lionville Laboratory Incorporated  
njpl12-505

1/28/05  
Date

The results presented in this report relate to the analytical testing and conditions of the samples upon receipt and during storage. All pages of this report are integral parts of the analytical data. Therefore, this report should only be reproduced in its entirety of 11 pages.

02

# Lionville Laboratory Incorporated

## WET CHEMISTRY

### METHODS GLOSSARY FOR SOIL/SOLIDS SAMPLE ANALYSIS

	<u>ASTM</u>	<u>SW846</u>	<u>OTHER</u>
% Ash	___ D2216-80		
% Moisture	___ D2216-80		___ ILMO4.0 (e)
% Solids	___ <input checked="" type="checkbox"/> D2216-80		___ ILMO4.0 (e)
% Volatile Solids	___ D2216-80		
ASTM Extraction in Water	___ D3987-81/85		
BTU	___ D240-87		
CEC		___ 9081	___ c
Chromium VI		___ <input checked="" type="checkbox"/> 3060A/7196A	
Corrosivity ___ by coupon ___ by pH		___ 1110(mod) ___ 9045C	
Cyanide, Total		___ 9010B	___ ILMO4.0 (e)
Cyanide, Reactive		___ Section 7.3/9014	
Halides, Extractable Organic		___ 9020B	___ EPA 600/4/84-008
Halides, Total		___ 9020B	___ EPA 600/4/84-008
EP Toxicity		___ 1310A	
Flash Point		___ 1010	
Ignitability		___ 1010	
Oil & Grease		___ <input checked="" type="checkbox"/> 9071A (mod.)	___ <input checked="" type="checkbox"/> EPA 413.1 (mod.)
Carbon, Total Organic		___ 9060	___ Lloyd Kahn (mod)
Oxygen Bomb Prep for Anions	___ D240-87(mod)	___ 5050	
Petroleum Hydrocarbons, Total Recoverable		___ 9071	___ EPA 418.1
pH, Soil		___ 9045C	
Sulfide, Reactive		___ Section 7.3/9030B	
Sulfide		___ 9030B(mod)	
Specific Gravity	___ D1429-76C/	___ D5057-90	
Sulfur, Total		___ 9056	
Synthetic Preparation Leach		___ 1312	
Paint Filter		___ 9095A	
Other: <i>Nitrate Nitrite</i>	Method:	<i>EPA 353.2 (mod.)</i>	
Other:	Method		

## Lionville Laboratory Incorporated

# METHOD REFERENCES AND DATA QUALIFIERS

### DATA QUALIFIERS

U = Indicates that the parameter was not detected at or above the reported limit. The associated numerical value is the sample detection limit.

\* = Indicates that the original sample result is greater than 4x the spike amount added.

### ABBREVIATIONS

MB = Method or Preparation Blank.  
MS = Matrix Spike.  
MSD = Matrix Spike Duplicate.  
REP = Sample Replicate  
LC = Laboratory Control Sample.  
NC = Not calculated.

A suffix of -R, -S, or -T following these codes indicate a replicate, spike or sample duplicate analysis respectively.

### ANALYTICAL WET CHEMISTRY METHODS

1. ASTM Standard Methods.
2. USEPA Methods for Chemical Analysis of Water and Wastes (USEPA 600/4-79-020).
3. Test Methods for Evaluating Solid Waste (USEPA SW-846).
  - a. Standard Methods for the Examination of Water and Waste, 16 ed, (1983).
  - b. Standard Methods for the Examination of Water and Waste, 17 ed, (1989)/18ed (1992).
  - c. Method of Soil Analysis, Part 1, Physical and Mineralogical Methods, 2nd ed, (1986).
  - d. Method of Soil Analysis, Part 2, Chemical and Microbiological Properties, Am. Soc. Agron., Madison, WI (1965).
  - e. USEPA Contract Laboratory Program, Statement of Work for Inorganic Analysis.
  - f. Code of Federal Regulations.



Lionville Laboratory, Inc.

INORGANICS DATA SUMMARY REPORT 01/24/05

CLIENT: TNUHANFORD F04-015 H2923

LVL LOT #: 0412L505

WORK ORDER: 11343-606-001-9999-00

SAMPLE	SITE ID	ANALYTE	RESULT	UNITS	REPORTING LIMIT	DILUTION FACTOR
-----	-----	-----	-----	-----	-----	-----
-001	B19966	% Solids	91.2	%	0.01	1.0
		Chromium VI	0.24	MG/KG	0.22	1.0
		Nitrate Nitrite	0.94	MG/KG	0.22	1.0
		Oil & Grease Gravimetri	731	u MG/KG	731	1.0

Lionville Laboratory, Inc.

INORGANICS METHOD BLANK DATA SUMMARY PAGE 01/24/05

CLIENT: TNUHANFORD F04-015 H2923

LVL LOT #: 0412L505

WORK ORDER: 11343-606-001-9999-00

SAMPLE	SITE ID	ANALYTE	RESULT	UNITS	REPORTING LIMIT	DILUTION FACTOR
-----	-----	-----	-----	-----	-----	-----
BLANK10	04LVI048-MB1	Chromium VI	0.20 u	MG/KG	0.20	1.0
BLANK10	05LN3B04-MB1	Nitrate Nitrite	0.20 u	MG/KG	0.20	1.0
BLANK10	04LOG047-MB1	Oil & Grease Gravimetri	667	u MG/KG	667	1.0

Lionville Laboratory, Inc.

INORGANICS ACCURACY REPORT 01/24/05

CLIENT: TNUHANFORD F04-015 H2923

LVL LOT #: 0412L505

WORK ORDER: 11343-606-001-9999-00

SAMPLE	SITE ID	ANALYTE	SPIKED SAMPLE	INITIAL RESULT	SPIKED AMOUNT	%RECOV	DILUTION FACTOR (SPK)
-----	-----	-----	-----	-----	-----	-----	-----
-001	B19966	Soluble Chromium VI	4.7	0.24	4.4	101.7	1.0
		Insoluble Chromium VI	1400	0.24	1190	118.0	100
		Nitrate Nitrite	6.4	0.94	5.5	99.4	1.0
		Oil & Grease Gravimetr	8530	731 u	8950	95.4	1.0
BLANK10	04LVI048-MB1	Soluble Chromium VI	4.1	0.20u	4.0	101.4	1.0
		Insoluble Chromium VI	1380	0.20u	1180	117.1	100
BLANK10	05LN3B04-MB1	Nitrate Nitrite	5.1	0.20u	5.0	102.8	1.0
BLANK10	04LOG047-MB1	Oil & Grease Gravimetr	8300	667 u	8160	101.7	1.0

Lionville Laboratory, Inc.

INORGANICS PRECISION REPORT 01/24/05

CLIENT: TNUHANFORD F04-015 H2923  
WORK ORDER: 11343-606-001-9999-00

LVL LOT #: 0412L505

SAMPLE	SITE ID	ANALYTE	INITIAL RESULT	REPLICATE	RPD	DILUTION FACTOR (REP)
-----	-----	-----	-----	-----	-----	-----
-001REP	B19966	% Solids	91.2	91.9	0.73	1.0
		Chromium VI	0.24	0.22u	143.0	1.0
		Nitrate Nitrite	0.94	0.46	68.6	1.0
		Oil & Grease Gravimetri	731 u	731 u	NC	1.0

**FIELD PERSONNEL: COMPLETE ONLY SHADED AREAS**

**A See SRC**

[illegible]

**Special Instructions:**

**DATE/REVISIONS:**

1. \_\_\_\_\_
2. \_\_\_\_\_
3. \_\_\_\_\_
4. \_\_\_\_\_
5. \_\_\_\_\_
6. \_\_\_\_\_

Relinquished by F. E. [Signature]	Received by [Signature]	Date 4/23/64	Time 11:20
---	-------------------------------	-----------------	---------------

Relinquished by	Received by	Date	Time

Relinquished by	Received by	Date	Time
"COMPOSITE WASTE"	ORIGINAL REWRITTEN		

COLLECTOR Pope/Pfister/Tyra/Wiberg		COMPANY CONTACT CS Clearlock		TELEPHONE NO. 372-9638		PROJECT COORDINATOR TRENT, SJ		PRICE CODE    SN                  DATA  TURNAROUND	
SAMPLING LOCATION 216-U-3; 127FT-129.SFT		PROJECT DESIGNATION 200-MW-1 Characterization Sampling and Analysis - Soil				SAF NO. FO4-015		AIR QUALITY <input type="checkbox"/> 45 Days / 45 Days.	
ICE CHEST NO. <b>SANS-500</b>		FIELD LOGBOOK NO. HNF-N-386 1		COA 119144ES10		METHOD OF SHIPMENT Federal Express			
SHIPPER TO Shoreline Services		OFFSITE PROPERTY NO. <b>SU PTR MLD2</b>				BILL OF LADING/AIR BILL NO. <b>Ser PTR MLD2</b>			
MATRIX* A=Air DL=Drum Liquids DS=Drum Solids L=Liquid O=Oil S=Soil SE=Sediment T=Tissue V=Vegetation W=Water WI=Wipe X=Other	POSSIBLE SAMPLE HAZARDS/ REMARKS N/A		PRESERVATION Cool 4C None	Cool 4C None					
		TYPE OF CONTAINER	SG	SG					
		NO. OF CONTAINER(S)	1	1					
		VOLUME	120mL	60mL					
		SPECIAL HANDLING AND/OR STORAGE Radioactive Tie To: B19956 mda	SAMPLE ANALYSIS SEE ITEM (1) IN SPECIAL INSTRUCTIONS						
		B19956 mda							
SAMPLE NO.	MATRIX*	SAMPLE DATE	SAMPLE TIME	X					
B19966	SOIL	12/20/04	0740	X					
CHAIN OF POSSESSION									
RELINQUISHED BY/REMOVED FROM		DATE/TIME	SIGN/ PRINT NAMES		SPECIAL INSTRUCTIONS				
David Teaga		12/20/04 0910	MLO-RSC, FAIS #16		(1)NO2/NO3 - 353.2; Oil & Grease - 413.1; Chromium Hex - 7196;				
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
MDA-GSC, KAT		12/21/04 0935	MLO-BACH/MG BACH		12/21/04 0935				
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
MLO-BACH/MG BACH		12/21/04 1008	KACLY						
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
Ted Eo		12-23-04 1020	Paul Sherman		12-23-04 1020				
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
RELINQUISHED BY/REMOVED FROM		DATE/TIME	RECEIVED BY/STORED IN		DATE/TIME				
LABORATORY SECTION		RECEIVED BY			TITLE		DATE/TIME		
FINAL SAMPLE DISPOSITION		DISPOSAL METHOD			DISPOSED BY		DATE/TIME		

Lionville Laboratory Incorporated  
SAMPLE RECEIPT CHECKLIST (SRC)

CLIENT: *TNU HANFORD*

Date: *12-23-04*

Purchase Order / Project# /

*SAF# / SOW# / Release #: F04-015*

LvLI Batch #: *0412L505*

Sample Custodian: *Victor Hernandez*

NOTE: EXPLAIN ALL DISCREPANCIES

- |   |   |  |
|---|---|--|
| 1. Samples Hand Delivered or <u>Shipped</u>   | Carrier <i>Fed Ex</i>   | Airbill# <i>7914 2525 4585</i>                       |
| 2. Custody seals on coolers or shipping container intact, signed and dated?   | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | <input type="checkbox"/> No Seals    Comments        |
| 3. Outside of coolers or shipping containers are free from damage?  | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |  |
| 4. All expected paperwork received (coc and other client specific information) sealed in plastic bag and easily accessible? | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |  |
| 5. Samples received cooled or ambient?  | Temp <i>4.5</i> °C  | Cooler # <i>SAWS-500</i>                             |
| 6. Custody seals on sample containers intact, signed and dated?   | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | <input type="checkbox"/> No Seals                    |
| 7. coc signed and dated?  | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |  |
| 8. Sample containers are intact?  | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |  |
| 9. All samples on coc received? All samples received on coc?  | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |  |
| 10. All sample label information matches coc?   | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |  |
| 11. Samples properly preserved?   | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |  |
| 12. Samples received within hold times? Short holds taken to wet lab?   | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |  |
| 13. VOA, TOC, TOX free of headspace?  | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | <input checked="" type="checkbox"/> N/A              |
| 14. QC stickers placed on bottles designated by client?   | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | <input type="checkbox"/> N/A                         |
| 15. Shipment meets LvLI Sample Acceptance Policy? (Identify all bottles not within policy. See reverse side for policy)     | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |  |
| 16. Project Manager contacted concerning discrepancies? name/date (or samples outside criteria)                             | <input type="checkbox"/> Yes <input type="checkbox"/> No            | <input checked="" type="checkbox"/> No Discrepancies |