

0049244

Department of Energy
Richland Operations Office
P.O. Box 550
Richland, Washington 99352

98-EAP-247

MAY 12 1998

Ms. J. J. Wallace
300 Area Project Manager
State of Washington
Department of Ecology
1315 West Fourth Avenue
Kennewick, Washington 99336



Dear Ms. Wallace:

**TRANSMITTAL OF SUPPORTING DOCUMENTS FOR THE 324 BUILDING
RADIOCHEMICAL ENGINEERING CELLS, HIGH-LEVEL VAULT (HLV), LOW-LEVEL
VAULT (LLV), AND ASSOCIATED AREAS CLOSURE PLAN (324 Closure Plan)**

Attached are supporting documents to the 324 Closure Plan. Attachment 1-3 includes the data summary packages and laboratory analytical information related to sampling and analyses events that were described in the 324 Closure Plan. The three attachments are analytical results from 1) the 1995 sampling of the collected B-Cell dispersible debris; 2) the 1990 sampling of the HLV and LLV tank contents; and 3) the 1996 sampling of the HLV tank contents. The results include summary data packages, chemists' bench sheets, and other relevant laboratory information provided by the Pacific Northwest National Laboratory (PNNL) 325 Laboratory.

Attachment 4-7 is supporting information for Chapter 5, Groundwater Monitoring. This includes 4) Uranium trend plots of wells within 305m of the 324 Building; 5) Strontium-90 trend plots for the wells within 305m of the 324 Building; 6) Data results for wells 399-8-2 and 399-1-18A upgradient and greater than 305m of the 324 building; and 7) Data results for the 18 wells within 305m of the 324 Building.

MAY 12 1998

Ms. J. J. Wallace
98-EAP-247

-2-

Should you have any questions regarding this transmittal, please call Ellen Mattlin, of my staff, on (509) 376-2385.

Sincerely,



James E. Rasmussen, Director
Environmental Assurance, Permits,
and Policy Division

EAP:EMM

Attachments 7

cc w/attach:

Administrative Record
J. K. Bartz, Ecology

cc w/o attach:

J. R. Wilkinson, CTUIR
R. M. Milliken, BWHC
A. M. Hopkins, FDH
D. L. Powaukee, NPT
R. C. Bowman, WMH
A. L. Prignano, WMH
R. Jim, YIN

Attachment 1:

1995 B-Cell Dispersible Debris Analytical Results

The following two analytical reports were prepared by the PNL 325 Laboratory. The reports contain data for the samples collected from the ten engineered containers (EC) used to collect dispersible material from the B-Cell floor. The containers were labeled EC-14, EC-15, EC-16, EC-17, EC-19, EC-21, EC-22, EC-23, EC-24, and EC-25. The samples were collected and analyzed 1995. The first report contains data from the EC-15 and EC-19 samples. The second report contains data from the remaining container samples.

**THIS PAGE INTENTIONALLY
LEFT BLANK**



Battelle

Pacific Northwest Laboratories

T3.1d.3
Dispersible
Results

Project Number 13802

Internal Distribution

Date December 1, 1995
To PJ Weaver
From IC Henry ICH
Subject Analysis of 324 B-Cell Samples

KJ Kuhl-Klinger
RT Steele
MW Uriel
LR Greenwood
KJ Smith
File/LB

Four samples were submitted for analysis of TCLP metals by ICP, radiochemistry (GEA, alpha, beta, Pu/AEA, Sr-90), and pH. Attached, you will find a five page report outlining the TCLP data and two tables summarizing the radiochemistry data. The pH data is outlined below:

<u>ACL#</u>	<u>ID</u>	<u>pH</u>
96-00670	15A	8.6
96-00670Dup	15A	8.6
96-00671	15B	8.4
96-00672	19A	8.5
96-00673	193	8.7

The pH analysis was performed on the solution derived from leaching 0.5 grams of sample material with 5 grams of water for 15 minutes.

Please contact me if you have questions or concerns.

RECEIVED

DEC 05 1995

P. J. WEAVER

RECEIVED
DEC 05 1995

P. J. WEAVER

Battelle PNL/ACL/Inorganic Analysis Group:
ICPAES Analytical Report

Project/WO: 13802/K41546

Client: PJ Weaver

Impact Level: II

ACL Number

96-000670 through 96-000673

"15A" through "19B"

ASR Number: 002587 (4 samples)

Procedure: PNL-ALO-211, "Determination of Elements by Inductively Coupled Argon Plasma Atomic Emission Spectrometry" (ICP-AES).

Analyst: DR Sanders

Analysis Date (Filename): 11/2/95 (A0020)

See ALO System File: "ICP-325-405-1" for traceability to Calibration, Quality Control, Verification, and Raw Data.

M&TE Number: ICPAES instrument -- WB73520
Mettler AT400 Balance -- Ser.No. 360-06-01-029

Jessy Weaver 11-21-95
Reviewed by

M.W. Hill 11-22-95
Concur

11/21/95

Battelle PNL/ACL/Inorganic Analysis Group:
ICPAES Analytical Report

Four radioactive samples and quality control standards were analyzed by ICPAES after being prepared by 325 SAL-SRPL lab using PNL-ALO-128 acid digestion procedure on the TCLP extracts. Acid digestion of the extracts were diluted 1.25 fold before analysis. Final results have been corrected for dilution.

None of the TCLP analytes measured exceed regulatory limits.

Analytes measured included Silver, Arsenic, Barium, Cadmium, Chromium, Lead, and Selenium.

Spike recoveries for all TCLP analytes were within tolerance except Silver (spike recovery approx. 50%). Low spike recoveries for silver using the TCLP method has been well documented in the literature. Even if the measurement results for Silver were doubled (accounting for the 50% spike recovery) the concentrations so calculated would still be below TCLP regulatory limit. Also noted was poor relative percent difference between acid digestion duplicate on sample 96-000670 (Client ID "15A"). All analyte concentrations above detection limit, varied between 16 and 50% RPD (Relative Percent Difference). The reason for this is unknown. RPD for both sample splits (true duplicate samples) were much better (by a factor of 2 or more).

Below is a "TCLP" Table. Concentrations (bolded print) are listed when TCLP limits are exceeded or analyte detection limit concentration when the regulatory limit is not exceeded.

See attached "ICPAES Data Report" for additional analyte measurement results, detection limits, and etc. Please note, bracketed values listed in the ICPAES Data Report are within ten times instrument detection limit. Those measurement values have a potential uncertainty much greater than 15%.

11/21/95

*Battelle PNL/ACL/Inorganic Analysis Group:
ICPAES Analytical Report*

Comments:

- 1) "Final Results" have been corrected for all laboratory dilutions performed on the sample during processing and analysis.
- 2) Detection limits (DL) shown are for acidified water. Detection limits for other matrices may be determined if requested.
- 3) Routine precision and bias is typically $\pm 15\%$ or better for samples in dilute, acidified water (eg. 2% v/v HNO₃ or less) at analyte concentrations greater than ten times detection limit up to the upper calibration level. This also presumes that the total dissolved solids concentration in the sample is less than 5000 $\mu\text{g/mL}$ (0.5 per cent by weight).
- 4) Absolute precision, bias and detection limits may be determined on each sample if required by the client.
- 5) The maximum number of significant figures for all ICP measurements is 2.
- 6) To convert "WT%" to "mg/Kg" or " $\mu\text{g/g}$ ", multiply concentration value by 10,000.
- 7) To convert "mg/Kg" or " $\mu\text{g/g}$ " to "WT%", divide concentration value by 10,000.

11/21/95

Battelle PNL/ACL/Inorganic Analysis Group:
ICP-AES Analytical Report

"TCLP" Table. Detection limit is listed when TCLP regulatory limit is NOT exceeded,
 and a concentration value is listed when a TCLP regulatory limit IS exceeded.

<u>Analyte=</u>		<u>Ag</u> (mg/L)	<u>As</u> (mg/L)	<u>Ba</u> (mg/L)	<u>Cd</u> (mg/L)	<u>Cr</u> (mg/L)	<u>Pb</u> (mg/L)	<u>Se</u> (mg/L)
<u>Measurement Units=</u>		5.00	5	100	1	5	5	1
<u>TCLP Reg.Limit=</u>		0.015	0.03	0.01	0.015	0.02	0.05	0.1
<u>Instrument Detection Limit=</u>		<0.02	<0.1	<0.01	<0.02	<0.03	<0.08	<0.13
<u>Multiplier</u>	<u>ACL #</u>	<u>Client ID</u>						
1.25	96-000570	15A	<0.02	<0.1	<0.01	<0.02	<0.03	<0.08
1.25	96-000571	15B	<0.02	<0.1	<0.01	<0.02	<0.03	<0.08
1.25	96-000572	19A	<0.02	<0.1	<0.01	<0.02	<0.03	<0.08
1.25	96-000573	19B	<0.02	<0.1	<0.01	<0.02	<0.03	<0.08

Note: The "TCLP" result table above lists "less than" values adjusted for instrument detection limit and sample preparation dilution.

Bolded values, where shown, are sufficiently above detection limit and exceed TCLP regulation limits.

11/21/95

Battelle PNL/ACL/Inorganic Analysis Group ... ICPAES Data Report

Multiplier=	1.3	1.3	1.3	1.3
ALO#=	96-000670	96-000671	96-000672	96-000673
Client ID#	15A	15B	15C	15D
Det. Limit (ug/mL)	Run Date=	(ug/mL)	(ug/mL)	(ug/mL)
(Analyte)				
0.015	Ag	[0.05]	[0.05]	--
0.050	Al	0.78	1.05	0.8
0.050	As	[0.37]	[0.42]	[0.2]
0.020	B	29.35	34.40	20.4
0.010	Ba	0.43	0.43	0.4
0.005	Be	--	--	--
0.100	Bl	[0.21]	[0.24]	--
0.050	Ca	920	558	754
0.015	Cd	[0.12]	[0.13]	[0.2]
0.100	Ce	[0.28]	[0.30]	[0.2]
0.010	Co	[0.07]	[0.08]	[0.1]
0.020	Cr	[0.22]	0.29	0.3
0.010	Cu	1.45	1.69	1.4
0.050	Dy	--	--	--
0.100	Eu	--	--	--
0.020	Fe	0.50	0.69	0.6
2.000	K	29.79	33.79	[21.5]
0.050	La	--	--	--
0.030	Li	[0.24]	[0.26]	[0.2]
0.100	Mg	18.57	21.52	15.9
0.005	Mn	3.18	3.67	4.9
0.030	Mo	1.59	2.17	1.4
0.050	Na	1630	1690	1509
0.050	Nd	[0.36]	[0.36]	[0.2]
0.030	Ni	2.30	2.52	4.5
0.100	P	1.27	1.47	[0.7]
0.050	Pb	[0.32]	[0.38]	[0.3]
0.300	Pd	[0.57]	[0.64]	--
0.300	Rh	--	--	--
0.100	Ru	[0.17]	[0.20]	--
0.050	Sb	[0.58]	0.64	[0.3]
0.100	Se	[0.24]	[0.30]	[0.1]
0.500	Si	27.05	42.08	22.8
1.000	Sn	--	--	--
0.005	Sr	8.55	9.20	7.0
0.500	Te	--	--	--
0.800	Th	--	--	--
0.005	Tl	0.07	0.09	[0.0]
0.500	Tl	--	--	--
2.000	U	[20.1E]	[21.8E]	[12.2]
0.010	V	[0.10]	[0.11]	[0.0]
0.500	W	--	--	--
0.010	Y	[0.04]	[0.04]	[0.0]
0.020	Zn	1.38	1.57	3.6
0.010	Zr	[0.06]	[0.0E]	[0.0]

Note: 1) Overall error greater than 10-times detection limit is estimated to be within +/- 15%.

2) Values in brackets [] are within 10-times detection limit with errors likely to exceed 15%.

3) -- indicate measurement is below detection. Sample detection limit may be found by multiplying "det. Limit" (far left column) by "multiplier" (top of each column).

Battelle Pacific Northwest Laboratory
Analytical Chemistry Laboratory
Radiochemistry Group - 325 Bldg.

96-00670
11/29/95

Client: Weaver
Wpk: K41546

Cognizant Scientist:

Richard T. Ross

Date: 11/29/95

Review:

T Trang-le

Date: 11/29/95

Measured Activities (microCuries/g)

ALO ID Client ID	GEA Filename	Total Alpha Error +/-	Pu-238+Am-241 Error +/-	Cm-243+Cm-244 Error +/-	Pu-239 Error +/-	Total Beta Error +/-	Cs-137 Error +/-	Eu-154 Error +/-	Am-241 Error +/-
96-00670 15A	T2020	1.04E 1 0%	7.58E 0 14%	2.82E 0 18%	<0. E-1	2.68E 4 1%	1.47E 4 2%	<4. E 0	<2. E 1
96-00670-PB Process Blank	G0102	0.54E-3 24%	4.60E-3 50%	3.94E-3 50%	<2. E-3	4.60E-1 5%	3.19E-1 2%	<3. E-3	<4. E-3
96-00671 15B	T2011	1.06E 1 8%	7.55E 0 12%	3.05E 0 16%	<0. E-1	2.49E 4 1%	1.48E 4 2%	<4. E 0	<2. E 1
96-00672 19A	T2012	1.92E 1 7%	1.22E 1 10%	5.65E 0 13%	1.40E 0 31%	2.25E 4 1%	1.31E 4 2%	0.20E 0 9%	1.30E 1 34%
96-00672-Dup 19A Dup	T2013	2.39E 1 6%	1.51E 1 10%	6.48E 0 13%	2.89E 0 21%	2.48E 4 4%	1.43E 4 2%	1.20E 1 7%	1.31E 1 33%
96-00673 19B	T2014	1.77E 1 7%	1.17E 1 10%	5.22E 0 13%	7.30E-1 34%	2.33E 4 4%	1.35E 4 2%	0.08E 0 10%	<2. E 1
Standard		94%				94%			
Matrix Spike		95%				00%			
96-00673									
Blank			<3. E-5			<1. E-3			

DATA REPORT
PNL Analytical Chemistry Lab.
Radioanalytical Group, 325 Building

11/30/95

Client: WEAVER
WP #: K41546

Cognizant scientist: J R Greenwood Date: 12-1-95

Reviewer: D. L. Ridgway Date: 12/1/95

ALO #	Customer ID	Sr-90 uCi/g Error %
96-00670-PB	PROCESS BLANK	<1. E-1
96-00670	15A	5.30E 3 7%
96-00671	15B	4.91E 3 8%
96-00672	19A	3.92E 3 8%
96-00672-D	19A DUPLICATE	4.89E 3 8%
96-00673	19B	4.43E 3 8%
STD-2587		96%
Blank Spike w/96-00670-PB		103%
Blank		<1. E-1

Date December 6, 1995
To PJ Weaver
From IC Henry ICH
Subject Analysis of 324 B-Cell Samples

KJ Kuhl-Klinger
RT Steele
HW Uriel
LR Greenwood
KJ Smith
File/LB

Attached you will find a revised table outlining the ICP data pertaining to your four 324 B-Cell samples, please discard the original table. The detection limits listed on the original table were erroneously "Bolded", which is meant to indicate a TCLP limit has been exceeded. This was not the case with your samples; all of the analytes of interest were below the limits stated on the summary table.

I apologize for any confusion this may have caused. If you have any questions or concerns, please contact me at your convenience.

RECEIVED

DEC 8 1995

P. J. WEAVER

Battelle PNL/ACL/Inorganic Analysis Group:
ICP-AES Analytical Report

"TCLP" Table. A concentration value (bolded) is entered in the table whenever a TCLP limit is exceeded otherwise a detection limit preceded by a "<" symbol is entered.

<u>Analyte=</u>	<u>Ag</u>	<u>As</u>	<u>Ba</u>	<u>Cd</u>	<u>Cr</u>	<u>Pb</u>	<u>Se</u>
<u>Measurement Units=</u>	(mg/L)	(mg/L)	(mg/L)	(mg/L)	(mg/L)	(mg/L)	(mg/L)
<u>TCLP Reg.Limit=</u>	5.00	5	100	1	5	5	1
<u>Instrument Detection Limit=</u>	0.015	0.05	0.01	0.015	0.02	0.05	0.1
<u>Multiplier</u>	<u>ACI#</u>	<u>Client ID</u>					
1.25	95-000670	15A	<0.02	<0.1	<0.01	<0.02	<0.03
1.25	95-000671	15B	<0.02	<0.1	<0.01	<0.02	<0.03
1.25	95-000672	19A	<0.02	<0.1	<0.01	<0.02	<0.03
1.25	95-000673	19B	<0.02	<0.1	<0.01	<0.02	<0.03

Note: The "TCLP" result table above lists "less than" values adjusted for instrument detection limit and sample preparation dilution.

Bolded values, where shown, are sufficiently above detection limit and exceed TCLP regulation limits.

12/5/95

Jerry Wayne
12-5-95

Battelle PNL/ACL/Inorganic Analysis Group:
ICPAES Analytical Report

Project/WO: 13802/K27289

Client: JK Larsen

Impact Level: II

ALO Log-In Number

95-007348 through 95-007363

"14A" through "25B"

(16 samples)

Procedure: PNL-ALO-211, "Determination of Elements by Inductively Coupled Argon Plasma Atomic Emission Spectrometry" (ICP-AES).

Analyst: DR Sanders

Analysis Date (Filename): 08/04/95 (95D216A) and 08/09/95 (95D221A)

See ALO System File: "ICP-325-405-1" for traceability to Calibration, Quality Control, Verification, and Raw Data.

M&TE Number: ICPAES instrument -- WB73520
Mettler AT400 Balance -- Ser.No. 360-06-01-029

Jerry Wexner 8-10-95
Reviewed by

MWJ/MW 8-11-95
Concur

8/10/95

Battelle PNL/ACL/Inorganic Analysis Group:
ICPAES Analytical Report

ICPAES analysis was performed on the TCLP acid digested extracts generated in the Shielded Analytic Laboratory and prepared in two batches. All samples were extracted at a 20:1 ratio. Based upon the results of the ICPAES analysis, several TCLP metals exceed the TCLP Regulatory Threshold in several of the samples.

Batch #1 (samples 14A through 21B):

The analytical QC samples (i.e. ICV/CCV) were within acceptable limits (i.e., $\pm 10\%$). Sample spike recoveries for Ag, As, Ba, Cd, Cr, Pb and Se on sample 17A were 32%, 104%, 108%, 110%, 106%, 107% and 113%, respectively. The Laboratory Control Standard (i.e., the Blank Spike) had analyte recoveries within acceptable limits (i.e., 85-115%), except Ag, which recovered at 34%. Since there was no Ag detected above the instrument detection limit (which is 200 times below the Regulatory Threshold) and the recoveries of the LCS and matrix spike are consistent, the Ag data is considered acceptable.

Batch #2 (samples 22A through 25B):

The analytical QC samples (i.e. ICV/CCV) were within acceptable limits (i.e., $\pm 10\%$). Sample spike recoveries for Ag, As, Ba, Cd, Cr, Pb and Se on sample 24A were 49%, 99%, 113%, 105%, 104%, 125% and 111%, respectively. The Laboratory Control Standard (i.e., the Blank Spike) had analyte recoveries within acceptable limits (i.e., 85-115%), except Ag, which recovered at 25%. Since there was no Ag detected above the instrument detection limit (which is 200 times below the Regulatory Threshold) and the recoveries of the LCS and matrix spike are consistent, the Ag data is considered acceptable. The high Lead spike recovery in the matrix spike is rendered meaningless because of the high concentration of Lead (54 $\mu\text{g/mL}$) in the sample (10 times higher than the spike concentration) and 10 times higher than the Regulatory Threshold. Lead spike recovery in the LCS was 105%, well within acceptable limits.

A summary of values found in the samples is presented in table form on the following page.

8/10/95

Summary of TCLP ICPAES Results (ug/mL)

ACN Number	Sample ID	Hg	As	Ea	Cd	Cr	Pb	Se
TCLP Limit	ug/mL=>	5	5	100	1	5	5	1
95-007348	14A	ND	ND	0.70	0.38	(0.10)	ND	ND
95-007349	14B	ND	ND	0.58	(0.31)	(0.05)	(0.18)	ND
95-007350	16A	ND	ND	1.50	0.99	0.92	7.2	ND
95-007351	16B	ND	(0.34)	2.00	1.00	0.82	62	ND
95-007352	17A	ND	ND	1.10	0.74	1.20	2.9	ND
95-007353	17B	ND	ND	0.97	0.72	1.00	4.6	ND
95-007354	21A	ND	ND	1.50	0.90	(0.40)	15	ND
95-007355	21B	ND	ND	1.50	0.90	(0.30)	11	ND
95-007356	22A	ND	(0.21)	1.70	0.62	(0.25)	54	ND
95-007357	22B	ND	ND	1.20	0.56	(0.25)	1.7	ND
95-007358	23A	ND	ND	0.55	0.62	(0.29)	5.4	ND
95-007359	23B	ND	(0.23)	1.10	0.78	(0.31)	22	ND
95-007360	24A	ND	(0.30)	1.20	(0.35)	6.4	64	(0.7)
95-007361	24B	ND	(0.25)	0.74	(0.37)	6.1	15	(0.6)
95-007362	25A	ND	ND	1.00	0.60	(0.30)	6.5	ND
95-007363	25B	ND	ND	1.00	0.60	(0.30)	3	ND
TCLP Ext Bk	TCLP Blank(1)	ND	ND	ND	ND	ND	ND	ND
TCLP Ext Bk	TCLP Blank(2)	ND	ND	ND	ND	ND	ND	ND
Prep Blank	Prep Blank(1)	ND	ND	ND	ND	ND	ND	ND
Prep Blank	Prep Blank(2)	ND	ND	ND	ND	ND	ND	ND
IDL	ug/mL=>	0.02	0.20	0.02	0.01	0.05	0.15	0.25

ND = Not Detected above IDL

(xx) = Results > IDL but < MDL; MDL = 10 * IDL

8/10/95

Container Number	Total Alpha		Pu-238		Pu-239/240		Total Beta		Sr-90	
	uCi/g	Total Ci	uCi/g	Total Ci	uCi/g	Total Ci	uCi/g	Total Ci	uCi/g	Total Ci
14	2.31E+01	2.52E+00	1.39E+00	1.52E-01	1.02E+00	1.11E-01	2.19E+04	2.39E+03	7.16E+03	7.82E+02
16	1.13E+01	9.59E-01	6.63E-01	5.63E-02	4.51E-01	3.83E-02	2.41E+04	2.05E+03	6.82E+03	5.79E+02
17	1.21E+01	1.19E+00	8.95E-01	8.79E-02	6.26E-01	6.15E-02	2.70E+04	2.65E+03	5.62E+03	5.52E+02
21	1.51E+01	1.82E+00	8.35E-01	1.01E-01	6.20E-01	7.49E-02	3.10E+04	3.84E+03	9.30E+03	1.12E+03
22	1.87E+01	1.85E+00	1.58E+00	1.56E-01	1.00E+00	9.87E-02	3.50E+04	3.45E+03	8.08E+03	7.97E+02
23	3.20E+01	3.16E+00	2.02E+00	1.99E-01	1.39E+00	1.37E-01	3.13E+04	3.09E+03	7.79E+03	7.69E+02
24	3.53E+00	3.64E-01	3.27E-01	3.37E-02	1.72E-01	1.77E-02	2.33E+04	2.40E+03	6.13E+03	6.32E+02
25	3.00E+01	3.69E+00	2.24E+00	2.75E-01	1.56E+00	1.92E-01	2.79E+04	3.43E+03	7.80E+03	9.58E+02
Average	1.82E+01	1.94E+00	1.24E+00	1.33E-01	8.55E-01	9.14E-02	2.78E+04	2.91E+03	7.34E+03	7.74E+02

Container Number	Cs-137		Eu-154		Am-241		Cs/Sr Ratio
	uCi/g	Total Ci	uCi/g	Total Ci	uCi/g	Total Ci	
14	8.43E+03	9.21E+02	1.05E+01	1.15E+00	1.25E+01	1.37E+00	1.177374302
16	1.12E+04	9.51E+02	5.57E+00	4.73E-01	5.88E+00	4.99E-01	1.642228739
17	1.53E+04	1.50E+03	6.03E+00	5.92E-01	9.25E+00	9.08E-01	2.722419929
21	1.29E+04	1.56E+03	7.67E+00	9.27E-01	8.03E+00	1.08E+00	1.387096774
22	1.75E+04	1.73E+03	7.91E+00	7.81E-01	1.00E+01	9.87E-01	2.165841584
23	1.44E+04	1.42E+03	1.41E+01	1.39E+00	1.73E+01	1.71E+00	1.848523748
24	1.02E+04	1.05E+03	1.41E+00	1.45E-01	4.29E+00	4.42E-01	1.663947798
25	1.22E+04	1.50E+03	1.33E+01	1.63E+00	1.52E+01	1.87E+00	1.564102564
Average	1.28E+04	1.33E+03	8.31E+00	8.86E-01	1.04E+01	1.11E+00	1.77E+00

Dispersible Containers

Container Identification Number	Tare Weight (KG)	Gross Weight (KG)	Ncl Weight (KG)	Contact Dose Rate (Roentgen/hr)	Instrument/Calibration Date	Initials/Date
014	106.3	215.52	109.22	1570	See Note 1; and See Note 2;	DGJ / 8/7/95
015	105.4	181.49	76.09	1860	See Note 1; and See Note 2;	DGJ / 8/7/95
016	106	190.9	84.9	5100	See Note 1; and See Note 2;	LJS / 8/8/95
017	106	204.2	98.2	3630	See Note 1; and See Note 2;	DGJ / 8/7/95
019	104.5	190.9	86.4	1025	See Note 1; and See Note 2;	LJS / 8/8/95
021	106	226.36	120.86	1740	See Note 1; and See Note 2;	DGJ / 8/7/95
022	105.5	204.2	98.7	1230	See Note 1; and See Note 2;	DGJ / 8/7/95
023	105.5	204.2	98.7	1820	See Note 1; and See Note 2;	DGJ / 8/7/95
024	106	209.09	103.09	4040	See Note 1; and See Note 2;	LJS / 8/8/95
025	104	226.86	122.86	1630	See Note 1; and See Note 2;	DGJ / 8/7/95

RLFCM Glass Containers

Container Identification Number	Tare Weight (KG)	Gross Weight (KG)	Ncl Weight (KG)	Dose Rate (Roentgen/hr)	Instrument/Calibration Date	Initials/Date
11	124.4	294.9	170.5	20,000 at 12"	See Note 1; and See Note 2;	DGJ / 8/7/95
12	124.4	272.72	144.32	20,000 at 11"	See Note 1; and See Note 2;	LJS / 8/8/95
13	12.4	200.0	75.6	20,000 at 7"	See Note 1; and See Note 2;	LJS / 8/8/95

Note 1: 4000 lbs. Dillon - s/n SG1-29-06-023 Calibration Expiration Date 10/10/95

Note 2: R07 High Range Probe - s/n 6034 Calibration Expiration Date 1/7/96

pH ANALYSIS

(325-SHIELDED ANALYTICAL LABORATORY)

CLIENT: Pat WeaverWORK PACKAGE: K41546 ASR/ARF/LOI/TI: ASR #12257 Rev 1QA PLAN: MCS-033IMPACT LEVEL: II324 B-Cell Dispersible SamplesSAMPLE IDENTIFICATION

ACL NUMBER	SAMPLE IDENTIFICATION	1st pH READING	2nd pH READING	pH AVERAGE
N/A	ICV # PH7 # 950355-24	7.04	7.05	
95-07348	14A	8.62 ^{8.62} 7.8	8.30	8.29
95-07348-DUP	14A Dup	8.49	8.50	8.50
95-07349	14B	8.26	8.27	8.26
95-07350	16A	8.26	8.24	8.25
95-07351	16B	8.18	8.12	8.15
95-07352	17A	8.13	8.13	8.13
95-07353	17B	8.12	8.10	8.11
95-07354	21A	8.47	8.50	8.49
95-07355	21B	8.65	8.63	8.64
N/A	CCV # 950355-24	6.96	6.98	6.97
95-07356	22A	8.26	8.22	8.21
95-07357	22B	8.34	8.38	8.36

CALIBRATION CHECK POINTS: 7 (Calib) / 10 (Calib) / 7 (Control)

PROCEDURE: PNL-ALO-225

BUFFER LOT NUMBER: 950389-24 195-0253-24 1950355-24BUFFER EXPIRATION DATE: 1-97 1-97 1-97

M&TE: Cor.v.09 7166.29

Analyst:

Date:

Reviewer:

Date:

10/11/9510/11/95

pH ANALYSIS
(325 SHIELDED ANALYTICAL LABORATORY)

CLIENT: Pat Weaver

WORK PACKAGE: K41546 ASR/ARF/LOI/TI: ASR #2257 Rev 1

QA PLAN: MCS-033

IMPACT LEVEL: II

324 B-Cell Dispersible Sample
SAMPLE IDENTIFICATION

CALIBRATION CHECK POINTS: See Pg 10 of J. (Calib) / (Calib) / (Control)

PROCEDURE: PNL-ALO-225

BUFFER LOT NUMBER: See Pg 1 OF 2 / /

BUFFER EXPIRATION DATE: See Pg 1 of 2 / /

MATE: Corning #101629

Analyst:

Date _____

Reviewer

Date

Analyst: J. Vaughan

Date: 10/11/95

Reviewer: MC Han

Date: 10/11/95

Attachment 2:

1990 HLV and LLV Vault Tank Contents Analytical Results

The following analytical data (including chemist's bench sheet) and analytical reports are from the PNL 325 Laboratory. Included are data for the samples collected from the HLV and LLV tanks' contents. The samples were collected and analyzed in 1990. These results were used to eventually designate the waste in all the tanks.

VALUES REPORTED IN mg/L

CUSTOMER _____
DATE RUN _____

	29-70	Final	30-70	Final	31-70	Final	32-70	THE NAME	166-90
	90-791	CORC.	90-792	CORC.	90-793	CORC.	90-794	CORC.	90-1872
Dilution	TK-101	uM/L	TK-102	uM/L	TK-103	uM/L	TK-105	uM/L	TK-106

	10X		10X		10X		10X		10X
Ag	.007								
Al	.04	97	478	406	2000	77	379	.47	33.5
As	.05			(4.8)	(24)				
B	.003	80.5	391.4	358	176	57	281	.84	(2.7) (49)
Ba	.0009	19.8	97.5	82	404	16.7	82.2	.14	70
Be	.0003								43.5
Ca	.0003	41.5	204.3	149	734	35.0	172	5.0	35.0
Cd	.006								91.1
Ce	.02								
Co	.005								
Cr	.002	,99	4.87	(.23)	(1.1)	(.12)	(.59)	.54	(.24) (.43)
Cu	.002			.34	1.7	.16	.79		14.8
Dy	.002								26.8
Fe	.002	8.20	40.4	48.2	237	5.05	24.9	2.00	100
K	.06	16.	79	20	99	16.	79		79.4
La	.003								12
L1	.002								22
Mg	.001	2.1	10.3	5.1	25	2.27	11.2		
Mn	.0003	-54	2.66	.33	1.6	.23	1.1	12.9	645
Mo	.007								.28 .51
Na	.01	3.00	1477	801	3950	304	1497	5638	*
Rd	.008								404
Ni	.005	1.67	8.22	.3	1.5	.3			7.1
P	.1	96.8	477	33	162	5.8	29		3.6
Pb	.04								
Rn	.01								1.16
Ru	.01								2.10
Sb	.2								
Se	.06								
Si	.01	52.9	310	334	1650	87.2	429	.56	28
Sr	.00001	.41	2.0	1.61	7.93	.36	1.8	.05	105.5
Te	.03								190.8
Tl	.002	,80	3.9	3.0	14.8	.54	2.7	5.0	2.5
Tl	.06								.90
U	.09								1.6
V	.006								
Zn	.001	.43	2.1	3.34	16.5	.56	2.8	.24	12
Zr	.001	.41	2.0	1.33	6.55	.32	1.6	14.8	740
									.76
									1.4

604 5/24/90

Detection limits determined under ideal conditions according to the USEPA CLP protocol.

All tabulated values have been corrected for our lab dilution. Values in () are approaching or at detection limit.
 Procedure and RMT used: PHL-SP-7/RM 55672. RTLS number:

VALUES REPORTED IN mg/L

卷之三

CATE RAY 5/14/80

FILE NAME TK@2

~~Detection limits determined under ideal conditions according to the USEPA CLP protocol.~~

All tabulated values have been corrected for our lab dilution. Values in () are approaching or at collection
Procedure and HST used: PHL-SP-74/WA 55672. RFLS number

CHORM ALLELE

Result file (<CR> for no storage) = SIMHS

Do you wish to normalise all standards [Y/N] ?

The following standards are used in this programme(s) :

CL1 CH4 CH3 CH2

Sample name : CL1

Press <CR> when ready to start measurement

24:132H6n

Sample name : CL1

Programme : ALLELE 14-May-96 11:04:46

[1] Direct Intensities

AG	5.12000	ALB	9.52000	AS	12.35000	P64	4.56000	BA02	5.71000	BE	6.12000
CA15	3.33000	CD	7.59000	CE18	11.89000	CO	33.73000	CR21	5.30000	CU	10.44000
DY26	6.71000	FEB5	5.54000	K14	24.81000	LA13	7.45000	LI10	5.15000	MG6	2.99000
MN26	5.47000	MO23	4.94000	NA22	5.66000	ND16	5.06000	NI19	4.54000	P4	11.97000
PB	7.16000	RE25	4.71000	RH12	8.61000	RUG3	8.56000	SR	3.85000	SE	7.76000
SI7	5.40000	SR17	5.62000	TE01	4.28000	TH	7.66000	TI11	3.86000	TL	4.83000
U	30.62000	V	8.74000	ZNP	4.23000	ZR24	6.90000				

[1] Direct Intensities

AG	5.68000	ALB	9.58000	AS	12.78000	P64	4.54000	BA02	5.71000	BE	6.08000
CA15	3.35000	CD	7.56000	CE18	11.86000	CO	33.66000	CR21	5.29000	CU	10.39000
DY26	6.68000	FEB5	5.53000	K14	24.79000	LA13	7.39000	LI10	5.14000	MG6	2.99000
MN26	5.46000	MO23	5.66000	NA22	5.79000	ND16	5.07000	NI19	4.55000	P4	12.69000
PB	7.11000	RE25	4.76000	RH12	8.59000	RUG3	8.50000	SR	3.82000	SE	7.66000
SI7	5.38000	SR17	5.59000	TE01	4.27000	TH	7.62000	TI11	3.85000	TL	4.55000
U	30.57000	V	8.76000	ZNP	4.26000	ZR24	6.89000				

[1] Direct Intensities

AG	5.11000	ALB	9.61000	AS	12.75000	P64	4.60000	BA02	5.70000	BE	6.11000
CA15	3.35000	CD	7.59000	CE18	11.84000	CO	33.70000	CR21	5.32000	CU	10.43000
DY26	6.70000	FEB5	5.54000	K14	24.81000	LA13	7.41000	LI10	5.16000	MG6	2.99000
MN26	5.51000	MO23	5.84000	NA22	5.79000	ND16	5.09000	NI19	4.56000	P4	11.94000
PB	7.22000	RE25	4.69000	RH12	8.64000	RUG3	8.49000	SR	3.86000	SE	7.59000
SI7	5.39000	SR17	5.63000	TE01	4.28000	TH	7.64000	TI11	3.78000	TL	4.58000
U	30.59000	V	8.74000	ZNP	4.26000	ZR24	6.87000				

NAME MV INT RSD PCOR

AG		5.10	0.41	0.00000
ALB		9.61	0.10	0.00000
AS		12.69	0.99	0.00000
P64		4.57	0.67	0.00000
BA02		5.71	0.10	0.00000
BE		6.10	0.34	0.00000
CA15		3.34	0.35	0.00000
CD		7.58	0.20	0.00000
CE18		11.85	0.39	0.00000
CO		33.58	0.20	0.00000
CR21		5.30	0.29	0.00000
CU		10.42	0.25	0.00000
DY26		6.70	0.23	0.00000
FEB5		5.54	0.10	0.00000
K14		24.86	0.05	0.00000
LA13		7.42	0.41	0.00000
LI10		5.15	0.19	0.00000
MG6		2.99	0.09	0.00000
MN26		5.49	0.42	0.00000
MO23		5.01	1.20	0.00000

TA27	5.79	6.10	6.00000
UB16	5.87	6.30	6.00000
UL13	3.55	0.15	6.00000
P4	12.00	0.66	6.00000
PB	7.18	1.22	6.00000
RE25	4.70	0.21	6.00000
RH12	8.61	0.29	6.00000
RU03	8.52	0.44	0.00000
SB	3.84	0.54	6.00000
SE	7.63	0.60	6.00000
S17	5.39	0.19	6.00000
SR17	5.61	0.37	6.00000
TE01	4.28	0.14	6.00000
TH	7.64	0.26	6.00000
TI11	3.87	0.68	6.00000
TL	4.59	0.88	6.00000
U	30.81	0.19	6.00000
V	8.75	0.13	6.00000
ZN9	4.23	0.71	6.00000
ZR24	6.89	0.22	6.00000

Store [N/Y] ? Y

Channel	Old	New	Nominal	Drift
AG	5.04667	5.10333	5.49667	*
AL8	9.92000	9.61000	13.74667	*
AS	12.41667	12.69333	13.05667	
BB4	4.56333	4.56667	5.09333	*
BA02	5.65667	5.72667	6.19667	*
BE	6.18000	6.10333	7.31000	*
CA15	3.34333	3.34333	3.99667	*
CD	7.44333	7.57667	8.50333	*
CE18	11.4833	11.8500	12.5200	*
CO	32.3600	33.6767	31.7933	*
CR21	5.27667	5.30333	5.72000	*
CU	18.1500	18.4200	16.9300	*
DY26	6.57667	6.69667	7.12333	*
FE05	5.47667	5.53667	5.91000	*
K14	24.0500	24.8033	24.2667	*
LA13	7.38333	7.41667	7.79333	*
LJ10	5.11667	5.15000	5.49333	*
M66	2.99333	2.99000	3.42333	*
MN20	5.45000	5.48000	6.14333	*
M023	5.21000	5.81333	6.05667	*
NA22	5.76333	5.79333	6.33000	*
NP16	4.99333	5.07333	5.44333	*
NJ19	4.53667	4.54667	5.34333	*
P4	12.1033	12.6000	14.98667	*
PB	7.14333	7.18333	8.42333	*
PE25	4.67333	4.70000	5.31333	*
RH12	8.31333	8.61333	9.91333	*
RU03	8.37667	8.51667	8.74333	*
SB	3.89333	3.84333	4.28000	*
SE	7.56000	7.63000	8.63667	*
S17	5.34000	5.39000	5.94000	*
SR17	5.52667	5.61333	6.02333	*
TE01	4.27333	4.27667	5.33333	*
TH	7.48333	7.64000	9.78667	*
TI11	3.87333	3.87000	4.54000	*

IL 4.49600 4.58467 5.61000 *
U 29.3533 30.6133 29.7700 *
V 3.48220 3.74667 3.24600 *
ZNP 4.19000 4.23000 5.34600 *
ZR24 6.79333 6.88667 7.43667 *

[*****] Excessive drift - check correct standard used
Update standard file [Y/N] ? Y

Sample name : CH4

Press <CR> when ready to start measurement

24:132H&n

Sample name : CH4

Programme : ALLELE 14-May-98 11:07:47

[1] Direct Intensities

AG 129.800 U 157.800

[1] Direct Intensities

AG 129.500 U 157.700

[1] Direct Intensities

AG 129.400 U 157.500

NAME	MV	INT	RSD	BCOR
------	----	-----	-----	------

AG	129.57	8.16	0.00000	
----	--------	------	---------	--

U	157.67	8.10	0.00000	
---	--------	------	---------	--

Store [N/Y] ? Y

Channel Old New Nominal Drift

AG 122.267 129.567 91.6467 *

U 151.833 157.667 118.600 *

[*****] Excessive drift - check correct standard used

Update standard file [Y/N] ? Y

Sample name : CH3

Press <CR> when ready to start measurement

24:132H&n

Sample name : CH3

Programme : ALLELE 14-May-98 11:12:11

[1] Direct Intensities

AL8 51.9800 BG4 132.800 CA15 3692.00 CD 362.000 CR21 142.300 DY26 253.200

K14 123.700 LA13 185.200 LI10 364.400 MN26 1114.00 NA22 210.600 ND16 27.3300

P4 43.4200 RE25 112.700 RU63 95.4600 SE 29.5900 SI7 35.8400 TH 28.6400

TL 6.47000

[1] Direct Intensities

AL8 51.9800 BG4 133.500 CA15 3696.00 CD 363.600 CR21 142.400 DY26 253.100

K14 123.600 LA13 185.300 LI10 364.900 MN26 1114.00 NA22 210.500 ND16 27.3700

P4 42.8400 RE25 112.800 RU63 95.6800 SE 29.6200 SI7 35.9500 TH 28.6700

TL 6.44000

[1] Direct Intensities

AL8 52.0400 BG4 134.200 CA15 3699.00 CD 364.200 CR21 143.100 DY26 253.300

K14 124.100 LA13 185.500 LI10 364.700 MN26 1118.00 NA22 211.000 ND16 27.3600

P4 43.3200 RE25 113.100 RU63 96.1800 SE 29.6800 SI7 35.9900 TH 28.6800

TL 6.40000

NAME	MV	INT	RSD	BCOR
------	----	-----	-----	------

AL8	52.00	6.67	0.00000	
-----	-------	------	---------	--

PG4	133.50	0.52	0.00000
CA15	3095.67	0.11	0.00000
CD	363.67	0.09	0.00000
CR21	142.67	0.28	0.00000
DY26	253.20	0.04	0.00000
K14	123.80	0.21	0.00000
LA13	185.33	0.02	0.00000
LI10	364.67	0.07	0.00000
MN20	1115.33	0.21	0.00000
NA22	210.80	0.09	0.00000
ND16	27.35	0.08	0.00000
P4	43.20	0.69	0.00000
RE25	112.87	0.18	0.00000
RUG3	95.77	0.39	0.00000
SE	29.63	0.15	0.00000
SI7	35.93	0.19	0.00000
TH	28.86	0.07	0.00000
TL	6.44	0.55	0.00000

Store [N/Y] ? Y

Channel	Old	New	Nominal	Drift
AL8	51.0600	52.0000	45.9067	*
PG4	131.333	133.500	101.193	*
CA15	3019.67	3095.67	2507.00	*
CD	349.433	363.667	283.133	*
CR21	137.033	142.667	109.933	*
DY26	249.667	253.200	192.733	*
K14	120.633	123.800	101.910	*
LA13	188.567	185.333	135.867	*
LI10	364.300	364.667	289.267	*
MN20	1869.43	1115.33	937.533	*
NA22	268.767	210.800	162.633	*
ND16	26.9233	27.3533	21.1833	*
P4	41.5633	43.2000	35.4267	*
RE25	115.433	112.867	91.4633	*
RUG3	91.6733	95.7733	72.9633	*
SE	28.7933	29.6300	25.3767	*
SI7	34.7267	35.9333	29.5567	*
TH	28.0360	28.6633	30.3633	*
TL	6.20333	6.43667	7.12333	*

[****] Excessive drift - check correct standard used

Update standard file [Y/N] ? Y

Sample name : CH2

Press <CR> when ready to start measurement

24:132H&n

Sample name : CH2

Programme : ALLELE 14-May-98 11:17:52

[1] Direct Intensities

AS	72.6100	BA02	658.760	BE	411.666	CE18	39.9280	CO	74.0600	CU	429.768
FEG5	246.900	MG6	2051.00	M023	251.800	NI19	76.1100	FB	48.6400	RH12	42.2100
SB	19.9900	SR17	2029.00	TE01	28.8700	TI11	119.100	V	428.100	ZN9	503.860
ZR24	288.900										

[1] Direct Intensities

AS	75.0900	BA02	662.900	BE	414.400	CE18	40.1300	CO	75.2100	CU	432.600
FEG5	248.000	MG6	2064.00	M023	253.000	NI19	76.6800	FB	48.6900	RH12	42.4900
SB	19.9900	SR17	2039.00	TE01	29.6100	TI11	119.960	V	431.200	ZN9	506.360

ZR24 290.600

(1) Direct Intensities

AS	73.5400	RA02	662.400	SE	413.400	CE18	40.1266	CO	75.2706	CU	432.200
FE05	248.500	MG6	2067.00	M023	253.400	NI19	76.7900	PB	48.9800	RH12	42.5000
SR	19.9500	SR17	2034.00	TE01	29.8700	TI11	119.900	V	431.300	ZN9	506.500

ZR24 290.500

NAME	MV	INT	RSD	POOR
AS	73.75	1.78	0.00000	
RA02	661.33	6.35	0.00000	
SE	413.47	6.39	0.00000	
CE18	40.06	6.30	0.00000	
CO	75.11	6.29	0.00000	
CU	431.50	6.36	0.00000	
FE05	248.07	6.41	0.00000	
MG6	2061.33	6.43	0.00000	
M023	252.73	6.33	0.00000	
NI19	76.53	6.48	0.00000	
PB	48.84	6.36	0.00000	
RH12	42.40	6.39	0.00000	
SR	19.94	6.28	0.00000	
SR17	2034.00	6.26	0.00000	
TE01	28.98	6.35	0.00000	
TI11	119.63	6.39	0.00000	
V	430.20	6.42	0.00000	
ZN9	505.67	6.33	0.00000	
ZR24	290.00	6.33	0.00000	

Store [N/Y] ? Y

Channel	Old	New	Nominal	Drift
---------	-----	-----	---------	-------

AS	68.7967	73.7467	51.9367	*
RA02	635.900	661.333	495.433	*
SE	399.633	413.467	283.333	*
CE18	38.7967	40.0567	33.4366	*
CO	72.5633	75.1133	68.8200	*
CU	411.433	431.500	311.633	*
FE05	237.367	248.067	186.467	*
MG6	1978.67	2061.33	1568.67	*
M023	262.600	252.733	198.633	*
NI19	73.1933	76.5267	59.2767	*
PB	46.9400	48.8367	39.9533	*
RH12	40.4500	42.4600	38.1000	*
SR	18.8767	19.9400	11.2900	*
SR17	1964.00	2034.00	1446.67	*
TE01	27.7033	28.9833	22.6633	*
TI11	114.300	119.633	95.8700	*
V	411.067	430.200	323.967	*
ZN9	483.867	505.667	395.200	*
ZR24	279.067	290.600	211.267	*

[*****] Excessive drift - check correct standard used

Update standard file [Y/N] ? Y

>

SAMPLE ALLELE

Result file (CSV) for no storage) = TK01
 Number of results to be stored in the file = 50
 Average number of elements per result = 46
 Sample name = CH3
 Sample number = 1029
 Sample code 1 =
 Sample code 2 =
 Sample code 3 =
 Weight =

Press <CR> when ready to start measurement

24;132Hén

Sample name : CH3

Sample number : 1029

Programme : ALLELE 14-May-90 11:23:26

[1] Direct Intensities

Ag	5.59000	Al	51.9800	AS	24.2000	B	132.900	Ba	5.89000	BE	6.59000
Ca	3100.00	CD	362.400	Ce	12.6000	CO	34.4800	Cr	142.400	CU	12.5300
Dy	253.300	Fe	5.97000	K	123.500	La	185.300	Li	365.300	Mg	3.72000
Mn	1115.00	Mo	5.76000	Na	211.100	Nd	27.3000	Ni	5.15000	P	43.4700
PB	8.49000	Re	112.300	Rh	10.0000	Ru	95.4600	Sb	4.00000	SE	29.2900
Si	35.8900	Sr	18.4500	Te	5.34000	TH	28.6400	Ti	4.36000	TL	6.48000
U	32.1000	V	10.3800	Zn	4.58000	Zr	32.5600				

[1] Direct Intensities

Ag	5.59000	Al	52.2700	AS	25.2000	B	134.300	Ba	5.89000	BE	6.60000
Ca	3120.00	CD	364.200	Ce	12.6300	CO	34.5600	Cr	143.400	CU	12.5400
Dy	254.600	Fe	5.96000	K	124.100	La	186.400	Li	366.900	Mg	3.76000
Mn	1121.00	Mo	5.79000	Na	212.300	Nd	27.4700	Ni	5.16000	P	43.3100
PB	8.49000	Re	113.500	Rh	10.0900	Ru	96.3800	Sb	4.02000	SE	29.5900
Si	36.8700	Sr	18.5000	Te	5.33000	TH	28.7500	Ti	4.34000	TL	6.36000
U	32.1900	V	10.4500	Zn	4.59000	Zr	32.6600				

[1] Direct Intensities

Ag	5.59000	Al	52.4800	AS	25.6900	B	136.600	Ba	5.90000	BE	6.60000
Ca	3135.00	CD	366.700	Ce	12.5900	CO	34.4900	Cr	144.200	CU	12.5700
Dy	256.400	Fe	5.98000	K	125.200	La	187.400	Li	370.100	Mg	3.75000
Mn	1126.00	Mo	5.85000	Na	213.000	Nd	27.5900	Ni	5.16000	P	43.1800
PB	8.41000	Re	114.100	Rh	10.0400	Ru	96.6700	Sb	3.99000	SE	29.6900
Si	36.2300	Sr	18.5900	Te	5.33000	TH	28.9300	Ti	4.34000	TL	6.38000
U	32.1500	V	10.4100	Zn	4.57000	Zr	32.8600				

NAME	MV	INT	CONDEN	RSD	BCOR	SCOR
Ag	5.83	6.6371	-8.23	0.00000	-0.0029	
Al	46.69	10.057	6.59	0.00000	0.00000	
AS	28.91	1.8949	1.73	0.00000	-0.1367	
B	101.86	10.678	1.20	0.00000	0.00000	
Ba	6.34	6.0023	3.69	0.00000	0.00000	
FE	7.64	6.0012	1.17	0.00000	0.00000	
Ca	2525.35	10.973	9.56	0.00000	0.00000	
CD	284.34	10.044	6.60	0.00000	0.00000	
Ce	13.69	6.2598	2.74	0.00000	-0.0024	
CO	32.38	6.1992	5.25	0.00000	-0.0020	
Cr	110.44	10.045	6.65	0.00000	-0.0040	
CU	12.45	6.0505	0.98	0.00000	0.00000	
Dy	103.85	10.664	6.63	0.00000	0.00000	
Fe	6.23	6.0179	2.31	0.00000	0.00000	
K	102.28	56.236	9.87	0.00000	0.00000	
La	136.61	10.656	6.59	0.00000	0.00000	

Li	293.44	10.154	0.57	0.00000	0.00000
Na	4.83	0.0037	2.76	0.00000	0.00000
Mn	841.53	10.048	6.49	0.00000	0.00000
Mo	6.67	0.0318	5.83	0.00000	0.00000
Na	163.85	100.78	3.65	0.00000	0.00000
Ne	21.25	10.091	0.55	0.00000	-0.0040
Ni	5.56	0.0847	0.95	0.00000	0.00000
P	35.51	10.038	0.46	0.00000	0.00000
PB	9.39	0.2912	3.54	0.00000	-0.0153
Re	91.99	10.049	6.69	0.00000	0.00000
Rh	11.11	0.4242	2.90	0.00000	0.00000
Ru	73.26	10.045	6.72	0.00000	-0.0002
SB	4.35	-0.092	-8.16	0.00000	-0.3721
SE	25.38	9.9266	1.83	0.00000	-2.8638
Si	29.56	10.043	6.55	0.00000	0.00000
Sr	15.19	0.0636	0.55	0.00000	0.00000
Te	6.67	0.4277	6.55	0.00000	0.00000
TH	38.41	10.025	6.69	0.00000	-0.6272
Ti	4.98	0.0394	5.66	0.00000	0.00000
TL	7.68	9.6979	5.62	0.00000	-0.0319
U	30.53	1.0079	3.43	0.00000	-0.1989
V	10.43	0.6384	2.87	0.00000	-0.0011
Zn	5.61	0.6070	2.86	0.00000	0.00000
Zr	26.00	0.9108	0.47	0.00000	0.00000

More samples [Y/N] ?

Sample name = CL1
 Sample number = 1030
 Sample code 1 =
 Sample code 2 =
 Sample code 3 =
 Weight =

Press <CR> when ready to start measurement

24:132H&n

Sample name : CL1
 Sample number : 1030
 Programme : ALLELE 14-May-98 11:30:00

[1] Direct Intensities

Ag	5.09000	Al	9.69000	AS	12.4400	B	5.17000	Ba	5.75000	BE	6.11000
Ca	3.40000	CD	7.55000	Ce	11.8700	CO	33.6700	Cr	5.33000	CU	10.4400
Dy	6.72000	Fe	5.57000	K	24.8800	La	7.46000	Li	5.15000	Mg	3.01000
Mn	5.49000	Mo	4.96000	Na	5.79000	Nd	5.69000	Ni	4.56000	P	12.1600
PB	7.23000	Re	4.68000	Rh	8.64000	Ru	8.55000	SB	3.88000	SE	7.63000
Si	5.40000	Sr	5.64000	Te	4.28000	TH	7.65000	Ti	3.89000	TL	4.67000
U	30.6400	V	8.74000	Zn	4.22000	Zr	6.92000				

[1] Direct Intensities

Ag	5.13000	Al	9.70000	AS	12.7700	B	5.18000	Ba	5.75000	BE	6.13000
Ca	3.40000	CD	7.56000	Ce	11.9800	CO	33.8800	Cr	5.32000	CU	10.5000
Dy	6.72000	Fe	5.58000	K	24.9600	La	7.46000	Li	5.16000	Mg	3.06000
Mn	5.52000	Mo	5.66000	Na	5.86000	Nd	5.16000	Ni	4.54000	P	12.1700
PB	7.22000	Re	4.71000	Rh	8.67000	Ru	8.55000	SB	3.88000	SE	7.79000
Si	5.41000	Sr	5.66000	Te	4.32000	TH	7.68000	Ti	3.88000	TL	4.57000
U	30.7800	V	8.86000	Zn	4.20000	Zr	6.92000				

[1] Direct Intensities

Ag	5.16000	Al	9.66000	AS	12.8000	B	5.01000		5.73000	BE	6.14000
Ca	3.39000	CD	7.52000	Ce	11.8100	CO		Cr	5.38000	CU	10.4400
Dy	6.69000	Fe	5.59000	K	24.8100	La	7.42000	Li	5.16000	Mg	3.08000
Mn	5.50000	Mo	5.64000	Na	5.79000	Nd	5.66000	Ni	4.54000	P	11.8800

PB	7.40666	Re	1631	Rn	0.34000	1.0	0.00000	0.0	1.00000	1.0
	5.36000	Sr	5.90000	Tc	0.17000	1.0	0.01000	1.0	0.00000	1.0
	38.6200	V	8.71000	Zn	4.15000	1.0	0.92000			

NAME	MV	INT	CONCEN	RES	PPM	SCUR
Ag	5.58	0.0001	1643.43	0.00000	-0.0001	
Al	13.68	0.0173	28.38	0.00000	0.00000	
As	13.86	0.0018	4634.49	0.00000	-0.0007	
B	6.49	0.0468	15.23	0.00000	0.00000	
Ba	6.22	0.0006	31.49	0.00000	0.00000	
Be	7.33	0.0001	65.45	0.00000	0.00000	
Ca	4.04	0.0002	10.83	0.00000	0.00000	
Cl	8.48	-0.001	-62.45	0.00000	0.00000	
Ce	12.53	0.0032	496.03	0.00000	-0.0004	
Co	31.83	0.0128	245.97	0.00000	-0.0001	
Cr	5.79	0.0008	111.96	0.00000	-0.0002	
Cu	18.96	0.0011	65.47	0.00000	0.00000	
Dy	7.13	0.0005	129.98	0.00000	0.00000	
Fe	5.93	0.0014	36.08	0.00000	0.00000	
K	24.33	0.0421	84.28	0.00000	0.00000	
La	7.81	0.0017	76.98	0.00000	0.00000	
Li	5.58	0.0024	86.58	0.00000	0.00000	
Mg	3.49	0.0008	229.12	0.00000	0.00000	
Mn	6.16	0.0002	65.47	0.00000	0.00000	
Mo	6.06	0.0003	793.64	0.00000	0.00000	
Na	6.33	0.0008	5987.00	0.00000	0.00000	
Nd	5.46	0.0073	53.32	0.00000	-0.0002	
Ni	5.34	-0.0003	**%	0.00000	0.00000	
P	14.95	0.0224	235.17	0.00000	0.00000	
Pb	9.47	0.0158	44.85	0.00000	-0.0002	
Re	5.31	-0.001	-173.19	0.00000	0.00000	
Rh	9.94	0.0169	47.24	0.00000	0.00000	
Ru	2.78	0.0038	43.34	0.00000	-0.0000	
Se	4.38	0.0405	-142.58	0.00000	-0.0237	
Si	8.69	0.0420	110.13	0.00000	-0.0008	
Si	5.97	0.0022	229.08	0.00000	0.00000	
Sn	6.04	0.0001	152.74	0.00000	0.00000	
Te	5.34	0.0054	193.44	0.00000	0.00000	
Th	9.79	0.0020	776.39	0.00000	-0.0012	
Ti	4.55	0.0012	43.36	0.00000	0.00000	
Tl	5.64	0.1248	227.82	0.00000	-0.0014	
U	29.82	0.6523	131.09	0.00000	-0.0002	
V	9.25	0.0002	457.65	0.00000	-0.0001	
Zn	5.32	-0.001	-57.28	0.00000	0.00000	
Zr	7.46	0.0007	43.30	0.00000	0.00000	

More samples [Y/N] ?

Sample name = 901871

Sample number = 1031

Sample code 1 = TK104

Sample code 2 = DIRECT

Sample code 3 =

Weight =

Press <CR> when ready to start measurement

24:132Hén

Sample name : 901871

Sample number : 1031

Sample code 1 : TK104

Sample code 2 : DIRECT

Programme : ALLELE 14-May-96 11:35:55

[1] Direct Intensities

Ag	5.17000	Al	10.7500	AS	12.4900	B	10.9300	Ba	16.9500	BE	6.15000
Ca	354.460	CD	2.00000	Ce	11.7600	CO	33.1000	Cr	6.15000	CU	29.5000
Dy	6.62000	Fe	22.7400	K	25.1600	La	10.6100	Li	5.16000	Mg	55.7200
Mn	29.6400	Mo	6.11000	Na	14.2800	Nd	5.65000	Ni	5.47000	P	15.1000
PB	13.0100	Re	4.68000	Rh	8.55000	Ru	8.76000	SB	3.88000	SE	7.53000
Si	10.7900	Sr	286.600	Te	4.25000	TH	7.60000	Ti	4.07000	TL	4.60000
U	35.7200	V	8.64000	Zn	9.68000	Zr	14.1500				

[1] Direct Intensities

Ag	5.18000	Al	10.7600	AS	12.6900	B	10.9600	Ba	17.0100	BE	6.18000
Ca	356.000	CD	7.92000	Ce	11.7500	CO	33.1800	Cr	6.12000	CU	29.7300
Dy	6.65000	Fe	22.9800	K	25.1600	La	10.6500	Li	5.17000	Mg	56.0500
Mn	29.8500	Mo	6.06000	Na	14.3200	Nd	5.06000	Ni	5.56000	P	15.3300
PB	13.1900	Re	4.68000	Rh	8.57000	Ru	8.78000	SB	3.89000	SE	7.63000
Si	10.8000	Sr	288.000	Te	4.29000	TH	7.61000	Ti	4.07000	TL	4.59000
U	35.9800	V	8.69000	Zn	9.76000	Zr	14.1200				

[1] Direct Intensities

Ag	5.19000	Al	10.7800	AS	12.9800	B	10.9600	Ba	16.9800	BE	6.19000
Ca	354.480	CD	7.95000	Ce	11.8600	CO	33.2900	Cr	6.15000	CU	29.5700
Dy	6.66000	Fe	22.8600	K	25.1900	La	10.6600	Li	5.18000	Mg	55.9000
Mn	29.7600	Mo	6.26000	Na	14.2700	Nd	5.07000	Ni	5.51000	P	15.3000
PB	13.1400	Re	4.67000	Rh	8.59000	Ru	8.76000	SB	3.90000	SE	7.76000
Si	10.7800	Sr	286.600	Te	4.29000	TH	7.64000	Ti	4.06000	TL	4.65000
U	35.9100	V	8.69000	Zn	9.79000	Zr	13.7600				

NAME	MV	INT	CONCEN	RSD	BCOR	SCOR
Ag	5.55	-0.004	-17.69	0.00000	-0.0099	
Al	14.62	0.2721	1.32	0.00000	0.00000	
AS	13.05	-0.045	-75.69	0.00000	-0.0445	
B	9.85	0.4951	0.27	0.00000	0.00000	
Ba	14.61	0.1719	0.27	0.00000	0.00000	
BE	7.36	0.0002	25.98	0.00000	0.00000	
Ca	288.64	1.1372	0.25	0.00000	0.00000	
CD	8.86	0.6107	10.64	0.00000	0.00000	
Ce	12.46	-0.057	-15.43	0.00000	-0.0288	
CO	31.45	-0.124	-18.45	0.00000	-0.0067	
Cr	6.41	0.0473	2.18	0.00000	-0.0136	
CU	24.62	0.4561	0.47	0.00000	0.00000	
Dy	7.69	-0.602	-39.03	0.00000	0.00000	
Fe	18.79	0.7132	0.48	0.00000	0.00000	
K	24.55	0.1852	4.72	0.00000	0.00000	
La	16.11	0.1812	0.82	0.00000	0.00000	
Li	5.51	0.0011	50.06	0.00000	0.00000	
Mg	41.96	0.2570	0.31	0.00000	0.00000	
Mn	24.31	0.2185	0.45	0.00000	0.00000	
Mo	6.94	0.0456	9.21	0.00000	0.00000	
Na	12.81	4.1446	0.31	0.00000	0.00000	
Nd	5.43	-0.020	-21.66	0.00000	-0.0136	
Ni	6.05	0.1315	2.28	0.00000	0.00000	
P	17.04	1.0395	3.86	0.00000	0.00000	
PB	12.91	1.4122	1.56	0.00000	-0.0114	
Re	5.29	-0.002	-24.74	0.00000	0.00000	
Rh	9.86	-0.013	-45.15	0.00000	0.00000	
Ru	8.95	0.0214	6.03	0.00000	-0.0073	
SB	4.30	0.2689	-9.21	0.00000	0.19299	
SE	8.63	-0.061	-79.38	0.00000	-0.0557	

Sc	18.13	1.7386	0.19	0.00000	0.00000
Sr	265.92	1.3076	0.29	0.00000	0.00000
Tc	5.33	-0.000	4.64186	0.00000	0.00000
Tb	9.76	-0.106	-7.62	0.00000	-0.0946
Ti	4.73	0.0173	2.94	0.00000	0.00000
Tl	5.64	0.6356	481.87	0.00000	-0.1085
U	33.42	4.5542	1.74	0.00000	-0.0550
V	9.19	-0.006	-9.65	0.00000	-0.0045
Zn	9.63	0.1100	1.63	0.00000	0.00000
Zr	12.57	0.2516	3.05	0.00000	0.00000

More samples [Y/N] ?

Sample name = 90-791
 Sample number = 1032
 Sample code 1 = TK101
 Sample code 2 = 10XDIL
 Sample code 3 =
 Weight =

Press <CR> when ready to start measurement

24;132H&n

Sample name : 90-791
 Sample number : 1032
 Sample code 1 : TK101
 Sample code 2 : 10XDIL
 Programme : ALLELE 14-May-90 11:42:33

[1] Direct Intensities

Ag	5.12000	Al	50.74000	AS	13.23000	B	167.300	Ba	135.400	BE	6.19000
Ca	1289.00	CD	8.01000	Ce	11.80000	CO	33.54000	Cr	6.45000	CU	10.9900
Dy	6.49000	Fe	25.3600	K	27.7900	La	7.48000	Li	5.20000	Mo	46.0500
Mn	11.4700	Mo	5.52000	Na	67.5400	Nd	5.07000	Ni	5.73000	P	42.3500
Pb	7.44000	Re	4.73000	Rh	8.63000	Ru	8.66000	Sb	3.91000	SE	7.81000
Si	24.5400	Sr	13.9200	Te	4.26000	TH	7.63000	Ti	4.80000	TL	4.70000
U	30.6900	V	8.74000	Zn	6.34000	Zr	8.06000				

[1] Direct Intensities

Ag	5.16000	Al	50.75000	AS	14.1500	B	168.400	Ba	135.400	BE	6.20000
Ca	1287.00	CD	8.13000	Ce	11.86000	CO	33.65000	Cr	6.48000	CU	11.0400
Dy	6.72000	Fe	25.4500	K	28.0600	La	7.56000	Li	5.19000	Mo	46.1600
Mn	11.5100	Mo	5.57000	Na	67.3400	Nd	5.10000	Ni	5.76000	P	42.2100
Pb	7.45000	Re	4.73000	Rh	8.66000	Ru	8.62000	Sb	3.95000	SE	7.77000
Si	24.6300	Sr	13.9500	Te	4.28000	TH	7.65000	Ti	4.86000	TL	4.66000
U	30.8400	V	8.82000	Zn	6.39000	Zr	8.07000				

[1] Direct Intensities

Ag	5.15000	Al	50.7400	AS	14.3300	B	169.160	Ba	135.300	BE	6.22000
Ca	1286.00	CD	8.01000	Ce	11.88000	CO	33.76000	Cr	6.46000	CU	11.0500
Dy	6.75000	Fe	25.4300	K	28.1300	La	7.49000	Li	5.22000	Mo	46.1800
Mn	11.5000	Mo	5.60000	Na	67.1800	Nd	5.10000	Ni	5.75000	P	42.0400
Pb	7.46000	Re	4.73000	Rh	8.65000	Ru	8.69000	Sb	3.89000	SE	7.74000
Si	24.6000	Sr	13.9500	Te	4.31000	TH	7.69000	Ti	4.86000	TL	4.62000
U	30.8100	V	8.81000	Zn	6.39000	Zr	8.01000				

NAME	MV	INT	CONCEN	RSD	SCOR	SCGR
Ag	5.52	0.0030	52.04	0.00000	-0.0003	
Al	44.95	9.7035	6.01	0.00000	0.00000	
AS	13.95	0.1051	39.63	0.00000	-0.1271	
B	82.46	8.0507	6.72	0.00000	0.00000	
Ba	162.95	1.9777	6.04	0.00000	0.00000	
BE	7.38	6.0002	15.27	0.00000	0.00000	

Ca	1043.29	4.1512	0.12	0.00000	0.000000
CD	8.97	0.0133	14.64	0.00000	0.000000
Co	12.52	0.0003	5637.29	0.00000	-0.00009
Cr	31.78	-0.004	-632.47	0.00000	-0.0002
Cr	8.81	0.0086	0.98	0.00000	-0.0004
CU	11.35	0.0144	5.30	0.00000	0.00000
Dy	7.14	0.0007	128.57	0.00000	0.00000
Fe	20.71	0.0196	6.24	0.00000	0.00000
K	23.77	1.6112	5.63	0.00000	0.00000
La	7.85	0.0041	13.64	0.00000	0.00000
Li	5.54	0.0030	28.64	0.00000	0.00000
Mg	34.86	0.2076	0.16	0.00000	0.00000
Mn	16.65	0.0542	0.35	0.00000	0.00000
Mo	6.48	0.0022	7.36	0.00000	0.00000
Na	53.27	30.032	0.31	0.00000	0.00000
Nd	5.46	0.0071	107.63	0.00000	-0.0004
Ni	6.24	0.1667	1.27	0.00000	0.00000
P	34.77	9.6795	0.51	0.00000	0.00000
PB	8.63	0.0526	4.26	0.00000	-0.0120
Re	5.34	0.0028	0.00	0.00000	0.00000
Rh	9.94	0.0099	45.82	0.00000	0.00000
Ru	8.87	0.0077	52.11	0.00000	-0.0034
SB	4.31	0.1351	3.16	0.00000	0.00007
SE	9.75	0.0074	264.81	0.00000	-0.0763
Si	20.79	6.2861	0.24	0.00000	0.00000
Sr	11.94	0.0411	0.21	0.00000	0.00000
Te	5.34	0.0027	377.51	0.00000	0.00000
TH	9.90	0.0050	261.40	0.00000	-0.0030
Ti	5.27	0.0063	0.06	0.00000	0.00000
TL	5.68	0.3930	54.56	0.00000	-0.0034
U	29.88	0.1196	55.76	0.00000	-0.0089
V	9.27	0.0009	107.16	0.00000	-0.0001
Zn	7.01	0.0427	1.35	0.00000	0.00000
Zr	8.27	0.0410	2.77	0.00000	0.00000

More samples [Y/N] ?

Sample name = 98-792
Sample number = 1633
Sample code 1 = TK162
Sample code 2 = 10XDL
Sample code 3 =
Weight =

Press <CR> when ready to start measurement

24:132H5n

Sample name : 96-792
Sample number : 1033
Sample code 1 : TK162
Sample code 2 : 16XDJL

Programme : ALLELE 18-May-96 11:49:59

[1] Direct Intensities

Ag	5.05600	Al	181.700	As	19.1960	R	463.000	Ba	545.668	SE	6.39600
Ca	4629.00	CD	7.87600	Ce	11.7560	CO	33.1560	Cr	5.64600	CU	11.8660
Dy	6.42660	Fe	122.300	K	28.7500	Ls	7.55600	Li	5.38600	Mg	168.660
Mn	9.14600	Mo	5.42600	Na	170.600	Nd	5.68600	Ni	4.74600	P	22.6120
FB	8.66660	Re	4.73060	Rh	8.50660	Ru	8.93660	SB	3.87660	SE	7.92600
Si	167.600	Sr	38.4100	Te	4.35660	TH	7.66600	Ti	7.27600	TL	4.62600
U	36.7860	V	8.86660	Zn	23.9860	Zr	10.7260				

Ag	5.86666	Al	132.866	As	15.7160	B	107.106	Ca	5.161160	Cr	5.30417
Ca	4639.68	CD	7.96666	Ce	11.7566	Cr	33.3266	Cr	5.61066	CU	11.8636
Dy	6.68666	Fe	122.766	K	28.6966	La	7.35666	Li	5.39666	Mo	168.566
Mn	9.15066	Mo	5.33666	Na	170.566	Nd	5.10666	Ni	4.77666	P	22.1766
PB	7.79666	Re	4.75666	Rh	8.54666	Ru	8.96666	SB	3.89666	SE	7.99666
Si	107.766	Sr	38.4966	Te	4.37666	TH	7.53666	Ti	7.36666	TL	4.59666
U	30.8566	V	8.39666	Zn	21.8166	Zr	10.6466				

[1] Direct Intensities

Ag	5.86666	Al	132.866	As	15.7160	B	107.106	Ba	542.466	BE	6.44666
Ca	4639.68	CD	7.96666	Ce	11.7566	Cr	33.3266	Cr	5.64666	CU	11.8966
Dy	6.68666	Fe	122.766	K	28.6966	La	7.62666	Li	5.46666	Mo	168.266
Mn	9.15066	Mo	5.33666	Na	170.566	Nd	5.09666	Ni	4.77666	P	22.5266
PB	8.61666	Re	4.75666	Rh	8.54666	Ru	8.96666	SB	3.98666	SE	8.14666
Si	107.766	Sr	38.4966	Te	4.37666	TH	7.63666	Ti	7.29666	TL	4.68666
U	31.0566	V	8.39666	Zn	20.9866	Zr	10.6466				

NAME	MV	INT	CONCEN	RSD	ECOR	SCOR
Ag	5.47	-0.664	-25.97	0.00066	-0.0005	
Al	144.19)40.558	0.33	0.00066	0.00000	
AS	17.08	6.4843	0.29	0.00066	-0.5364	
B	348.65)35.758	0.48	0.00066	0.00000	
Ba	468.25	8.2198	0.35	0.00066	0.00000	
BE	7.52	0.0008	0.63	0.00066	0.00000	
Ca	3744.68)14.946	0.35	0.00066	0.00000	
CD	8.74	0.00026	4.93	0.00066	0.00000	
Ce	12.46	-0.001	-38.44	0.00066	-0.0015	
CO	31.56	-0.002	-57.64	0.00066	-0.0004	
Cr	6.63	6.6231	3.89	0.00066	-0.0007	
CU	11.95	6.6348	3.28	0.00066	0.00000	
Dy	7.12	-0.006	-115.48	0.00066	0.00000	
Fe	92.96	4.8213	0.18	0.00066	0.00000	
K	27.37	2.6001	2.29	0.00066	0.00000	
La	7.92	0.0096	20.66	0.00066	0.00000	
Li	5.68	0.6134	4.17	0.00066	0.00000	
Mo	86.83	6.5113	0.24	0.00066	0.00000	
Mn	8.96	6.6331	0.42	0.00066	0.00000	
Mo	6.39	0.0175	17.81	0.00066	0.00000	
Na	131.49	80.066	0.35	0.00066	0.00000	
Nd	5.46	6.6068	61.07	0.00066	-0.0007	
Ni	5.53	6.6296	0.12	0.00066	0.00000	
P	21.77	3.3446	2.23	0.00066	0.00000	
PB	9.04	0.1460	2.26	0.00066	-0.0493	
Re	5.36	0.6249	47.19	0.00066	0.00000	
Rh	9.85	-0.622	-54.54	0.00066	0.00000	
Ru	9.65	-0.684	-46.29	0.00066	-0.0492	
SB	4.38	0.2241	-26.63	0.00066	0.14823	
SE	8.93	6.0185	343.53	0.00066	-0.2674	
Si	84.85)33.431	0.26	0.00066	0.00000	
Sr	29.31	6.1616	0.31	0.00066	0.00000	
Te	5.46	0.0391	26.83	0.00066	0.00000	
TH	9.75	-0.623	-41.91	0.00066	-0.0051	
Ti	7.24	0.2951	0.45	0.00066	0.00000	
TL	5.66	0.2284	107.16	0.00066	-0.0058	
U	29.96	6.1913	57.39	0.00066	-0.5291	
V	9.33	6.0027	58.11	0.00066	-0.0002	
Zn	18.37	0.3342	0.18	0.00066	0.00000	
Zr	16.15	0.1330	1.62	0.00066	0.00000	

More samples F1.011.7
 Sample name = 98-793
 Sample number = 1634
 Sample code 1 = TK163
 Sample code 2 = 10XDIL
 Sample code 3 =
 Weight =

Press <CR> when ready to start measurement

24:132Hén

Sample name : 98-793

Sample number : 1634

Sample code 1 : TK163

Sample code 2 : 10XDIL

Programme : ALLELE 14-May-90 11:54:37

[1] Direct Intensities

Ag	5.15000	Al	42.1800	AS	13.9400	B	77.9300	Pa	115.060	BE	6.15000
Ca	1098.00	CD	8.69000	Ce	11.7200	CO	33.2600	Cr	5.48000	CU	11.0900
Dy	6.66000	Fe	17.8600	K	28.6900	La	7.43000	Li	5.18000	Mg	49.7400
Mn	8.00000	Mo	5.13000	Na	68.3400	Nd	5.06000	Ni	4.75000	P	13.7400
PB	7.66000	Re	4.69000	Rh	8.55000	Ru	8.47000	Sb	3.87000	SE	7.64000
Si	32.0100	Sr	12.0300	Te	4.27000	TH	7.57000	Ti	4.56000	TL	4.67000
U	30.3700	V	8.66000	Zn	7.09000	Zr	7.80000				

[1] Direct Intensities

Ag	5.16000	Al	42.1400	AS	14.0100	B	77.9000	Pa	114.800	BE	6.14000
Ca	1095.00	CD	8.66000	Ce	11.7000	CO	33.2400	Cr	5.48000	CU	11.1000
Dy	6.66000	Fe	17.7700	K	28.0100	La	7.46000	Li	5.17000	Mg	49.5400
Mn	8.00000	Mo	5.13000	Na	67.9500	Nd	5.05000	Ni	4.77000	P	13.8500
PB	7.56000	Re	4.69000	Rh	8.53000	Ru	8.57000	Sb	3.92000	SE	7.69000
Si	31.9800	Sr	12.0100	Te	4.31000	TH	7.57000	Ti	4.48000	TL	4.66000
U	30.3600	V	8.66000	Zn	7.01000	Zr	7.80000				

[1] Direct Intensities

Ag	5.16000	Al	42.3400	AS	13.7200	B	78.3600	Pa	115.200	BE	6.16000
Ca	1098.00	CD	8.66000	Ce	11.7400	CO	33.2600	Cr	5.45000	CU	11.1100
Dy	6.66000	Fe	17.8600	K	28.0100	La	7.41000	Li	5.19500	Mg	49.7700
Mn	8.03000	Mo	5.24000	Na	68.3400	Nd	5.01000	Ni	4.78000	P	13.8800
PB	7.55000	Re	4.66000	Rh	8.58000	Ru	8.49500	Sb	3.86000	SE	7.72000
Si	32.0900	Sr	12.0900	Te	4.28000	TH	7.57000	Ti	4.52000	TL	4.68000
U	30.3700	V	8.66000	Zn	7.01000	Zr	7.80000				

NAME	MV	INT	CONDEN	RED	BCOR	SCOR
Ag	5.53	0.0048		9.22	0.00000	0.00045
Al	38.49	7.6929		6.32	0.00000	0.00000
AS	13.82	0.0998		24.56	0.00000	-0.0973
B	59.86	5.6908		0.38	0.00000	0.00000
Ba	87.75	1.6670		0.18	0.00000	0.00000
BE	7.34	0.0001		21.43	0.00000	0.00000
Ca	881.67	3.5065		0.23	0.00000	0.00000
CD	9.34	0.0305		2.77	0.00000	0.00000
Ce	12.42	-0.045		-15.65	0.00000	0.00132
CO	31.48	-0.107		-6.89	0.00000	0.00031
Cr	5.91	0.0128		9.57	0.00000	0.00062
CU	11.41	0.0161		1.47	0.00000	0.00000
Dy	7.18	-0.001		0.00	0.00000	0.00000
Fe	15.03	0.5052		0.14	0.00000	0.00000
K	26.83	1.6331		1.43	0.00000	0.00000
La	7.79	-0.000		-459.00	0.00000	0.00000
Li	5.52	0.0017		33.33	0.00000	0.00000
Mg	37.45	0.2260		0.27	0.00000	0.00000

Mn	8.84	0.0223	0.68	0.00000	0.00000
Mo	4.18	0.0062	41.42	0.00000	0.00000
Mo	53.92	30.446	0.36	0.00000	0.00000
Mo	5.42	-0.014	-81.55	0.00000	0.00002
Ni	5.51	0.0306	5.94	0.00000	0.00000
P	16.89	0.5759	3.67	0.00000	0.00000
PB	8.73	0.0887	16.35	0.00000	-0.0007
Re	5.38	-0.002	-86.48	0.00000	0.00000
Rh	9.86	-0.610	-41.94	0.00000	0.00000
Ru	8.76	-0.006	-102.36	0.00000	-0.0052
SB	4.36	0.2658	16.12	0.00000	0.19568
SE	8.68	-0.003	-286.52	0.00000	-0.0394
Si	26.54	0.7207	0.21	0.00000	0.00000
Sr	11.16	0.0356	0.50	0.00000	0.00000
Te	5.34	0.0048	268.16	0.00000	0.00000
TH	9.72	-0.029	8.96	0.00000	0.00434
Ti	5.64	0.0544	3.17	0.00000	0.00000
TL	5.39	0.4554	11.88	0.00000	0.00497
U	29.68	-0.196	-6.14	0.00000	-0.0070
V	9.18	-0.002	6.72	0.00000	0.00022
Zn	7.52	0.0560	1.65	0.00000	0.00000
Zr	8.89	0.0323	0.00	0.00000	0.00000

More samples [Y/N] ?

Sample name = CH2
 Sample number = 1035
 Sample code 1 =
 Sample code 2 =
 Sample code 3 =
 Weight =

Press <CR> when ready to start measurement

24:132Hén

Sample name : CH2
 Sample number : 1035
 Programme : ALLELE 14-May-98 12:00:07

[1] Direct Intensities

Ag	6.24000	Al	11.2700	As	73.9900	B	7.00000	Ba	666.100	Br	415.400
Ca	13.0400	CD	8.20000	Ce	40.1400	CO	74.9800	Cr	5.54000	CU	433.300
Dy	7.17000	Fe	248.800	K	24.6900	La	8.66000	Li	5.12000	Mo	2066.00
Mn	5.78000	Mo	253.000	Na	26.8500	Nd	5.29000	Ni	76.6100	P	13.9500
PB	48.9100	Re	4.82000	Rh	42.5500	Ru	9.65000	SB	20.6000	SE	10.4900
Si	5.92000	Sr	2652.00	Te	28.9300	TH	9.47000	Ti	120.300	TL	5.07000
U	75.7400	V	432.000	Zn	565.600	Zr	291.300				

[1] Direct Intensities

Ag	6.24000	Al	11.2400	As	73.5000	B	6.00000	Ba	664.500	Br	414.100
Ca	13.0300	CD	8.14000	Ce	40.0300	CO	74.8100	Cr	5.53000	CU	432.500
Dy	7.16000	Fe	248.200	K	24.6500	La	8.61000	Li	5.11000	Mo	2062.00
Mn	5.79000	Mo	251.800	Na	26.8000	Nd	5.29000	Ni	76.3300	P	13.5400
PB	48.7600	Re	4.85000	Rh	42.4100	Ru	9.63000	SB	20.6800	SE	10.6100
Si	5.94000	Sr	2644.00	Te	28.9000	TH	9.58000	Ti	119.900	TL	4.99000
U	75.6500	V	430.700	Zn	564.100	Zr	290.100				

[1] Direct Intensities

Ag	6.19000	Al	11.1900	As	72.4400	B	6.56000	Ba	664.800	Br	412.800
Ca	13.0100	CD	8.00000	Ce	39.9900	CO	74.5000	Cr	5.52000	CU	433.200
Dy	7.13000	Fe	247.500	K	24.6700	La	8.59000	Li	5.16000	Mo	2057.00
Mn	5.76000	Mo	252.300	Na	26.8300	Nd	5.26000	Ni	76.8600	P	13.7400
PB	48.6200	Re	4.81000	Rh	42.4600	Ru	9.56000	SB	19.7800	SE	10.3800
Si	5.92000	Sr	2643.00	Te	28.9500	TH	9.44000	Ti	119.800	TL	5.61000

U	V5.4606 V	420.660 En	502.460 I:	270.660	
NAME	MV INT	CONCEN	F50	DCOR	SCOR
Ag	6.27	0.0071	29.58	0.00000	-0.0056
Al	14.98	0.3838	2.47	0.00000	0.00000
As	51.66	9.4845	1.35	0.00000	-0.3806
B	6.75	0.1722	9.92	0.00000	0.00000
Ba	498.27	10.058	0.13	0.00000	0.00000
Be	283.81	1.0017	0.34	0.00000	0.00000
Ca	11.84	0.0313	0.26	0.00000	0.00000
CD	8.92	0.6151	19.12	0.00000	0.00000
Ce	33.43	9.7569	0.27	0.00000	-0.2479
Co	60.57	9.8582	0.59	0.00000	-0.0574
Cr	5.93	-0.169	-1.15	0.00000	-0.1169
CU	312.18	10.033	0.10	0.00000	0.00000
Dy	7.45	0.0185	4.56	0.00000	0.00000
Fe	186.54	10.084	0.27	0.00000	0.00000
K	24.16	-0.067	-15.06	0.00000	0.00000
La	8.66	0.0674	3.37	0.00000	0.00000
Li	5.46	-0.082	-25.00	0.00000	0.00000
Mg	1500.91	10.002	0.22	0.00000	0.00000
Mn	6.37	0.0027	5.15	0.00000	0.00000
Mo	198.35	9.9852	0.24	0.00000	0.00000
Na	22.37	10.260	0.12	0.00000	0.00000
Nd	5.59	-0.024	-30.68	0.00000	-0.1169
Ni	59.13	9.9731	0.38	0.00000	0.00000
P	16.05	0.5588	11.76	0.00000	0.00000
PR	39.87	9.8783	0.24	0.00000	-0.0961
Re	5.41	0.0117	16.43	0.00000	0.00000
Rh	38.16	10.022	0.21	0.00000	0.00000
Ru	9.57	0.0236	21.75	0.00000	-0.1020
SB	11.32	10.115	-0.15	0.00000	-18.225
SE	10.82	1.3446	4.69	0.00000	-0.3282
Si	6.37	0.1757	2.15	0.00000	0.00000
Sr	1455.43	10.061	0.24	0.00000	0.00000
Te	22.62	9.9771	0.16	0.00000	0.00000
TH	11.57	0.0558	20.74	0.00000	-0.8147
Ti	96.16	10.032	0.23	0.00000	0.00000
TL	5.97	1.4253	15.58	0.00000	-0.9351
U	61.62	33.233	0.32	0.00000	-2.1876
V	324.36	9.9761	0.30	0.00000	-0.0366
Zn	393.98	9.9698	0.30	0.00000	0.00000
Zr	211.60	10.016	0.26	0.00000	0.00000

More samples [Y/N] ?

Sample name = CL1
 Sample number = 1036
 Sample code 1 =
 Sample code 2 =
 Sample code 3 =
 Weight =

Press <CR> when ready to start measurement

24;132Hén
 Sample name : CL1
 Sample number : 1036
 Programme : ALLELE 14-May-90 12:07:18
 [1] Direct Intensities

Ag	5.61000	Al	9.37000	As	12.1600	B	1.16000	Br	7.10000	C	7.11000
Ca	3.36000	Cr	7.47000	Co	11.7000	Cr	33.3600	Cr	5.29000	Cu	10.3900
Dy	6.65000	Fe	5.53000	K	24.7100	La	7.39000	Li	5.13000	Mg	3.61000
Mn	5.44000	Mo	4.99000	Na	5.73000	Nd	5.67000	Ni	4.51000	F	11.9700
PB	7.11000	Re	4.68000	Rh	8.58000	Ru	8.49000	Sb	3.88000	Se	7.68000
Si	5.36000	Sr	5.61000	Te	4.36000	Th	7.59000	Ti	3.85000	Tl	4.67000
U	30.3700	V	8.68000	Zn	4.21000	Zr	6.86000				

[1] Direct Intensities

Ag	5.68000	Al	9.67000	As	12.72000	B	5.25000	Br	5.71000	Se	6.16000
Ca	3.38000	Cr	7.56000	Co	11.76000	Cr	33.3500	Cr	5.27000	Cu	10.3900
Dy	6.65000	Fe	5.53000	K	24.72000	La	7.39000	Li	5.14000	Mg	3.61000
Mn	5.45000	Mo	5.67000	Na	5.76000	Nd	5.64000	Ni	4.51000	F	11.9200
PB	7.24000	Re	4.67000	Rh	8.59000	Ru	8.49000	Sb	3.84000	Se	7.58000
Si	5.37000	Sr	5.60000	Te	4.26000	Th	7.59000	Ti	3.85000	Tl	4.66000
U	30.3400	V	8.67000	Zn	4.20000	Zr	6.85000				

[1] Direct Intensities

Ag	5.10000	Al	9.66000	As	13.66000	B	5.26000	Br	5.76000	Se	6.11000
Ca	3.43000	Cr	7.55000	Co	11.75000	Cr	33.4200	Cr	5.26000	Cu	10.3900
Dy	6.64000	Fe	5.53000	K	24.76000	La	7.39000	Li	5.13000	Mg	3.61000
Mn	5.44000	Mo	4.98000	Na	5.77000	Nd	5.63000	Ni	4.52000	F	11.8200
PB	7.25000	Re	4.71000	Rh	8.58000	Ru	8.51000	Sb	3.86000	Se	7.58000
Si	5.36000	Sr	5.59200	Te	4.36000	Th	7.59000	Ti	3.84000	Tl	4.70000
U	30.3400	V	8.68000	Zn	4.19000	Zr	6.82000				

NAME	MV	INT	CONCEN	RSD	BCOR	SCOR
------	----	-----	--------	-----	------	------

Ag	5.49	-0.001	-131.78	0.00000	0.00050	
Al	13.72	0.0118	28.00	0.00000	0.00060	
AS	13.69	0.0105	424.33	0.00000	0.00172	
B	5.60	0.0525	5.97	0.00000	0.00000	
Ba	6.19	-0.000	-173.16	0.00000	0.00000	
BE	7.31	0.0000	149.95	0.00000	0.00000	
Ca	4.63	0.0002	77.26	0.00000	0.00000	
CD	8.45	-0.002	-57.74	0.00000	0.00000	
Ce	12.45	-0.032	-6.17	0.00000	0.00145	
CO	31.58	-0.072	-12.65	0.00000	0.00034	
Cr	5.76	-0.002	-71.13	0.00000	0.00068	
CU	10.92	-0.000	-138.57	0.00000	0.00000	
DY	7.89	-0.002	-11.55	0.00000	0.00000	
Fe	5.91	-0.000	8.00	0.00000	0.00000	
K	24.22	-0.029	-40.75	0.00000	0.00000	
La	7.77	-0.001	6.00	0.00000	0.00000	
Li	5.48	-0.001	-34.64	0.00000	0.00000	
Mg	3.50	0.0001	0.00	0.00000	0.00000	
Mn	6.12	-0.000	-15.75	0.00000	0.00000	
Mo	6.06	0.0000	6631000	0.00000	0.00000	
Na	6.31	-0.011	-42.84	0.00000	0.00000	
Nd	5.42	-0.011	-82.40	0.00000	0.00068	
Ni	5.32	-0.005	-17.32	0.00000	0.00000	
P	14.85	-0.027	-100.64	0.00000	0.00000	
PB	8.94	0.0045	411.56	0.00000	0.00055	
Re	5.30	-0.001	-156.11	0.00000	0.00000	
Rh	9.89	-0.009	-19.25	0.00000	0.00000	
Ru	8.75	-0.003	-65.54	0.00000	0.00000	
Sb	4.23	0.1270	42.04	0.00000	0.13282	
SE	8.66	-0.023	-27.53	0.00000	0.00243	
Si	5.94	-0.009	-21.65	0.00000	0.00000	
Sr	6.01	-0.000	-75.81	0.00000	0.00000	
Te	5.34	0.0040	230.54	0.00000	0.00000	
TH	9.74	-0.017	-13.96	0.00000	0.00477	

Fr	3.51	-0.002	-14.74	6.00000	0.00000
Tl	5.59	0.4920	21.60	0.00000	0.00547
U	29.59	-0.207	-6.51	0.00000	0.00033
V	9.19	-0.001	-2.52	0.00000	0.00023
Zn	5.32	-0.001	-33.34	0.00000	0.00000
Zr	7.41	-0.002	-48.84	0.00000	0.00000

More samples [Y/N] ?

Sample name = 98-794
 Sample number = 1037
 Sample code 1 = TK108
 Sample code 2 = 10XDIL
 Sample code 3 =
 Weight =

Press <CR> when ready to start measurement

24;132Hén

Sample name : 98-794
 Sample number : 1037
 Sample code 1 : TK108
 Sample code 2 : 10XDIL
 Programme : ALLELE 14-May-96 12:12:35

[1] Direct Intensities

Ag	5.18000	Al	9.81000	AS	12.86000	B	5.48000	Ba	6.59000	SE	6.16000
Ca	156.900	CD	7.62000	Ce	11.8100	CO	33.5700	Cr	6.06000	CU	10.6600
Dy	6.71000	Fe	10.4100	K	25.1400	La	7.46000	Li	5.16000	Mg	6.36000
Mn	148.800	Mo	5.01000	Na	1163.00	Nd	5.09000	Ni	4.98000	P	12.0700
Pb	7.28000	Re	4.69000	Rh	8.66000	Ru	8.62000	Sb	3.80000	SE	7.89000
Si	5.58000	Sr	6.71000	Te	4.28000	Th	7.64600	Ti	9.68000	TL	4.71000
U	30.9900	V	8.76000	Zn	5.41000	Zr	48.6400				

[1] Direct Intensities

Ag	5.18000	Al	9.81000	AS	13.0200	B	5.66000	Ba	6.60000	SE	6.15000
Ca	156.700	CD	7.60000	Ce	11.8000	CO	33.5500	Cr	6.06000	CU	10.6700
Dy	6.73000	Fe	10.4100	K	25.0600	La	7.43000	Li	5.16000	Mg	6.35000
Mn	148.500	Mo	5.18000	Na	1164.00	Nd	5.07000	Ni	4.96000	P	11.7500
Pb	7.24000	Re	4.73000	Rh	8.66000	Ru	8.55000	Sb	3.83000	SE	7.85000
Si	5.55000	Sr	6.68000	Te	4.30000	Th	7.62000	Ti	9.67000	TL	4.70000
U	30.9600	V	8.79000	Zn	5.42000	Zr	48.7000				

[1] Direct Intensities

Ag	5.18000	Al	9.81000	AS	13.1000	B	5.59000	Ba	6.63000	
Ca	156.300	CD	7.59000	Ce	11.8300	CO	33.6100	Cr	6.06	
Dy	6.72000	Fe	10.3800	K	25.1400	La	7.45			
Mn	148.600	Mo	5.19000	Na	1158.00	Nd				
Pb	7.36000	Re	4.71000	Rh						7.8600
Si	5.55000	Sr								TL
U	31.0400	V								4.71

NAME :

Ag			-0.00007
		96	0.00000
		71	0.00000
		4.39	0.
			0.0137
			7.35
			0.00
			128.07

CD
Ce

					0.00000
				360	0.00000
			.11	0.00000	0.00000
		16	87.26	0.00000	0.00000
		3563.92	6.28	0.00000	0.00000
	5.45	0.0026	219.51	0.00000	-0.0010
	5.66	0.0058	2.36	0.00000	0.00000
P	14.85	-0.030	-171.54	0.00000	0.00000
PB	8.51	0.0271	46.50	0.00000	-0.0009
Re	5.32	0.0007	268.03	0.00000	0.00000
Rh	9.95	0.6128	13.32	0.00000	0.00000
Ru	8.81	0.0060	67.21	0.00000	-0.0020
SB	4.27	-0.010	-129.79	0.00000	0.04240
SE	8.88	0.1682	24.07	0.00000	-0.0123
Si	6.89	0.0557	18.19	0.00000	0.00000
Sr	6.79	0.0053	1.61	0.00000	0.00000
Te	5.36	0.0148	113.55	0.00000	0.00000
TH	9.78	-0.009	-76.64	0.00000	-0.0069
Ti	9.12	0.5010	8.17	0.00000	0.00000
TL	5.72	0.6407	4.74	0.00000	-0.0000
U	30.04	-0.021	-153.62	0.00000	-0.3222
V	9.27	0.0009	51.44	0.00000	0.00002
Zn	6.27	0.0237	8.84	0.00000	0.00000
Zr	37.51	1.4755	8.63	0.00000	0.00000

More samples [Y/N] ?

Sample name = 901872
 Sample number = 1038
 Sample code 1 = TK106
 Sample code 2 = 10XDIL
 Sample code 3 =
 Weight =

Press <CR> when ready to start measurement

24;132H&n

Sample name : 901872
 Sample number : 1038
 Sample code 1 : TK106
 Sample code 2 : 10XDIL
 Programme : ALLELE 14-May-90 12:18:13
 [1] Direct Intensities

Ag	5.09000	Al	95.5800	AS	16.2100	B	190.100	Ba	291.100	BE	6.28000
Ca	2819.00	CD	7.69000	Cr	11.7700	CO	33.3300	Cr	5.65000	CU	72.6200
Dy	6.68000	Fe	198.000	K	27.1200	La	7.55000	Li	5.29000	Mg	148.960
Mn	8.62000	Mo	5.63000	Na	88.5300	Nd	5.08000	Ni	4.60000	P	12.7400
PB	7.81000	Re	4.69000	Rh	8.50000	Ru	9.20000	SB	3.86000	SE	7.95000
Si	37.6300	Sr	23.7900	Te	4.35000	TH	7.50000	Ti	5.65000	TL	4.69000
U	30.6400	V	8.79000	Zn	18.6500	Zr	9.07000				

[1] Direct Intensities

Ag	5.07000	Al	95.6200	AS	16.0600	B	191.600	Ba	290.900	BE	6.29000
Ca	2821.00	CD	7.75000	Cr	11.7900	CO	33.4000	Cr	5.65000	CU	72.6800
Dy	6.69000	Fe	198.400	K	27.1200	La	7.55000	Li	5.27000	Mg	149.000
Mn	8.61000	Mo	5.74000	Na	88.5700	Nd	5.07000	Ni	4.60000	P	12.6800

Fe	7.81600	Re	4.76000	Si	8.53000	Pu	7.14600	Si	3.96000	Se	7.30000
Sr	37.6600	Sr	23.8600	Te	4.33000	Th	7.59600	Ti	5.48600	Tl	4.71000
U	38.6900	V	8.26000	Zn	18.7600	Zr	9.81000				

[1] Direct Intensities

As	5.65600	Al	95.7460	As	16.1666	B	191.866	Pa	291.460	RE	6.25600
Ca	2823.00	CD	7.68000	Ce	11.7500	CO	33.3400	Cr	5.63000	CU	72.7900
Dy	6.66600	Fe	197.966	K	27.1166	La	7.56000	Li	5.26000	Mo	148.900
Mn	6.61600	Mo	5.64000	Na	88.7500	Nd	5.67000	Ni	4.66000	P	12.3900
PB	7.68600	Re	4.76000	Rh	8.57000	Ru	9.15000	SB	3.84600	SE	7.87000
Si	37.5900	Sr	23.7900	Te	4.33000	Th	7.57000	Ti	5.66000	Tl	4.69000
U	38.6600	V	8.76000	Zn	18.7500	Zr	8.99000				

NAME	MV	INT	CONCEN	RSD	BCOR	SCOR
------	----	-----	--------	-----	------	------

As		5.47	-0.603	-55.74	0.00000	-0.0001
Al		79.62)20.296	0.16	0.00000	0.00000
As		15.24	0.2658	0.56	0.00000	-0.2992
B		144.17)14.473	0.50	0.00000	0.00000
Ba		219.19	4.3535	0.69	0.00000	0.00000
Be		7.43	0.0064	12.25	0.00000	0.00000
Ca		2284.68	9.1118	0.67	0.00000	0.00000
CD		8.60	0.0037	29.12	0.00000	0.00000
Ce		12.46	-0.029	-23.99	0.00000	-0.0002
CO		31.57	-0.677	-11.75	0.00000	-0.0000
Cr		6.04	0.0247	2.93	0.00000	-0.0001
CU		55.31	1.4790	0.14	0.00000	0.00000
Dy		7.11	-0.001	-49.49	0.00000	0.00000
Fe		149.27	7.9398	0.14	0.00000	0.00000
K		26.68	1.1684	0.25	0.00000	0.00000
La		7.89	0.0077	4.23	0.00000	0.00000
Li		5.59	0.0069	12.39	0.00000	0.00000
Mo		169.64	0.7090	0.04	0.00000	0.00000
Mn		8.49	0.0282	0.18	0.00000	0.00000
Na		69.48	40.460	0.14	0.00000	0.00000
Nd		5.45	0.0029	149.98	0.00000	-0.0001
Ni		5.38	0.0074	0.06	0.00000	0.00000
P		15.31	0.1955	31.91	0.00000	0.00000
PB		8.86	0.1156	15.48	0.00000	-0.0244
Re		5.33	0.0015	227.17	0.00000	0.00000
Rh		9.83	-0.011	-15.75	0.00000	0.00000
Ru		9.24	-0.007	-51.97	0.00000	-0.0010
SB		4.27	0.0079	26.91	0.00000	0.14043
SE		8.82	0.0356	121.39	0.00000	-0.1666
Si		38.86	10.554	0.11	0.00000	0.00000
Sr		18.94	0.0396	0.03	0.00000	0.00000
Te		5.38	0.0243	19.24	0.00000	0.00000
TH		9.73	-0.029	-13.55	0.00000	-0.0005
Ti		5.95	0.1549	0.85	0.00000	0.00000
TL		5.71	0.5940	10.35	0.00000	-0.0006
U		29.79	0.0071	493.00	0.00000	-0.0165
V		9.27	0.0009	52.86	0.00000	-0.0000
Zn		16.61	0.2290	0.42	0.00000	0.00000
Zr		8.97	0.0755	1.95	0.00000	0.00000

More samples [Y/N] ?

Sample name = 90-794

Sample number = 1039

Sample code 1 = NI

Sample code 1 : 10XDIL

Sample code 3 :

Weight =

Press <CR> when ready to start measurement

24:132H6n

Sample name : 98-794

Sample number : 1039

Sample code 1 : NI

Sample code 2 : 10XDIL

Programme : ALLELE 14-May-98 12:25:18

[1] Direct Intensities

Ag	5.11600	Al	9.95000	As	14.3200	B	6.25000	Ba	6.01000	Br	6.16000
Ca	36.5200	CD	8.40000	Ce	11.8600	CO	33.7600	Cr	5.70000	CU	10.9700
Dy	6.71000	Fe	9.63000	K	3460.60	La	7.44000	Li	5.13000	Mg	8.36000
Mn	107.600	Mo	5.11000	Na	6.96000	Nd	5.08000	Ni	793.500	P	12.5000
PB	7.57000	Re	4.95000	Rh	8.71000	Ru	8.86000	SB	4.23000	SE	7.90000
Si	5.66000	Sr	5.75000	Te	4.39000	TH	7.65000	Ti	7.18000	TL	4.79000
U	30.5800	V	8.88000	Zn	25.6200	Zr	7.03000				

[1] Direct Intensities

Ag	5.13000	Al	9.98000	As	14.8900	B	6.13000	Ba	6.06000	Br	6.18000
Ca	36.6600	CD	8.58000	Ce	11.8900	CO	33.9900	Cr	5.74000	CU	11.0300
Dy	6.78000	Fe	9.65000	K	3471.60	La	7.48000	Li	5.16000	Mg	8.35000
Mn	108.000	Mo	5.07000	Na	6.99000	Nd	5.09000	Ni	791.300	P	12.8900
PB	7.58000	Re	5.61000	Rh	8.75000	Ru	8.82000	SB	4.24000	SE	7.87000
Si	5.65000	Sr	5.75000	Te	4.39000	TH	7.67000	Ti	7.20000	TL	4.79000
U	30.7800	V	8.97000	Zn	25.2700	Zr	7.06000				

[1] Direct Intensities

Ag	5.13000	Al	9.97000	As	14.1200	B	5.99000	Ba	6.02000	Br	6.19000
Ca	36.8100	CD	8.54000	Ce	11.8900	CO	33.9900	Cr	5.74000	CU	11.0300
Dy	6.77000	Fe	9.67000	K	3475.60	La	7.50000	Li	5.16000	Mg	8.38000
Mn	108.100	Mo	5.14000	Na	7.08000	Nd	5.09000	Ni	793.400	P	12.2400
PB	7.71000	Re	5.68000	Rh	8.75000	Ru	8.86000	SB	4.28000	SE	8.00000
Si	5.68000	Sr	5.76000	Te	4.39000	TH	7.69000	Ti	7.21000	TL	4.78000
U	30.8100	V	8.95000	Zn	25.4800	Zr	7.08000				

NAME	MV	INT	CONCEN	RSD	BCOR	SCOR
Ag	5.51	0.6614	49.65	0.00000	-0.0002	
Al	14.02	0.0841	4.28	0.00000	0.00000	
As	14.00	0.2415	8.14	0.00000	-0.0020	
K	6.25	0.1207	8.36	0.00000	0.00000	
Ba	6.45	0.0652	10.50	0.00000	0.00000	
Br	7.36	0.0002	20.83	0.00000	0.00000	
Ca	30.97	0.1973	8.44	0.00000	0.00000	
CD	9.22	0.0262	10.16	0.00000	0.00000	
Ce	12.54	0.0166	54.36	0.00000	-0.0004	
CO	31.96	0.0570	55.97	0.00000	-0.0001	
Cr	6.10	0.0305	4.44	0.00000	-0.0003	
CU	11.35	0.0146	5.87	0.00000	0.00000	
Dy	7.16	0.0023	66.81	0.00000	0.00000	
Fe	8.97	0.1696	6.49	0.00000	0.00000	
K	2725.30	11739.4	8.23	0.00000	0.00000	
La	7.83	0.0032	53.91	0.00000	0.00000	
Li	5.49	0.0000		0.00000	0.00000	
Mg	7.38	0.0260	8.75	0.00000	0.00000	
Mn	22.72	0.9210	6.60	0.00000	0.00000	
Mo	6.13	0.0038	37.63	0.00000	0.00000	
Na	7.24	0.5865	1.75	0.00000	0.00000	
Nd	5.45	0.0057	39.77	0.00000	-0.0003	

Al	593.49	1169.35	6.87	0.00000	0.00000
P	15.25	6.1741	66.21	0.00000	0.00000
PB	8.75	0.1045	17.69	0.00000	-0.00003
Pa	5.54	0.0265	11.21	0.00000	0.00000
Rh	10.82	0.0365	18.72	0.00000	0.00000
Ru	8.99	0.0338	16.33	0.00000	-0.0017
Sb	4.46	0.6681	-2.05	0.00000	-0.1044
Se	8.86	0.1616	23.76	0.00000	-0.0028
Si	6.17	0.0695	5.59	0.00000	0.00000
Sr	6.12	0.0007	4.12	0.00000	0.00000
Te	5.41	0.0459	6.00	0.00000	0.00000
TH	9.82	0.0123	59.05	0.00000	-0.0020
Ti	7.16	0.2874	6.46	0.00000	0.00000
TL	5.78	1.0788	2.65	0.00000	-0.0023
U	29.85	0.0053	115.17	0.00000	-0.0013
V	9.38	0.0843	23.37	0.00000	-0.0001
Zn	21.67	0.4199	8.92	0.00000	0.00000
Zr	7.56	0.0068	14.80	0.00000	0.00000

More samples [Y/N] ?

Sample name = 98-794
 Sample number = 1649
 Sample code 1 = NI
 Sample code 2 = 166X
 Sample code 3 =
 Weight =

Press <CR> when ready to start measurement

24;132H&n

Sample name : 98-794
 Sample number : 1649
 Sample code 1 : NI
 Sample code 2 : 166X
 Programme : ALLELE 14-May-98 12:32:47

[1] Direct Intensities

Ag	5.64000	Al	9.60000	AS	12.70000	B	5.20000	Ba	5.68000	Br	6.08000
Ca	11.6600	CD	7.60000	Ce	11.6400	CO	33.6400	Cr	5.20000	CU	10.4200
Dy	6.60000	Fe	5.90000	K	406.100	La	7.33000	Li	5.09000	Mg	3.84000
Mn	16.2700	Mo	4.94000	Na	5.08000	Nd	5.00000	Ni	38.9700	P	11.8100
PB	7.15000	Re	4.63000	Rh	8.53000	Ru	8.46000	SB	3.88000	SE	7.64000
Si	5.33000	Sr	5.50000	Te	4.26000	TH	7.54000	Ti	4.18000	TL	4.66000
U	30.0600	V	8.59000	Zn	6.44000	Zr	6.20000				

[1] Direct Intensities

Ag	5.05000	Al	9.62000	AS	12.73000	B	5.18000	Ba	5.70000	Br	6.08000
Ca	10.9800	CD	7.41000	Ce	11.6800	CO	33.1400	Cr	5.30000	CU	10.4200
Dy	6.66000	Fe	5.93000	K	402.000	La	7.37000	Li	5.11000	Mg	3.88000
Mn	16.2800	Mo	4.98000	Na	5.09000	Nd	5.01000	Ni	38.6900	P	12.1300
PB	7.22000	Re	4.66000	Rh	8.54000	Ru	8.51000	SB	3.82000	SE	7.74000
Si	5.36000	Sr	5.57000	Te	4.29000	TH	7.57000	Ti	4.20000	TL	4.69000
U	30.1400	V	8.65000	Zn	6.41000	Zr	6.81000				

[1] Direct Intensities

Ag	5.64000	Al	9.60000	AS	12.89000	B	5.14000	Ba	5.70000	Br	6.08000
Ca	10.9900	CD	7.58000	Ce	11.6600	CO	33.1200	Cr	5.30000	CU	10.4200
Dy	6.59000	Fe	5.90000	K	403.400	La	7.34000	Li	5.11000	Mg	3.84000
Mn	16.2800	Mo	4.90000	Na	5.08000	Nd	4.99000	Ni	38.5900	P	11.9100
PB	7.17000	Re	4.66000	Rh	8.54000	Ru	8.36000	SB	3.81000	SE	7.70000
Si	5.34000	Sr	5.58000	Te	4.25000	TH	7.54000	Ti	4.19000	TL	4.69000
U	30.1100	V	8.64000	Zn	6.45000	Zr	6.80000				

NAME	MV INT	CONCEN	PCT	PPM	SCOR	SCOR
Ag	5.46	-0.004	-9.55	0.00000	0.00005	
Al	13.74	-0.001	-346.45	0.00000	0.00000	
As	13.11	0.0167	98.61	0.00000	0.00349	
B	5.55	0.0471	5.64	0.00000	0.00000	
Ba	6.19	-0.006	-86.40	0.00000	0.00000	
Be	7.29	-0.000	0.00	0.00000	0.00000	
Ca	16.19	0.0247	0.13	0.00000	0.00000	
Co	8.47	-0.001	-223.73	0.00000	0.00000	
Ce	12.38	-0.065	-18.55	0.00000	0.00277	
Cr	31.39	-0.139	-9.17	0.00000	0.00064	
Cr	5.77	0.0006	122.71	0.00000	0.00131	
CU	10.94	0.0005	173.21	0.00000	0.00000	
Py	7.05	-0.004	-5.77	0.00000	0.00000	
Fe	6.19	0.0154	4.64	0.00000	0.00000	
K	321.54)191.44	6.55	0.00000	0.00000	
La	7.74	-0.004	-29.74	0.00000	0.00000	
Li	5.46	-0.003	-24.74	0.00000	0.00000	
Mg	4.12	0.0042	2.30	0.00000	0.00000	
Mn	14.23	0.0973	0.65	0.00000	0.00000	
Mo	6.00	-0.003	-54.55	0.00000	0.00000	
Na	6.48	0.0472	10.34	0.00000	0.00000	
Nd	5.39	-0.032	-13.79	0.00000	0.00131	
Ni	68.43)11.698	6.24	0.00000	0.00000	
P	14.87	-0.016	-327.42	0.00000	0.00000	
PB	8.43	0.0027	233.74	0.00000	0.00107	
Re	5.27	-0.005	-34.54	0.00000	0.00000	
Rh	9.85	-0.023	-7.53	0.00000	0.00000	
Ru	8.71	-0.009	-102.16	0.00000	-0.0002	
Sb	4.28	0.2436	17.68	0.00000	0.25529	
SE	8.68	0.0408	70.53	0.00000	0.00300	
Si	5.92	-0.015	-32.73	0.00000	0.00000	
Sr	6.00	-0.000	-15.75	0.00000	0.00000	
Te	5.33	-0.004	-268.16	0.00000	0.00000	
TH	9.78	-0.034	-21.76	0.00000	0.00911	
Ti	4.77	0.0276	3.13	0.00000	0.00000	
TL	5.70	0.5158	17.98	0.00000	0.01046	
U	29.42	-0.396	-9.94	0.00000	0.00064	
V	9.15	-0.002	-29.83	0.00000	0.00044	
Zn	7.05	0.0439	6.94	0.00000	0.00000	
Zr	7.38	-0.003	-6.93	0.00000	0.00000	

More samples [Y/N] ?

Sample name = CH3
 Sample number = 1641
 Sample code 1 =
 Sample code 2 =
 Sample code 3 =
 Weight =

Press <CR> when ready to start measurement

24;132H&n

Sample name : CH3
 Sample number : 1641
 Programme : ALLELE 14-May-90 12:59:33
 [1] Direct Intensities

Ag	5.99000	Al	52.6900	As	25.1900	B	135.600	Ba	5.90000	BE	6.62600
Ca	3151.60	CD	376.100	Ce	12.6400	CO	34.5400	Cr	145.000	CU	12.5800

Dy	259.160	Fe	5.96660	K	124.200	La	189.060	Li	247.160	Mo	7.71600
Mn	1134.00	Mo	5.83660	Ni	214.460	Lu	27.6866	Li	5.13660	P	40.4866
Pb	8.56660	Fe	114.760	Sb	10.6566	Ru	97.1566	Sb	3.98660	SE	29.8766
Si	36.3566	Sr	18.6566	Te	5.34660	TH	28.9966	Ti	4.31660	TL	6.57660
U	32.1866	V	10.4466	Zn	4.58660	Zr	32.9766				

[1] Direct Intensities

Ag	5.68660	Al	52.8666	As	25.4766	B	136.966	Ba	5.96660	Br	6.64666
Ca	3153.00	CD	371.660	Ce	12.6660	CO	34.6660	Cr	145.666	CU	12.6660
Dy	259.560	Fe	6.81660	K	124.760	La	189.666	Li	378.160	Mo	3.73666
Mn	1136.00	Mo	5.93660	Ns	214.260	Nd	27.6866	Ni	5.19660	P	43.6866
Pb	8.56660	Fe	115.260	Rh	10.1160	Ru	97.1566	Sb	3.98660	SE	30.0466
Si	36.5066	Sr	18.7160	Te	5.34660	TH	29.0366	Ti	4.31660	TL	6.52666
U	32.2160	V	10.4566	Zn	4.58660	Zr	33.0666				

[1] Direct Intensities

Ag	5.59660	Al	53.0666	As	25.2566	B	138.066	Ba	5.89660	Br	6.64666
Ca	3171.00	CD	372.966	Ce	12.6660	CO	34.6160	Cr	145.266	CU	12.6266
Dy	259.660	Fe	6.06660	K	124.960	La	189.566	Li	371.360	Mo	3.72666
Mn	1141.00	Mo	5.94660	Ns	214.866	Nd	27.8166	Ni	5.19660	P	44.6966
Pb	8.49660	Fe	115.366	Rh	10.6966	Ru	93.2466	Sb	3.95660	SE	30.1666
Si	36.5966	Sr	18.7466	Te	5.38660	TH	29.1666	Ti	4.34660	TL	6.54666
U	32.2160	V	10.4666	Zn	4.58660	Zr	33.1466				

NAME	MV	INT	CONCEN	RSD	SCOR	SCOR
Ag	5.84	0.0373	1.19	0.00000	-0.2638	
Al	46.54	10.196	6.36	0.00000	0.26266	
As	21.69	1.9354	1.22	0.00000	-0.1388	
Br	103.68	10.259	0.91	0.00000	0.00000	
Ca	6.34	0.6029	3.04	0.00000	0.00000	
CD	7.67	0.0013	2.18	0.00000	0.00000	
Ce	2557.72	10.263	6.35	0.00000	0.00000	
CO	299.52	10.233	0.39	0.00000	0.00000	
Cr	13.12	0.2761	1.45	0.00000	-0.0087	
CU	32.43	0.2168	4.20	0.00000	-0.0020	
Dy	112.16	10.269	0.43	0.00000	-0.0041	
Fe	12.48	0.0518	6.92	0.00000	0.00000	
La	136.68	10.224	6.31	0.00000	0.00000	
Li	6.25	0.0198	3.32	0.00000	0.00000	
Mn	102.54	50.404	6.36	0.00000	0.00000	
Nd	138.36	10.195	6.34	0.00000	0.00000	
Na	292.59	20.306	6.36	0.00000	0.00000	
Mo	4.01	0.0035	1.37	0.00000	0.00000	
Ni	853.76	10.195	6.32	0.00000	0.00000	
Pb	6.76	0.0365	3.56	0.00000	0.00000	
Si	165.17	101.63	6.34	0.00000	0.00000	
Th	21.44	10.162	6.33	0.00000	-0.0041	
Tl	5.82	0.0287	6.98	0.00000	0.00000	
V	35.77	10.168	1.07	0.00000	0.00000	
W	9.43	0.3045	2.96	0.00000	-0.0156	
Re	93.22	10.203	6.29	0.00000	0.00000	
Rh	11.14	0.4341	2.85	0.00000	0.00000	
Ru	74.43	10.229	6.63	0.00000	-0.0002	
Sb	4.34	-0.183	-7.47	0.00000	-0.4845	
Se	25.64	10.160	6.56	0.00000	-2.9109	
Si	79.98	10.179	6.39	0.00000	0.00000	
Sr	15.32	0.0645	6.35	0.00000	0.00000	
Te	6.09	0.4385	1.95	0.00000	0.00000	
TH	30.69	10.160	6.41	0.00000	-0.0287	
Ti	4.98	0.0394	3.34	0.00000	0.00000	
TL	7.21	10.544	1.29	0.00000	-0.0330	

NAME	MV	INT	CONCEN	RSD	SCOR	SCOR
Ag	5.84	0.0373	1.19	0.00000	-0.2638	
Al	46.54	10.196	6.36	0.00000	0.26266	
As	21.69	1.9354	1.22	0.00000	-0.1388	
Br	103.68	10.259	0.91	0.00000	0.00000	
Ca	6.34	0.6029	3.04	0.00000	0.00000	
CD	7.67	0.0013	2.18	0.00000	0.00000	
Ce	2557.72	10.263	6.35	0.00000	0.00000	
CO	299.52	10.233	0.39	0.00000	0.00000	
Cr	13.12	0.2761	1.45	0.00000	-0.0087	
CU	32.43	0.2168	4.20	0.00000	-0.0020	
Dy	112.16	10.269	0.43	0.00000	-0.0041	
Fe	12.48	0.0518	6.92	0.00000	0.00000	
La	136.68	10.224	6.31	0.00000	0.00000	
Li	6.25	0.0198	3.32	0.00000	0.00000	
Mn	102.54	50.404	6.36	0.00000	0.00000	
Nd	138.36	10.195	6.34	0.00000	0.00000	
Na	292.59	20.306	6.36	0.00000	0.00000	
Mo	4.01	0.0035	1.37	0.00000	0.00000	
Ni	853.76	10.195	6.32	0.00000	0.00000	
Pb	6.76	0.0365	3.56	0.00000	0.00000	
Si	165.17	101.63	6.34	0.00000	0.00000	
Th	21.44	10.162	6.33	0.00000	-0.0041	
Tl	5.82	0.0287	6.98	0.00000	0.00000	
V	35.77	10.168	1.07	0.00000	0.00000	
W	9.43	0.3045	2.96	0.00000	-0.0156	
Re	93.22	10.203	6.29	0.00000	0.00000	
Rh	11.14	0.4341	2.85	0.00000	0.00000	
Ru	74.43	10.229	6.63	0.00000	-0.0002	
Sb	4.34	-0.183	-7.47	0.00000	-0.4845	
Se	25.64	10.160	6.56	0.00000	-2.9109	
Si	79.98	10.179	6.39	0.00000	0.00000	
Sr	15.32	0.0645	6.35	0.00000	0.00000	
Te	6.09	0.4385	1.95	0.00000	0.00000	
TH	30.69	10.160	6.41	0.00000	-0.0287	
Ti	4.98	0.0394	3.34	0.00000	0.00000	
TL	7.21	10.544	1.29	0.00000	-0.0330	

P	10.87	1.0459	1.17	1.00000	-0.1619
V	10.52	0.6394	1.27	0.99993	-0.0012
Zn	5.61	0.0070	0.56	0.66666	0.66666
Zr	26.28	0.9244	0.52	0.88888	0.00000

More samples [Y/N] ? N

>

SET

Result file = Result file = Result file =
Result file = TK62
Sample name : =
Sample number : =
Sample code 1 : =
Sample code 2 : =
Sample code 3 : =
Programme : =
Date : =
Time : =
Sample mode : =
Calc mode : =
Mode number : =
Step [Y/N] ? N
Devices (P for printer) = P

Sample name : CH3

Sample number : 1629

Programme : ALLELE 14-May-90 11:23:20

Ag	0.03714	Al	16.6574	As	1.89493	B	16.0698	Po	0.68285	RE	0.66121
Ca	10.0733	CD	10.0441	Ce	0.25981	CO	0.19915	Cr	10.0446	CU	0.65651
Dy	10.0636	Fe	0.01787	K	56.2357	La	10.0581	Li	26.1539	Mg	0.68366
Mn	10.0421	Mo	0.03176	Na	165.788	Nd	10.0489	Ni	0.68475	P	10.0385
Pb	0.29117	Re	16.0493	Rh	0.42423	Ru	10.0453	Sb	-0.6919	SE	0.92657
Si	10.0426	Sr	0.03368	Te	0.42768	TH	10.0246	Ti	0.63945	TL	0.69786
U	1.66792	V	0.03844	Zn	0.06393	Zr	0.91083				

Sample name : CL1

Sample number : 1630

Programme : ALLELE 14-May-90 11:38:00

Ag	0.00015	Al	0.01738	As	0.00095	B	0.04085	Po	0.06656	RE	0.00066
Ca	0.00017	CD	-0.0009	Ce	0.00318	CO	0.01278	Cr	0.00020	CU	0.00111
Dy	0.00054	Fe	0.00137	K	0.04269	La	0.00169	Li	0.00037	Mg	0.00083
Mn	0.00021	Mo	0.00027	Na	0.00000	Nd	0.00731	Ni	-0.0000	P	0.02244
Pb	0.01584	Re	-0.0009	Rh	0.01685	Ru	0.00304	Sb	0.04055	SE	0.04201
Si	0.00218	Sr	0.00010	Te	0.00540	TH	0.00194	Ti	0.00115	TL	0.12475
U	0.05227	V	0.00018	Zn	-0.0005	Zr	0.00094				

Sample name : 901971

Sample number : 1631

Sample code 1 : TK104

Sample code 2 : DIRECT

Programme : ALLELE 14-May-90 11:35:55

Ag	-0.0036	Al	0.27208	As	-0.0450	B	0.49569	Po	0.17193	RE	0.00016
Ca	1.13719	CD	0.01649	Ce	-0.0571	CO	-0.1241	Cr	0.04734	CU	0.45613
Dy	-0.0022	Fe	0.71318	K	0.18519	La	0.18117	Li	0.06111	Mg	0.25700
Mn	0.21850	Mo	0.04562	Na	4.14458	Nd	-0.6196	Ni	0.13152	P	1.03953
Pb	1.41223	Re	-0.0022	Rh	-0.0128	Ru	0.02138	Sb	0.26891	SE	-0.0615
Si	1.76798	Sr	1.38757	Te	-0.0000	TH	-0.1057	Ti	0.01699	TL	0.03562
U	4.05619	V	-0.0062	Zn	0.10995	Zr	0.25161				

Sample name : 90-791

Sample number : 1632

Sample code 1 : TK101

Sample code 2 : 10XDIL
 Programme : ALLELE 14-May-98 11:42:33
 AG -0.00298 Al 9.78055 AS 0.16514 B 0.05667 Ba 1.97765 BE 0.00625
 Ca 4.15219 Cd 0.01331 Ce 0.00028 Co -0.0041 Cr 0.09858 Cu 0.01441
 Dy 0.00695 Fe 0.81956 K 1.61116 La 0.00412 Li 0.00297 Mg 0.20959
 Mn 0.05418 Mo 0.62228 Na 00.0315 Nd 0.00766 Ni 0.16671 P 0.67949
 Pb 0.05203 Re 0.00277 Rh 0.00987 Ru 0.00769 SB 0.13515 SE 0.00748
 Si 6.28615 Sr 0.04105 Te 0.00370 TH 0.00497 Ti 0.09034 TL 0.39381
 U 0.11961 V 0.00098 Zn 0.04274 Zr 0.04097

Sample name : 98-792
 Sample number : 1033
 Sample code 1 : TK162
 Sample code 2 : 10XDIL
 Programme : ALLELE 14-May-98 11:43:58
 AG -0.0038 Al 0.40.5575 AS 0.49431 B 0.35.7497 Ba 0.21799 BE 0.00075
 Ca)14.9456 Cd 0.00263 Ce -0.0311 CO -0.0024 Cr 0.02365 Cu 0.03396
 Dy -0.0064 Fe 4.82126 K 2.00007 La 0.00955 Li 0.01335 Mg 0.51138
 Mn 0.03318 Mo 0.01749 Na 00.0057 Nd 0.00675 Ni 0.02954 P 0.34402
 Pb 0.14660 Re 0.00493 Rh -0.0217 Ru -0.0041 SB 0.22414 SE 0.01853
 Si)33.4312 Sr 0.16162 Te 0.63913 TH -0.0225 Ti 0.29514 TL 0.22843
 U 0.19133 V 0.00272 Zn 0.33424 Zr 0.13364

) Indicates overrange

Sample name : 98-793
 Sample number : 1034
 Sample code 1 : TK163
 Sample code 2 : 10XDIL
 Programme : ALLELE 14-May-98 11:54:37
 AG 0.00484 Al 7.39285 AS 0.09978 B 5.69881 Ba 1.66701 BE 0.00011
 Ca 3.50650 Cd 0.00047 Ce -0.0448 CO -0.1067 Cr 0.01276 Cu 0.01615
 Dy -0.0015 Fe 0.50523 K 1.63365 La -0.0062 Li 0.00167 Mg 0.22685
 Mn 0.62286 Mo 0.00619 Na 00.0462 Nd -0.0143 Ni 0.03056 P 0.57585
 Pb 0.00891 Re -0.0019 Rh -0.0173 Ru -0.0059 SB 0.26576 SE -0.0032
 Si 0.72694 Sr 0.03563 Te 0.00465 TH -0.0298 Ti 0.05442 TL 0.45545
 U -0.1957 V -0.0010 Zn 0.00597 Zr 0.03226

Sample name : CH2
 Sample number : 1035
 Programme : ALLELE 14-May-98 12:00:09
 AG 0.00714 Al 0.38295 AS 0.50447 B 0.17218 Ba 10.0580 BE 1.60172
 Ca 0.03134 Cd 0.01516 Ce 0.75687 CO 0.05816 Cr -0.0999 Cu 10.0356
 Dy 0.01853 Fe 10.0041 K -0.0673 La 0.00745 Li -0.0022 Mg 10.0016
 Mn 0.00267 Mo 9.98526 Na 10.2598 Nd -0.0241 Ni 0.97314 P 0.55876
 Pb 9.87838 Re 0.01171 Rh 10.0217 Ru 0.02364 SB 10.1149 SE 1.34458
 Si 0.17571 Sr 10.0008 Te 0.97767 TH 0.05578 Ti 10.0317 TL 1.42526
 U 33.2332 V 9.97610 Zn 0.96876 Zr 10.0165

Sample name : CL1
 Sample number : 1036
 Programme : ALLELE 14-May-98 12:07:18
 AG -0.0005 Al 0.01186 AS 0.01651 B 0.05248 Ba -0.0001 BE 0.00002
 Ca 0.00015 Cd -0.0020 Ce -0.0316 CO -0.0721 Cr -0.0015 Cu -0.0004
 Dy -0.0020 Fe -0.0003 K -0.0286 La -0.0015 Li -0.0009 Mg 0.00010
 Mn -0.0003 Mo 0.00000 Na -0.0114 ND -0.0113 Ni -0.0046 P -0.0267
 Pb 0.00455 Re -0.0012 Rh -0.0089 Ru -0.0027 SB 0.12693 SE -0.0229

Si	-0.2697	Er	-0.6661	Tc	0.26365	Th	-0.6174	Ti	-0.6626	Tl	0.49197
U	-0.2669	V	-0.6614	Zn	-0.6666	Zr	-0.6615				

Sample name : 90-794

Sample number : 1637

Sample code 1 : TK108

Sample code 2 : 16XDIL

Programme : ALLELE 14-May-98 12:12:35

Ag	0.66558	Al	0.64718	As	0.64168	B	0.68351	Ba	0.61373	Be	0.66013
Ca	0.49571	CD	0.68876	Ce	-0.6151	CO	-0.6246	Cr	0.65469	CU	0.66662
Dy	0.66895	Fe	0.26653	K	0.15657	La	0.66169	Li	0.66019	Mg	0.61631
Mn	1.28984	Mo	0.66458	Na	0.663.822	Nd	0.66260	Ni	0.65881	P	-0.6299
PB	0.62714	Re	0.66092	Rh	0.61283	Ru	0.66598	SB	-0.6162	SE	0.16824
Si	0.65566	Sr	0.66531	Tc	0.61484	Th	-0.6685	Ti	0.56102	TL	0.64669
U	-0.6265	V	0.66089	Zn	0.62373	Zr	1.47550				

) Indicates overrange

Sample name : 901872

Sample number : 1638

Sample code 1 : TK106

Sample code 2 : 16XDIL

Programme : ALLELE 14-May-98 12:18:13

Ag	-0.6628	Al	0.26.2965	As	0.26583	B	0.14.4726	Ba	4.35349	BE	0.66642
Ca	0.11178	CD	0.68366	Ce	-0.6285	CO	-0.6773	Cr	0.62467	CU	1.47897
Dy	-0.6669	Fe	7.93977	K	1.16639	La	0.66763	Li	0.66386	Mg	0.76503
Mn	0.62823	Mo	0.62651	Na	40.4663	Nd	0.66291	Ni	0.66741	P	0.19551
PB	0.11562	Re	0.66154	Rh	-0.6189	Ru	-0.6669	SB	0.66788	SE	0.63558
Si	10.5544	Sr	0.68963	Tc	0.62428	Th	-0.6291	Ti	0.15491	TL	0.59398
U	0.66713	V	0.66886	Zn	0.23897	Zr	0.67547				

) Indicates overrange

Sample name : 90-794

Sample number : 1639

Sample code 1 : NI

Sample code 2 : 16XDIL

Programme : ALLELE 14-May-98 12:26:18

Ag	0.66144	Al	0.68414	As	0.24154	B	0.12673	Ba	0.66524	BE	0.66618
Ca	0.10777	CD	0.62616	Ce	0.61863	CO	-0.65697	Cr	0.63653	CU	0.61481
Dy	0.66230	Fe	0.16968	K	0.1739.38	La	0.66318	Li	0.66660	Mg	0.62601
Mn	0.92102	Mo	0.68377	Na	0.58847	Nd	0.66570	Ni	0.69.652	P	0.17415
PB	0.10458	Re	0.62650	Rh	0.63650	Ru	0.63380	SB	0.66866	SE	0.16157
Si	0.68749	Sr	0.66869	Tc	0.64587	Th	0.61228	Ti	0.28737	TL	0.67399
U	0.66527	V	0.68434	Zn	0.41880	Zr	0.68600				

) Indicates overrange

Sample name : 90-794

Sample number : 1640

Sample code 1 : NI

Sample code 2 : 160X

Programme : ALLELE 14-May-98 12:32:47

Ag	-0.6648	Al	-0.6668	As	0.61667	B	0.64765	Ba	-0.6662	BE	-0.6601
Ca	0.62473	CD	-0.6013	Ce	-0.6646	CO	-0.1385	Cr	0.66658	CU	0.66647
Dy	-0.6641	Fe	0.61539	K	0.191.436	La	-0.6639	Li	-0.6826	Mg	0.66423
Mn	0.69728	Mo	-0.6630	Na	0.64715	Nd	-0.6316	Ni	0.11.6977	P	-0.6166
PB	0.66267	Re	-0.6846	Rh	-0.6227	Ru	-0.6686	SB	0.24361	SE	0.64686
Si	-0.6153	Sr	-0.6662	Tc	-0.6646	Th	-0.6337	Ti	0.62764	TL	0.51498

-0.3953 V -0.8621 In 0.63024 L -0.7620

) Indicates overrange

Sample name : CH5
Sample number : 1041
Programme : ALLELE 14-May-96 12:39:33
Al 0.03732 Al 10.1958 As 1.93839 B 10.2585 Ba 0.66290 BE 0.66136
Ca 10.2627 Cd 10.2325 Ce 0.27666 Co 0.21678 Cr 10.2094 Cu 0.95177
Dy 10.2245 Fe 0.01897 K 50.4841 La 10.1949 Li 20.3640 Mg 0.00355
Mn 10.1952 Mo 0.03647 Na 101.626 Nd 10.1619 Ni 0.68891 P 10.1677
Pb 0.30450 Re 10.2634 Rh 0.43416 Ru 10.2286 Sb -0.1826 SE 10.1599
Si 10.1790 Sr 0.06452 Te 0.43848 Th 10.1660 Ti 0.63945 TL 10.5436
U 1.04694 V 0.03942 Zn 0.00698 Zr 0.92436

All results scanned

>

KATAYAMA

IC ANALYSIS RESULTS

Customer CLARK HARVEY

Work Package No M-67162

LRB And Page Nos 53730-29

H&TE 94483

Analyse

Date 5/21/20

Method 40.8 - PNL-MA - 517.00

Reviewer

Date 7/1/90

TK-104

1440 gallons

Customer R. STEELE/KATAYAMA Work Package No M-41817SAMPLE ID
LAB NO(S)

Concentration, PPM / % Recovery

Fluoride Chloride Nitrite Nitrate Phosphate Sulfate

16590

90-1871
TANK 104

6287

LRB And Page Nos 53730-8H&TE 94483

Analyst

Date 3/23/90Method 40.8-PNL-MA-517,011 ReviewerJ. M. EusepiDate 3/23/90

IC ANALYSIS RESULTS

customer CLARK HARVEY / KATAYAMA Work Package No M-67162

LRB And Page Nos 53730-31

M&TE 94483

Analyst

Date 6/8/90

Method 40.8 - PNL-MA - 517. III

Analyst John Cooper
Reviewer MW

Date 6/8/90

Customer R. Steele

CARBON ANALYSIS

Work Package No. M-4181

LRB And Page Nos 53093 - 30

M&TE 64102

Analysis

Date 3/21/20

METHOD 40.4- PNL-MA-597 III Reviewer *M.W.Hill*

Date 3/21/98

TK-105 543 gallons

Customer L. Steel

IC ANALYSIS RESULTS

Work Package No M-41817

LRB And Page Nos 5-3730-41

H&TE 94483

Analyst

Date 7/19/90

Method 40.8- PNL-MA-517.07

Reviewer

Date 7/9/20

* SLIGHTLY BELOW REPORTING DETECTION LIMIT - ESTIMATE ONLY

ONLY
milk

TK-112 194 gallons
Analyze before return to TK-107

IC ANALYSIS RESULTS

Customer R. Steck

Work Package No.

LRB And Page Nos 53730-10

M&TE 94483

Analysis of Error

Date 4/5/90

Method 40.8-PL-MA-577.071

Reviewers

Date 9/5/00

TK 101 147281

SERIAL NUMBER 104085

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer Buck/Katayama		Date Received 1/17/90	Work Order No. M41817
Serial No	Customer Ident	Constituent	Result
29-70	101 90-0791	IC Anions	See attachment
MTE No. BNW52920 p.			
Serial Number	104085	Date 5/29/90	Approval C&F

54-1700-177 (05/89)

54-1700-177 (05/89)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
29-90	TK 101 90-0721	Pu	alpha emitting Pu 7.11E+2 ^{ppm}
BNW52920 ng 105,108	129,130	HTA-4-15	
Serial Number	103167	Date 5/24/90	Approval Caff

SERIAL NUMBER 103167

4724 → 26/40

1.0086 ml (DIGESTED) → 4.9662 ml
2 m HNO₃

— 0.5045 ml -2 (1.0024 ml)

— 1000 λ
glass cal. b
(97.83)

54-1700-177 (05/89)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
Buck / KATAYAMA	1/17/90		
29-90	101 90-0791	Td	5.04 E 3 ppm
BNW52920 ng 105,108,110		HTA-4-22	
Serial Number	102648	Date 5/14/90	Approval LSK

SERIAL NUMBER 102648

Rf = Run
1.0086 ml → {DIGESTED} → 4.9662 ml
— 0.0996 ml

$$df = \frac{1}{0.0996}$$

54-1700-177 (05/89)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
KATAYAMA	1/17/90		
29-90	TK 101 90-0791	Td AEA for Am+CM	241 Am 2.22E+3 ^{ppm} 243+244 Cm 2.11E+3 "
Serial Number	102900	Date 6-8-90	Approval Caff

SERIAL NUMBER 102900

54-1700-177 (05/89)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No	Customer Ident	Constituent	Result
29 - 90	TK-101 90-0791	U	0.17 ug mL
MTE No. WA 521-4 BNW52920 p. 120-121 RHO 52442 P 83		HIA-4-16	
Serial Number	104080 5/11/90	Date	Approval
	C. H. Harring	5-13-90	COT

SERIAL NUMBER 104080

1.0086 → 4.9662

Sample 0.0998 mL

Spk 0.020 mL 0.1054 ug/mL

54-1700-177 (05/89)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No	Customer Ident	Constituent	Result
Buck/Katayama		1/17/90	M41817
29-90	TK-101 90-0791	GSA	$c_{\text{g}}^{137} \text{ Cs } 6.54 \pm 6.97$
BNW52920 Hg 105, 103	111	HIA-4-9	$\begin{matrix} {}^{137}_{Cs} & 2.41 \pm 3 \\ {}^{134}_{Cs} & \pm 5.97 \pm 2 \end{matrix}$
Serial Number	102656 5/12/90	Date	Approval
	V. A. Harring	5-15-90	COT

SERIAL NUMBER 102656

1.0086 mL → {DIGESTED} → 4.96
2mL

-3(0.0999mL) → SV

$$SV = \frac{1.0086(3)(0.0999)}{4.9662} - 0.6668669$$

54-1700-177 (05/89)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No	Customer Ident	Constituent	Result
Buck/Katayama		1/17/90	M41817
29 - 90	101 90-0791	ICP Metals	See attachment
MTE No. BNW52920 p.			
Serial Number	104084	Date	Approval
	5/29/90		COT

SERIAL NUMBER 104084

1.0086 → 4.9662

SERIAL NUMBER 104079

1.0086 → 4.9662 - 0.50
Cof

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No	Customer Ident	Constituent	Result dPm/ml
29-90	101 90-0791	SSA +Cs strip	56125 4.71E+3 ± 1.14E+3 Eu 3.11E+4 ± 8.06E+2
MTE No. BNW52920 p.		HTA-3-9 MTE WTA3001 BNW52345P-S3	
Serial Number	104079	Date 5/29/90	Approval Cof

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No	Customer Ident	Constituent	Result
29	TK-101 90-0791	pH	6.33
MTE No. 014409 BNW52920 p. BNW52913 p.		HTA-1-2	
Serial Number	104082	Date 4/24/90	Approval Cof

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No	Customer Ident	Constituent	Result
29-90	101 90-0791	Sr-90	1.38E+6 dpm/ml
MTE No. BNW52920 p. 103, 119	118, 119	HTA-4-11	
Serial Number	104081	Date 5/10/90	Approval Cof

SERIAL NUMBER 104081

1.0086ml → {Diluted} → 4.9662 ml

- 0.4999ml - 10 ml vol. flask
- 1.0110 mlT_d = 11:04 AM DSF PDT
HAK 5/10/90

KATHYAMA

CARBON ANALYSIS

Customer CLARK HARVEY

Work Package No. M-41817

SAMPLE ID LAB NO(S)	Concentration, PPM				
	TIC				
	TC	TOC	As CO ₂	As CO ₃	As C
29-90 TANK 101 90-0791	1782	1779			3
20-90 TANK 102 90-0793	297	257			40
31-90 TANK 103 90-0793	2595	2272 "		323
166-90 TANK 106 90-1872	10.9	10.4			0.5
32-90 TANK 108 90-0794	34.9	34.7			0.2
* This sample was acidified prior to sampling for IC analysis. Therefore the TC results may be incorrect due to loss of CO ₂ from inorganic carbonates that may have been present.					
LRB And Page Nos 53093-34					
M&TE 64102	Analyst John Curran	Date 5/21/90			
METHOD 40.4-PNK-MA-597, III	Reviewer J. M. Miller	Date 5/21/90			

Tank 102 1872 81

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Customer Ident.	Date Received	Work Order No.
Buck/Katayama		1/17/90	M41817
Serial No	Customer Ident.	Constituent	Result
30-90	102 90-0792	GSA +Cs strip HTA-4-9 7/17/90 1002 64052343 p153	no Gamma emitters other than Cs identified
MTE No. ----- BNW52920 p. ---			
Serial Number	104086	CG Harvey	Date 5/29/90 Approval CGH

SERIAL NUMBER 104086

2.0228 → 9.963 - 0.5051
CCH

SV = $\frac{(2.0228)(0.5051)}{9.963} = 0.102551$

54-1700-177 (05089)

SERIAL NUMBER 102899

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
30-90	TK 102 90-0792	Tl, AEA for Am + CM	241 Am 9.92 E+2 ^{dpm} 243,244 Cm 1.15E+3 ^{dpm}
Serial Number	102899	Date	Approval
		6-9-90.	Cof

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
30-90	TK 102 90-0792 BNW52920, PS112,114, 29,130	Pu	1.64 E+2 ^{dpm} alpha emitting Pu only
Serial Number	103166	Date	Approval
	5/24/90		

SILVER SPRING
SERIAL NUMBER 103166 $2(1.0114 \text{ ml}) \{ \text{DILUTED} \} \rightarrow 2(4.9815 \text{ ml})$

- 0.5045 ml = 2(1.0024 ml)

- 1000 \times
glass calib pipet.
(997.83)SILVER SPRING
SERIAL NUMBER 104092

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
30-90	102 90-0792 :	IC Anions	See attachment
MTE No. _____ BNW52920 p. ____			
Serial Number	104092	Date	Approval
		5/29/90	Cof

SERIAL NUMBER 102657

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result: ppm
30-90	TK-102 90-0792	GSA	$^{23} \text{Na}$ 1.81×10^6
BNW52920 HS 105, 108, 111		MTE WA93002 BNW52920 p. 51	$^{23} \text{Na}$ 1.10×10^3 $\pm 1.61 \times 10^2$
Serial Number	1026574	Date	Approval
	Alma Dunn	5/2/90	C64

$1.0086 \text{ ml} \rightarrow \{\text{digested}\} \rightarrow 4.9662 \text{ ml}$
 2 M HNO_3
 $-3(0.0999 \text{ ml}) \rightarrow \bar{s}$

SERIAL NUMBER 104091

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result:
30-90	102 90-0792	ICP Metals	See attachment
MTE No. BNW52920 p. ...			
Serial Number	104091	Date	Approval
		5/27/90	C64

 $2.0288 \rightarrow 2(4.9.8) \text{ ml}$

SERIAL NUMBER 102649

RERUN
 $1.0086 \text{ ml} \rightarrow \{\text{digested}\} \rightarrow 4.9662 \text{ ml}$
 2 M HNO_3
 -0.0492 ml

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
30-90	102 90-0792	Ta	$2.31 \times 10^{-3} \text{ ppm}$
BNW52920 HS 105, 108, 111 V3 109, 110, 111 V4 5/1/90			
Serial Number	102649	Date	Approval
	V3 5/1/90	5/1/90	C64

SERIAL NUMBER 104089

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer Buck/Katayama		Work Order No. M41817	
Serial No.	Customer Ident	Constituent	Result
30	TK-102 90-0792	pH	7.27
MTE No. 0144097 BHWS2920 p. --- BAW 52442 A II		HTA-1-2	
Serial Number	104089	Date 4/24/90	Approval Colf

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer Buck/Katayama		Work Order No. M41817	
Serial No.	Customer Ident	Constituent	Result
30-90	102 90-0792	Sr-90	3.65 E +5 c/mL
Zo 5/10/90	114, 118, 119	HTA-4-11	
MTE No. BHWS2920 p. 112			
Serial Number	104088 titanium column	Date 5/10/90	Approval Colf

S-SERIAL NUMBER 104088

 $2(1.0114 \text{ ml}) \rightarrow \{\text{Diluted}\} \rightarrow 2(4.981 \text{ mL})$

- 0.4999 ml - 10ml vol. first

- 1.0110 ml

4.985 ml - 10 ml
+ 0.0046 $T_d = 11:04 \text{ AM DST PDT}$
EEK 5/10/90

S-SERIAL NUMBER 104087

 $1.0086 \rightarrow 4.7662$
0.0998 Sample

0-020 0.1004 4.7662 sample

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer Buck/Katayama		Work Order No. M41817	
Serial No.	Customer Ident	Constituent	Result
30-90	TK-102 90-0792	U	0.11 mg/mL
MTE No. WA 52444 BHWS2920 p. 120 A II BAW 52442 A II		HTA-4-16	
Serial Number	104087 Cottage cheese	Date 5-11-90	Approval Colf

KATHAYA BTA

CARBON ANALYSIS

Customer CLARK HARVEYWork Package No. M-4/817

SAMPLE ID LAB NO(S)	Concentration, PPM				
	TIC				
	TC	TOC	As CO ₂	As CO ₃	As C
29-90 TANK 101 90-0791	1782	17.79			3
20-90 TANK 102 90-0792	297	257			40
31-90 TANK 103 90-0793	2595	2272		323
166-90 TANK 104 90-1872	10.9	10.4			0.5
32-90 TANK 108 90-0794	34.9	34.7			0.2

* This sample was acidified prior to sampling for IC analysis therefore the TC results may be incorrect due to loss of CO₂ from inorganic carbonates that may have been present.

LRB And Page Nos 53093-34M&TE 64102

Analyst

J. E. CurranDate 5/1/90METHOD 40.4-PNL-MA-597, ReviewJ. M. MillerDate 5/24/90

TK 103 1488 gal

54-1700-177 (0509)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No	Customer Ident	Constituent	Result
31-90 BNW52420	TK103 15 105, 108, 29, 130	Pa	1.72E+5 ^{dpm} alpha emitting Pb ox/ Hg - 4-15
Serial Number	103165	Date	Approval
	5/24/90	6-7-90	Coff

Total min 5007
SERIAL NUMBER
4124-1414 [REDACTED] 103165
1.0086 → 4.9662 ml 2M HNO₃

- 0.5045 ml - 2(1.0024 ml)

- 10007
(997.83)
q1as = calib pipet

SERIAL NUMBER 102898

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No	Customer Ident	Constituent	Result
31-90	TK103	Tl - AEA for Am + Cm	241 Am 4.09E+3 ^{dm} 243,244 Cm 3.04E+3 242 Cm 21
Serial Number	102898.	Date	Approval
		6-8-90	C04

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No	Customer Ident	Constituent	Result
31-90	103 90-0793	AEA +Cs strip HTA-4-9 MTE WATECOZ BNW52345P53	125 ^{dP} 56 ^{ml} 3.71E+3 ± 9.58E+2
MTE No. BNW52920 p.			
Serial Number	104093	Date	Approval
	6-8-90 Harvey	5/29/90	C04

SILVER NUMBER 104093

$$1.0086 \rightarrow 4.9662 \rightarrow 0.5051$$

^{corr}

$$SV = \frac{(1.0086)(0.5051)}{4.9662} = 0.1025822$$

SILVER NUMBER 104099

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No	Customer Ident	Constituent	Result
31-90	103 90-0793	IC Anions	See attachment
MTE No. BNW52920 p.			
Serial Number	104099	Date	Approval
		5/29/90	C04

SERIAL NUMBER 102658

1.0086 ml → {DIGESTED} → 4.9662
2M HNO₃

- 3(0.0999 ml) → SV

SV 0.0608669 ml

Pacific Northwest Laboratory		ANALYTICAL REPORT		
Customer	Date Received	Work Order No.		
Serial No.	Customer Ident	Constituent	Result	
Buck/Katayama BNW52920 105, 108	TK-103 90-0793	GSA MTE KWA3002 BNW52345 p51	Cs ¹³⁷ 6.80 E+6 dpm Cs ¹³⁴ 3.83 E+3 ± 9.41 E+2	✓/L
Serial Number	1026580	5/2/90	Date 5-19-90	Approval Cof

SERIAL NUMBER 104098

1.0086 → 4.9662

Pacific Northwest Laboratory		ANALYTICAL REPORT		
Customer	Date Received	Work Order No.		
Serial No.	Customer Ident	Constituent	Result	
Buck/Katayama BNW52920 p. ---	103 90-0793	ICP Metals	See attachment	
Serial Number	104098		Date 5/29/90	Approval Cof

SERIAL NUMBER 102650

Re-run
1.0086 ml → {DIGESTED} → 4.9662 M
2M HNO₃
- 0.0996 ml

Pacific Northwest Laboratory		ANALYTICAL REPORT		
Customer	Date Received	Work Order No.		
Serial No.	Customer Ident	Constituent	Result	
Buck/Katayama BNW52920 105, 108 110	103 90-0793	TOK	8.83 E 3 dpm/ml	
Serial Number	102650	5/1/90	Date 5-15-90	Approval LSC

SERIAL NUMBER 104096

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No	Customer Ident	Constituent	Result
31	TK-103 90-0793	pH	8.39
MTE No. 0144077 BNW52920 p. 111 BNW52913 B 11		HTA-I-2	
Serial Number	104096	Date	4/24/90 Approval Cof4

S SERIAL NUMBER 104095

$1.0086 \text{ ml} \rightarrow [(\text{diluted})] \rightarrow 4.9662 \text{ ml}$
 2 ml HgO
 $- 0.4999 \text{ ml} = 10 \text{ ml vol flask}$
 $- 1.0110 \text{ ml}$

$T_o = 11:05 \text{ AM DST PDT}$
 Ack 5/10/90

S SERIAL NUMBER 104094

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No	Customer Ident	Constituent	Result
31 - 90	103 90-0793	Sr-90	1.76 E+6 4% ml
MTE No. BNW52920 p. 105, 108, 118, 119		HTA-I-11	
Serial Number	104094	Date	5-10-90 Approval Cof4

$1.0086 \rightarrow 4.9662$
 0.8988 ml sample
 $0.020 \text{ ml } 0.1004 \text{ ml spike}$

KATHYAMA

CARBON ANALYSIS

Customer CLARK HARVEY

Work Package No. M-41817

SAMPLE ID LAB NO(S)	Concentration, PPM				
	TC	TOC	TIC		
			As CO ₂	As CO ₃	As C
29-90 TANK 101 90 - 0791	1782	1779			3
30-90 TANK 102 90 - 0792	297	257			40
31-90 TANK 103 90 - 0793	2595	2272 "		323
166-90 TANK 106 90 - 1872	10.9	10.4			0.5
32-90 TANK 108 90 - 0794	34.9	34.7			0.2
* This sample was acidified prior to sampling for IC analysis therefore the TC results may be incorrect due to loss of CO ₂ from inorganic carbonates that may have been present					
LRB And Page Nos 53093-34					
M&TE 64102	Analyst John Curran Date 5/3/90				
METHOD 40.4-PNL-MA-597, III	Reviewer M. J. Miller Date 5/21/90				

SERIAL NUMBER 103158

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
165-90	TK-104 90-1871	F ⁺ BNR52920 A 105-106 HTA-4-15 LFB 52946 P.S.	1.14 0.10 N.
Serial Number	103158	Date	5-17-90 Approval

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
165-90	TK-104 90-1871 TK-104 BNR52920 A 105-106 KTF W 52/64 SNW 52442 A 93	URANIUM HTA-4-15 LASER	0.17 47 mL
Serial Number	102795	5-11-90 COHony	Date Approval

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
165-90	TK-104 90-1871	GSA HTA-4-15 LFB 52946 P.S.	0.5 ¹³⁷ 4.87 44 1.07 E+9 47 mL
Serial Number	102629	4/25/90	Date Approval

54-1700-177 (05/09)

SILVER 102795

$$1.0021 \times 1 + 1.0021 + 2(5.0351) \times 1$$

$$0.0798 \text{ mL Sample} \\ 0.020 \text{ mL } 0.1007 \text{ mg Sample}$$

SILVER 102629

$$0.0250 \text{ mL} \rightarrow 1.0060 \text{ mL} + 0.0250 \text{ } 2 \text{ M HNO}_3$$

$$\rightarrow 2(0.0996 \text{ mL}) \rightarrow 2(5.0698 \text{ mL}) \text{ } 2 \text{ M HNO}_3$$

$$\frac{2(5.0698)}{(0.0250)(6.1992)} = 207.6281 \text{ mL dilute}$$

$$\text{Sample size } 4.83026 \text{ E-3 mL}$$

$$\text{LCD } \frac{1}{15} = 30 : 11 = 1$$

0.4999 मात्रा. — 10 ml V₁. फिल्टर
~~— 0.1000 मात्रा → 1.0110 मात्रा~~
~~(गैस की सिर्फ वातावरण की गति का अनुपात है)~~

$$1.00021 + 2(5.0351) =$$

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident.	Constituent	Result
90-1871	TK-104	Tl	72.165×10^4 dpm ^{235}Pu $1.21 E+3$ $^{238}Pu + ^{241}Am$ $8.51 E+3$ ^{243}Am $6.93 E+3$
Serial Number	Nº 101335	Cost (-12-E)	Date (-14-90) Approval C-04

SERIAL NUMBER 101335

• 1970 ml. 5% into 1 ml. HNO₃
digested → 2.9834 - 0.0999

丁
四

Dedicate
Discs

Pacific Northwest Laboratory

ANALYTICAL REPORT

Customer KATHAYAMA

Date Received
3-2-90Work Order No
M41817

Serial No

Customer Ident

Constituent

Result

165-90

TK 104

Cs Strip

No other

90-1871

GSA

Gamma Emiss.

Identified

MTE 11843002
511152345, p. 53

Serial Number

102681

Date
5/29/90 Approval
CST

SERIAL NUMBER 102681

$$1.0021 \rightarrow 2(5.0351) + 1.0021 - \\ - 0.0248$$

$$S = \frac{(1.0021)(0.0248)}{11.0723} = 0.0029445$$

Pacific Northwest Laboratory

ANALYTICAL REPORT

Customer

KATHAYAMA

Date Received

3-2-90

Work Order No

M41817

Serial No

Customer Ident

Constituent

Result

165-90

TK 104

ICP metals

See
attachment

90-1871

Serial Number

Date
5/29/90 Approval
CST

SERIAL NUMBER 103479

Pacific Northwest Laboratory

ANALYTICAL REPORT

Customer

B. KATAYAMA

Date Received

3-2-90

Work Order No.

M41817

Serial No.

Customer Ident.

Constituent

Result

90-1871

TK 104

pH

1.4

Serial Number

No. 101375

Date
3-15-90 Approval
JES

SERIAL NUMBER 103482

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No	
Serial No	Customer Ident	Constituent	Result
9306	105	Pu	^{239}Pu 2.793 E5 dpm ^{238}Pu 6.694 E5 dpm from $\frac{239}{238}$ = 1.254 Total Pu from $239 + 238 = 1.254$ from 238 = 53
RFAS M41/65-2 MTF WM 05/90 BRW 52910 PL8			
Serial Number	103482	Date	Approval
		5/1/87	LSK

This is a copy of the original report. Cost

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No	
Serial No	Customer Ident	Constituent	Result
245-70 Submitted by L Bray	TK-105	Cs-137	^{137}Cs 2.645 E10 dpm
		HTA-4-9	
Serial Number	102682	Date	Approval
	5/14/90	5/14/90	Cost

SILVER NUMBER 102682
100SX Dilution 1n Cell
0.0993 ml → SV

SERIAL NUMBER 103483

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No	
Serial No	Customer Ident	Constituent	Result
9306	105	90 Sr	1.397E+10 dpm/g ↓ 459 uCi/ml ↓ 6.29 mCi/ml
RFAS M 41665-2 M+TE 5C-23 08-04 3C0 - 0C 01-01b WA 32277			
Serial Number BNW 52914 P 71-72	103483	Date 3-19-89	Approval LSK

This is a copy of the original report ref.

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No	
Serial No	Customer Ident	Constituent	Result
KATAYAMA	2-7-89	M41817	
9306	TK105	Cs-134 Cs-137 Eu-154 Am-241	dPM/ml 1.11E+5 ± 2.22E+4 4.41E+7 3.77E+5 ± 4.44E+4 1.55E+5 ± 2.22E+4
Serial Number	103475	Date 5/29/90	Approval CGF

SERIAL NUMBER 103475

checked by
101.4 X

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No	Customer Ident	Constituent	Result
KATAYAMA J. Serma	2-7-89	M41817	
9306	TK105	U	6.96 uCi/ml
BNW 52914 P. 131,132			
Serial Number	102690	Date 5-23-90	Approval CGF

SERIAL NUMBER 102690

PGR 5-23-90
CGF0.0199 ml-R₁ = 0.25
0.0199 ml-R₂ = 0.51
of 1.0005
~~ug U~~
ml.

KATHY HARRIS

CARBON ANALYSIS

Customer CLARK HARVEY

Work Package No. M-41817

SAMPLE ID LAB NO(S)	Concentration, PPM				
	TC	TOC	TIC		
			As CO ₂	As CO ₃	As C
29-90 TANK 101 90-0791	1782	1779			3
30-90 TANK 102 90-0792	297	257			40
31-90 TANK 103 90-0793	2595	2272"		323
166-90 TANK 104 90-1872	10.9	10.4			0.5
32-90 TANK 105 90-0794	34.9	34.7			0.2
This sample was acidified prior to sampling for IC analysis therefore the TC results may be incorrect due to loss of CO ₂ from inorganic carbonates that may have been present					
LRB And Page Nos 53093-34					
M&TE 64102	Analyst John Curran	Dates 5/6/90			
METHOD 40.4-PNL-MA.597, JU Reviewer J.M.U. Date 5/6/90					

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No
B. KATAYAMA		3-2-90	M41817
Serial No	Customer Ident	Constituent	Result
103335-70	TK-106 90-1872	URANIUM LASER	4.0 E-2 ^{ug} mL
KTE No. WA 32/64 BNR 52920 P. 107, 120, 121 BXW 52442 100, 103		KTA-4-16 KTE WA52154	
Serial Number	103335	Date	Approval
	5-11-90 Collins	5-11-90	Coll

SERIAL NUMBER 103335-7
 10.57 → 11.57 - ~~3.65%~~ - 4.95%

0.0998 mL Sample
 0.020 mL 0.1004 4% Spike

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
166-90	TK-106	ICP	See attachment
Serial Number	103476	Date	Approval
		5-15-90	C&G

SERIAL NUMBER 103476

10.57 → 11.57 → 3.0192 → 4.9885

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
166-90	TK-106 90-1872	ST	6.19
		Iron	
		3/15/90	
Serial Number	102676	Date	Approval
		5-15-90	C&G

SERIAL NUMBER 102676

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
B. KATAYAMA		3-2-90	W41817
166-90	TK106 90-1872	90 STRONTIUM	3.54E+6 44/ ml
MTE No. 360	α-61-018		
ENK52920 p.	117, 115, 119	XIA-4-51	
Serial Number	103334	Date	Approval
	J. Dorn	5/15/90	C&G

SERIAL NUMBER 103334

10.57 → 11.57 →
3 (1.0064 ml) → {DIGESTED} → 4.9885
2 ml HNO3
This is 1000 ml

- 0.4999 ml → 10 ml vol flasic

- 0.1000 ml

T₀ = 11:07 AM DST 4/26/90
PDT

SERIAL NUMBER 103481

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
166-90	TK 106	IC ANIONS	See Attachment
90-1872			
Serial Number	103481	Date	Approval
	5/23/90	CGK	

SILVER NUMBER 103408

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
R KATAYAMA	3-21-90	M41817	
166-90	TK106	GSA	$\frac{10.57}{4.9886} = \frac{2.125}{0.4977}$ 5.22E+6 ml
			$\frac{10.57}{4.9886} = \frac{2.125}{0.4977}$ 4.22E+4 ml
Serial Number	103408	Date	Approval
	5-17-90	CGK	

SILVER NUMBER 103879

$$\begin{aligned} & 3(1.0064 \text{ ml}) \rightarrow \{ \text{Diluted} \} \rightarrow 4.986 \text{ ml} \\ & - 0.0248 \text{ ml} \end{aligned}$$

 $10.57 \rightarrow 11.57$

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
B. KATAYAMA	3-2-90	M41817	
166-90	TK106	TX	9.00 E 4 dm ³ /ml
90-1872			
BNW52920			
1717, 120			
Serial Number	103879	Date	Approval
	5/11/90	LSK	

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
165-90	TK-106 90-1872	AMERICIUM-CURIUM <i>J. Martin</i> EPA-4-13	$^{241}_{\text{Am}} 4.16 \text{ E}+4 \frac{\text{dpm}}{\text{ml}}$ $^{243}_{\text{Am}} 2.44$ $^{242}_{\text{Cm}} 3.79 \text{ E}+4$ $^{242}_{\text{Cm}} 3.25 \text{ E}+2$ $^{3.25}_{\text{Cm}} \text{ E}+2$
KTE No. BNW52920			
Serial Number	103331	Date 6-7-90	Approval CGH

SERIAL NUMBER 103331

$$\begin{aligned}
 & 10.57 - 1 \rightarrow 11.57 - 1 \\
 & (3 \times 1.0064 \text{ ml}) \rightarrow 4.9886 \text{ ml} - \\
 & 1000 \text{ ml} \xrightarrow{\quad} 500 \text{ ml} \xrightarrow{\quad} 25 \text{ ml} \\
 & [1.0037 \text{ ml}] [0.5024 \text{ ml}] \\
 & \text{Find } 52920 \text{ ? } 117 \quad \text{Find } 52920 \text{ ? } 122
 \end{aligned}$$

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
KATAYAMA	3-2-90	M41817	
166-90	TK106 90-1862	Pu $\frac{1}{257}$ $\frac{1}{250}$	$7.71 \text{ E}+2 \frac{\text{dpm}}{\text{ml}}$ alpha emitt + Pu only
BNW52920 KS-129,130, 117			
Serial Number	103161 <i>Ugma Dunn</i>	Date 5/24/90	Approval CGH

SERIAL NUMBER 103161

$$\begin{aligned}
 & 10.57 \rightarrow 11.57 \\
 & (3)(1.0064) \rightarrow 4.9886 \text{ ml} - \\
 & - 0.1005 \text{ ml} = 2(1.0024 \text{ ml}) \\
 & - 1000 \text{ ml} \\
 & \cdot \text{ glass calib pipet} \\
 & (997.83)
 \end{aligned}$$

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
KATAYAMA	3-2-90	M41817	
166-90	TK106 90-1872	CS STRP GSA <i>DATE 10/4/90 BNW52920 KS-129,130, 117</i>	$^{154}_{\text{Eu}} \frac{\text{dpm/ml}}{\text{E}} = 5.69 \text{ E}+4$
Serial Number	102678 <i>Colleary</i>	Date 5/29/90	Approval CGH

SERIAL NUMBER 102678

$$\begin{aligned}
 & 10.57 \rightarrow 11.57 - 3(1.0064) \rightarrow \\
 & \rightarrow 4.9886 - 0.5051
 \end{aligned}$$

$$SV = \frac{(10.57)(3.0192)(0.5051)}{(11.57)(4.9886)} = 0.279275 \text{ ml}$$

TK 108 1871 81

KATAYAMA Customer CLARK HARVEY		CARBON ANALYSIS			Work Package No. M-41817
SAMPLE ID LAB NO(S)	TC	TOC	Concentration, PPM		
			As CO ₂	As CO ₃	As C
29-90 TANK 101 90-0791	1782	1779			3
20-90 TANK 102 90-0792	297	257			40
31-90 TANK 103 90-0793	2595	2272 "		323
166-90 TANK 102 90-1872	10.9	10.4			0.5
32-90 TANK 108 90-0794	34.9	34.7			0.2
* This sample was acidified prior to sampling for IC analysis therefore the TC results may be incorrect due to loss of CO ₂ from inorganic carbonates that may have been present. LRB And Page Nos 53093-34					
M&TE 64102	Analyst	John Curran	Dates 5/1/90		
METHOD 40.4-PNL-MA-597, III Reviewer		JM	Date 5/21/90		

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
32-90	(108 tit. no. 90-0794 (ZP Fusion))	U	Total Sample $\leq 0.19 \mu\text{g}/\text{ml}$ Supernate $8.9 \times 10^{-3} \mu\text{g}/\text{ml}$
MTE No. WA 52164 BNW52920 p. 120 BNW 52442 p. 83		HTA-4-16	
Serial Number:	104203	5-15-80 Colterocy	Date Approval 5-15-80 Cof

SERIAL NUMBER 104203

2 mL → 100 mL

0.0998 ml Sample

0.020 ml .1004 mg/mL Spike

A Supernate from untreated
sample direct

0.040 ml Sample

0.020 ml .1004 mg/mL Spike

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
32-90	(TK 108 tit. no. 90-0794 (ZP Fusion))	Sr-90	$2.16 \times 10^{-7} \mu\text{g}/\text{ml}$
MTE No. BNW52920 p. 119	119	HTA-4-11	
Serial Number:	104204	5-10-80 Date	Approval Cof

SERIAL NUMBER 104204

2.26775 → 100 ml
(2.0 ml)

5/8/80

No

0.4999 ml - 10 ml vol flask

- 0.5029 ml

T₀ = 11:07 AM PBT

SERIAL NUMBER 104205

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
32	(tit. 108 90-0794)	pH	< 1
MTE No. 0144097 BNW52920 p. --- BNW52913 B/11		HTA-1-2 tit. PAL-MA - 577 US Method 40.22	4.28 M.
Serial Number:	104205	LKB 52886 R13 by MC Emt	Date Approval 4/24/80 Cof

SERIAL NUMBER 102659

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
32-90	TK-108 904 90-0794 (Zr Fusion) BNW 52920 MS 114	GSA 147EWA3002 BNW 52920-51 HTA-4-9	C ₅ ¹³⁷ 5.25 E + 8 dpm/ml
Serial Number	102659	Date	Approval
	(McGinnis & Dunn)	5/2/90	COD

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
32-90	TANK 108 90-0794 (Zr Fusion) BNW 52920 MS 114	T _A cation Column Method Frank 5/1/90	5.41 E 3 dpm/ml
Serial Number	102651	Date	Approval
		5/1/90	LCK

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident	Constituent	Result
32-90	TK 108 90-0794	Pu	Total alpha activity low no further alpha analysis performed
Serial Number	103164	Date	Approval

SERIAL NUMBER 102651

2.267g (2.0ml) \rightarrow 100 ml
 0.0997ml \rightarrow 500 λ \rightarrow 100 λ
 Sample [0.4991ml 0.1015g
 BNW 52920 p. 115]

SERIAL NUMBER 103164

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
32-90	108 TOT VNO 90-0794	ICP Metals	See attachment
MTE No. BNW52920 p.			
Serial Number	104207	Date 5/29/90	Approval Coff

SERIAL NUMBER 104207
(1ml) 100ml

2ml -> 100ml

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
32-90	108 TOT VNO 90-0794	IC Anions	See attachment
MTE No. BNW52920 p.			
Serial Number	104208	Date 5/29/90	Approval Coff

SERIAL NUMBER 104208

54-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No.	
Serial No.	Customer Ident	Constituent	Result
32-90	108 VNO 90-0794	6SA 4Cs strip	125 dpm/ 3.09 ± ± 3.76 E+4
MTE No. BNW52920 p.		HTA-4-9 MTE WKA3002 BNW52345p53	
Serial Number	104100	Date 5/29/90	Approval Coff

SERIAL NUMBER 104100

1ml Sample fused, disl.
+ 100ml) / 1ml → 101 ml

0.5051 measured

$$SV = \frac{101}{(1ml)(100ml)} = \frac{(1ml)(0.5051)}{100} = 0.005051$$

0.005051 ml

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No	
Serial No	Customer Ident	Constituent	Result
167-9	TK112 90-1873	Cs Strip CsI Eu	174446 1.50 E+9 1PPM 1.16067 E-5 dL
Serial Number	102679	Date	Approval
	30/4/80	5/29/80	CEH

SERIAL NUMBER 102679

1ml (fused) → 100 ml

0.0248 → 0.5299 - 0.0248

$$\text{SV} = \frac{(1)(0.0248)(0.0248)}{(100)(0.5299)} =$$

1.16067 E-5 dL

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No	
Serial No	Customer Ident	Constituent	Result
167-90	TK112 90-1873	ICP Metals	See Attachment
Serial Number	103480	Date	Approval
		5/29/80	CEH

SERIAL NUMBER 103480

54-1700-177 (05M09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No
Serial No	Customer Ident	Constituent	Result
167-90	TK-112 90-1873 TK-104	239-240 PLUTONIUM HTA-4-35	$^{239-240}$ Pm 5.32×10^{-6} 238 Pm 8.40×10^{-6} HTA-4-35
BNW 52920 HS113			
Serial Number	102798	Date 5/14/90	Approval COTF

SERIAL NUMBER 102798

1 ml \rightarrow 100 ml

0.0558g. DRY

0.0247 ml \rightarrow 2 (~~0.5211 mg~~)
BNW 5-15-90

— (1000)

Calib glass pipet
(100.7.)

54-1700-177 (05M09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No
Serial No	Customer Ident	Constituent	Result
167-90	TK-112 90-1873 TK-104	AMERICIUM-241	$A = 1.31 \times 10^{-7}$ HTA-4-35 ^{242}Am 1.08×10^{-7} ^{242}Cm 7.91×10^{-8} 5/15/90
BNW 52920 HS113			
Serial Number	102796	Date 6-8-90	Approval COTF

SERIAL NUMBER 102796

(1 ml \rightarrow 100 ml)

0.0558g. DRY

0.0247 ml \rightarrow 500 ml \rightarrow ~~1000~~ 250 ml
Sample [0.4931 ml 0.0250 ml]
BNW 52920 P. 115

54-1700-177 (05M09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No
Serial No	Customer Ident	Constituent	Result
KATAYAMA		3-7-90	W41817
167-90	TK 112	IC Anions	See Attachment
90-1873			
Serial Number	103478	Date 5/29/90	Approval COTF

SERIAL NUMBER 103478

SA-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No	
Serial No	Customer Ident	Constituent	Result
167-90	TK-112 90-1873	T _α	2.52 E 9 dpm/mL
BNWS2920, PS 105,106		HTA-4-22	
Serial Number	102631	Date	4/24/90
	J. Dunn	5-15-90	Approval
		LSC	

SERIAL NUMBER 102631

1 mL → 100 mL
4.09583)

0.0250 mL → 1.00E0 mL
2mHg₃

— 0.0996 mL → 5.0695 mL
2mHg₃

$$d\% = \frac{(1.0060)(5.0698)}{(0.0250)(0.0996)(0.0250)} = 8.193 / E + 4$$

SA-1700-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No	
Serial No	Customer Ident	Constituent	Result
167-90	TK-112 90-1873	GSA	Cs ¹³⁷ 1.42 E + 11 mL Cs ¹³⁴ 6.47 E + 5
BNWS2920, PS 105,106		HATZ WH43002 GW 52845 P51 HTA-4-9	
Serial Number	102630	Date	4/25/90
	J. Dunn	5-15-90	Approval
		Coff	

SERIAL NUMBER 102630

0.0250 mL → 1.00E0 mL 2mHg₃

— 0.0250 mL → 2(5.0698 mL)
2mHg₃

$$SV = \frac{(0.0250)(0.0250)}{1.0060} = 6.212 E - 4 mL$$

1mL
(1.1097 g) wt wt
100 mL

SERIAL NUMBER 102800

0.0938g, DRY

1mL → 100 mL -0.0778 →
Coff 541-21

5.4725 — 5.0297
0.299

Spike 20 μL 0.9385 μg/mL

JUN 1990-177 (05/09)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer	Date Received	Work Order No	
Serial No	Customer Ident	Constituent	Result
167-90	TK-112 90-1873 TK-1074 NO 5/8/90	URANIUM	4.9 μg/mL
BNWS2920 R12-121 HATZ 52164 GW 528442 P3 P3		HTA-4-16 LASER	
Serial Number	102800	Date	5-11-90
	C. Harvey	Approval	Coff

54-1700-177 (09/07) GPO 892-039 (1987)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident.	Constituent	Result
167-90	TK-112 90-1873 TK-112 5/15/90	POTASSIUM HTA-4-11	9.23 E+10 g/mL
BKK52920 15118			
Serial Number	102799	5/15/90	Date Approval
	102799	5/15/90	COT

SERIAL NUMBER 102799

0.0996g. DRY
(1ml → 100 ml)

2(0.0996ml) → 10 ml vol. flask
→ 5.1000 ml → 5.0713 ml H₂O
→ 0.0247 ml

T₀ = 11:10 AM ~~DST~~ PDT
12 sicked

54-1700-177 (09/07) GPO 892-039 (1987)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident.	Constituent	Result
90-1873	TK112	pH	0.7
Serial Number	Nº 101376	Date	Approval
	101376	3/15/90	KIS

SERIAL NUMBER 103160

54-1700-177 (09/07) GPO 892-039 (1987)

Pacific Northwest Laboratory		ANALYTICAL REPORT	
Customer		Date Received	Work Order No.
Serial No.	Customer Ident.	Constituent	Result
KATAYAMA		3-21-90	141817
167-90	TK-112	pH	
90-1873		HTA-1-2 3.15-50 BWW 5250s P-15	.7
Serial Number	103160	Date	Approval
	103160	3-17-90	COT

Attachment 3:

1996 HLV Tank Waste Analytical Results

The following analytical reports were prepared by the PNL 325 Laboratory. The reports contain data for the samples collected from the HLV Tanks' contents. The samples were collected and analyzed in 1996. This sampling and analyses was performed in conjunction with HLV tank cleanout performed in support of milestone M-89-01.

**THIS PAGE INTENTIONALLY
LEFT BLANK**

Date July 9, 1996

File/LB

To Gary Sevigny

From Ofelia Bredt

Subject Analytical Result for the 324 High Level Vault Samples

Attachments one through six provide the analytical results obtained by the Pacific Northwest National Laboratory 325 Analytical Chemistry Laboratory (ACL). Analysis was preformed on 324 building 104 and 107 high level vault (HLV) samples. The first set of samples were received on June 12, 1996. The second set of samples were received on June 17, 1996. The analysis requirements for the HLV samples were outlined in ASR 3174 with DSI February 14, 1996 (Gary Sevigny).

Because of the dose rates, both samples required significant dilution. All reported analytical results were corrected for dilutions. In addition, all results are reported on a per gram basis to convert the results to milliters use the specific gravity.

During sample receipt it was noted that sample labeling was inconsistent with associated documentation. The 324 technician that prepared and loaded the vials came to the shielded analytical laboratory (SAL) and identified the samples as described in attachment 1. Samples HLV001 through HLV004 were composited and labeled HLV104Comp. Samples HLV005 through HLV008 were composited and labeled HLV107Comp. HLV104Comp was assigned ACL number 96-04817 and HLV107Comp was assigned ACL number 96-04818.

Specific Gravity (SpG) determination were performed on both samples following method PNL-ALO-501. All quality control requirements were met. For samples HLV104Comp and HLV107Comp, the SpG was 1.007 g/mL and 1.076 g/mL, respectively.

Both HLV104Comp and HLV107Comp were prepared in the SAL by acid digestion. Aliquots of both digestates at a total dilution of 2500 fold were analyzed for total alpha, and gamma energy analysis. Additionally, HLV107Comp digestate was analyzed for plutonium, americium/curium and plutonium isotopes. All quality control requirements were met except the ^{239}Pu blank spike recovery was high (i.e., 121%). In addition, the ^{238}Pu result has a higher uncertainty than the other Pu isotopes due to interference from ^{232}U .

Both samples were titrated with a 1N NaOH solution. The milliequivalents of NaOH required to bring samples HLV104Comp and HLV107Comp to a pH of 10.5 were 0.21 and

Gary Sevigny
July 9, 1996
Page 2

0.71, respectively. Confirmation of instrument calibration was performed prior to and upon completion of the analysis.

For the anion analyses, samples HLV104Comp and HLV107Comp were diluted in the SAL 1140 fold in order for the dose level to fall within the applicable radiation work permit (RWP). The diluted sample aliquots were analyzed by method PNL-ALO-212 for fluoride, chloride, bromide, nitrate, nitrite, phosphate, and sulfate. All quality control requirements were met.

Total inorganic carbon analysis was performed on the NaOH solution used to titrate the samples. The analysis provided the concentration of TIC contamination in the NaOH solution. Greater than normal uncertainty is associated with the TIC results because no matrix spike or blank spike were performed. An assessment of the matrix effects on the method could not be performed due to the lack of matrix spike results. Confirmation of acceptable method performance could not be assessed due to the lack of blank spike results.

Due to limited quality control samples, the ICP uncertainty are greater than normal. The results should be used with caution. The HLV104Comp acid digestate was diluted to approximately 125 fold to bring the dose to a level within the limits of the applicable RWP. From Table 2-1 in the "Waste Analysis Plan For the 324 Building HLV Interim Removal Action", March 1996, the lead content was expected to be 16 $\mu\text{g}/\text{mL}$. At this level, the result would be above the ICP lead detection limit of 7.5 $\mu\text{g}/\text{mL}$ (at 125 fold dilution) but below the estimated quantitation limit (EQL). Matrix spike, serial dilution and post digestion spike were not performed because the concentration of the analytes were expected to be at the detection limits and the analyst would have been unnecessary exposed. The blank spike was not performed because with the dilution applied would have resulted in the analytes not being detectable above the ICP EQL.

Concurrence M W This 7-9-96

ATTACHMENT 1



Project No. 24896

Internal Distribution

File/LB

Date July 8, 1996

To Ofelia P. Bredt

From Rick T. Steele *Rick*

Subject 324 HLV Sample Receipt/Prep Narrative

Sample Receipt

Eight samples were transferred from the 324 Building hot cells to the 325 Building Shielded Analytical Laboratory hot cells. Two shipments were required. The One Ton Lab and Dry Storage cask will accommodate 5 sample vials. The first shipment arrived on June 12, 1996. Identification markings on two sample vials, HLV003 and HLV005 were in question upon receipt and unloading into the cell. Specifically in question were the tank identification markings. The technician that prepared and loaded the vials in the 324 Facility verified that HLV003 identifiers were correct as received. However, HLV0005 vial was labeled with tank 107. The technician verified that vial HLV005 was collected from their tank 104/105 composite. The second shipment arrived on June 17, 1996 without incident. Upon receipt, samples HLV001-HLV004 (Tank 107) were observed to be opaque brown liquids. Samples HLV005-HLV008 (Tank 104/105 composites) were colorless, clear liquids with a minute amount of settled solids. Samples HLV001 through HLV004 were combined by weight (68.9617 grams) to form HLV107Comp. Samples HLV005 through HLV008 were combined by weight (60.3409 grams) to form HLV104Comp.

Specific Gravity Determination

The specific gravity was determined for both composite samples using 10ml volumetric flasks and a four place electronic analytical balance. HLV104Comp SpG is 1.007 grams/mL. HLV107Comp SpG is 1.076 grams/mL. Applying these SpG values, the composited sample volumes were determined to be 59.9mLs and 64.1mLs respectively.

Sample Preparation for Analysis

A Nitric Acid - Hydrochloric Acid digestion of the tank composite samples was performed in the cell. The resulting digestate was submitted to the Radiochemistry and Advanced Inorganic Chemistry Groups for analysis. Nominally 100X dilutions were made after digestion before submittal to the groups. The digestion process creates a 25X dilution. Total dilution of the digestate delivered was 2500X.

The composite samples were diluted 1000X with deionized water and submitted to the Inorganic Group for chloride analysis by ion chromatography.


Radiation Dose Information

The radiation readings associated with the composite sample materials are extremely high. Sample processing dilutions were made and radiation readings taken on the primary sample containers when they were brought out of the hot cell for distribution to other laboratories. The table below details the results:

Sample Dose Rates

Sample Identification	Dilution Factor	Sample Container Readings			
		Beta-Gamma (mRad/Hr)	Gamma (mrem/Hr)	@ Contact	@ 30 Centimeters
HLV104Comp	1000X	150	9	Not Measured	Not Measured
HLV104Comp	2500X	31	3	1	0.3
HLV107Comp	1000X	900	60	Not Measured	Not Measured
HLV107Comp	2500X	170	17	4.1	0.8

Concurrence:

 7/8/96

Shielded Analytical Laboratory
Bench Sheet

Client: GARY SEVICKY

KP Number: K-5606

TI# ASR: ASR# 3174

Procedure: PNL-ALO-501

96-04817 HLV104 COMP: 96-04818 HLV107 COMP SPECIFIC GRAVITY

SAMPLE IDENTIFICATION

96-04817 HLV104 COMP

96-04818 HLV107 COMP

9.3054 g

VOL FLASK TARE

9.8338 g

19.3765 g

VOL FLASK GROSS

19.6435 g

10.0711 g

NET SOLUTION WEIGHT

10.7547 g

VOL FLASK CAPACITY = 10 mL

SDG = NET SOLUTION WEIGHT / VOL FLASK CAPACITY = G/mL

96-04817 10.0711 / 10 = 1.00711 g/mL

96-04818 10.7547 / 10 = 1.0755 g/mL

K&TE: Cell 2 (360-06-01-016) Mettler AE160 Balance Other

Cell 5 (360-06-01-039) Mettler AT400 Balance

Bench (360-06-01-040) Denver A160 Balance

Cell 5 (360-06-01-045) Toledo 3026 Balance

Analyst:

Date:

Reviewer:

Date:

John J. Sevick

6/19/96

Rick L. Steele

6/19/96

Shielded Analytical Laboratory
Bench Sheet

Client: Gary Sevigny
TI#(ASR) 3174

WP Number: K45606
Procedure: Sp. Gr.

HLV 104 COMP 107 COMP

SAMPLE IDENTIFICATION

96-4817

19.3745
9.3054

$$10.0711 \div 10 = 1.0071$$

96-4818

19.4435
9.8888

$$10.7547 \div 10 = 1.0755$$

ACID DIGEST

10 mL PIPET DIVID 22°C

ACID DIGEST

.0983 $\bar{x} = .0983$ %

1 mL PIPET DIVID 22°C (1.002222)

.0982

.9994 $\bar{x} = .9999$ g.

.0983 $S = .0001$

.9996 $S = .0009$

.0982

1.0015 $RSQ = .09\%$

.0984 RSD = .09%

.9994 $10.0 = 1.0021$ mL

ACID DIGEST

.9998

10 mL PIPET DIVID 20°C

10.0682 $\bar{x} = 10.0682$

10.0237

10.0568 $S = .0166$

10.0549

10.0462 RSD = .17%

10.0681

Dif Fact:

.0985 $\rightarrow 10.0681 = 10.3.2 \times$

.0985

M&TE: Cell 2 (360-06-01-016) Mettler AE160 Balance Other

Cell 5 (360-06-01-039) Mettler AT400 Balance

Bench (360-06-01-040) Denver A160 Balance

Cell 5 (360-06-01-045) Toledo 3026 Balance

Analyst:

Date:

Reviewer:

Date:

Gary Sevigny

6/18/96

Rose Hule

6/18/96

Shielded Analytical Laboratory
Bench Sheet

Client: GARY SEVIGNY

WP Number: K 45606

TI#/ASR: ASR 3174

Procedure: BENCH INSTRUCTION

96-04817 HLV104 COMP; 96-04818 HLV107 COMP ION CHROMATOGRAPHY

SAMPLE IDENTIFICATION

Filtered about 1 ml of 96-4818 thru .45 nm membrane

then made a double dilution in both samples.

$$1 \rightarrow 10 \times 1 \rightarrow 10 \text{ (DIN)} = 1140 \cdot 2 \times$$

Right calibration on a mid point Bench Met.

M&TE: Cell 2 (360-06-01-016) Mettler AE160 Balance Other _____

Cell 5 (360-06-01-039) Mettler AT400 Balance

Bench (360-06-01-040) Denver A160 Balance

Cell 5 (360-06-01-045) Toledo 3026 Balance

Analyst:

Date:

Reviewer:

Date:

J. Mayhew

6/19/96

Rick S. Steele

6/24/96

SAMPLE PREP SHEET
(325 SHIELDED ANALYTICAL LABORATORY)

TI/ARF NO.: ASR 3174 PROJECT NO.: 24896 WBS NO.:

SAMPLE TYPE: LIQUID

ISSUED BY: RT STEELE DATE: 6/18/96

PREP TYPE: NONE

ANALYST: John Doe DATE: 6/12/24

CONTROLLING PROCEDURE: _____ N/A _____

REVIEW: *Rivulus* / *Astyanax* DATE: 6/19/96

QA PLAN: MCS-033 IMPACT LEVEL: II

CLIENT: GARY SEVIGNY CORE ID: N/A

CORE ID: N/A

TANK ID: TANK 104/105 & 107

$$\text{Dilution: } \left(\frac{0.985}{0.985} - 1 + \frac{10.0637}{0.985} \right) \left(\frac{1.0021}{1.0021} - 1 + \frac{10.0637}{1.0021} \right) = 1110.2 \times$$

PNL-ALO-128

Nitric and Hydrochloric Acid Extraction of High-level Radioactive Liquids and TCLP Leachates

Client: GARY SEVIGNY; QA Plan: MCS-033 Rev. 31 (D-11-11); QA plan: MCS-033 Rev. 31 (D-11-11); Work Auth: Doc (WAD): ASR 3174; Impact Level: III; Work Package/Project: EK45606; Balance M&TE: 360201201-011; Tank/Cone/Outer ID: 324 HLV TANKS; Prep. lab (SAL or SRPL): SAL's; Additional Information: USE 1ML SAMPLE DILUTED WITH DIW TO 5MLS FOR DIGESTION. USE 1ML SPIKE VOLUME. BRING TO 25MLS FINAL VOLUME.

ALO #	Client ID	Sample Net Weight (g)	Spike volume (ml)	Final extract volume (ml)	Process Factor	Tdrc	Gross
1	96-04817-PB	PROCESS BLANK		2.5	25	18-96	
2	96-04817-US	BLANK SPIKE	1.0031		21.4-25		
3	96-04817	HLV104 COMP	1.0085		21.77	21.5272	22.5357
4	96-04817-DUP	HLV104 COMP DUP	1.0131		21.68	21.1471	22.4622
5	96-04817-MS	HLV104 COMP MATRIX SPIKE	1.0170	1.0031	21.58	21.1273	22.4463
6	96-04818	HLV107 COMP	1.0489		23.83	21.3613	22.4102
7	96-04818-DUP	HLV107 COMP DUP	1.0723		23.31	21.5236	22.5959
8	96-04818-MS	HLV107 COMP MATRIX SPIKE	1.0710	1.0031	23.31	21.6365	22.7075
9							
10							
11							
12							
13							
14							
15							
16							

Analyst comments (e.g. identification number for spikes, sample preparation problems encountered, unusual sample properties):

SAMPLES FILTERED:

YES

NO

Analyst/Date: J. Mayfield-Haynes 6/18/16

Reviewer/Date:

Rick Steele 6/18/16 rev. 2.0 J-9-25 JMR

SAMPLE PREP SHEET
(325.SHIILEDDED ANALYTICAL LABORATORY)

TIARF NO.: ASR 3174 PROJECT NO.: 24096 WDS NO.: _____

SAMPLE TYPE: LIQUID

ISSUED BY: RT STEELE DATE: 6/10/96

PREP TYPE: ACID DIGESTION

ANALYST: J. Langford-Bergman DATE: 6/19/96

CONTROLLING PROCEDURE: N/A

REVIEW: *15th St. Steeple*, DATE: 6/19/96.

QA PLAN: MCS-033 IMPACT LEVEL: II

CLIENT: GARY SEVIGNY CORE ID: N/A

TANK ID: TANK 104/105 & 107

$$\text{Diff. EGT: } 0735 \rightarrow 10.0631 = 103.2X$$

SAMPLE PREP SHEET
(325 SHIELDED ANALYTICAL LABORATORY)

TI/ARF NO.: ASR 3174 PROJECT NO.: 24096 WBS NO.:

SAMPLE TYPE: LIQUID

ISSUED BY: RT STEELE DATE: 6/18/96

PREP TYPE: ACID DIGESTION

ANALYST: John Miller DATE: 6/19/96

CONTROLLING PROCEDURE: N/A

REVIEW: John J. Steele DATE: 6/11/96

QA PLAN: MCS-033 IMPACT LEVEL: II

CLIENT: GARY SEVIGNY CORE ID: N/A

TANK ID: TANK 104/105 & 107

Analytical Chemistry Laboratories
Shielded Analytical Laboratory

Shielded Analytical Laboratory
Bench Sheet

Client: Gary Sevigny
T#(ASR) 3174

WP Number: K45606
Procedure: Sp. Gr.

HLV 104 CHP 107 COMP.

SAMPLE IDENTIFICATION

96-4817

19.3765
9.3054

$$10.0711 \div 10 = 1.0071$$

96-4818

19.6435
9.8888

$$10.7547 \div 10 = 1.0755$$

acid digest

10 mL Pipet D/W @ 22°C

ACID Digest

.0993 $\bar{x} = .0983$ %

.0992

.0993 $S = .0001$

.0982

.0994 $RSD = .09\%$

.9996 $S = .0009$

$\Delta_{rel} = .0985$ mL

1.0015 $RSD = .09\%$

ACID Digest

.9994

$\Delta_{rel} = 1.0021$ mL

10 mL Pipet D/W @ 20°C

.9998

10.0182 $\bar{x} = 10.0200$

10.0237

10.0568 $S = .0166$

10.0549

10.0462 $RSD = .17\%$

$\Delta_{rel} = 10.0681$

OIL Factor:

.0985 $\div 10.0681 = 103.2 \times$

.0985

M&TE: Cell 2 (360-06-01-016) Mettler AE160 Balance Other

Cell 5 (360-06-01-039) Mettler AT400 Balance

Bench (360-06-01-040) Denver A160 Balance

Cell 5 (360-06-01-045) Toledo 3026 Balance

Analyst:

Date:

Reviewer:

Date:

Wendy M. Morgan

6/18/96

Rick J. Hale

6/18/96

PNL-ALO-128

Nitric and Hydrochloric Acid Extraction of High-level Radioactive Liquids and TCLP Leachates

Client: GARY SEVIGNY
QA plant: MCS-033
Work Auth. Doc (WAD): ASR 3174
Impact level: II
Work/Packing/Project: K45606/124896
Tank/Core/Other ID: 324 HLV/TANKS
Prep. lab (SAL or SRPL): SAL

Additional Information: USE 1ML SAMPLE DILUTED WITH DIW TO 5MLS FOR DIGESTION. USE 1ML SPIKE VOLUME. BRING TO 25MLS FINAL VOLUME.

ALO #	Client ID	Sample Weight (g)	Spike volume (ml)	Final extract volume (ml)	Process Factor	Post Digest Dilution Factor
1	96-04817-PB	PROCESS BLANK		25	25	5.01 X
2						
3	96-04817	HLV104 COMP	1.0085		24.79	
4	96-04817-DUP	HLV104 COMP DUP	1.0131	✓	24.68	✓
5						
6						
7						
8						
9						
10						
11						
12						
13						
14						
15				(1.0032) -1- 8.0385 = 5.0064	X	
16				2(1.0033)		

Analyst comments (e.g. identification number for spikes, sample preparation problems encountered, unusual sample properties): SAMPLES FILTERED: YES [] NO [X]

Pipet CALIB: 8.0112 $\bar{x} = 8.0187$ g.
8.0347 $s = .0065$
8.0134 $RSD = .08\%$
8.0221 $W_{dil} = 8.0385$ ml
DIW @ 23°C
 $1:0085 \bar{x} = 1.0002$ g:
.9772 $s = .0010$
1.0017 $RSD = .1\%$
1.0002 $RSD = .1\%$
1.0013 $W_{dil} = 1.0033$ ml.

Analyst/Date:

G. Hayes L. Dugay 7/1/96

Reviewer/Date:

Buck L. Steele 7/1/96

ATTACHMENT 2

File/LB

Date July 8, 1996

To Ofelia Bredt

From Larry Greenwood *LGL*Subject Radiochemical Analyses for Gary Seviony (96-4817-4818)

Composite samples from HLV104 and HLV107 were prepared in the hot cell by acid digestion. Small aliquots were then analyzed for total alpha activity, gamma energy analysis, plutonium, americium/curium, and plutonium isotopes. Results are listed on the attached spreadsheet and are discussed below.

Total Alpha Analyses Total alpha activities were measured following procedures PNL-ALO-420/421. Duplicate analyses show good agreement and a ^{239}Pu standard recovered at 109%. No alpha activity was observed in either the prep blank or the lab blank.

Plutonium, Americium, and Curium Analyses Procedure PNL-ALO-417 was followed to sequentially separate the Pu and Am/Cm fractions. Tracers of ^{242}Pu and ^{243}Am were added to determine the radiochemical yields. Blank spikes of ^{241}Am and ^{239}Pu recovered at 90 and 121%, respectively. The sample, duplicate, and lab replicate results show good agreement. The lab blank indicated a small amount of contamination; however, the activities were at least 5 orders of magnitude below that of the samples.

The results indicate that ^{241}Am , $^{243+244}\text{Cm}$, and ^{239}Pu make up most of the alpha activity, in that order. The sum of the individual alpha emitters is in excellent agreement with the total alpha results.

Plutonium Isotopes The plutonium isotopic mass percents were measured in duplicate by Thermal Ionization Mass Spectrometry following procedure PNL-ALO-455. The sample showed some interference at mass 238 from uranium. Measurement of standard NBS 946 indicated excellent agreement. The conversion of mass to activity for the various plutonium isotopes is given for convenience on a second attached spreadsheet.

Gamma Energy Analyses Small fractions of each sample were directly gamma counted using procedure PNL-ALO-450. Results indicate that ^{137}Cs is by far the largest source of gamma activity. However, ^{134}Cs , ^{154}Eu , and ^{241}Am were also easily detected. The gamma results for ^{241}Am are in reasonable agreement with the alpha energy analyses (AEA); however, the AEA results are judged to be more reliable due to potential interferences with the low energy gamma from ^{241}Am .

Battelle Pacific Northwest National Laboratory
 Analytical Chemistry Laboratory
 Radiochemistry Group - 325 Bldg.

Client: G. Sevigny
 WP #: K45606

9G-4017
 7/1/96

Cognizant Scientist:

L.R. Greenwald

Date:

7/1/96

Review:

T. Trang-le

Date:

7/1/96

ALO ID Client ID	Measured Activities (uCi/g)			Alpha Energy Analysis			Gamma Energy Analysis			Analysis		
	Total Alpha Error +/-	Am-241 Error +/-	Cm-244 Error +/-	Cm-242 Error +/-	Pu-240 Error +/-	Pu-238 Error +/-	Cs-134 Error +/-	Cs-137 Error +/-	Eu-154 Error +/-	Eu-155 Error +/-	Am-241 Error +/-	
9G-4017PB HLV104 Comp PB	<4. E-3						<3. E-2	7.94E-2 18%	<7. E-2	<9. E-2	<9. E-2	
9G-4017 HLV104 Comp	1.22E 1 0%						0.05E-1 10%	5.98E 0 2%	5.00E 0 5%	<4. E 0 20%	6.10E 0	
9G-4017 D HLV104 Comp Duplicate	1.12E 1 0%						1.01E 0 -15%	5.99E 0 2%	6.02E 0 5%	<4. E 0 20%	6.25E 0	
9G-4018 HLV107 Comp	1.40E 3 4%	8.05E 2 4%	5.36E 2 4%	3.51E 0 31%	4.40E 1 22%	1.13E 2 21%	3.46E 1 10%	3.61E 4 3%	6.50E 2 3%	1.33E 2 20%	7.79E 2 6%	
9G-4018D HLV107 Comp Duplicate	1.38E 3 4%	7.26E 2 4%	4.63E 2 4%	3.05E 0 31%	4.00E 1 21%	1.07E 2 21%	3.70E 1 17%	3.47E 4 3%	6.53E 2 3%	1.12E 2 21%	6.50E 2	
9G-4018D Replicate HLV107 Comp Duplicate	1.34E 3 4%	7.10E 2 4%	5.00E 2 4%	5.28E 0 26%	4.25E 1 22%	1.10E 2 21%						
Standard	109%	90%				121%						
Blank	<4. E-5 9%	3.70E-5 9%				7.74E-5 21%	2.18E-5 21%					

Plutonium Isotopes (Mass%)	Pu-238	Pu-239	Pu-240	Pu-241	Pu-242
9G-4018 HLV107 Comp	2.16E+0	3.50E+1	5.01E+1	2.30E+0	2.45E+0
9G-4018D HLV107 Comp Duplicate	1.27E+0	3.57E+1	5.04E+1	2.25E+0	2.30E+0
Standard -Measured:	2.10E-1	0.55E+1	1.24E+1	1.20E+0	5.92E-1
Standard -NDS 94G	2.10E-1	0.55E+1	1.24E+1	1.20E+0	5.02E-1

Note: Apparent interference from U-238.

Plutonium Mass%/Activity Conversions

G. Sevigny 96-4513

7/1/96

Isotope	Ci/g	Mass%	ug/g	uCi/g	Source	239+240	
						Ci/g	Mass%
238	17.11900	1.60	6.43E+00	1.10E+02	AEA	0.164563	93.670
239	0.06204	35.44	9.77E+01	6.06E+00	TIMS		
240	0.22696	58.23	1.61E+02	3.64E+01	TIMS		
241	103.00000	2.32	6.40E+00	6.59E+02	TIMS		
242	0.00393	2.41	6.64E+00	2.61E-02	TIMS		
	sum=	100.00	2.76E+02	8.11E+02	= Total		

Alpha Energy Analysis

Isotope	uCi/g	ug/g	Net Pu, ug/g
238	110	6.43E+00	4.02E+02 Interference on TIMS
239+240	42.5	2.56E+02	2.76E+02 Use this for analysis

J. D. Sevigny
7-1-96

ATTACHMENT 3

File/LB

Date June 27, 1996

To Gary Sevigny

From Irving C. Henry

Subject Titration of 324 HLV Tank 104/107 Samples

The two submitted 324 HLV tank samples were assigned lab designations of 96-4817 and 96-4818 respectively (ASR# 3174). The milli-equivalence of NaOH required to bring the pH of the samples to 10.5 was determined by titrating sample aliquots as per PNL-ALO-228. The Brinkman 636 Titroprocessor, M&TE WB76843, equipped with the Dosimat E635, M&TE WB76839, was used to perform the analysis.

The samples were titrated against a standardized NaOH solution and the milli-equivalence (mEq) of NaOH per volume of sample required to raise the sample pH to 10.5 was calculated with the following equation:

$$mEq = \frac{N \text{ of NaOH} \times \text{Vol[mls] of NaOH}}{\text{Vol[mls] of Sample}}$$

where the "Vol[mls] of NaOH" is the volume of NaOH corresponding to a pH of 10.5

HLV104 Composite was titrated in duplicate:


mEq = 0.21 Std Dev = 0.0007

HLV107 Composite was titrated in triplicate:

mEq = 0.71 Std Dev = 0.0476 (resulting from inhomogeneity of sample)

All data supporting this analysis is recorded in Laboratory Record Book# ACL0018, pages 53 - 63. If you have any questions concerning this data, you may contact me at 373-7231.

Irving C. Henry
Chemist
Analytical Chemistry Lab



Concur:

 6-28-96

96-4817 → 4818

96 Gary Sevigny 376-0395 D7-41 K45606 ASR# 3174

Determine the milliequivalence of NaOH needed to bring the pH of 2 samples to 10.5

Analysis was performed in accordance to PHC-ALO-228 with a Brinkmann 636 Titroprocessor (MITE WB76843) with a Dosimat E635 (MITE WB76839)

pH Buffer 4	lot # 946941-24	Exp date 12/96
pH Buffer 7	950389-24	1/97
pH Buffer 10	950253-24	1/97


The instrument was retrofitted to the hot cell & the titration took place in-cell. (due to the high rad dose of the samples)

The instrument was calibrated as per procedure and the calibration was verified by reading the pH 7 Buffer → 7.1

The % of the 1.02N NaOH std was verified by titra tins. it against a standardized 19.11 HNO₃ std.

NaOH 1.02N Chem Rec 08

HNO₃ 19.11 Chem Rec 17



P.M. 1.7700

L-200

6-26-96 Gary Sevigny ASR# 3174 ACL# 96-4817 → 4818 K4565

REBALANCING INSTRUMENT

1 2 3 4 5 6 7 8 9 10 11 12

SCS

Sols to 3174(4)
vs NaOH
1.02 N

3mls 96-4817

VS.

1.02 N NaOH

LRB-ACL0018.P3 55

ROUTINE # SES PHINITI 2.001 VITCIAL 5.000
1 VOL 0.512 PHINI 4.443
2 VOL 0.554 PHINI 7.377
3 VOL 0.566 PHINI 7.473

DATE 26.6.96 NAME

Data pts pertaining to curve
obtained from display of 636
during titration of sample

Volume [mls]	pH
.295	2.524
.422	3.148
.470	3.478
.510	4.503
.528	5.639
.547	6.675
.565	7.887
.576	8.429
.581	8.429
.593	9.321
.607	10.068
.619	10.530
.635	10.840
.661	11.068
.706	11.281
.776	11.460
.880	11.644

* Linear curve fit was applied to the cited data pts to yield a data pt @ pH 10.5 \Rightarrow vol .618mls pH 10.5

The milli equivalence of NaOH required to bring the sample to the desired pH of 10.5

$$m.Eq = \frac{N \text{ of NaOH titrant} \times \text{Vol[mls] of NaOH titrant}}{\text{Volume[mls] of Sample}}$$

$$m.Eq = 1.02 N \times .618 \text{ mls} = 0.210$$

-96 Gary Sevigny ASR #3174 ACL#96-4817 196-9818 K43606

3mLs. 96-4817
vs.

1.02 N NaOH

LBB = ACL 0018 P356

DATUM 4 101
S PHM1(PH1) 2.181 VITC(VAL 5.000
VPHL 0.372 PHM1 2.181
VPHL 0.512 PHM1 4.531
VPHL 0.545 PHM1 7.209
VPHL 0.574 PHM1 7.457
VPHL 2.788 PHM1 12.326


Data Points

Volume [mLs] pH

.298	2.564
.386	2.945
.445	3.301
.501	3.903
.513	4.55
.524	5.442
.539	6.554
.557	8.015
.563	8.367
.575	8.935
.589	9.574
.603	10.209
.617	10.595
.637	10.894
.667	11.133
.717	11.363
.788	11.547
.891	11.715
1.020	11.859

near. Curve Fit between these two pts yield \Rightarrow Vol. 614 pH 10.500

$$Eq = \frac{1.02N \times .614 \text{ mLs}}{3 \text{ mLs}} = 209$$




76 Gary Seigny ASR#3174 ACL#96-4817 + 96-4818 K45606

Data Points


Volume [mls]	pH
.375	5.02
.387	5.352
.399	5.770
.434	6.219
.504	7.012
.574	8.123
.591	8.872
.596	8.993
.601	9.076
.607	9.361
.621	9.514
.626	9.662
.645	9.800
.697	10.014 *
.774	10.825
.814	10.989
.892	11.124
1.018	11.365
1.138	11.456

ROUTINE # 101
1 PHENOL 2.814 VITRIOL 5.000
2 VITRIOL 0.891 PHENOL 3.090
3 VITRIOL 0.300 PHENOL 0.494
4 VITRIOL 0.583 PHENOL 0.497
5 VITRIOL 0.411 PHENOL 0.190
6 VITRIOL 0.768 PHENOL 10.722 *Linear Curve Fit between these three pts yields \Rightarrow Vol. 743 mls
Correlation Coefficient pH 10.500
 $= 1.0000$

$$mEq = \frac{1.02N \times 743 \text{ mls}}{1 \text{ ml}} = 758$$



6-26-96 Gary Seigny ASR# 3174 ACC# 96-4817 & 96-481




Data Pts

Volume [mls] pH

296	3.605
423	5.836
474	6.583
509	7.043
520	7.444
531	7.639
558	8.659
574	8.981
580	8.925
619	10.067
638	10.127
728	10.663
789	10.938
861	11.126
964	11.401
1.064	11.493
1.228	11.598
1.408	11.753
1.574	11.823
1.773	11.941

* Linear Curve Fit between these two pts. yield \Rightarrow Vol. 701 mls
pH 10.5

$$\frac{1.02 \text{ N} \times 701 \text{ mls}}{1 \text{ ml}} = 715$$



Gary Seigny 6-27-96

6-28-96

6-26-96. Gary Sevigny ASR#3174 ACL#96-4817 & 96-4818 K456.

DRUKKARII

ROUTINE 8 181
1 VML PHIMIN 2.741 VITCIAL 5.880
2 VML 0.399 PHIMI 5.727

96-4818-11 (E)
1.02 N NaOH

1ml 96-4818

VS

1.02 N NaOH

LRB-ACL0018 Pg 60


MANN CALIBRATION 7/20/96

Data Pts

	Volume [mls]	pH
	.289	3.786
	.377	5.292
	.382	5.372
	.397	5.657
	.407	5.994
	.413	6.065
	.418	6.120
	.458	6.959
	.481	7.1
	.531	7.836
	.564	8.553
	.587	9.616
	.592	9.704
	.597	9.766
	[.633]	10.339
	.662	10.626
	.703	10.874
	.763	11.086
	.848	11.237
	.973	11.420

* Linear Fit between these pts yields \Rightarrow Vol[mls] 650 pH 10.500

$$m \text{ Eq} = \frac{1.02 \text{ N} \times 650 \text{ mls}}{1 \text{ ml}} = 663$$



ATTACHMENT 4

File/LB

Date June 26, 1996

To Ofelia Bredt

From M. O'Neill


Subject 324 HLV Tank 104/105 and 107 Samples

The solutions from the 324 Building high level vault tank 104/105 and 107 were analyzed on 6/20 and 6/26/96 according to procedure PNL-ALO-212 using IC system 1 (M&TE # WD25214). These samples, diluted in the SAL 1140X, (to stay within limits allowed by the RWP) included a dilution blank/96-4817-DB, HLV104 Comp/96-4817, HLV104 Comp DUP/96-4817-DUP, HLV107 Comp/96-4818, and HLV107 Comp DUP/96-4818-DUP. The blank spike, matrix spikes and a duplicate matrix spike (for sample 96-4817 only) were prepared in lab 400 during the sample analysis. Further dilutions of these samples in the lab were not required except in the case of sample HLV107 Comp/96-4818 which required an additional dilution of 4X to determine the nitrate concentration.

IC system 1 was calibrated from 0.25 - 7.5 $\mu\text{g}/\text{ml}$ for the halides (F, Cl, Br) and 0.5 - 30.0 $\mu\text{g}/\text{ml}$ for the oxyanions (NO_2^- , NO_3^- , PO_4^{3-} , and SO_4^{2-}). The continuing calibration "mid" verification standard recovery was within acceptable limits of $100 \pm 10\%$. All analyte concentrations in the dilution blank 96-4817-DB were less than the detection limit. The blank spike recoveries for all the analytes were within acceptable limits of $100 \pm 20\%$. The post matrix spikes of both samples and post matrix spike duplicate of 96-4817 had acceptable recoveries of $100 \pm 25\%$. The relative percent difference (RPD) was also within acceptable limits of less than 20% for all analytes of the sample and duplicate.

All sample and QC results can be found in system file: IC-325-400 System 1 File# 96.22.

M. O'Neill 6/26/96
MM O'Neill

Concur: 

BATTELLE-PNL

.....ION CHROMATOGRAPHY.....
ANALYTICAL RESULTS.....

Client : G. Savigny
 WP #: K45606

Archive: IC-325-400-SYS-1 File #: 86.22

LAB NUMBER ----- SAMPLE ID	DL	>>>>>>>>>>>>>>>> CONCENTRATION (z) <<<<<<						
		F (0.25)	Cl (0.25)	NO2 (0.50)	Br (0.25)	NO3 (0.50)	PO4 (0.50)	SO4 (0.50)
96-04817-DB		<290	<290	<570	<290	<570	<570	<570
HLV104 Comp								
Blank Spike Recovery (%)		103	113	89	93	93	91	86
Multiplier		1140.2	1140.2	1140.2	1140.2	1140.2	1140.2	1140.2
Date of Analysis		06/20/96	06/20/96	06/20/96	06/20/96	06/20/96	06/20/96	6/20/96
96-04817		<290	<290	<570	<290	12,300	<570	800
HLV104 Comp								
Spike Recovery (%)		97, 92	95, 92	92, 89	95, 92	101, 98	79, 80	95, 93
Multiplier		1140.2	1140.2	1140.2	1140.2	1140.2	1140.2	1140.2
Date of Analysis		06/20/96	06/20/96	06/20/96	06/20/96	06/20/96	06/20/96	6/20/96
DUP96-C4817		<290	<290	<570	<290	13,700	<570	900
HLV104 Comp								
Spike Recovery (%)								
Multiplier		1140.2	1140.2	1140.2	1140.2	1140.2	1140.2	1140.2
Date of Analysis		06/20/96	06/20/96	06/20/96	06/20/96	06/20/96	06/20/96	6/20/96
96-04818		<290	<290	<570	<290	54,000	<570	<570
HLV107 Comp								
Spike Recovery (%)		101	99	94	102	100	98	97
Multiplier		1140.2	1140.2	1140.2	1140.2	4560.8	1140.2	1140.2
Date of Analysis		06/20/96	06/20/96	06/20/96	06/20/96	06/20/96	06/20/96	6/20/96
Comments		..						

M & TE: PN-900902 WD25214
 Method : PNL-MA599-ALO-212

Analyst: M. Sjölin
 Reviewer: J. Z. Lai

Date: 6-26-96
 Date: 6-26-96

- (a) Units = ug/mL (liquids), ug/g (solids), unless otherwise noted.
- (b) Spike recovery analysis requirements as per by ALO-212, MCS-033--or at analysts discretion.
- (c) Calibration, Verification, & Spike Std. data in IC Std. binder.
- (d) Multiply Detection Limit (DL) values by multiplier used to determine a Sample DL value for a particular analyte.
- (e) See attached "Client Information Sheet" for accuracy/precision guidelines, unless otherwise noted.

BATTELLE-PNL

*****ICN CHROMATOGRAPHY*****
 *****ANALYTICAL RESULTS*****

Client : G. Sevigny
 WP #: K45606

Archive: IC-325-400-SYS-1 File #: 96.22

LAB NUMBER SAMPLE ID	DL	>>>>>>>>>>>>>>>> CONCENTRATION (a) <<<<<<						
		F (0.25)	Cl (0.25)	NO2 (0.50)	Br (0.25)	NO3 (0.50)	PO4 (0.50)	SO4 (0.50)
DUP96-04818		<290	<290	<570	<290	58,000	<570	<570
HLV107 Comp								
Spike Recovery (%)								
Multiplier		1140.2	1140.2	1140.2	1140.2	4560.8	1140.2	1140.2
Date of Analysis		06/20/96	06/20/96	06/20/96	06/20/96	06/20/96	06/20/96	6/20/96
Spike Recovery (%)								
Multiplier								
Date of Analysis				.				
Spike Recovery (%)								
Multiplier								
Date of Analysis				.				
Spike Recovery (%)								
Multiplier								
Date of Analysis				.				
Comments								

M & TE: PN-900902 WD25214
 Method : PNL-MA599-ALO-212

Analyst: W. O'Neill
 Reviewer: J. C. Smith

Date: 6-26-96
 Date: 6-26-96

- (a) Units = ug/mL (liquids), ug/g (solids), unless otherwise noted.
- (b) Spike recovery analysis requirements as per by ALO-212, MCS-033--or at analysts discretion.
- (c) Calibration, Verification, & Spike Std. data in IC Std. binder.
- (d) Multiply Detection Limit (DL) values by multiplier used to determine a Sample DL value for a particular analyte.
- (e) See attached "Client Information Sheet" for accuracy/precision guidelines, unless otherwise noted.

ATTACHMENT 5

System File/LB

Date June 28, 1996

To Project manager

From DL Baldwin 

Subject TIC (by Dohrmann DC-80) Results for
96-04819 NaOH Solution


This work is done by the UV-catalyzed persulfate/NDIR method, Test Procedure PNL-ALO-382, Rev. 0, "Solutions Analysis: Carbon", using the Dohrmann DC-80 Total Organic Carbon Analyzer. The work was performed to IL II and ASR 3174. The M&TE No. for the carbon measurements is WA64102, M&TE No. for the balance is 362-06-01-046. The data is located in the ALO Records Office System File. TIC standard used is potassium acid phthalate, lot# 52809, and the TIC standard is sodium carbonate, lot# 52815.

Narrative: The QC for method involved an abbreviated protocol of a standard, blank, and duplicate. The sample was analyzed in duplicate, by replicate injection. System standards and blanks were all within required limits. TIC only was analyzed due to the abbreviated protocol. No matrix or blank spike was performed due to the abbreviated protocol. The precision (RPD) is high, at 26%, but is due to the low, near detection limit levels.

ACL Number	Sample ID	TIC (ug/ml)	RPD (%)
96-04819	NaOH	25	26%
	Dup.	34	

An MDL (Method Detection Limit) was determined from the pooled SD of five batch blanks. MDL is set equal to 10x pooled SD, therefore is equal, with no dilution factor, to 0.5 ug/ml for TC, TOC and TIC. For this sample, with a TIC dilution factor of 5x, the MDL is 2.5 ug/ml.

Concur by:
Disk File:


UV-TOC.55 System File: TC062896

Date: 6-28-96
Run Log: 002

ATTACHMENT 6

*Battelle PNNL/ACL/Inorganic Analysis Group:
ICPAES Analytical Report*

WO/Project: K45606
Client: G Sevigny
Impact Level: II

ACL Nmbr(s): 96-004817

Client ID: "HLV104 COMP"

ASR Nmbr 3174

Total Samples: 1

Procedure: PNL-ALO-211, "Determination of Elements by Inductively Coupled Argon Plasma Atomic Emission Spectrometry" (ICP-AES).

Analyst: DR Sanders

Analysis Date (Filename): 07/01/96 (A0140)

See ALO System File: "ICP-325-405-1" for traceability to Calibration, Quality Control, Verification, and Raw Data.

M&TE Number: ICPAES instrument -- WB73520
Mettler AT400 Balance -- Ser.No. 360-06-01-029

Jenij Wagner 7-2-96
Reviewed by

M.W.Th 7-8-96
Concur

7/2/96

*Battelle PNNL/ACL/Inorganic Analysis Group:
ICPAES Analytical Report*

Two radioactive liquid sample aliquots were analyzed by ICPAES following sample preparation by the 325 Shielded Analytical Laboratory. PNL-ALO-128 procedure was used to prepare the sample for analysis ("Nitric and Hydrochloric Acid Extraction of High-level Radioactive Liquids and TCLP Leachates"). Samples were diluted about 125 fold in order to reduce radiation exposure to the technician during ICPAES analysis. Beta-Gamma activity in the sample aliquots was estimated to be about 900 mRem each. Major analytes present in the sample include Iron, Sodium, Strontium and Lanthanum.

Chromium and Lead exceeded TCLP regulatory limits. The measured Lead concentrations were within a factor of 2 times detection limit and therefore may not actually be present. The Lead measurement result may be due to interference from high concentrations of Lanthanum. Lanthanum concentration in the sample was about 275 $\mu\text{g}/\text{mL}$. Following is a list of the TCLP analytes measured: Ag, As, Ba, Cd, Cr, Pb, and Se.

See attached "ICPAES Data Report" for measurement results, detection limits, and etc.

Please note, bracketed values listed in the data report are within ten times instrument detection limit. Those measurement values have a potential uncertainty much greater than 15%.

Comments:

- 1) "Final Results" have been corrected for all laboratory dilutions performed on the sample during processing and analysis unless specifically noted.
- 2) Detection limits (DL) shown are for acidified water. Detection limits for other matrices may be determined if requested.
- 3) Routine precision and bias is typically $\pm 15\%$ or better for samples in dilute, acidified water (eg. 2% v/v HNO₃ or less) at analyte concentrations greater than ten times detection limit up to the upper calibration level. This also presumes that the total dissolved solids concentration in the sample is less than 5000 mg/mL (0.5 per cent by weight).
- 4) Absolute precision, bias and detection limits may be determined on each sample if required by the client.
- 5) The maximum number of significant figures for all ICP measurements is 2.
- 6) To convert "WT%" to "mg/Kg" or "mg/g", multiply concentration value by 10,000.
- 7) To convert "mg/Kg" or "ug/g" to "WT%", divide concentration value by 10,000.

7/2/96

Battelle PNL/ACL/Inorganic Analysis Group: ICPAES Data Report

Multipier =	124.2	123.6	125.3	
ALOR#	95-4817	95-4817 DUP	95-4817-BLK	
Client ID#	HIV104 COMP	HIV104 COMP DUP	Process Blank	
Det. Limit ($\mu\text{g/mL}$)	Run Date# (Analyte)	7/1/95 $\mu\text{g/g}$	7/1/95 $\mu\text{g/g}$	7/1/95 $\mu\text{g/g}$
0.015	Ag	-	-	-
0.050	Al	[23]	[22]	[6]
0.050	As	-	-	-
0.050	B	104	98.4	[57]
0.010	Ba	[5]	[4]	-
0.005	Be	-	-	-
0.100	Bi	-	-	-
0.250	Ca	[105]	[155]	[95]
0.015	Cd	-	-	-
0.150	Ce	-	-	-
0.050	Co	-	-	-
0.020	Cr	97.8	91.2	[18]
0.050	Cu	-	-	-
0.050	Dy	-	-	-
0.100	Eu	-	-	-
0.050	Fe	547	557	[53]
2.000	K	-	-	-
0.050	La	277	260	-
0.030	Li	-	-	-
0.100	Mg	[23]	[22]	-
0.050	Mn	[15]	[18]	-
0.030	Mo	45.5	45.8	-
0.250	Na	420	415	[66]
0.100	Nd	[43]	[43]	-
0.030	Ni	74.1	75.1	[5]
0.250	P	-	-	-
0.100	Pb	[14]	[14]	-
0.250	Pr	-	-	-
0.300	Rh	-	-	-
0.100	Ru	[52]	[52]	-
0.100	Sb	-	-	-
0.100	Se	-	-	-
0.500	Si	[222]	[174]	[112]
1.000	Sn	-	-	-
0.015	Sr	222	225	-
0.500	Te	-	-	-
0.800	Th	-	-	-
0.025	Tl	-	-	-
0.500	Tl	-	-	-
2.000	U	-	-	-
0.015	V	-	-	-
0.500	W	-	-	-
0.025	Y	-	-	-
0.020	Zn	[4]	[7]	[6]
0.025	Zr	[15]	[11]	-

Note: 1) Overall error greater than 10-times detection limit is estimated to be within $\pm 15\%$.

2) Values in brackets [] are within 10-times detection limit with errors likely to exceed 15%.

3) "-" indicates measurement is below detection. Sample detection limit may be found by multiplying "det. limit" (far left column) by "multiplier" (top of each column).

**THIS PAGE INTENTIONALLY
LEFT BLANK**



Project No. 24896

Internal Distribution

Date August 5, 1996 File/LB
To Gary Sevigny
From Ofelia Bredt *OFB 8/5/96*
Subject ICP/MS Results for the 324 High Level Vault Samples

Attached is the ICP/MS analytical results obtained by the 3708 Advanced Inorganic Group (AIG). Analysis was preformed on 324 building 104 and 107 high level vault (HLV) samples. The first set of samples were received on June 12, 1996. The second set of samples were received on June 17, 1996. The analysis requirements for the HLV samples were outlined in ASR 3174 with DSI February 14, 1996 (Gary Sevigny).

Because of the dose rates, both samples required significant dilution. All reported analytical results were corrected for dilutions. In addition, all results are reported on a per gram basis (to convert the results to milliliters use the specific gravity provided in the analytical report issued on July 9, 1996).

During sample receipt it was noted that sample labeling was inconsistent with associated documentation. The 324 technician that prepared and loaded the vials came to the shielded analytical laboratory (SAL) and identified the samples as described in attachment 1. Samples HLV001 through HLV004 were composited and labeled HLV104Comp. Samples HLV005 through HLV008 were composited and labeled HLV107Comp. HLV104Comp was assigned ACL number 96-04817 and HLV107Comp was assigned ACL number 96-04818.

Both HLV104Comp and HLV107Comp were prepared in the SAL by acid digestion. Aliquots of both digestates at a total dilution of 2500 fold were analyzed for ICP/MS. Due to the high instrument background sodium and potassium results were not obtained. The ICP/MS detected contamination in the process blank. The process blank results for Al, Ca, Fe, Mg, Pb, and Zn were comparable in some cases to the results reported for the samples. In addition, silicon was detected in the 1% HNO₃ blank at approximately 40% to 60% of the sample results. The ICP analysis of the process blank also indicated the presence of Al, Fe, Zn, and Ca at similar concentrations in the process blank. As a result, it is believed that the contamination of Al, Fe, Zn, and Ca most likely came from the SAL preparation. For analytes detected in the blanks at levels equal to the samples, indicate a potential false positive for the sample results. The blank spike and matrix spike recoveries for analytes not detected in the process blank were with the required recovery limits. However due to the high concentration of Pb in the process blank, the spike recovery could

Gary Sevigny
August 5, 1996
Page 2

not be determine. The uncertainty associated with the Mn, Zn, and Te result were high indicating a potential instability in the instrument.

Concurrence Mitchell 8/5/96



Project Number

Internal Distribution

3708/108 File
LSO Project File

Date July 24, 1996
To Ofelia Bredt
From James Bramson *Jones*
Subject ICP/MS Analysis of Submitted Samples
(ACL# 96-4817 and 96-4818)

Pursuant to your request, the samples that you submitted on 6/21/96 were analyzed for selected elements by ICPMS. The results of this analysis are reported on the following pages.

NIST standards were used to generate the calibration curves. An Inorganic Ventures Ca standard and Spex multi-element standards (ICPMS-1,2,3,4) were used as the continuing calibration verification (CCV) standards. Unless otherwise specified, the overall uncertainty of the values is conservatively estimated at $\pm 15\%$ ($\pm 20\%$ for Si and Fe), and is based on the precision between consecutive analytical runs as well as the accuracy of the CCV standard results.

Some problems with this analysis include:

- Sodium and potassium results were not obtained due to high instrument background for both elements.
- Strontium and barium results appear to be biased low.
- Results for Mg, Al, Ca, Fe, Zn and Pb are very high in the process blank.
- There was a high silicon concentration in the 1% HNO₃ blank.
- Spike recovery results for Pb are poor.
- High uncertainties for Mn, Zn and Te.

If you have any questions regarding this analysis, feel free to call me at 372-0624 or Eric Wyse at 376-3074.

James S. Sevigny
7/29/96

DATA REVIEW

Reviewed by: *[Signature]*
Date: 7/29/96 Pages: 1 of 3

5/5/94
CPB

Gary Sevigny Analysis

July 29, 1996

Results are reported in $\mu\text{g/g}$ (ppm) of solid sample

Sample Number	ICP/MS Number	Mg $\mu\text{g/g}$	Al $\mu\text{g/g}$	Si $\mu\text{g/g}$	Ca $\mu\text{g/g}$	Ti $\mu\text{g/g}$	V $\mu\text{g/g}$	Cr $\mu\text{g/g}$	Mn $\mu\text{g/g}$	Fe $\mu\text{g/g}$	Co $\mu\text{g/g}$
1%HNO3	6715a1	<0.001	0.004±0.003	0.0829	<0.01	<0.0005	<0.0005	0.006±0.004	0.005±0.003	<0.01	<0.0005
Rm111 1%HNO3	6715a2							0.001±0.001	0.001±0.002		<0.0005
4817-PB	6715a3	120	150±20	162	6220	24	13	<10	<10	1160	<5
4817-BS	6715a28	44.4	145	555	2100	8.3	10±3	150±30	46±44	<100	<5
Spike Recovery			-7%					100%			
4817	6715a27	65.2	74.4	537	1930	8.7	15	120±30	87±38	1500	5.4
4817 Dup.	6715a30	51±6	79.5	405	1700±200	8.9	12	110±30	79±43	1490	5.1
4817-MS	6715a29	71.0	137	761	2460	8±3	12	230±30	84±50	740±100	5±3
Spike Recovery			81%					78%			
4818	6715a31	89.8	164	335	2850	15±3	15	357	220±40	9990	8±3
4818 Dup.	6715a26	84.5	166	532	2480	13±3	14	390	240±30	8440	7.6
4818-MS	6715a25	97.8	228	550±70	3560	23±3	13	506	260±70	9030	8±3
Spike Recovery			90%					94%			
CCV results are in ng/ml (ppb)											
10ppb ICPMS-1	6715a20							9.5±1.8	10±2		9.37
10ppb ICPMS-2	6715a21										
10ppb ICPMS-3	6715a22										
10ppb ICPMS-4	6715a23										
20ppb ICPMS-1	6715a32							18±3	20±4		18.8
20ppb ICPMS-2	6715a33										
20ppb ICPMS-3	6715a34										
20ppb ICPMS-4	6715a35										
4ppb ICPMS-2	6723a15	3.82	3.87				3.51				111
100ppb ICPMS-2	6723a16	96.9	88.8				.96.3				55±14
100ppb ICPMS-2	6723a31	95.4	89.3				94.8				265
300ppb ICPMS-2	6723a38										
50ppb ICPMS-4	6723a17		53.8		49.6						
300ppb ICPMS-4	6723a37		258		275						
100ppb Ca I.V.	6723a20			110±20							
200ppb Ca I.V.	6723a36			184							

James Brown
7/27/96

7/27/94

DATA REVIEW

Reviewed by: ~~Jeff Maye~~
Date: 7/29/96 Pages: 2 of 3

Gary Sevigny Analysis

July 29, 1990

Results are reported in $\mu\text{g/g}$ (ppm) of solid sample

James Brown
7/29/96

Gary Sevigny Anaylsis

July 29, 1996

Results are reported in $\mu\text{g/g}$ (ppm) of solid-sample

DATA REVIEW

Reviewed by: *[Signature]*

Date: 7/29/96 Pages: 3 of 3

Sample Number	ICP/MS Number	La $\mu\text{g/g}$	Nd $\mu\text{g/g}$	Dy $\mu\text{g/g}$	Pb $\mu\text{g/g}$	U $\mu\text{g/g}$
1%HNO3	6715a1	<0.0005	<0.0005	<0.0005	<0.0005	<0.0005
Rm111 1%HNO3	6715a2	<0.0005	<0.0005	<0.0005		<0.0005
4817-PB	6715a3	<5	<5	<5	181	<5
4817-BS	6715a28	<5	<5	<5	136	2.84
Spike Recovery					-180%	113%
4817	6715a27	253	44±5	<5	170±20	44.0
4817 Dup.	6715a30	265	41±8	<5	162	41.3
4817-MS	6715a29	252	37.4	<5	164	46.4
Spike Recovery					-0%	97%
4818	6715a31	760	2480	15±5	109	2420
4818 Dup.	6715a26	827	2630	10±2	76.5	2620
4818-MS	6715a25	846	2870	18.0	105	2650
Spike Recovery					-17%	
10ppb ICPMS-1	6715a20	9.66	11±2	9.73		
10ppb ICPMS-2	6715a21					8.16
10ppb ICPMS-3	6715a22					
10ppb ICPMS-4	6715a23					
20ppb ICPMS-1	6715a32	18.6	20.6	19.5		
20ppb ICPMS-2	6715a33					18.5
20ppb ICPMS-3	6715a34					
20ppb ICPMS-4	6715a35					
4ppb ICPMS-2	6723a15				3.92	
100ppb ICPMS-2	6723a16				109	
100ppb ICPMS-2	6723a31				94.7	
300ppb ICPMS-2	6723a38					
50ppb ICPMS-4	6723a17					
300ppb ICPMS-4	6723a37					
100ppb Ca I.V.	6723a20					
200ppb Ca I.V.	6723a36					

**THIS PAGE INTENTIONALLY
LEFT BLANK**



Project No. 24896

Internal Distribution

File/LB

Date August 19, 1996

To Gary Sevigny

From Ofelia Bredt ^{OTD}

Subject Cadmium Results by ICP/MS on the High Level
Vault Samples

Attached are the revised ICP/MS tables. During transcription of the ICP/MS data, the cadmium result was inadvertently omitted from the August 5, 1996 ICP/MS tables. Please discard the August 5, 1996 ICP/MS tables and replace with the attached ICP/MS tables.

Concurrence M. M. Zill 8-19-96

8/14/96

Gary Sevigny Analysis
July 29, 1996 (revised 8/14/96)

Reviewed by: J. P. Miller
Date: 8/14/96 Pages: 175

Results are reported in $\mu\text{g/g}$ (ppm) of solid sample

Sample Number	ICPMS Number	Mg $\mu\text{g/g}$	Al $\mu\text{g/g}$	Si $\mu\text{g/g}$	Cu $\mu\text{g/g}$	Tl $\mu\text{g/g}$	V $\mu\text{g/g}$	Cr $\mu\text{g/g}$	Mn $\mu\text{g/g}$	Fe $\mu\text{g/g}$	Co $\mu\text{g/g}$
1% HNO ₃	G715a1	<0.001	0.004±0.003	0.0029	<0.01	<0.0005	<0.0005	0.006±0.004	0.005±0.003	<0.01	<0.0005
Dm111 1% HNO ₃	G715a2							0.001±0.001	0.001±0.002		<0.0005
4017-PB	G715a3	120	150±20	102	0220	24	13	<10	<10	1160	<5
4017-DS	G715a28	44.4	145	555	2100	0.3	10±3	150±30	46±44	<100	<5
Spike Recovery			-7%					100%			
4017	G715a27	65.2	74.4	537	1930	0.7	15	120±30	07±38	1500	5.4
4017 Dup.	G715a30	51±6	79.5	405	1700±200	0.9	12	110±30	79±43	1490	5.1
4017-MS	G715a29	71.0	137	731	2400	0±3	12	230±30	84±50	740±100	5±3
Spike Recovery			81%					78%			
4018	G715a31	09.0	164	335	2050	15±3	15	357	220±40	9990	0±3
4018-Dup.	G715a26	04.5	166	532	2400	13±3	14	390	240±30	8440	7.6
4018-MS	G715a25	97.0	22.0	550±70	3560	23±3	13	500	260±70	9030	0±3
Spike Recovery			90%					94%			
CCV results are in ng/ml (ppb)											
10 ppb ICPMS-1	G715a20										
10 ppb ICPMS-2	G715a21							9.5±1.0	10±2		9.37
10 ppb ICPMS-3	G715a22										
10 ppb ICPMS-4	G715a23										
20 ppb ICPMS-1	G715a32										
20 ppb ICPMS-2	G715a33								10±3	20±4	10.8
20 ppb ICPMS-3	G715a34										
20 ppb ICPMS-4	G715a35										
4 ppb ICPMS-2	G723a15	3.02	3.07				3.51				
100 ppb ICPMS-2	G723a10	96.9	88.8				96.3				111
100 ppb ICPMS-2	G723a31	95.4	89.3				94.8				55±14
300 ppb ICPMS-2	G723a30										205
50 ppb ICPMS-4	G723a17			53.0		49.0					
300 ppb ICPMS-4	G723a37			250		275					
100 ppb Ca I.V.	G723a20				110±20						
200 ppb Ca I.V.	G723a36					184					

JH Johnson
8/14/96

8/14/96

Gary Sevigny Analysis

July 29, 1996 (revoked 8/14/96)

Reviewed by: ~~John W. Gage~~
Date: 8/11/96 Pages: 2 of 5

Results are reported in $\mu\text{g/g}$ (ppm) of solid sample

8/14/96

DATA REVIEW

Reviewed by: G. Sevigny
 Date: 8/14/96 Pages: 3 of 5

Gary Sevigny Analysis

July 29, 1996 (revised 8/14/96)

Results are reported in $\mu\text{g/g}$ (ppm) of solid sample

Sample Number	ICPMS Number	La $\mu\text{g/g}$	Nd $\mu\text{g/g}$	Dy $\mu\text{g/g}$	Pb $\mu\text{g/g}$	U $\mu\text{g/g}$
1%HNO3	6715a1	<0.0005	<0.0005	<0.0005	<0.0005	<0.0005
Rm111 1%HNO3	6715a2	<0.0005	<0.0005	<0.0005		<0.0005
4017-PB	6715a3	<5	<5	<5	101	<5
4017-DS	6715a20	<5	<5	<5	130	2.04
Spike Recovery					-180%	113%
4017	6715a27	253	44±5	<5	170±20	44.0
4017 Dup.	6715a30	265	41±8	<5	162	41.3
4017-MS	6715a29	252	37.4	<5	164	40.4
Spike Recovery					-8%	97%
4018	6715a31	760	2400	15±5	109	2420
4018 Dup.	6715a26	827	2630	10±2	76.5	2620
4018-MS	6715a25	846	2070	10.0	105	2050
Spike Recovery					-17%	
10ppb ICPMS-1	6715a20	9.00	11±2	9.70		
10ppb ICPMS-2	6715a21					0.16
10ppb ICPMS-3	6715a22					
10ppb ICPMS-4	6715a23					
20ppb ICPMS-1	6715a32	18.6	20.6	19.5		
20ppb ICPMS-2	6715a33					10.5
20ppb ICPMS-3	6715a34					
20ppb ICPMS-4	6715a35					
4ppb ICPMS-2	6723a15				3.92	
100ppb ICPMS-2	6723a16				109	
100ppb ICPMS-2	6723a31				94.7	
300ppb ICPMS-2	6723a30					
50ppb ICPMS-4	6723a17					
300ppb ICPMS-4	6723a37					
100ppb Ca I.V.	6723a20					
200ppb Ca I.V.	6723a36					

ICP ANALYSIS ON ACIDIFIED SAMPLES

Element Concentration in the Sample

1.0 The ICP/AES analysis are performed by the Analytical Process and Support Laboratory (APSL) using the method APSL-14.
 The instrument used is a Thermo Jarrell-Ash Model 61E Spectrometer located in room 146 in 324 Building.

2.0 Customer	Sevigny		Data File No. 471		
3.0 Laboratory Log No.	1478-96	1479-96	0	0	0
4.0 Customer's Sample ID	Hlv 5	Hlv 11	-0	0	0
	0	0	0	0	0
5.0 Acid used	HNO3	HNO3	0	0	0
6.0 Dilution Factor	10	10	0	0	0
7.0 ICP Analysis	TK104	TK107			

Since the ICP have detection limit values which are different for each element, concentrations below the estimated detection limits are tabulated as negative values. Sample dilution's performed by this laboratory have been corrected in the tabulated "Element Concentration in the Samples".

Element	Concentration Limit	Element Conc in Sample ug/ml					
Ag	0.005	-0.05	-0.05	0.00	0.00	0.00	0.00
Al	0.030	-0.30	-0.30	0.00	0.00	0.00	0.00
B	0.010	33.04	42.30	0.00	0.00	0.00	0.00
Ba	0.003	2.38	6.79	0.00	0.00	0.00	0.00
Be	0.003	-0.03	-0.03	0.00	0.00	0.00	0.00
Bi	0.060	-0.60	-0.60	0.00	0.00	0.00	0.00
Ca	0.100	3.03	5.60	0.00	0.00	0.00	0.00
Cd	0.006	-0.06	-0.06	0.00	0.00	0.00	0.00
Ce	0.040	-0.40	0.47	0.00	0.00	0.00	0.00
Co	0.010	-0.10	-0.10	0.00	0.00	0.00	0.00
Cr	0.020	33.86	62.51	0.00	0.00	0.00	0.00
Cu	0.035	-0.06	-0.06	0.00	0.00	0.00	0.00
Dy	0.006	-0.06	-0.06	0.00	0.00	0.00	0.00
Eu	0.004	-0.04	-0.04	0.00	0.00	0.00	0.00
Fe	0.005	-0.05	-0.05	0.00	0.00	0.00	0.00
K	2.000	-20.00	-20.00	0.00	0.00	0.00	0.00
La	0.01	-0.10	-0.10	0.00	0.00	0.00	0.00
Li	0.01	0.08	0.33	0.00	0.00	0.00	0.00
Mg	0.06	-0.60	1.99	0.00	0.00	0.00	0.00
Mn	0.00	-0.03	0.09	0.00	0.00	0.00	0.00
Mo	0.01	14.91	42.16	0.00	0.00	0.00	0.00
Na	0.05	10699.10	17541.00	0.00	0.00	0.00	0.00
Nd	0.02	-0.20	0.20	0.00	0.00	0.00	0.00
Ni	0.02	0.22	0.33	0.00	0.00	0.00	0.00
P	0.08	3.87	5.53	0.00	0.00	0.00	0.00
Pb	0.08	-0.80	-0.80	0.00	0.00	0.00	0.00
S	0.08	375.09	175.71	0.00	0.00	0.00	0.00
Si	0.01	62.81	58.07	0.00	0.00	0.00	0.00
Sn	0.08	8.89	9.51	0.00	0.00	0.00	0.00
Sr	0.00	1.12	3.53	0.00	0.00	0.00	0.00
Ta	0.06	-0.60	0.83	0.00	0.00	0.00	0.00
Tl	0.00	-0.03	-0.03	0.00	0.00	0.00	0.00
V	0.01	-0.10	-0.10	0.00	0.00	0.00	0.00
Y	0.00	-0.03	-0.03	0.00	0.00	0.00	0.00
Zn	0.05	-0.50	-0.50	0.00	0.00	0.00	0.00
Zr	0.01	-0.10	-0.10	0.00	0.00	0.00	0.00

Total - 11238.40 17962.97 0.00 0.00 0.00 0.00

8.0 Comment

9.0 Calculated by and date

10.0 Approved by and date

tk107

100% deionized water

UIC-107

	tk107 initial	tk107-0.1		tk107-0.2	
Element	mg/L	mg/L	% removed	mg/L	% removed
Al	190.4	1.5	99.2	1.1	99.4
B	144.6	33.4	76.9	27.8	80.8
Ba	1207.8	27.8	97.7	0.8	99.9
Ca	426.9	39.3	90.8	3.0	99.3
Cd	49.4		100.0		100.0
Ce	834.9		100.0		100.0
Cr	426.7		100.0		100.0
Eu	5.4		100.0		100.0
Fe	12923.9	0.0	100.0	0.0	100.0
La	889.5	0.0	100.0		100.0
Mg	49.1	0.7	98.7	0.8	98.4
Mn	244.3		100.0		100.0
Mo	409.4	47.4	88.4	39.8	90.3
Nd	216.4	0.9	99.6	0.9	99.6
P	45.1	0.4	99.2	0.7	98.5
S		38.2		30.7	
Si	39.7		100.0		100.0
Sr	1178.8	228.3	80.6	4.5	99.6
Zn	103.7		100.0		100.0
Zr	14.5	0.0	99.9		100.0

Project No. 24896

Internal Distribution

Date March 18, 1997

File/LB

To Gary Sevigny

From M.M. O'Neill and O.P. Bredt

Subject Analytical Results for High Level Vault (HLV)
Rinse/Filtered Solid and Resin Samples.

A summary of sample preparations and analyses performed, along with a discussion of results, is presented below for the HLV rinse, filtered solid from the HLV rinse, and resin samples. All preparative benchesheets have been provided in Attachment 1, and analytical results are provided in Attachments 2 & 3. The table below outlines the sample client identification (ID), ACL lab ID, description, analytical services request (ASR) reference number, and receipt date.

Client ID	PNNL ACL Lab ID	Description	ASR #	Receipt Date
HLV-30	96-6864	Tank Rinse	3452	9/26/96
HLV-31	96-6865	Tank Rinse	3452	9/26/96
HLV-30 Filtered Solids	97-0631	Filtered Solid	3569	9/26/96
HLV IX-01	97-0832	Resin	3593	10/22/96
HLV IX-02	97-0833	Resin	3593	10/22/96
HLV IX-03	97-0834	Resin	3593	10/22/96
HLV IX-05	97-0835	Resin	3593	10/22/96
HLV IX-07	97-0836	Resin	3593	10/22/96
HLV IX-08	97-0837	Resin	3593	10/22/96

Preparation of Rinse/96-6864 and Filtered Solid/97-0631:

The HLV-30 rinse, 96-6864, was filtered 10/17/96 in the SAL and found to be 0.3% solids by weight. The filtered solid from this sample, 97-0631, was fused according to PNL-ALO-115, on 3/4/97 in the SAL, and aliquoted for total alpha and ICP/MS. Approximately 40 µg of this solid was fused in a nickel crucible and diluted to 100 ml.

RECEIVED

MAR 20 1997

DOE - RL / RN

Gary Sevigny
March 18, 1997
Page 2

Sample 96-6864 was acid digested according to PNL-ALO-128, on 2/4/97 in the SAL, and aliquots were sent for ICP/MS, total alpha and GEA analysis. Approximately one gram of sample was digested and brought to a final volume of 25ml. On 2/11/97, an aliquot of 96-6864 was diluted approximately 100 fold, in the SAL, and sent for tritium analysis. All analytical results have been corrected for dilution(s).

Preparation of Resin Samples/97-0832 through 97-0837:

The resin samples were TCLP extracted according to PNL-ALO-110 on 1/29 and 1/30/97, and acid digested according to PNL-ALO-128 on 2/7/97 in the SAL. The digestates were aliquoted for ICP/MS analysis. All analytical results have been corrected for dilution(s). The ICP/MS results have been reported in ug/g because the sample aliquots were taken gravimetrically instead of volumetrically. Assuming the weights represent a 20ml volume, the highest density would be 1.028 g/ml. The results for Ba, Cd, Cr, and Pb would still be below the TCLP limit if the results were adjusted for the density. Sample HLV IX-05 consisted of only 3.7411 g, resulting in a sample dilution factor of 26.24 during TCLP extraction. If the sample results were increased by a factor of 1.312 to account for the extra dilution, the results for the TCLP metals of interest would still fall below the TCLP limits.

pH Analysis

The pH analysis on HLV-30, sample 96-6864, and HLV-31, sample 96-6865, was performed in the SAL, according to PNL-ALO-225. These results are provided in Attachment 1 along with the TCLP extraction benchesheets. For both analyses, the continuing calibration verification performed at the beginning and end of the analytical batch met quality control limits. Because the pH results for sample 96-6864 and its duplicate were 2.57 and 2.58 respectively, pH analysis was requested for sample HLV-31, (ASR 3452.03). The pH of sample 96-6865 and its duplicate was 7.25 and 7.28, respectively.

Tritium, Total Alpha and GEA Analysis

Sample results for total alpha following PNL-ALO-421, gamma energy analysis following PNL-ALO-450, and tritium following PNL-ALO-418, are in Attachment 2. All quality control requirements were met for the total alpha and tritium analyses of 96-6864, as well as the total alpha of 97-0631. The GEA quality control requirements were also met, except the Cs-134 relative percent difference (RPD) which was 33%. However, calculation of the mean difference for those results gives a value of 0.91, which indicates 95% confidence that the results are equal.

Gary Sevigny
March 18, 1997
Page 3

Inductively Coupled Plasma Mass Spectrometry Analysis

The sample results for ICP/MS following PNL-ALO-280, are in Attachment 3. Only the QC for the analytes of interest which include, Cr, Sr, Cd, Ba, and Pb are discussed below. The remaining analytes and their QC are reported for information only.

Analysis of Fused Filtered Solid/97-0631:

The fusion of the filtered solid, 97-0631, included a sample, process blank, and standard reference material (SRM) 2710. A duplicate was not prepared due to the small amount of sample available. All quality control requirements were met for chromium and barium, and the post spike recoveries were all acceptable, except for cadmium, which was 139%. The high recovery indicates a potential matrix interference, and as a result, the sample results may be biased high. For the process blank, lead and strontium were found at concentrations greater than 5% of that found in the sample. In addition, all CCV's recovered within 90%-110%, except one Cd CCV (121%) and one Pb CCV (120.3%). In the SRM 2710, the Sr recovery (129%) is biased high and Pb recovery (63%) is biased low. However, the Sr concentration in this sample is low, or approximately 2.5 times the blank. In addition, the Pb concentration for this SRM is approximately twice that found in 97-0631, and Pb concentrations at that level can be difficult to solubilize. Because the SRM used does not match the sample matrix, no bias is expected for these analytes.

Analysis of Digested Rinse/96-6864:

The digestion of the HLV-30 tank rinse, 96-6864, included the sample, duplicate, process blank, matrix spike and blank spike. The matrix spike recoveries were within acceptable limits of $100 \pm 25\%$, and the blank spike recoveries were within acceptable recoveries of $100 \pm 20\%$. A post spike was also analyzed, because Sr was not included in the spiking solution, and all recoveries were acceptable. The process blank contained Pb at concentrations greater than 5% of that found in the sample, and the RPD's were within acceptable limits of less than 20%, except Cr, which had an RPD of 33%. Finally, all CCV's recovered within 90%-110%, except one Ba CCV (87.6%), and one Pb CCV (81.1%).

Analysis of Extracted Samples/97-0832 through 97-0837:

The TCLP extraction of the resins, 97-0832 through 97-0837, included the six samples, an extraction blank, process blank, blank spike, matrix spike and one duplicate. A post spike of 97-0837 was also analyzed, because Sr was not included in the spiking solution. The matrix and post spike recoveries were within acceptable limits of $100 \pm 25\%$. The blank spike recoveries were also within acceptable limits of $100 \pm 20\%$, except Cd, which had a slightly low recovery of 79%.

Gary Sevigny
March 18, 1997
Page 4

The concentrations of the primary analytes were low in these samples, and high RPD's for Ba (42%) and Pb (71%) were found for 97-0832 sample and duplicate. The high Ba RPD is the result of the low concentrations found in these preparations. However, the Pb in these samples is near the level found in the process and extraction blanks, and may be the result of contamination. These blanks also contained Sr, at concentrations greater than 5% of that found in the samples. All CCV's recovered within 90%-110%, except one Ba CCV (87.6%), and one Pb CCV (81.1%). However, even if the results are increased by a factor of 20% to account for the low bias in the CCV discussed above, none of the primary analyte concentrations would fall above the TCLP limit.

Concurrence

K. Ladd - Kugler

Attachment 1

Shielded Analytical Laboratory
Bench Sheet

Client: GARY SEVIGNY

WP Number: K37308

TI#/ASR: ASR 3452

Procedure: BENCH INSTRUCTION

96-06864 HLV-30 FILTRATION

SAMPLE IDENTIFICATION

SNAP CAP VIAL LID TARE WEIGHT (GRAMS): 3.5903 3.5717

FILTER PAPER + SNAP CAP VIAL TARE WEIGHT (GRAMS): 3.0115 3.5963

SNAP CAP VIAL LID + FILTER PAPER + DRIED SOLIDS WEIGHT (GRAMS): 3.6276 3.6277

WEIGHT OF DRIED SOLIDS (GRAMS): 0.0161 0.0314

FILTRATE

HLV-30 VIAL + CAP GROSS WEIGHT (GRAMS): 17.2595

HLV-30 VIAL + CAP TARE WEIGHT (GRAMS): 32.8084

WEIGHT OF ORIGINAL SAMPLE (GRAMS): 15.5459

PERCENT SOLIDS (BY WEIGHT) = (WEIGHT OF DRIED SOLIDS / WEIGHT OF ORIGINAL SAMPLE) X 100

= 0.3 %

SAMPLE WAS FILTERED WITH MILLIPORE TYPE BS 2.0µM
25MM FILTER PAPER. DRY SOLIDS VIAL TARE = 8.5965

GROSS = 8.6430

M&TE: Cell 2 (360-06-01-016) Mettler AE160 Balance Other _____
 Cell 5 (360-06-01-039) Mettler AT400 Balance
 Bench (360-06-01-040) Denver A160 Balance
 Cell 5 (360-06-01-045) Toledo 3026 Balance

Analyst:

Date:

Reviewer:

Date:

Gary Sevigny

10/17/96

Rick Miller

10/17/96

NL-ALO-128

Nitric and Hydrochloric Acid Extraction of High-level Radioactive Liquids and TCLP Leachates

Client: G. Sevigny

QA plan: MCS-033

Work Auth. Doc (WAD): ASR 3452.02

Impact level: II

Work Package/Project: KG1902

Balance M&TE:

Tank/Core/Other ID: High Level Vault Tank

Prep. lab (SAL or SRPL): SAL

Additional Information: HIGH LEVEL VAULT TANK RINSE

ALO #	Client ID	Sample weight (g)	Spike volume (ml)	Final extract volume (ml)	Process Factor			
1	96-06864-PB	PROCESS BLANK						
2	96-06864-BS	BLANK SPIKE	0.5791	.5013	.25	18.16	SPIKE WT. = .5791	
3	96-06864	HLV-30	0.9853		.25	35.37		
4	96-06864-DUP	HLV-30	0.9823		.25	35.45		
5	96-06864-MS	HLV-30	1.0706	.5013	.25	27.35	SPIKE WT. = .5852	
6								
7								
8								
9								
10								
11								
12								
13								
14								
15								
16								

Analyst comments (e.g. identification number for spikes, sample preparation problems encountered, unusual sample properties):	SAMPLES FILTERED: 5/14	YES <input checked="" type="checkbox"/>	NO <input type="checkbox"/>
9 ml Calib. 9.0218 $\bar{x} = 9.0582 \pm 14$ Diln @ 33°C 7.0283 $s = .00334$ 9.0317 $s = .00334$ 9.0198 RSD = .06% (16) 9.0200 (Dil = 9.0443/ml) $\bar{x} = .0959 \bar{x} = .0988$ $s = .0982 s = .0002$ $s = .0959 RSD = .270$ $s = .0941 (Dil = .0990) \bar{x} = .4993 \bar{x} = .5001$ $s = .5005 s = .0006$ $s = .5002 RSD = .172$ $s = .5005 RSD = .172$ $\bar{x} = .4997 (Dil = .5013 ml)$			

Analyst/Date:

J. Sevigny 2/4/97

Reviewer/Date:

J. Sevigny 2/5/97

rev.2.0 3-9-95 JMR

SAMPLE PREP SHEET
(325 SHIELDED ANALYTICAL LABORATORY)

TIA/RF NO.: ASR 3452.02 PROJECT NO.: 27223 WDS NO.:

SAMPLE TYPE: LIQUID

ISSUED BY: RT STEELE DATE: 1/30/91

PREP TYPE: ACID DIGEST (PNL-ALO-128)

ANALYST: DATE: 2/2/97

CONTROLLING PROCEDURE: PNL-ALO-010

REVIEW: Kicker Stake DATE: 2/8/97

QA PLAN: MCS-033 IMPACT LEVEL: II

CLIENT: G. SEVIGNY CORE ID: NA TANK ID: HIGH LEVEL VAULT

• Sr,Pb,Cr,Cd,Ba is of interest.

$$\frac{0.770}{C_6} = 9.2 \cdot 1.25 = 9.2 \cdot 1.25$$

SAMPLE PREP SHEET
(325 SHIELDED ANALYTICAL LABORATORY)

TI/ARF NO.: ASR 3452.02 PROJECT NO.: 27223 WBS NO.:

SAMPLE TYPE: LIQUID

ISSUED BY: RT STEELE DATE: 1/30/97

PREP TYPE: ACID DIGEST (PNL-ALO-120)

ANALYST: J. Michael Johnson DATE: 2/2/22

CONTROLLING PROCEDURE: PNL-ALO-010

REVIEW: Ticky Tacky DATE: 3/8/97

QA PLAN: MCS-033 IMPACT LEVEL: II

CLIENT: G. SEVIGNY CORE ID: NA TANK ID: HIGH LEVEL VAULT

TOTAL ALPHA ONLY IF pH <9

$$-0.990 \rightarrow 9.0492 = 92.470$$

PNL-ALO-115

Solubilization of Metals from Solids Using a KOH-KNO₃ Fusion

Client name: GARY SEVIGNY

Work Auth. Doc (WAD): ASR 3569

Tank/Core/Project: 24B96

Special Instructions

Work package number:

Project number:

PNL QA plan:

K37308

24B96

MCS-033

II

PNL impact level:

SAL

Prep. lab (SAL/SPRU/Other):

Preparation batch number:

	ACL Sample ID	ACL order number or Client sample ID	Crucible Identifier	Crucible weight (g)	Crucible + sample weight (g)	Sample weight (g)	Spike added Vol. (ml)	Final solution Weight. (g)	Process Volume (ml)	Process Factor (1)
1	97-00631-PD-Ni	PROCESS BLANK	1						100	
2	97-00631-Ni	HLV-30 FILTERED SOLIDS	8	39.0709	39.1124	0.0415)	2404.64
3	SRM 2710-Ni	LCS/HLV-30/Ni	9	32.3941	32.4755	0.0814			.6	1225.57
4										
5										
6										
7										
8										
9										
10										
11										
12										
13										
14										

Analyst's sample preparation comments:

DOSE RATE:

Spike source:

PNL spike ID number:

Anal. balance MATE: 360.00 17.0

HCl volume added (ml):

2

Solution heated (yes/no):

yes

Sample filtered (yes/no):

no

(1) Process factor = Final volume (ml) / [Crucible & sample weight (g) - Crucible weight (g)]

Other sample preparation worksheets may be substituted at the discretion of the Coringant Scientist. Use one worksheet per client.

Analyst/Dates: *Gary Sevigny 12/3/96*

Reviewer/Dates:

John J. Stiles 12/3/96

SAMPLE PREP SHEET
(325 SHIELDED ANALYTICAL LABORATORY)

TII/ARF NO.: ASR 3569 PROJECT NO.: 24896 WBS NO.:

SAMPLE TYPE: SOLIDS

ISSUED BY: RT STEELE DATE: 11/14/96

PREP TYPE: NIKOH FUSION

ANALYST: J. L. Jackson, Jr. DATE: 12-3-96

CONTROLLING PROCEDURE: PNL-ALO-010

REVIEW: Kicker Sticks DATE: 12/3/96

QA PLAN: MCS-033 IMPACT LEVEL: II

CLIENT: G. SEVIGNY CORE ID: N/A TANK ID: N/A

SAMPLE PREP SHEET
(325 SHIELDED ANALYTICAL LABORATORY)

TI/ARF NO.: ASR 3569 PROJECT NO.: 2489G WBS NO.:

SAMPLE TYPE: SOLIDS

ISSUED BY: RT STEELE DATE: 11/14/96

PREP TYPE: NI/KOH FUSION

ANALYST: D. Lundström DATE: 1-2-3-96

CONTROLLING PROCEDURE: PNL-ALO-010

REVIEW: Kathy Stiles DATE: 12/3/96

QA PLAN: MCS-033 IMPACT LEVEL: II

CLIENT: G. SEVIGNY CORE ID: N/A TANK ID: N/A

Shielded Analytical Laboratory
Bench Sheet

Client: GARY SEVIGNY

WP Number: K61902

TI#/ASR: ASR 3593

Procedure: PNL-ALO-110

97-00832 THRU 97-00837 TCLP EXTRACTION GENERAL NOTES

SAMPLE IDENTIFICATION

Original pH check on 1x02

13.7140

13.2680

0.5060 g. + 10 ml. DIW.

pH started out at 9.4

After 1st addition it was 2.4 : extraction fluid will
be used for its extraction.

M&TE: Cell 2 (360-06-01-016) Mettler AE160 Balance Other

Cell 5 (360-06-01-039) Mettler AT400 Balance

Bench (360-06-01-040) Denver A160 Balance

Cell 5 (360-06-01-045) Toledo 3026 Balance

Analyst:

Date:

Reviewer:

Date:

1/29/97

Rick Steele

1/30/97

pH ANALYSIS
(325 SHIELDED ANALYTICAL LABORATORY)

CLIENT: GARY SEVIGNY

WORK PACKAGE: K61902 ASR/ARF/LOI/TI: ASR 3593

QA PLAN: MCS-033

IMPACT LEVEL: II

97-00833-HLV IX-02-EXTRACTION FLUID DETERMINATION

SAMPLE IDENTIFICATION

CALIBRATION CHECK POINTS: 4 (Calib) / 7 (Calib) / 10 (Control) PROCEDURE: PNL-ALO-225

BUFFER LOT NUMBER: 953624-24 1 961196-24 1 965222-24 1 950555 M&TE:

BUFFER EXPIRATION DATE: 5/97 3/98 10/98 3/97 Corning pH Meter S/N 0029

Analyst:

Date:

Reviewer

Date:

J. W. Jackson, Jr.

1/29/2020

R. V. Steele

1/30/97

Shielded Analytical Laboratory
Bench Sheet

Client: GARY SEVIGNY

WP Number: K61902

TI# / ASR: ASR 3593

Procedure: PNL-ALO-110

97-00832 THRU 97-00837 TCLP EXTRACTION GENERAL NOTES

SAMPLE IDENTIFICATION

Weighted up 5 grams of each sample except 1X-5 which may total about 4 grams total.
Added 100 mls of Extract #1 determined by pH check. Then mixed for 18 hrs. extracted at 4:30 1/29/97 and stopped at 10:30 1/30/97
Filtered and stored in 125 ml poly bottles. Took out about 6 mls for pH analysis

M&TE: Cell 2 (360-06-01-016) Mettler AE160 Balance Other

Cell 5 (360-06-01-039) Mettler AT400 Balance

Bench (360-06-01-040) Denver A160 Balance

Cell 5 (360-06-01-045) Toledo 3026 Balance

Analyst:

Date:

Reviewer:

Date:

Fiona J. Hite 1/31/97 Fiona J. Hite 2/3/97

Shielded Analytical Laboratory
TCLP EXTRACTION

Project Id: 27223

WP Number: K61902

TI/ASR Number: ASR 3593

Sample Ident.	Sample Gross Wt (g)	Sample Tare Wt (g)	Sample Net Wt (g)	HOAc Gross Wt (g)	HOAc Tare Wt (g)	HOAc Net Wt (g)	Spike Volume
97-00832-EB EXTRACTION BLANK				130.2510	30.7503	99.5005	
97-00832 HLV-IX-01	37.2606	32.3647	5.0559	132.7290	31.9861	100.7429	
97-00833 HLV-IX-02	35.6540	30.35486	5.1066	134.2061	35.4562	98.7199	
97-00834 HLV-IX-03	37.6476	32.5732	5.0544	131.3722	31.5373	100.3549	
97-00835 HLV-IX-5	34.3989	30.6578	3.7411	133.0193	34.8721	98.1472	
97-00836 HLV-IX-07	35.6968	32.11338	5.2630	135.1927	34.9823	100.2104	
97-00837 HLV-IX-08	37.3265	32.2129	5.1136	130.9632	30.5031	100.4601	

Spike Id: _____

Used all sample.

- STE: Cell 2 (360-06-01-016) Mettler AE160 Balance Other _____
 Cell 5 (360-06-01-039) Mettler AT400 Balance
 Bench (360-06-01-040) Denver A160 Balance
 Cell 5 (360-06-01-045) Toledo 3026 Balance

Catalyst: Margie Hayes

Date: 4/30/97

Reviewer: Jeanne Miller

Date: 2/3/97

Analytical Chemistry Laboratory
Shielded Analytical Laboratory

pH ANALYSIS
(325 SHIELDED ANALYTICAL LABORATORY)

CLIENT: GARY SEVIGNY

WORK PACKAGE: K61902 ASR/ARF/LOI/TI: ASR 3593

QA PLAN: MCS-033

IMPACT LEVEL: II

HIGH LEVEL VAULT RESIN TCLP POST EXTRACTION FLUID
SAMPLE IDENTIFICATION

ACL NUMBER	SAMPLE IDENTIFICATION	OBSERVED pH
	CONTROL BUFFER 7	6.99
97-00832-EB	EXTRACTION BLANK	11.79
97-00832-EB	EXTRACTION BLANK	11.80
97-00832	HLV-IX-01	5.14
97-00832	HLV-IX-01	5.16
97-00833	HLV-IX-02	5.16
97-00833	HLV-IX-02	5.18
97-00834	HLV-IX-03	5.08
97-00834	HLV-IX-03	5.09
97-00835	HLV-IX-5	5.05
97-00835	HLV-IX-5	5.08

CALIBRATION CHECK POINTS: 4 (Calib) / 7 (Calib) / 7 (Control)

PROCEDURE: PNL-ALO-225

BUFFER LOT NUMBER: 953624-24 / 961196-24 / 950353-24

M&TE:

BUFFER EXPIRATION DATE: 5/97 / 3/98 / 2/97

Corning pH Meter S/N 6629

Analyst:

Date:

Reviewer:

Date:

Gary Sevigny

1/31/97

Peter H. Hale

2/3/97

pH ANALYSIS
(325 SHIELDED ANALYTICAL LABORATORY)

CLIENT: GARY SEVIGNY

WORK PACKAGE: KG1902 ASR/ARF/LOI/TI: ASR 3593

QA PLAN: MCS-033

IMPACT LEVEL: II

HIGH LEVEL VAULT RESIN TCLP POST EXTRACTION FLUID
SAMPLE IDENTIFICATION

CALIBRATION CHECK POINTS: _____ (Calib) / _____ (Calib) / _____ (Control) PROCEDURE: PNL-ALO-225

BUFFER LOT NUMBER: / /

BUFFER EXPIRATION DATE: / /

Corning pH Meter S/N 6029

Analyst:

Date:

Reviewer

Date:

1/31/97

2/3/07

PNL-ALO-128

Nitric and Hydrochloric Acid Extraction of High-level Radioactive Liquids and TCLP Leachates

Client: G. Sevigny

QA plan: MCS-033

Work Auth. Doc (WAD): ASR 3593

Impact level: II

Work Package/Project: K61902 27223

Balance M&TE: BlcO-(Xn-CI - Cl) Cr

Tank/Core/Other ID: High Level Vault Tank

Prep. lab (SAL or SRPL): SAL

Additional Information: TCLP LEACH OF HLV RESIN SAMPLES

ALO #	Client ID	Sample weight (g)	Spike volume (ml)	Final extract volume (ml)	Process Factor			
1	97-00832-EB	EXTRACT BLANK	19.4321	.25	1.29			
2	97-00832-PB	PROCESS BLANK			1.27	1/1/97		
3	97-00832-BS	BLANK SPIKE	0.5211	501.3				
4	97-00832	HLV IX-01	20.5674		1.22			
5	97-00832-DUP	HLV IX-01	19.1753		1.30			
6	97-00832-MS ✓	HLV IX-01	17.4387	501.3	1.29	SPike wt = .1826		
7	97-00833	HLV IX-02	20.0628		1.25			
8	97-00834	HLV IX-03	20.5302		1.22			
9	97-00835	HLV IX-5	19.9903		1.25			
10	97-00836	HLV IX-07	19.5071		1.28			
11	97-00837	HLV IX-08	20.3549		1.23			
12								
13								
14								
15								
16								

Analyst comments (e.g. identification number for spikes, sample preparation problems encountered, unusual sample properties):

SAMPLES FILTERED:

YES NO For P: per calib. see Bench sheet for
HLV Tank Rinse ASR 345-2.02

Spike = A 966321-TCLP

Analyst/Date: *John F. Rogers* 2/7/97Reviewer/Date: *Rod S. Steele* 2/7/97

rev.2.0 J-9-95 JAR

SAMPLE PREP SHEET
(325 SHIELDED ANALYTICAL LABORATORY)

TIA/RFC NO.: ASR-3593 PROJECT NO.: 27223 WBS NO.:

SAMPLE TYPE: LIQUID

ISSUED BY: RT STEELE DATE: 1/31/97

PREP TYPE: ACID DIGEST (PNL-ALO-128)

ANALYST: J. P. Gandy, Jr. DATE: 2/7/97

CONTROLLING PROCEDURE: PNL-ALO-010

REVIEW: Printed Style DATE: 2/7/97

QA PLAN: MCS-033 IMPACT LEVEL: II

CLIENT: G. SEVIGNY CORE ID: N/A TANK ID: HIGH LEVEL VAULT TANK

Cd, Cr, Ba, Pb OF INTEREST

$$\text{D.L. Factor: } .0990 \rightarrow \frac{9.04}{.0990} = 92.44$$

SAMPLE PREP SHEET
(325 SHIELDED ANALYTICAL LABORATORY)

TI/ARF NO.: ASR 3593 PROJECT NO.: 27223 WBS NO.: .

SAMPLE TYPE: LIQUID

ISSUED BY: RT STEELE DATE: 1/31/97

PREP TYPE: ACID DIGEST (PNL-ALO-120)

ANALYST: J. L. Johnson DATE: 2/7/97

CONTROLLING PROCEDURE: PNL-ALO-010

REVIEW: First Grade DATE: 2/7/97

QA PLAN: MCS-033 IMPACT LEVEL: II

CLIENT: G. SEVIGNY CORE ID: N/A TANK ID: HIGH LEVEL VAULT TANK

Cd: Cr. Ba.: Pp. OF INTEREST

$$\text{Diff. FACT: } .0990 \rightarrow \frac{9.00 \text{ to } 9.90}{.0990} = 92.4X$$

Analytical Chemistry Laboratory
Shielded Analytical Laboratory

pH ANALYSIS
(325 SHIELDED ANALYTICAL LABORATORY)

CLIENT: GARY SEVIGNY

WORK PACKAGE: KG1902

ASR/ARF/LOI/TI: ASR 3452.03

QA PLAN: MCS-033

IMPACT LEVEL: _____ II

96-06865 HLV-31

CALIBRATION CHECK POINTS: / (Calib) / / (Calib) / / (Control)

PROCEDURE: PNL-ALO-225

BUFFER LOT NUMBER: 953624-24 1956355-24 1964924-24

M&TE

BUFFER EXPIRATION DATE: 5-97 1 2-97 1 5-98

Corning pH Meter S/N 6029

Analyst: 6

Date:

2/27/22

Reviewer:

Reviewer:

Date:

3/22/27

Shielded Analytical Laboratory
Bench Sheet

Client: G. SEVIGNY

WP Number: K61902

TI# / ASR: ASR 3452.02

Procedure: BENCH INSTRUCTION

96-6864 HLV-30 TRITIUM SUBALIQUOT

SAMPLE IDENTIFICATION

10 ml First dilution at 22°C

.1 ml First dilution at 22°C

10.0447 g = 10.0439 g.

.0986 g = .0985 g

10.0409 g = .0032

.0983 g = .0002

10.0476 RSD = .03%

.0984 g = .2%

10.0466 RSD = .03%

.0988 g = .2%

Wt/d = 10.0663 ml.

Wt/g = .0987 ml.

.0987 → 10.0663 = 102.99 g

.0987

Made a 102.99 g solution using Distilled Water

M&TE: Cell 2 (360-06-01-016) Mettler AE160 Balance Other _____

Cell 5 (360-06-01-039) Mettler AT400 Balance

Bench (360-06-01-040) Denver A160 Balance

Cell 5 (360-06-01-045) Toledo 3026 Balance

Analyst:

Date:

Reviewer:

Date: 11/11/97

G. Sevigny

3/11/97

R. L. Hsu

3/11/97

SAMPLE PREP SHEET
(325 SHIELDED ANALYTICAL LABORATORY)

TI/ARF NO.: ASR 3452.02 PROJECT NO.: 27223 WBS NO.:

SAMPLE TYPE: LIQUID

ISSUED BY: RT STEELE DATE: 2/04/97

PREP TYPE: NONE

ANALYST: Christopher Blomma DATE: 2/11/27

CONTROLLING PROCEDURE: PNL-ALO-010

REVIEW: Eric J. Heller DATE: 2/11/97

QA PLAN: MCS-033 IMPACT LEVEL: II

CLIENT: GARY SEVIGNY CORE ID: N/A TANK ID: _____

D.L.: -0937 → 10.0663 = 102.99x
-0557

Attachment 2

Battelle Pacific Northwest Laboratory
Analytical Chemistry Laboratory
Radioanalytical Group • 325 Bldg.

96-6864
2/28/97

Client : G. Sevigny
Wp#: K61902

Cognizant Scientist: M.L. Sevigny Date: 2/23/97
Concur: Ronald T. Ross Date: 2/28/97

Measured Activities (uCi/g)

ALO ID Client ID	Total Alpha Error +/-	Tritium Error +/-	Cs-134 Error +/-	Cs-137 Error +/-	Eu-154 Error +/-	Am-241 Error +/-
96-6864-PB Process Blank	< 5E-5	<4.E-3	< 2E-4	8.36E-4 9%	< 4E-4	< 6E-4
96-6864 HLV-30	1.10E-1 10%	<4.E-3	6.67E-1 13%	1.05E+3 2%	5.49E+0 3%	6.22E+0 14%
96-6864-DUP HLV-30	1.05E-1 10%	<4.E-3	4.78E-1 12%	1.01E+3 2%	5.44E+0 3%	6.15E+0 14%
RPD	4%		33%	4%	1%	1%
Standard	98%	98%				
Matrix Spike	105%	98%				
Blank		<4.E-3				

Battelle Pacific Northwest Laboratory
Analytical Chemistry Laboratory
Radioanalytical Group - 325 Bldg.

97-631
3/4/97

Client : G. Sevigny
Wp#: K61902

Cognizant Scientist:

J.K. Sevigny
T. Tizang - L

Date :

3/4/97

Concur:

Date :

3/4/97

Measured Activities ($\mu\text{Ci/g}$)

ALO ID Client ID	Total Alpha Error +/-
97-631-PB Process Blank	<5.E-3
97-631 HLV-30-Filtered Solids	2.92E 2 5%
97-631 Dup HLV-30-Filtered Solids	3.05E 2 5%
Standard	61%
Matrix Spike	62%
Blank	<5.E-3

Attachment 3



Project Number

Internal Distribution

Date March 6, 1997
To Ofelia Bredt
From Eric Wyse *Eric*
Subject ICP/MS Analysis of HLV Samples
(ACL #97-00631; 00832 thru 837; 00864)

Pursuant to your request, the 11 resin TCLP leach samples, the 5 tank rinse samples, and the 3 filtered solids digestions (including corresponding QC) that you submitted were analyzed by ICP/MS quantitatively for Cr, Sr, Cd, Ba and Pb. The samples were dissolved by the 325 hot cell staff with a total process dilution factor of ~2500X, and we diluted them an additional 2X-100X for analysis. The concentration results of these primary analytes are displayed on the attached spreadsheet. Other analytes are also reported for information.

The quality control results for the primary analytes of interest were all within acceptance criteria for the resin leaches and the tank rinses. Most of the other analytes in these sample sets were also acceptable; those that are not are highlighted in gray. There were some problems, however, with the QC on the filtered solids preps. The most notable was with the SRM prep. Most of the SRM results were not within acceptance limits. Most of the other QC results were acceptable. Exceptions for the primary analytes of interest included one CCV for Cd and one for Pb. There was also one unacceptable spike sample recovery for Cd, however this can be attributed to the relatively high concentration of Cd found in the sample. QC results for other analytes was varied; sample results for these analytes are reported for information only. Please note the QC results for each analyte when evaluating the data.

If you have any questions regarding this analysis, please give me a call at 376-3074.

ICP/MS Analysis of HLV Filtered Solids

March 5, 1997

Reviewed by: *C. M. Pfeifer*
 Date: 3/6/97 Pages: 1 of 4

Results are reported in $\mu\text{g/g}$ (ppm) of original sample

Sample Number	Client ID	ICP/MS Number	Cr $\mu\text{g/g}$	Sr $\mu\text{g/g}$	TlCd $\mu\text{g/g}$	Da $\mu\text{g/g}$	Pb $\mu\text{g/g}$	Be $\mu\text{g/g}$	Mg $\mu\text{g/g}$	V $\mu\text{g/g}$	Mn $\mu\text{g/g}$
1%HNO3		7303a1	<100	<50	<1	<100	<50	<1	<2	<100	<100
1%HNO3		7303a1G	<100	<50	<1	<100	<50	<1	<2	<100	<100
1%HNO3		7303a24	<100	<50	<1	<100	<50	<1	<2	<100	<100
97-00631-PB	Process Blank	7303a25	<100	130±100	<1	250±220	200±150	1,110.4	142	<100	<100
97-00631-NI	HLV-30 Filtered Solids	7303a26	1500	1260	120	30700	2150	2,510.6	132	2120	2743
97-00631-NI	HLV-30 Filtered Solids	7303a27	2000±300	1300±300	120	34000±6000	2760	3,111.3	139	1670	3100±650
97-00631-Ni + spike	HLV-30 Filtered Solids	7303a29&30	10400	4730	150	20400	11.5	2400	11100	7649	
Spike Recovery			110%	86%	139%		91%	76%	113%	112%	122%
SRM 2710-NI	LCS/HLV-30/Ni	7303a28		130±100	2014	640±3400	6.24	10760		11000	
True Value				240	21.8	707	5530	8530		10100	

CCV results are reported in $\mu\text{g/ml}$ (ppb)

INT-OC-MCVA-1	7220a14	26.4									
True Value		25.0									
INT-ICP1.1A	7220a21							113			
INT-ICP1.1A	7220a51							115			
True Value								125			
INT-ICP1.1D	7303a21										
INT-ICP1.1D	7303a36										
True Value											
CLMS-1 10ppb	7220a25										
CLMS-1 10ppb	7220a57										
INT-OC-MCVB-3	7303a17										
INT-OC-MCVB-3	7303a32										
True Value											
1643d (10x)	7303a18	302		537			7220				
1643d (10x)	7303a33	205		525			7340				
1643d	7303a19	10.1	275	540	11.3		33.1	37.4			
1643d	7303a34	19.5	205	503	17.0		36.5	39.1			
True Value		10.5	295	6.47	506	18.2	12.5	7990	35.1	37.7	
INT-ICP1.5/Cs	7303a20										
INT-ICP1.5/Cs	7303a35										
True Value											
INT-OC-MCVB-2	7303a22										
INT-OC-MCVB-2	7303a37										
True Value											

†Results are from procedure 7220a (2x dilution)

*Result is from procedure 7303a (50x dilution)

HLV 3/3/97

J/Braun
3/4/97

ICP/MS Analysis of HLV Filtered Solids

March 5, 1997

Results are reported in $\mu\text{g/g}$ (ppm) of original sampleReviewed by: E. J. Mire
Date: 3/6/97 Pages: 2 of 11

Sample Number	Client ID	ICP/MS Number	tCo $\mu\text{g/g}$	tCu $\mu\text{g/g}$	tZn $\mu\text{g/g}$	tAs $\mu\text{g/g}$	tPb $\mu\text{g/g}$	Zr $\mu\text{g/g}$	Nb $\mu\text{g/g}$	Mo $\mu\text{g/g}$	tRh $\mu\text{g/g}$
1%HNO3		7303a1	<1	<2	<2	<1	<1	<50	<50	<50	<1
1%HNO3		7303a16	<1	<2	<2	<1	<1	<50	<50	<50	<1
1%HNO3		7303a24	<1	<2	<2	<1	<1	<50	<50	<50	<1
97-00631-PB	Process Blank	7303a25	5.3±1.0	34.7	77.0	34.5	272	170±70	58±15	100±40	<1
97-00631-NI	HLV-30 Filtered Solids	7303a26	109	220	200±20	315	766	44000	10459	59600	307
97-00631-NI	HLV-30 Filtered Solids	7303a27	223	366	256	404	020	54000±10000	12000±2000	65000±14000	418
97-00631-Ni + spiko	HLV-30 Filtered Solids	7303a29&30	340±40	375	360±60	577	805				404
Spike Recovery			94%	95%	100%	95%	67%				100±40%
SRM 2710-Ni	LCS/HLV-30/NI	7303a28									
True Value											
INT-OC-MCVA-1		7228a14	50.0	40.0	50.0	110					
True Value			50.0	50.0	50.0	125					
INT-ICP1.1A		7228a21	10.3	10.3		0.95					
INT-ICP1.1A		7228a51	10.0	10.0		1.02					
True Value			10.0	10.0		10.0					
INT-ICP1.1D		7303a21						20.0			0.30
INT-ICP1.1D		7303a36						24.0			9.51
True Value											
CLMS-1 10ppb		7228a25									
CLMS-1 10ppb		7228a57									
INT-OC-MCVD-3		7303a17									
INT-OC-MCVD-3		7303a32									
True Value											2.00
1643d (10x)		7303a10									
1643d (10x)		7303a33									
1643d		7303a19									
1643d		7303a34	26.8	55.5	60.6	50.0	9.07				99.0
True Value			25.0	56.1	72.5	56.0	10.0				97.4
113											
INT-ICP1.5/Cs		7303a20									
INT-ICP1.5/Cs		7303a35									
True Value											
INT-OC-MCVD-2		7303a22									1.07
INT-OC-MCVD-2		7303a37									1.97
True Value											2.00

*Results are from procedure 7228a (2x dilution)

*Result is from procedure 7303a (50x dilution)

*Results are from procedure 7228a (4x dilution)

HLV 3/3/97

JJ Dawson
3/6/97

ICP/MS Analysis of HLV Filtered Solids

March 5, 1997

Reviewed by: EG Moore
Date: 3/6/97 Pages: 3 of 11Results are reported in $\mu\text{g/g}$ (ppm) of original sample

Sample Number	Client ID	ICP/MS Number	Pd $\mu\text{g/g}$	fSn $\mu\text{g/g}$	fSb $\mu\text{g/g}$	Cs $\mu\text{g/g}$	fLa $\mu\text{g/g}$	fCe $\mu\text{g/g}$	fPr $\mu\text{g/g}$	fNd $\mu\text{g/g}$	fEu $\mu\text{g/g}$	fGd $\mu\text{g/g}$
1%HNO3		7303a1	<50	<2	<1	<100	<1	<1	<1	<1	<1	<1
1%HNO3		7303a16	<50	<2	<1	394	<1	<1	<1	<1	<1	<1
1%HNO3		7303a24	<50	<2	<1	200	<1	<1	<1	<1	<1	<1
97-00631-PB	Process Blank	7303a25	<50	4±1	<1	390±150	<1	2±2	<1	<1	<1	<1
97-00631-NI	HLV-30 Filtered Solids	7303a26	30100	708	109	3170	55.9	43.5	19±2	50±9	6±4	2±2
97-00631-NI	HLV-30 Filtered Solids	7303a27	42000±9000	762	110	3000±1400	66.7	43.5	22±8	50±5	9±1	<1
97-00631-Ni + spike	HLV-30 Filtered Solids	7303a29&30		797	260	194000	88.8	77.3	49.4	74.1	39.4	42±8
Spike Recovery				129%	88%	79%	80%	82%	74%	80%	82%	98%
SRM 2710-Ni	LCS/HLV-30/Ni	7303a20										
True Value				17.4	130	16.4	31.2	17.3	17.3	17.3	17.3	17.3
				38.4	107	34.0	57.0	38.4	38.4	38.4	38.4	38.4

INT-OC-MCVA-1 7220a14

True Value

INT-ICP1,1A 7220a21

INT-ICP1,1A 7220a51

True Value

INT-ICP1,1B 7303a21

INT-ICP1,1B 7303a36

True Value

CLMS-1 10ppb 7220a25

CLMS-1 10ppb 7220a57

0.03 0.00 10.8 9.20 11.0 10.2
9.59 0.04 10.9 9.50 10.3 9.05

INT-OC-MCVB-3 7303a17

INT-OC-MCVB-3 7303a32

True Value 4.00

1643d (10x) 7303a10

1643d (10x) 7303a33

1643d 7303a19

1643d 7303a34

True Value 54.0

INT-ICP1,S/Cs 7303a20

INT-ICP1,S/Cs 7303a35

True Value 50.0

INT-OC-MCVB-2 7303a22

INT-OC-MCVB-2 7303a37

True Value 2.00

(Results are from procedure 7220a (2x dilution))

HLV 3/3/97

3/6/97

ICP/MS Analysis of HLV Filtered Solids

March 5, 1997

Results are reported in $\mu\text{g/g}$ (ppm) of original sample

Sample Number	Client ID	ICP/MS Number	tTb $\mu\text{g/g}$	tDy $\mu\text{g/g}$	tHo $\mu\text{g/g}$	tEr $\mu\text{g/g}$	tTm $\mu\text{g/g}$	tYb $\mu\text{g/g}$	U $\mu\text{g/g}$
1%HNO ₃		7303a1	<1	<1	<1	<1	<1	<1	<50
1%HNO ₃		7303a16	<1	<1	<1	<1	<1	<1	<50
1%HNO ₃		7303a24	<1	<1	<1	<1	<1	<1	<50
97-00631-PD	Process Blank	7303a25	<1	<1	<1	<1	<1	<1	<50
97-00631-NI	HLV-30 Filtered Solids	7303a26	<1	1±1	<1	<1	<1	<1	680±380
97-00631-NI	HLV-30 Filtered Solids	7303a27	<1	<1	<1	<1	<1	<1	1060
97-00631-NI + spiko	HLV-30 Filtered Solids	7303a29&30	32.8 79%	26±12 61%	31±5 75%	37±7 89%	34.9 84%	40±9 96%	107000 110%
Spike Recovery									
SRM 2710-Ni	LCS/HLV-30/Ni	7303a20							
True Value									

INT-OC-MCVA-1 7220a14

True Value

INT-ICP1.1A 7220a21

INT-ICP1.1A 7220a51

True Value

INT-ICP1.1B 7303a21

INT-ICP1.1B 7303a36

True Value

CLMS-1 10ppb 7220a25

CLMS-1 10ppb 7220a57

INT-OC-MCVB-3 7303a17

INT-OC-MCVB-3 7303a32

True Value

1643d (10x) 7303a18

1643d (10x) 7303a33

1643d 7303a19

1643d 7303a34

True Value

INT-ICP1.5/Cs 7303a20

INT-ICP1.5/Cs 7303a35

True Value

INT-OC-MCVB-2 7303a22

INT-OC-MCVB-2 7303a37

True Value

(Results are from procedure 7220a (2x dilution)

(Results are from procedure 7220a (4x dilution)


DATA REVIEW

Reviewed by: E. W. W.
Date: 3/6/97 Pages: 1 of 4

HLV 3/3/97

ICP/MS Analysis of HLV Tank Rinse Samples

March 5, 1997


 3/5/97
Results are reported in $\mu\text{g/g}$ (ppm) of original sample

ALOX Number	Client ID	ICP/MS Number	Cr $\mu\text{g/g}$	Sr $\mu\text{g/g}$	Cd $\mu\text{g/g}$	Da $\mu\text{g/g}$	Pb $\mu\text{g/g}$	Be $\mu\text{g/g}$	Mg $\mu\text{g/g}$	V $\mu\text{g/g}$	Mn $\mu\text{g/g}$	Co $\mu\text{g/g}$	Ni $\mu\text{g/g}$
1%HNO3		7220a1	<2	<1	<1	<1	<1	<1	3±1	<2	<2	<1	2.4
1%HNO3		7227a26	<2	<1	<1	<1	7±5	<1	3.0	9.3	<2	<1	<2
1%HNO3		7220a49	<2	<1	<1	<1	<1	1.4	3.4	15.3	<2	<1	<2
96-06864-PB	Process Blank	7220a27	<2	2.4	<1	<1	32±21	6.5	42.5	24.5	4.8	<1	3.0
96-06864-BS	Blank Spike	7220a42	255		52.1	4470	260						260±40
Spike Recovery			.105%		106%	93%	95%						107%
96-06864	HLV-30	7220a38	10±3	52±11	<1	1.2	0.7	4.4	46±6	48±10	0.7	<1	9±4
96-06864 Duplicate	HLV-30	7220a40	14±3	51±7	<1	<1	10±2	6±2	47.0	49±16	0.2	<1	7±4
96-06864-DUP	HLV-30	7220a39	10±3	47±8	<1	<1	5.5	4±0.4	40.3	41±8	0.4	<1	7±3
96-06864-MS	HLV-30	7220a44	133		25±6	2210	120						140±20
Spike Recovery			105%		103%	95%	95%						112%
96-06864-DUP+spike	HLV-30	7220a47&48	36.6	122	87.7	77.0	401±6	20.4	1020	207	90.8	108	180
Spike Recovery			94%	96%	111%	97%	98%	107%	106%	106%	108%	119%	110%

DATA REVIEW

Reviewed by: 
 Date: 3/5/97 Pages: 1 of 6

HLV 3/3/97

ICP/MS Analysis of HLV Tank Rinse Samples

March 5, 1997

J. Dawson
3/5/97

CCV results are reported in ng/ml (ppb)

ALO# Number	Client ID	ICP/MS Number	Cr ng/ml	Sr ng/ml	Cd ng/ml	Da ng/ml	Pb ng/ml	Be ng/ml	Mg ng/ml	V ng/ml	Mn ng/ml	Co ng/ml	Ni ng/ml
INT-QC-MCVA-1		7228a14	46.7	25.0	27.6	23.1	129			48.5	24.3	50.0	40.6
True Value			50.0	25.0	25.0	25.0	125			50.0	25.0	50.0	50.0
INT-QC-MCVB-3		7228a18											
INT-QC-MCVB-3		7228a52											
True Value													
INT-ICP1.1B		7228a20											
INT-ICP1.1B		7228a50											
True Value													
1643d (50x)		7228a23		203		472			7220				
1643d (50x)		7228a55		315		540±110			7340				
1643d		7228a24	17.7	206	6.3±0.4	513	19.3	11.3	33.3	37.0	26.0	55.5	
True Value			18.5	205	6.47	506	18.2	12.5	35.1	37.7	25.0	50.1	
INT-ICP1.1A		7228a21	9.53	4.61		4.09	22.7		113		10.3	9.10	
INT-ICP1.1A		7228a51	9.99	4.66		4.00	20±4		115		11.6	10.7	
True Value			10.0	5.00		5.00	25.0		125		10.0	10.0	
INT-QC-MCVB-2		7228a19											
INT-QC-MCVB-2		7228a53											
True Value													
INT-ICP1.5/Cs		7228a22											
INT-ICP1.5/Cs		7228a54											
True Value													
10ppb CLMS-1		7228a25											
10ppb CLMS-1		7228a57											
True Value													

DATA REVIEW

Reviewed by: *Z. J. Weller*
 Date: 3/5/97 Pages: 2 of 6

HLV 3/3/97

ICP/MS Analysis of HLV Tank Rinse Samples

March 5, 1997

*J.P. Dawson
3/5/97*Results are reported in $\mu\text{g/g}$ (ppm) of original sample

ALOW Number	Client ID	ICP/MS Number	Cu $\mu\text{g/g}$	Zn $\mu\text{g/g}$	As $\mu\text{g/g}$	Nb $\mu\text{g/g}$	Zr $\mu\text{g/g}$	Nb $\mu\text{g/g}$	Mo $\mu\text{g/g}$	Rh $\mu\text{g/g}$	Pd $\mu\text{g/g}$	Sn $\mu\text{g/g}$	Sb $\mu\text{g/g}$	Cs $\mu\text{g/g}$
1%HNO3		7228a1	<2	<2	<2	3±2	<1	<1	<1	<1	<1	<1	<1	<1
1%HNO3		7227a26	9±3	<2	<2	<4	<1	<1	1±1	<1	1±1	2±1	<1	<1
1%HNO3		7228a49	<2	<2	4.6	<4	<1	<1	<1	<1	1.9	<1	<1	1.8
96-06864-PD	Process Blank	7228a27	26.6	257	2.8	<4	<1	<1	<1	<1	<1	0.0	<1	1.1
96-06864-BS	Blank Spike	7228a42	303	670±80	226									
Spike Recovery			115%	171%	93%									
96-06864	HLV-30	7228a38	18±4	191	10.9	<4	10±7	<1	5±5	10±2	2±0.03	7±4	<1	22±5
96-06864 Duplicate	HLV-30	7228a40	16.0	170	12±6	<4	22±7	<1	4±1	10.4	4±3	6±1	<1	24±3
96-06864-DUP	HLV-30	7228a39	12±5	210	8±1	<4	20±5	<1	2.8	9.3	4±1	6±3	<1	16±3
96-06864-MS	HLV-30	7228a44	140±20	290±60	113.10									
Spike Recovery			104%	84%	88%									
96-06864-DUP+spike	HLV-30	7228a47&48	277	398	373	52.5	160±30	61.3	74.0	82.0	60.0	84±9	161	5710
Spike Recovery			169%	120%	93%	78%	104%	90%	107%	109%	96%	116%	95%	85%

DATA REVIEW

Reviewed by: *J.P. Dawson*
 Date: 3/5/97 Pages: 3 of 6

HLV 3/3/97

ICP/MS Analysis of HLV Tank Rinse Samples

March 5, 1997

J.P. DeRosa
3/5/97

CCV results are reported in ng/ml (ppb)

ALO# Number	Client ID	ICP/MS Number	Cu ng/ml	Zn ng/ml	As ng/ml	Rb ng/ml	Zr ng/ml	Nb ng/ml	Mo ng/ml	Rh ng/ml	Pd ng/ml	Sn ng/ml	Sb ng/ml	Cs ng/ml
INT-QC-MCVA-1		7228a14	49.0	50.0	119									
True Value			50.0	50.0	125									
INT-QC-MCVB-3		7228a10						1.61				3.0±0.4		
INT-QC-MCVB-3		7228a52						1.5±0.2				4.0±0.0		
True Value								2.00				4.00		
INT-ICP1.1B		7228a20					25.9		10±2					
INT-ICP1.1B		7228a50					21.4		10.1					
True Value							25.0		10.0					
1643d (50x)		7228a23												
1643d (50x)		7228a55												
1643d		7228a24	20.4	68.6	50.0	0.37			104				47.5	
True Value			20.5	72.5	56.0	13.0			113				54.1	
INT-ICP1.1A		7228a21	10.3	8.05										
INT-ICP1.1A		7228a51	11.3	11.2										
True Value			10.0	10.0										
INT-QC-MCVB-2		7228a19							1.07	2.20				
INT-QC-MCVB-2		7228a53							1.97	2.0±0.2				
True Value									2.00	2.00				
INT-ICP1.5/Cs		7228a22											51.0	
INT-ICP1.5/Cs		7228a54											49.0	
True Value													50.0	
10ppb CLMS-1		7228a25												
10ppb CLMS-1		7228a57												
True Value														

DATA REVIEW

Reviewed by: *EJ Wynn*
Date: 3/5/97 Page 4 of 6

HLV 3/3/97

ICP/MS Analysis of HLV Tank Rinse Samples

March 5, 1997

3/5/97

Results are reported in $\mu\text{g/g}$ (ppm) of original sample

ALO# Number	Client ID	ICP/MS Number	La $\mu\text{g/g}$	Ce $\mu\text{g/g}$	Pr $\mu\text{g/g}$	Nd $\mu\text{g/g}$	Eu $\mu\text{g/g}$	Gd $\mu\text{g/g}$	Tb $\mu\text{g/g}$	Dy $\mu\text{g/g}$	Ho $\mu\text{g/g}$	Er $\mu\text{g/g}$	Tm $\mu\text{g/g}$	Yb $\mu\text{g/g}$	U $\mu\text{g/g}$
1%HNO3		7220a1	<1	<1	<1	<1	<1	<1	<1	<2	<1	<1	<1	<1	<2
1%HNO3		7227a26	<1	<1	<1	<1	<1	<1	<1	<2	<1	<1	<1	<1	<2
1%HNO3		7228a49	<1	<1	<1	<1	<1	<1	<1	<2	<1	<1	<1	<1	<2
96-06864-PO	Process Blank	7220a27	<1	<1	<1	<1	<1	<1	<1	<2	<1	<1	<1	<1	<2
96-06864-BS	Blank Spike	7220a42													
Spike Recovery															
96-06864	HLV-30	7220a38	11.0	7.7	4.6	25±3	<1	<1	<1	<2	<1	<1	<1	<1	37.8
96-06864 Duplicate	HLV-30	7220a40	14±3	6.6	5.4	24±9	<1	<1	<1	<2	<1	<1	<1	<1	20±6
96-06864-DUP	HLV-30	7220a39	11±3	6.0	4.6	13±2	<1	<1	<1	<2	<1	<1	<1	<1	25±6
96-06864-MS	HLV-30	7220a44													
Spike Recovery															
96-06864-DUP+spike	HLV-30	7220a47&40	43.2	43.0	48±8	60±12	36.5	29±8	38±7	45±9	40±4	38±11	45.1	45±5	2740
Spike Recovery			00%	90%	100%	117%	00%	69%	92%	107%	97%	92%	109%	109%	101%

DATA REVIEW

Reviewed by: Eugene
 Date: 3/5/97 Pages: 5 of 6

HLV 3/3/97

ICP/MS Analysis of HLV Tank Rinse Samples
March 5, 1997

J/Grennan
3/5/97

CCV results are reported in ng/ml (ppb)

ALO# Number	Client ID	ICP/MS Number	La ng/ml	Ce ng/ml	Pr ng/ml	Nd ng/ml	Eu ng/ml	Gd ng/ml	Tb ng/ml	Dy ng/ml	Ho ng/ml	Er ng/ml	Tm ng/ml	Yb ng/ml	U ng/ml	
INT-QC-MCVA-1		7220a14														
True Value																
INT-QC-MCVB-3		7220a10														
INT-QC-MCVB-3		7220a52														
True Value																
INT-ICP1.1B		7220a20														
INT-ICP1.1B		7220a50														
True Value																
1643d (50x)		7220a23														
1643d (50x)		7220a55														
1643d		7220a24														
True Value																
INT-ICP1.1A		7220a21														
INT-ICP1.1A		7220a51														
True Value																
INT-QC-MCVB-2		7220a19														
INT-QC-MCVB-2		7220a53														
True Value																
INT-ICP1.5/Cs		7220a22													49.2	
INT-ICP1.5/Cs		7220a54													45.5	
True Value															50.0	
10ppb CLMS-1		7220a25	0.69	0.66	10.5	0.07	10.6	0.8±1.6	7.35	0.9±1.2	7.90	0.9±1.6	8.59	10.6		
10ppb CLMS-1		7220a57	0.27	0.51	10.5	0.15	0.78	0.29	0.31	1.1	0.6±1.2	0.27	10±3	0.74	9.66	
True Value			10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	

DATA REVIEW

Reviewed by: *E.G. Myrick*
 Date: 3/5/97 Pages: 6 of 6

Results are reported in Jig/J (ppm) of original sample

March 5, 1997

ICP/MS Analysis of HLV Resin Samples (TCLP Leach)

7G/C/C A7H

ALO#	Clinical ID	ICP/Ms	Number	mg/g	mg/g	mg/g	mg/g	mg/g	mg/g	mg/g	mg/g	Co	
1%HNO3	7220a1	<0.1	<0.05	<0.05	<0.1	<0.05	<0.1	<0.05	<0.1	<0.1	<0.05	1%HNO3	
7227a26	7227a26	<0.1	0.05	<0.05	<0.1	<0.05	<0.1	<0.05	0.10	0.4	<0.1	<0.05	
7220a49	7220a49	<0.1	0.05	<0.05	<0.1	<0.05	<0.1	<0.05	0.16	0.7	<0.1	<0.05	
7220a20	ExtracI Dlank	<0.1	0.0030-0.05	<0.05	<0.05	1.020-2	0.225	1.32	1.5	0.1540-0.03	<0.05	7220a20-ED	
7220a29	Process Dlank	<0.1	0.0040-0.01	<0.05	<0.05	0.76	0.3240-0.0	1.03	1.7	0.1040-0.02	<0.05	7220a29-PO	
7220a41	Dlank Spike	6.42	1.00	1.00	1.00	1.26	0.66	0.66	0.66	0.66	0.66	7220a41-DS	
7220a30	HLV 1X-01	<0.1	0.023	<0.05	<0.1540-0.05	0.57	0.3040-0.03	1.240-3	0.3340-0.17	6.49	1.6	0.1440-0.02	<0.05
7220a37	HLV 1X-01	0.1040-0.02	1.04	<0.05	0.2340-0.03	1.240-3	0.3040-0.03	1.240-3	0.3340-0.17	6.49	2.4	0.2740-0.06	<0.05
7220a43	HLV 1X-01	6.41	1.40	1.40	1.27	7.311.7	0.3340-0.17	1.240-3	0.3340-0.17	6.49	2.4	0.2740-0.06	<0.05
7220a31	HLV-1X-02	<0.1	0.040	<0.05	0.34	2.040-2	0.3240-0.05	6.53	1.7	0.27	<0.05	7220a31-34	
7220a32	HLV-1X-03	<0.1	0.015	<0.05	0.3340-0.11	0.79	0.2740-0.03	8.36	1.8	0.38	<0.05	7220a33-35	
7220a33	HLV-1X-5	0.1640-0.03	0.7040-0.07	<0.05	0.2440-0.10	0.7740-0.19	0.2740-0.12	6.10	2.1	0.2340-0.04	<0.05	7220a34-36	
7220a34	HLV-1X-07	0.1240-0.02	1.1140-0.02	<0.05	0.4740-0.23	0.04140-0.70	0.2540-0.03	9.547.0	1.740-2	0.2140-0.03	<0.05	7220a35-37	
7220a35	HLV-1X-08	0.1240-0.05	1.1140-0.2	<0.05	0.4740-0.36	0.04040-1.0	0.2040-0.3	400	43.3	20.1	<0.05	7220a36-38	
7220a36	HLV-1X-09	0.1240-0.05	1.1140-0.2	<0.05	0.4740-0.36	0.04040-1.0	0.2040-0.3	400	43.3	20.1	<0.05	7220a37-39	

HLV 3/3/97

ICP/MS Analysis of HLV Resin Samples (TCLP Leach)

March 5, 1997

J.P.Brown
3/5/97

CCV results are reported in ng/ml (ppb)

ALOT Number	Client ID	ICP/MS Number	Cr ng/ml	Sr ng/ml	Cd ng/ml	Ba ng/ml	Pb ng/ml	Be ng/ml	Mg ng/ml	V ng/ml	Mn ng/ml	Co ng/ml
INT-QC-MCVA-1		7220a14	46.7	25.0	27.0	23.1	129			40.5	24.3	50.0
True Value			50.0	25.0	25.0	25.0	125			50.0	25.0	50.0
INT-QC-MCVB-3		7220a10										
INT-QC-MCVB-3		7220a52										
True Value												
INT-ICP1.1B		7220a20										
INT-ICP1.1B		7220a50										
True Value												
1643d (50x)		7220a23		203		472			7220			
1643d (50x)		7220a55		315		540±110			7340			
1643d		7220a24	17.7	206	6.313.4	513	19.3	11.3		33.3	37.0	26.8
True Value			18.5	205	6.47	506	18.2	12.5	7990	35.1	37.7	25.0
INT-ICP1.1A		7220a21	9.53	4.61		4.89	22.7		113			10.3
INT-ICP1.1A		7220a51	9.99	4.66		4.38	20.4		115			11.6
True Value			10.0	5.00		5.00	25.0		125			10.0
INT-QC-MCVB-2		7220a19										
INT-QC-MCVB-2		7220a53										
True Value												
INT-ICP1.5/Cs		7220a22										
INT-ICP1.5/Cs		7220a54										
True Value												
10ppb CLMS-1		7220a25										
10ppb CLMS-1		7220a57										
True Value												

DATA REVIEW

Reviewed by: *E.P. Myre*
Date: 3/5/97 Pages: 2 of 8

HLV 3/3/97

ICP/MS Analysis of HLV Resin Samples (TCLP Leach)

March 5, 1997

JF Dawson
3/5/97

Results are reported in $\mu\text{g/g}$ (ppm) of original sample

ALOT Number	Client ID	ICP/MS Number	Ni $\mu\text{g/g}$	Cu $\mu\text{g/g}$	Zn $\mu\text{g/g}$	As $\mu\text{g/g}$	Rb $\mu\text{g/g}$	Zr $\mu\text{g/g}$	Nb $\mu\text{g/g}$	Mo $\mu\text{g/g}$	Rh $\mu\text{g/g}$	Pd $\mu\text{g/g}$
1%HNO3		7220a1	0.12	<0.1	<0.1	<0.1	<0.1	<0.05	<0.05	<0.05	<0.05	<0.05
1%HNO3		7227a26	<0.1	0.4±0.2	<0.1	<0.1	<0.1	<0.05	<0.05	0.06±0.05	<0.05	0.06±0.06
1%HNO3		7220a49	<0.1	<0.1	<0.1	0.2±0.1	<0.1	<0.05	<0.05	<0.05	<0.05	0.09±0.04
97-00032-EB	Extract Blank	7220a20	<0.1	1.39	1.97	0.11±0.05	<0.1	<0.05	0.1±0.1	0.07±0.07	<0.05	0.07±0.04
97-00032-PB	Process Blank	7220a29	<0.1	1.2±0.2	2.36	0.16±0.05	<0.1	<0.05	0.07	<0.05	<0.05	0.05±0.03
97-00032-BS	Blank Spike	7220a41	6.58	7.52	7.39	6.38						
Spike Recovery			100%	97%	78%	96%						
97-00032	HLV 1X-01	7220a30	<0.1	0.03	1.31±0.03	0.10±0.05	<0.1	<0.05	0.07	0.06±0.05	<0.05	0.47
97-00032-DUP	HLV 1X-01	7220a37	<0.1	0.74±0.11	2.50	0.42±0.10	<0.1	<0.05	0.08	<0.05	<0.05	0.43±0.20
97-00032-MS	HLV 1X-01	7220a43	6.03	7.4±0.7	7.39	5.94						
Spike Recovery			104%	101%	94%	99%						
97-00033	HLV-1X-02	7220a31	0.15±0.05	0.68	6.72	0.211±0.03	<0.1	<0.05	0.06±0.03	<0.05	<0.05	0.55±0.11
97-00034	HLV-1X-03	7220a32	<0.1	0.01	3.14	0.12±0.04	0.12±0.02	<0.05	0.07±0.01	0.07±0.07	<0.05	0.09±0.07
97-00035	HLV-1X-5	7220a33	0.21±0.05	1.13	9.26	0.15±0.03	<0.1	<0.05	0.10±0.02	<0.05	<0.05	1.8±0.9
97-00036	HLV-1X-07	7220a34	0.58±0.10	0.90	1.61	0.32±0.12	<0.1	<0.05	0.10±0.02	0.11±0.10	<0.05	1.1±0.2
97-00037	HLV-1X-08	7220a35	0.15±0.03	0.92±1.13	6.93	0.27±0.04	<0.1	<0.05	0.09±0.02	0.07±0.04	<0.05	0.99±0.14
97-00037+spike	HLV-1X-08	7220a45&46	41.5	42±5	51±9	43.2	10.0	21.5	10.8	11.5	11.7	12±2
Spike Recovery			100%	100%	116%	94%	87%	95%	94%	100%	103%	97%

DATA REVIEW

Reviewed by: *Ed Myrick*
 Date: 3/5/97 Pages: 3 of 8

HLV 3/3/97

ICP/MS Analysis of HLV Resin Samples (TCLP Leach)

March 5, 1997

J.P. Dawson
3/5/97

CCV results are reported in ng/ml (ppb)

ALOT Number	Client ID	ICP/MS Number	Ni ng/ml	Cu ng/ml	Zn ng/ml	As ng/ml	Rb ng/ml	Zr ng/ml	Nb ng/ml	Mo ng/ml	Rh ng/ml	Pd ng/ml
INT-QC-MCVA-1		7220a14	48.6	49.0	50.0	119						
True Value			50.0	50.0	50.0	125						
INT-QC-MCVB-3		7220a10					1.61					
INT-QC-MCVB-3		7220a52					1.5±0.2					
True Value							2.00					
INT-ICP1.1D		7220a20					25.9				10±2	
INT-ICP1.1D		7220a50					21.4				8.91	
True Value							25.0				10.0	
1643d (50x)		7220a23										
1643d (50x)		7220a55										
1643d		7220a24	55.5	20.4	60.6	50.9	9.37				104	
True Value			58.1	20.5	72.5	56.0	13.0				113	
INT-ICP1.1A		7220a21	9.10	10.3	0.95							
INT-ICP1.1A		7220a51	10.7	11.3	11.2							
True Value			10.0	10.0	10.0							
INT-QC-MCVB-2		7220a19								1.87	2.20	
INT-QC-MCVB-2		7220a53								1.97	2.0±0.2	
True Value										2.00	2.00	
INT-ICP1.5/Cs		7220a22										
INT-ICP1.5/Cs		7220a54										
True Value												
10ppb CLMS-1		7220a25										
10ppb CLMS-1		7220a57										
True Value												

DATA REVIEW

Reviewed by: *Z.F. Myers*
 Date: 3/5/97 Pages: 4 of 8

HLV 3/3/97

ICP/MS Analysis of HLV Resin Samples (TCLP Leach)

March 5, 1997

J.P. Brown
3/5/97Results are reported in $\mu\text{g/g}$ (ppm) of original sample

ALOT Number	Client ID	ICP/MS Number	Sn $\mu\text{g/g}$	Sb $\mu\text{g/g}$	Cs $\mu\text{g/g}$	La $\mu\text{g/g}$	Ce $\mu\text{g/g}$	Pr $\mu\text{g/g}$	Nd $\mu\text{g/g}$	Eu $\mu\text{g/g}$	Gd $\mu\text{g/g}$	Tb $\mu\text{g/g}$	Dy $\mu\text{g/g}$
1%HNO3		7220a1	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	0.05±0.02
1%HNO3		7227a26	0.11±0.03	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05
1%HNO3		7220a49	<0.05	<0.05	0.09±0.02	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	0.05±0.05
97-00032-EB	Extract Blank	7220a28	0.50±0.20	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05
97-00032-PD	Process Blank	7220a29	0.39	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05
97-00032-DS	Blank Spike	7220a41											
Spike Recovery													
97-00032	HLV 1X-01	7220a30	0.22±0.06	<0.05	0.06±0.02	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05
97-00032-DUP	HLV 1X-01	7220a37	0.29	<0.05	0.05±0.02	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05
97-00032-MS	HLV 1X-01	7220a43											
Spike Recovery													
97-00033	HLV-1X-02	7220a31	0.23±0.06	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05
97-00034	HLV-1X-03	7220a32	0.24±0.12	<0.05	2.78	<0.05	<0.05	<0.05	0.10±0.10	<0.05	<0.05	<0.05	<0.05
97-00035	HLV-1X-5	7220a33	0.32	<0.05	0.12±0.02	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	0.10±0.08
97-00036	HLV-1X-07	7220a34	0.36±0.12	<0.05	0.22±0.10	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05
97-00037	HLV-1X-08	7220a35	0.37	<0.05	0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05	<0.05
97-00037+spike	HLV-1X-08	7220a45&46	13.0	24±4	936	6.30	6.02	6.61	512	6.46	7.73	6±1	6±2
Spike Recovery													
			111%	84%	82%	92%	99%	96%	73%	94%	113%	87%	87%

DATA REVIEW

Reviewed by: *E.J. Nipke*
 Date: 3/5/97 Pages: 5 of 8

HLV 3/3/97

ICP/MS Analysis of HLV Resin Samples (TCLP Leach)

March 5, 1997

J.P. Sauer
3/5/97

CCV results are reported in ng/ml (ppb)

ALOT Number	Client ID	ICP/MS Number	Sn ng/ml	Sb ng/ml	Cs ng/ml	La ng/ml	Ce ng/ml	Pr ng/ml	Nd ng/ml	Eu ng/ml	Gd ng/ml	Tb ng/ml	Dy ng/ml
INT-QC-MCVA-1		7220a14											
True Value													
INT-OC-MCVB-3		7220a18	3.8±0.4										
INT-OC-MCVB-3		7220a52	4.0±0.8										
True Value			4.00										
INT-ICP1.1D		7220a20											
INT-ICP1.1D		7220a50											
True Value													
1643d (50x)		7220a23											
1643d (50x)		7220a55											
1643d		7220a24		47.5									
True Value				54.1									
INT-ICP1.1A		7220a21											
INT-ICP1.1A		7220a51											
True Value													
INT-QC-MCVB-2		7220a19											
INT-OC-MCVB-2		7220a53											
True Value													
INT-ICP1.5/Cs		7220a22			51.0								
INT-ICP1.5/Cs		7220a54			49.0								
True Value					50.0								
10ppb CLMS-1		7220a25				0.69	0.66	10.5	0.87	10.6	0.79	7.35	0.9±1.2
10ppb CLMS-1		7220a57				0.27	0.51	10.5	0.15	0.70	0.29	0.3±1.1	0.6±1.2
True Value						10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

DATA REVIEW

Reviewed by: *J.P. Sauer*
 Date: 3/5/97 Pages: 6 of 8

HLV 3/3/97

ICP/MS Analysis of HLV Resin Samples (TCLP Leach)

March 5, 1997

J.P. Burns
3/5/97

Results are reported in $\mu\text{g/g}$ (ppm) of original sample

ALO# Number	Client ID	ICP/MS Number	Ho $\mu\text{g/g}$	Er $\mu\text{g/g}$	Tm $\mu\text{g/g}$	Yb $\mu\text{g/g}$	U $\mu\text{g/g}$
1%HNO3		7220a1	<0.05	<0.05	<0.05	<0.05	0.06±0.03
1%HNO3		7220a26	<0.05	<0.05	<0.05	<0.05	<0.05
1%HNO3		7220a49	<0.05	<0.05	<0.05	<0.05	<0.05
97-00032-EB	Extract Blank	7220a20	<0.05	<0.05	<0.05	<0.05	0.05
97-00032-PB	Process Blank	7220a29	<0.05	<0.05	<0.05	<0.05	<0.05
97-00032-BS	Blank Spike	7220a41					
Spike Recovery							
97-00032	HLV 1X-01	7220a30	<0.05	<0.05	<0.05	<0.05	0.07±0.06
97-00032-DUP	HLV 1X-01	7220a37	<0.05	<0.05	<0.05	<0.05	0.06±0.06
97-00032-MS	HLV 1X-01	7220a43					
Spike Recovery							
97-00033	HLV-1X-02	7220a31	<0.05	<0.05	<0.05	<0.05	0.10±0.02
97-00034	HLV-1X-03	7220a32	<0.05	<0.05	<0.05	<0.05	0.10±0.10
97-00035	HLV-1X-5	7220a33	<0.05	<0.05	<0.05	<0.05	0.05±0.03
97-00036	HLV-1X-07	7220a34	<0.05	0.07±0.04	<0.05	<0.05	2.1±0.3
97-00037	HLV-1X-08	7220a35	<0.05	<0.05	<0.05	<0.05	0.20±0.22
97-00037+spike	HLV-1X-08	7220a45&46	0.23	7±1	6.73	7±2	431
Spike Recovery							
			91%	102%	98%	102%	95%

DATA REVIEW

Reviewed by: *E. Mifflin*
 Date: 3/5/97 Pages: 7 of 8

HLV 3/3/97

ICP/MS Analysis of HLV Resin Samples (TCLP Leach)

March 5, 1997

J/Brown
3/5/97

CCV results are reported in ng/ml (ppb)

ALOT Number	Client ID	ICP/MS Number	Ho ng/ml	Er ng/ml	Tm ng/ml	Yb ng/ml	U ng/ml
INT-OC-MCVA-1		7228a14					
True Value							
INT-OC-MCVB-3		7228a18					
INT-OC-MCVB-3		7228a52					
True Value							
INT-ICP1.1B		7228a20					
INT-ICP1.1B		7228a50					
True Value							
1643d (50x)		7228a23					
1643d (50x)		7228a55					
1643d		7228a24					
True Value							
INT-ICP1.1A		7228a21					
INT-ICP1.1A		7228a51					
True Value							
INT-QC-MCVB-2		7228a19					
INT-QC-MCVB-2		7228a53					
True Value							
INT-ICP1.5/Cs		7228a22				49.2	
INT-ICP1.5/Cs		7228a54				45±5	
True Value						50.0	
10ppb CLMS-1		7228a25	7.90	0.0±1.6	0.59	10.6	
10ppb CLMS-1		7228a57	0.27	10±3	0.74	9.66	
True Value			10.0	10.0	10.0	10.0	

DATA REVIEW


Reviewed by: *EJ/Heffner*
 Date: 3/5/97 Pages: 8 of 8

ATTACHMENT 4

Uranium Trend Plots of Wells Within 305m of the 324 Building

Uranium in Well 399-3-1


Well: 399-3-1
Code: U □



Uranium in Well 399-3-2


Well: 399-3-2

Code: U □




Uranium in Well 399-3-2

Well: 399-3-2
Code: U □




Uranium in Well 399-3-3

Well: 399-3-3
Code: U □




Uranium in Well 399-3-3

Well: 399-3-3
Code: U □




Uranium in Well 399-3-6

Well: 399-3-6
Code: U □




Uranium in Well 399-3-6

Well: 399-3-6
Code: U □




Uranium in Well 399-3-7

Well: 399-3-7
Code: U □



Uranium in Well 399-3-8


Well: 399-3-8
Code: U □



Uranium in Well 399-3-9


Well: 399-3-9

Code: U □




Uranium in Well 399-3-9

Well: 399-3-9
Code: U □




Uranium in Well 399-3-10

Well: 399-3-10
Code: U □




Uranium in Well 399-3-10

Well: 399-3-10
Code: U □




Uranium in Well 399-3-11

Well: 399-3-11
Code: U □




Uranium in Well 399-3-12

Well: 399-3-12
Code: U □




Uranium in Well 399-4-1

Well: 399-4-1
Code: U □




Uranium in Well 399-4-1

Well: 399-4-1
Code: U □




Uranium in Well 399-4-5

Well: 399-4-5
Code: U □




Uranium in Well 399-4-9

Well: 399-4-9
Code: U □




Uranium in Well 399-4-10



Uranium in Well 399-4-11

Well: 399-4-11
Code: U □




ATTACHMENT 5

Strontium-90 Trend Plots of Wells Within 305m of the 324 Building


Sr-90 in 399-3-2

Well: 399-3-2
Code: SR-90 □




Sr-90 in 399-3-3

Well: 399-3-3
Code: SR-90 □




Sr-90 in Well 399-3-8

Well: 399-3-8
Code: SR-90 □




MEASUREMENT (pCi/L)



SR-90 in Me II 399-3-9


Sr-90 in Well 399-3-10

Well: 399-3-10
Code: SR-90 □




Sr-90 in Well 399-3-11

Well: 399-3-11
Code: SR-90 □




Sr-90 in Well 399-3-12

Well: 399-3-12
Code: SR-90 □




Sr-90 in Well 399-4-1

Well: 399-4-1
Code: SR-90




Sr-90 in Well 399-4-9

Well: 399-4-9
Code: SR-90 □




Sr-90 in Well 399-4-10

Well: 399-4-10
Code: SR-90 □



Sr-90 in Well 399-4-11

Well: 399-4-11
Code: SR-90



ATTACHMENT 6

**Data Results for Wells 399-8-2 and 399-1-18A Upgradient
and Greater Than 305m of the 324 Building**

Results for upgradient well 399-8-2

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Analysis Date	Dilu- tion	Lab	Comment
Barium	399-8-2	6/18/85	H000DMB4	N	34	42.00		ug/L	7/15/85	USTEST	
		7/22/85	H000DMB5	N	34	45.00		ug/L	9/04/85	USTEST	
		8/19/85	H000DMB6	N	34	36.00		ug/L	9/30/85	USTEST	
		9/25/85	H000DMB8	N	34	38.00		ug/L	10/29/85	USTEST	
		10/23/85	H000DMB9	N	34	38.00		ug/L	11/21/85	USTEST	
		12/05/85	H000DMC2	N	34	37.00		ug/L	1/10/86	USTEST	
		1/20/86	H000DMC3	N	34	39.00		ug/L	2/05/86	USTEST	
		2/20/86	H000DMC5	N	34	38.00		ug/L	3/26/86	USTEST	
		3/20/86	H000DMC6	N	34	40.00		ug/L	4/11/86	USTEST	
		4/18/86	H000DMC8	N	34	38.00		ug/L	5/13/86	USTEST	
		5/20/86	H000DMC9	N	34	39.00		ug/L	6/20/86	USTEST	
		6/25/86	H000DMD0	N	34	38.00		ug/L	7/29/86	USTEST	
		7/16/86	H000DMD3	N	34	39.00		ug/L	8/20/86	USTEST	
		8/19/86	H000DMD4	N	34	39.00		ug/L	9/22/86	USTEST	
		9/22/86	H000DMD5	N	34	39.00		ug/L	10/28/86	USTEST	
			H000DMD5F	Y	34	36.00		ug/L	10/28/86	USTEST	
		10/22/86	H000DMD8	N	34	39.00		ug/L	11/04/86	USTEST	
			H000DMD8F	Y	34	37.00		ug/L	11/04/86	USTEST	
		11/13/86	H000DMD9	N	34	38.00		ug/L	11/20/86	USTEST	
			H000DMD9F	Y	34	38.00		ug/L	11/20/86	USTEST	
		12/08/86	H000DMF0	N	34	38.00		ug/L	12/16/86	USTEST	
			H000DMF0F	Y	34	38.00		ug/L	12/15/86	USTEST	
		1/16/87	H000DMF2	N	34	38.00		ug/L	1/28/87	USTEST	
			H000DMF2F	Y	34	38.00		ug/L	1/28/87	USTEST	
		2/20/87	H000DMF3	N	34	39.00		ug/L	2/27/87	USTEST	
			H000DMF3F	Y	34	39.00		ug/L	2/27/87	USTEST	
		3/29/87	H000DMF4	N	34	41.00		ug/L	4/23/87	USTEST	
			H000DMF4F	Y	34	41.00		ug/L	4/23/87	USTEST	
		4/15/87	H000DMF6	N	34	40.00		ug/L	5/11/87	USTEST	
			H000DMF6F	Y	34	40.00		ug/L	5/11/87	USTEST	
		6/19/87	H000DMF7	N	34	43.00		ug/L	7/22/87	USTEST	
			H000DMF7F	Y	34	39.00		ug/L	7/22/87	USTEST	
		8/18/87	H000DMF9	N	34	45.00		ug/L	9/18/87	USTEST	
			H000DMF9F	Y	34	42.00		ug/L	9/22/87	USTEST	
		11/13/87	H000DMG1	N	34	43.00		ug/L	12/03/87	USTEST	
			H000DMG1F	Y	34	43.00		ug/L	12/11/87	USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Barium	399-8-2	5/10/88	H000DMG4	N	34	46.00		ug/L	5/13/88		USTEST	
			H000DMG4F	Y	34	45.00		ug/L	5/20/88		USTEST	
		8/18/88	H000DMG6	N	34	45.00		ug/L	9/14/88		USTEST	
			H000DMG6F	Y	34	46.00		ug/L	9/14/88		USTEST	
		12/09/88	H000DMG8	N	34	35.00		ug/L	12/22/88		USTEST	
			H000DMG8F	Y	34	38.00		ug/L	12/16/88		USTEST	
		6/13/89	H000DMG9	N	34	38.00	4.69	ug/L	6/26/89		USTEST	
			H000DMG9F	Y	34	37.00	4.60	ug/L	6/26/89		USTEST	
		12/18/91	B00KC6	N	34	34.00	4.69	ug/L	2/26/92	0	DATACH	
		1/07/92	B01DY2	N	4	41.40		ug/L			SKINER	
		5/06/92	B062Y4	N	4	41.20		ug/L			SKINER	
			B062Y5	Y	4	37.70		ug/L			SKINER	
		9/10/92	B07615	N	4	35.20		ug/L			SKINER	
			B07616	Y	4	37.10		ug/L			SKINER	
Cadmium	399-8-2	6/18/85	H000DMB4	N	34	2.00 U		ug/L	7/15/85		USTEST	
		7/22/85	H000DMB5	N	34	2.00 U		ug/L	9/04/85		USTEST	
		8/19/85	H000DMB6	N	34	3.00		ug/L	9/30/85		USTEST	
		9/25/85	H000DMB8	N	34	2.00 U		ug/L	10/29/85		USTEST	
		10/23/85	H000DMB9	N	34	2.00 U		ug/L	11/21/85		USTEST	
		12/05/85	H000DMC2	N	34	2.00 U		ug/L	1/10/86		USTEST	
		1/20/86	H000DMC3	N	34	2.00 U		ug/L	2/05/86		USTEST	
		2/20/86	H000DMC5	N	34	2.00 U		ug/L	3/26/86		USTEST	
		3/20/86	H000DMC6	N	34	2.00 U		ug/L	4/11/86		USTEST	
		4/18/86	H000DMC8	N	34	2.00 U		ug/L	5/13/86		USTEST	
		5/20/86	H000DMC9	N	34	2.00 U		ug/L	6/20/86		USTEST	
		6/25/86	H000DMD0	N	34	2.00 U		ug/L	7/29/86		USTEST	
		7/16/86	H000DMD3	N	34	2.00 U		ug/L	8/20/86		USTEST	
		8/19/86	H000DMD4	N	34	2.00 U		ug/L	9/22/86		USTEST	
		9/22/86	H000DMD5	N	34	2.00 U		ug/L	10/28/86		USTEST	
			H000DMD5F	Y	34	2.00 U		ug/L	10/28/86		USTEST	
		10/22/86	H000DMD8	N	34	2.00 U		ug/L	11/04/86		USTEST	
			H000DMD8F	Y	34	2.00 U		ug/L	11/04/86		USTEST	
		11/13/86	H000DMD9	N	34	2.00 U		ug/L	11/20/86		USTEST	
			H000DMD9F	Y	34	2.00 U		ug/L	11/20/86		USTEST	
		12/08/86	H000DMF0	N	34	2.00 U		ug/L	12/16/86		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Filt-tered	Method ID	Result	Error	Units	Analysis Date	Dilu-tion	Lab	Comment
Cadmium	399-8-2	12/08/86	H000DMF0F	Y	34	2.00 U		ug/L	12/15/86		USTEST	
		1/16/87	H000DMF2	N	34	2.00 U		ug/L	1/28/87		USTEST	
			H000DMF2F	Y	34	2.00 U		ug/L	1/28/87		USTEST	
		2/20/87	H000DMF3	N	34	2.00 U		ug/L	2/27/87		USTEST	
			H000DMF3F	Y	34	2.00 U		ug/L	2/27/87		USTEST	
		3/29/87	H000DMF4	N	34	2.00 U		ug/L	4/23/87		USTEST	
			H000DMF4F	Y	34	2.00 U		ug/L	4/23/87		USTEST	
		4/15/87	H000DMF6	N	34	2.00 U		ug/L	5/11/87		USTEST	
			H000DMF6F	Y	34	2.00 U		ug/L	5/11/87		USTEST	
		6/19/87	H000DMF7	N	34	2.00 U		ug/L	7/22/87		USTEST	
			H000DMF7F	Y	34	2.00 U		ug/L	7/22/87		USTEST	
		8/18/87	H000DMF9	N	34	2.00 U		ug/L	9/18/87		USTEST	
			H000DMF9F	Y	34	2.00		ug/L	9/22/87		USTEST	
		11/13/87	H000DMG1	N	34	2.00 U		ug/L	12/03/87		USTEST	
			H000DMG1F	Y	34	2.00 U		ug/L	12/11/87		USTEST	
		5/10/88	H000DMG4	N	34	2.00 U		ug/L	5/13/88		USTEST	
			H000DMG4F	Y	34	2.00 U		ug/L	5/20/88		USTEST	
		8/18/88	H000DMG6	N	34	2.00 U		ug/L	9/14/88		USTEST	
			H000DMG6F	Y	34	2.00 U		ug/L	9/14/88		USTEST	
		12/09/88	H000DMG8	N	34	2.00 U		ug/L	12/22/88		USTEST	
			H000DMG8F	Y	34	2.00 U		ug/L	12/16/88		USTEST	
		6/13/89	H000DMG9	N	34	2.00 U	1.38	ug/L	6/26/89		USTEST	
			H000DMG9F	Y	34	2.00 U	1.38	ug/L	6/26/89		USTEST	
		12/18/91	B00KC6	N	34	U			2/26/92	0	DATACH	
		1/07/92	B01DY2	N	4	1.00		ug/L			SKINER	
		5/06/92	B062Y4	N	4	2.00		ug/L			SKINER	
			B062Y5	Y	4	2.00		ug/L			SKINER	
		9/10/92	B07615	N	4	1.50		ug/L			SKINER	
			B07616	Y	4	1.50		ug/L			SKINER	
Cesium-137	399-8-2	8/02/76	H000DM57	N	77	11.00		pCi/L			USTEST	
		1/26/77	H000DM58	N	77	.53		pCi/L			USTEST	
		10/31/77	H000DM69	N	77	20.00		pCi/L			USTEST	
		1/11/78	H000DM72	N	77	10.00		pCi/L			USTEST	
		6/20/78	H000DM74	N	77	31.00		pCi/L			USTEST	
		1/16/87	H000DMF1	N	77	.35 U	4.67	pCi/L	2/12/87		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil-tered	Method ID	Result	Error	Units	Analysis Date	Dilu-tion	Lab	Comment
Cesium-137	399-8-2	4/15/87	H000DMFS	N	77	2.67 U	6.80	pCi/L	5/06/87		USTEST	
		7/22/87	H000DMF8	N	77	0.00 U	6.42	pCi/L	8/10/87		USTEST	
		10/19/87	H000DMG0	N	77	-3.79 U	6.40	pCi/L	10/30/87		USTEST	
		1/07/92	B01DY2	N	232	9.02 U		pCi/L			TMA	
		5/06/92	B062Y4	N	232	11.00 U		pCi/L			TMA	
		9/10/92	B07615	N	232	10.00 UJ		pCi/L			TMA	
Chromium	399-8-2	6/18/85	H000DMB4	N	34	10.00 U		ug/L	7/15/85		USTEST	
		7/22/85	H000DMB5	N	34	10.00 U		ug/L	9/04/85		USTEST	
		8/19/85	H000DMB6	N	34	10.00 U		ug/L	9/30/85		USTEST	
		9/25/85	H000DMB8	N	34	10.00 U		ug/L	10/29/85		USTEST	
		10/23/85	H000DMB9	N	34	10.00 U		ug/L	11/21/85		USTEST	
		12/05/85	H000DMC2	N	34	10.00 U		ug/L	1/10/86		USTEST	
		1/20/86	H000DMC3	N	34	10.00 U		ug/L	2/05/86		USTEST	
		2/20/86	H000DMC5	N	34	10.00 U		ug/L	3/26/86		USTEST	
		3/20/86	H000DMC6	N	34	10.00 U		ug/L	4/11/86		USTEST	
		4/18/86	H000DMC8	N	34	10.00 U		ug/L	5/13/86		USTEST	
		5/20/86	H000DMC9	N	34	10.00 U		ug/L	6/20/86		USTEST	
		6/25/86	H000DMD0	N	34	10.00 U		ug/L	7/29/86		USTEST	
		7/16/86	H000DMD3	N	34	10.00 U		ug/L	8/20/86		USTEST	
		8/19/86	H000DMD4	N	34	10.00 U		ug/L	9/22/86		USTEST	
		9/22/86	H000DMD5	N	34	10.00 U		ug/L	10/28/86		USTEST	
			H000DMD5F	Y	34	10.00 U		ug/L	10/28/86		USTEST	
		10/22/86	H000DMD8	N	34	10.00 U		ug/L	11/04/86		USTEST	
			H000DMD8F	Y	34	10.00 U		ug/L	11/04/86		USTEST	
		11/13/86	H000DMD9	N	34	10.00 U		ug/L	11/20/86		USTEST	
			H000DMD9F	Y	34	10.00 U		ug/L	11/20/86		USTEST	
		12/08/86	H000DMF0	N	34	10.00 U		ug/L	12/16/86		USTEST	
			H000DMF0F	Y	34	10.00 U		ug/L	12/15/86		USTEST	
		1/16/87	H000DMF2	N	34	10.00 U		ug/L	1/28/87		USTEST	
			H000DMF2F	Y	34	10.00 U		ug/L	1/28/87		USTEST	
		2/20/87	H000DMF3	N	34	10.00 U		ug/L	2/27/87		USTEST	
			H000DMF3F	Y	34	10.00 U		ug/L	2/27/87		USTEST	
		3/29/87	H000DMF4	N	34	10.00 U		ug/L	4/23/87		USTEST	
			H000DMF4F	Y	34	10.00 U		ug/L	4/23/87		USTEST	
		4/15/87	H000DMF6	N	34	10.00 U		ug/L	5/11/87		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Filt-tered	Method ID	Result	Error	Units	Analysis Date	Dilu-tion	Lab	Comment
Chromium	399-8-2	4/15/87	H000DMF6F	Y	34	10.00 U		ug/L	5/11/87		USTEST	
		6/19/87	H000DMF7	N	34	10.00 U		ug/L	7/22/87		USTEST	
			H000DMF7F	Y	34	10.00 U		ug/L	7/22/87		USTEST	
		8/18/87	H000DMF9	N	34	10.00 U		ug/L	9/18/87		USTEST	
			H000DMF9F	Y	34	10.00 U		ug/L	9/22/87		USTEST	
		11/13/87	H000DMG1	N	34	10.00 U		ug/L	12/03/87		USTEST	
			H000DMG1F	Y	34	10.00 U		ug/L	12/11/87		USTEST	
		5/10/88	H000DMG4	N	34	10.00 U		ug/L	5/13/88		USTEST	
			H000DMG4F	Y	34	10.00 U		ug/L	5/20/88		USTEST	
		8/18/88	H000DMG6	N	34	10.00 U		ug/L	9/14/88		USTEST	
			H000DMG6F	Y	34	10.00 U		ug/L	9/14/88		USTEST	
		12/09/88	H000DMG8	N	34	10.00 U		ug/L	12/22/88		USTEST	
			H000DMG8F	Y	34	10.00 U		ug/L	12/16/88		USTEST	
		6/13/89	H000DMG9	N	34	10.00 U	5.13	ug/L	6/26/89		USTEST	
			H000DMG9F	Y	34	10.00 U	5.13	ug/L	6/26/89		USTEST	
		12/18/91	B00KC6	N	34	U			2/26/92	0	DATACH	
		1/07/92	B01DY2	N	4	26.40		ug/L			SKINER	
		5/06/92	B062Y4	N	4	11.90		ug/L			SKINER	
			B062Y5	Y	4	3.00		ug/L			SKINER	
		9/10/92	B07615	N	4	5.40		ug/L			SKINER	
			B07616	Y	4	2.60		ug/L			SKINER	
Lead	399-8-2	6/18/85	H000DMB4	N	34	45.00		ug/L	7/15/85		USTEST	
		7/22/85	H000DMB5	N	34	168.00		ug/L	9/04/85		USTEST	
		8/19/85	H000DMB6	N	34	30.00 U		ug/L	9/30/85		USTEST	
		9/25/85	H000DMB8	N	34	30.00 U		ug/L	10/29/85		USTEST	
		10/23/85	H000DMB9	N	34	30.00 U		ug/L	11/21/85		USTEST	
		12/05/85	H000DMC2	N	34	30.00 U		ug/L	1/10/86		USTEST	
		9/22/86	H000DMD5	N	40	5.00 U		ug/L	10/17/86		USTEST	
		10/22/86	H000DMD8	N	40	5.00 U		ug/L	11/24/86		USTEST	
		11/13/86	H000DMD9	N	40	5.00 U		ug/L	12/12/86		USTEST	
		12/08/86	H000DMF0	N	40	5.00 U		ug/L	1/07/87		USTEST	
		1/16/87	H000DMF2	N	40	5.00 U		ug/L	1/22/87		USTEST	
		2/20/87	H000DMF3	N	40	5.00		ug/L	3/04/87		USTEST	
		3/29/87	H000DMF4	N	40	5.00 U		ug/L	4/27/87		USTEST	
		4/15/87	H000DMF6	N	40	5.00 U		ug/L	5/12/87		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Analysis Units	Dilu- tion	Lab	Comment
Lead	399-8-2	6/19/87	H000DMF7	N	40	5.00 U		ug/L	8/11/87	USTEST	
		8/18/87	H000DMF9	N	40	5.00 U		ug/L	9/23/87	USTEST	
		11/13/87	H000DMG1	N	40	5.00 U		ug/L	11/27/87	USTEST	
		5/10/88	H000DMG4	N	40	5.00 U		ug/L	5/12/88	USTEST	
		8/18/88	H000DMG6	N	40	5.00 U		ug/L	9/06/88	USTEST	
		12/09/88	H000DMG8	N	40	5.00 U		ug/L	1/03/89	USTEST	
		6/13/89	H000DMG9	N	40	5.00 U	2.55	ug/L	7/06/89	USTEST	
		1/07/92	B01DY2	N	6	1.80		ug/L		SKINER	
		5/06/92	B062Y4	N	6	1.60		ug/L		SKINER	
			B062Y5	Y	6	2.30 *		ug/L		SKINER	
		9/10/92	B07615	N	6	2.30 *		ug/L		SKINER	
			B07616	Y	6	7.90		ug/L		SKINER	
Strontium-90	399-8-2	1/07/92	B01DY2	N	281	.06 UJ		pCi/L		TMA	
		5/06/92	B062Y4	N	281	- .09 U		pCi/L		TMA	
		9/10/92	B07615	N	281	-1.20 UJ		pCi/L		TMA	
Uranium	399-8-2	2/01/59	H000DM14	N	77	10.00		pCi/L		USTEST	
		3/01/59	H000DM15	N	77	4.00		pCi/L		USTEST	
		4/01/59	H000DM16	N	77	3.00		pCi/L		USTEST	
		1/19/67	H000DM20	N	77	140.00		pCi/L		USTEST	
		7/17/67	H000DM21	N	77	14.00		pCi/L		USTEST	
		1/17/68	H000DM22	N	77	19.00		pCi/L		USTEST	
		1/26/77	H000DM58	N	77	2.40		pCi/L		USTEST	
		2/01/77	H000DM59	N	77	3.40		pCi/L		USTEST	
		3/02/77	H000DM60	N	77	2.50		pCi/L		USTEST	
		3/30/77	H000DM61	N	77	2.70		pCi/L		USTEST	
		4/25/77	H000DM62	N	77	21.00		pCi/L		USTEST	
		6/30/77	H000DM64	N	77	2.40		pCi/L		USTEST	
		9/01/77	H000DM66	N	77	1.60		pCi/L		USTEST	
		3/27/78	H000DM73	N	77	6.90		pCi/L		USTEST	
		6/20/78	H000DM74	N	77	6.90		pCi/L		USTEST	
		9/12/78	H000DM75	N	77	6.80		pCi/L		USTEST	
		1/08/79	H000DM76	N	77	6.90		pCi/L		USTEST	
		3/19/79	H000DM77	N	77	6.90		pCi/L		USTEST	
		6/13/79	H000DM78	N	77	6.90		pCi/L		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect	Sample	Fil-	Method	Result	Error	Units	Analysis	Dilu-	Lab	Comment
		Date	Number	tered	ID				Date	tion		
Uranium	399-8-2	9/04/79	H000DM79	N	77	6.90		pCi/L			USTEST	
		1/11/80	H000DM80	N	77	6.90		pCi/L			USTEST	
		4/09/80	H000DM81	N	77	6.90		pCi/L			USTEST	
		6/25/80	H000DM82	N	77	6.90		pCi/L			USTEST	
		1/09/81	H000DM83	N	77	6.90		pCi/L			USTEST	
		3/26/81	H000DM84	N	77	6.90		pCi/L			USTEST	
		6/25/81	H000DM85	N	77	6.00		pCi/L			USTEST	
		9/14/81	H000DM86	N	77	6.70		pCi/L			USTEST	
		1/07/82	H000DM87	N	77	6.70		pCi/L			USTEST	
		3/19/82	H000DM88	N	77	6.70		pCi/L			USTEST	
		6/15/82	H000DM89	N	77	6.70		pCi/L			USTEST	
		9/16/82	H000DM90	N	77	6.70		pCi/L			USTEST	
		11/24/82	H000DM91	N	77	6.70		pCi/L			USTEST	
		3/22/83	H000DM92	N	77	6.70		pCi/L			USTEST	
		6/21/83	H000DM93	N	77	6.70		pCi/L			USTEST	
		9/21/83	H000DM94	N	77	6.70		pCi/L			USTEST	
		12/02/83	H000DM95	N	77	6.70		pCi/L			USTEST	
		3/29/84	H000DM96	N	77	2.80		pCi/L			USTEST	
		6/29/84	H000DM97	N	77	4.00		pCi/L			USTEST	
		10/12/84	H000DM98	N	77	2.20		pCi/L			USTEST	
		12/28/84	H000DM99	N	77	2.70		pCi/L			USTEST	
		1/29/85	H000DMB0	N	77	14.00		pCi/L			USTEST	
		4/15/85	H000DMB2	N	77	4.00		pCi/L			USTEST	
		9/12/85	H000DMB7	N	77	2.20		pCi/L			USTEST	
		12/05/85	H000DMC0	N	77	4.70		pCi/L			USTEST	
		1/30/86	H000DMC4	N	77	4.00		pCi/L			PNL-KI	
		4/18/86	H000DMC7	N	77	3.90		pCi/L			PNL-KI	
		7/16/86	H000DMD2	N	77	1.80 U		pCi/L			PNL-KI	
		10/22/86	H000DMD7	N	77	21.00		pCi/L			PNL-KI	
		1/16/87	H000DMF1	N	77	4.49	1.48	pCi/L	2/13/87		USTEST	
		4/15/87	H000DMF5	N	77	2.97	.89	pCi/L	5/12/87		USTEST	
		7/22/87	H000DMF8	N	77	1.76	.56	pCi/L	11/06/87		USTEST	
		10/19/87	H000DMG0	N	77	1.86	.59	pCi/L	11/03/87		USTEST	
		11/13/87	H000DMG1	N	77	2.75	.82	ug/L	12/08/87		USTEST	
		2/04/88	H000DMG2	N	77	1.91	.63	pCi/L	3/24/88		USTEST	
		5/10/88	H000DMG3	N	77	1.84	.62	pCi/L	6/07/88		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Uranium	399-8-2	7/07/88	H000DMG5	N	77	1.92	.65	pCi/L	8/11/88		USTEST	
		12/02/88	H000DMG7	N	77	1.38	.46	pCi/L	12/21/88		USTEST	
		12/09/88	H000DMG8	N	77	1.89	.62	pCi/L	12/29/88		USTEST	
		6/13/89	H000DMG9	N	77	2.32	.73	pCi/L	7/06/89		USTEST	
		12/18/91	B00MH6	N	145	2.37	.77	ug/L	1/15/92	1	ITASRL	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Analysis Units	Date	Dilu- tion	Lab	Comment
Barium	399-8-2	6/18/85	H000DMB4	N	34	42.00		ug/L	7/15/85		USTEST	
		7/22/85	H000DMB5	N	34	45.00		ug/L	9/04/85		USTEST	
		8/19/85	H000DMB6	N	34	36.00		ug/L	9/30/85		USTEST	
		9/25/85	H000DMB8	N	34	38.00		ug/L	10/29/85		USTEST	
		10/23/85	H000DMB9	N	34	38.00		ug/L	11/21/85		USTEST	
		12/05/85	H000DMC2	N	34	37.00		ug/L	1/10/86		USTEST	
		1/20/86	H000DMC3	N	34	39.00		ug/L	2/05/86		USTEST	
		2/20/86	H000DMC5	N	34	38.00		ug/L	3/26/86		USTEST	
		3/20/86	H000DMC6	N	34	40.00		ug/L	4/11/86		USTEST	
		4/18/86	H000DMC8	N	34	38.00		ug/L	5/13/86		USTEST	
		5/20/86	H000DMC9	N	34	39.00		ug/L	6/20/86		USTEST	
		6/25/86	H000DMD0	N	34	38.00		ug/L	7/29/86		USTEST	
		7/16/86	H000DMD3	N	34	39.00		ug/L	8/20/86		USTEST	
		8/19/86	H000DMD4	N	34	39.00		ug/L	9/22/86		USTEST	
		9/22/86	H000DMD5	N	34	39.00		ug/L	10/28/86		USTEST	
			H000DMD5F	Y	34	36.00		ug/L	10/28/86		USTEST	
		10/22/86	H000DMD8	N	34	39.00		ug/L	11/04/86		USTEST	
			H000DMD8F	Y	34	37.00		ug/L	11/04/86		USTEST	
		11/13/86	H000DMD9	N	34	38.00		ug/L	11/20/86		USTEST	
			H000DMD9F	Y	34	38.00		ug/L	11/20/86		USTEST	
		12/08/86	H000DMF0	N	34	38.00		ug/L	12/16/86		USTEST	
			H000DMF0F	Y	34	38.00		ug/L	12/15/86		USTEST	
		1/16/87	H000DMF2	N	34	38.00		ug/L	1/28/87		USTEST	
			H000DMF2F	Y	34	38.00		ug/L	1/28/87		USTEST	
		2/20/87	H000DMF3	N	34	39.00		ug/L	2/27/87		USTEST	
			H000DMF3F	Y	34	39.00		ug/L	2/27/87		USTEST	
		3/29/87	H000DMF4	N	34	41.00		ug/L	4/23/87		USTEST	
			H000DMF4F	Y	34	41.00		ug/L	4/23/87		USTEST	
		4/15/87	H000DMF6	N	34	40.00		ug/L	5/11/87		USTEST	
			H000DMF6F	Y	34	40.00		ug/L	5/11/87		USTEST	
		6/19/87	H000DMF7	N	34	43.00		ug/L	7/22/87		USTEST	
			H000DMF7F	Y	34	39.00		ug/L	7/22/87		USTEST	
		8/18/87	H000DMF9	N	34	45.00		ug/L	9/18/87		USTEST	
			H000DMF9F	Y	34	42.00		ug/L	9/22/87		USTEST	
		11/13/87	H000DMG1	N	34	43.00		ug/L	12/03/87		USTEST	
			H000DMG1F	Y	34	43.00		ug/L	12/11/87		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect	Sample	Fil-	Method	Result	Error	Units	Analysis	Dilu-	Lab	Comment
		Date	Number	tered	ID				Date	tion		
Barium	399-8-2	5/10/88	H000DMG4	N	34	46.00		ug/L	5/13/88		USTEST	
			H000DMG4F	Y	34	45.00		ug/L	5/20/88		USTEST	
		8/18/88	H000DMG6	N	34	45.00		ug/L	9/14/88		USTEST	
			H000DMG6F	Y	34	46.00		ug/L	9/14/88		USTEST	
		12/09/88	H000DMG8	N	34	35.00		ug/L	12/22/88		USTEST	
			H000DMG8F	Y	34	38.00		ug/L	12/16/88		USTEST	
		6/13/89	H000DMG9	N	34	38.00	4.69	ug/L	6/26/89		USTEST	
			H000DMG9F	Y	34	37.00	4.60	ug/L	6/26/89		USTEST	
		12/18/91	B00KC6	N	34	34.00	4.69	ug/L	2/26/92	0	DATACh	
		1/07/92	B01DY2	N	4	41.40		ug/L			SKINER	
		5/06/92	B062Y4	N	4	41.20		ug/L			SKINER	
			B062Y5	Y	4	37.70		ug/L			SKINER	
		9/10/92	B07615	N	4	35.20		ug/L			SKINER	
			B07616	Y	4	37.10		ug/L			SKINER	
Cadmium	399-8-2	6/18/85	H000DMB4	N	34	2.00 U		ug/L	7/15/85		USTEST	
		7/22/85	H000DMB5	N	34	2.00 U		ug/L	9/04/85		USTEST	
		8/19/85	H000DMB6	N	34	3.00		ug/L	9/30/85		USTEST	
		9/25/85	H000DMB8	N	34	2.00 U		ug/L	10/29/85		USTEST	
		10/23/85	H000DMB9	N	34	2.00 U		ug/L	11/21/85		USTEST	
		12/05/85	H000DMC2	N	34	2.00 U		ug/L	1/10/86		USTEST	
		1/20/86	H000DMC3	N	34	2.00 U		ug/L	2/05/86		USTEST	
		2/20/86	H000DMC5	N	34	2.00 U		ug/L	3/26/86		USTEST	
		3/20/86	H000DMC6	N	34	2.00 U		ug/L	4/11/86		USTEST	
		4/18/86	H000DMC8	N	34	2.00 U		ug/L	5/13/86		USTEST	
		5/20/86	H000DMC9	N	34	2.00 U		ug/L	6/20/86		USTEST	
		6/25/86	H000DMD0	N	34	2.00 U		ug/L	7/29/86		USTEST	
		7/16/86	H000DMD3	N	34	2.00 U		ug/L	8/20/86		USTEST	
		8/19/86	H000DMD4	N	34	2.00 U		ug/L	9/22/86		USTEST	
		9/22/86	H000DMD5	N	34	2.00 U		ug/L	10/28/86		USTEST	
			H000DMD5F	Y	34	2.00 U		ug/L	10/28/86		USTEST	
		10/22/86	H000DMD8	N	34	2.00 U		ug/L	11/04/86		USTEST	
			H000DMD8F	Y	34	2.00 U		ug/L	11/04/86		USTEST	
		11/13/86	H000DMD9	N	34	2.00 U		ug/L	11/20/86		USTEST	
			H000DMD9F	Y	34	2.00 U		ug/L	11/20/86		USTEST	
		12/08/86	H000DMF0	N	34	2.00 U		ug/L	12/16/86		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Cadmium	399-8-2	12/08/86	H000DMF0F	Y	34	2.00 U		ug/L	12/15/86		USTEST	
		1/16/87	H000DMF2	N	34	2.00 U		ug/L	1/28/87		USTEST	
			H000DMF2F	Y	34	2.00 U		ug/L	1/28/87		USTEST	
		2/20/87	H000DMF3	N	34	2.00 U		ug/L	2/27/87		USTEST	
			H000DMF3F	Y	34	2.00 U		ug/L	2/27/87		USTEST	
		3/29/87	H000DMF4	N	34	2.00 U		ug/L	4/23/87		USTEST	
			H000DMF4F	Y	34	2.00 U		ug/L	4/23/87		USTEST	
		4/15/87	H000DMF6	N	34	2.00 U		ug/L	5/11/87		USTEST	
			H000DMF6F	Y	34	2.00 U		ug/L	5/11/87		USTEST	
		6/19/87	H000DMF7	N	34	2.00 U		ug/L	7/22/87		USTEST	
			H000DMF7F	Y	34	2.00 U		ug/L	7/22/87		USTEST	
		8/18/87	H000DMF9	N	34	2.00 U		ug/L	9/18/87		USTEST	
			H000DMF9F	Y	34	2.00		ug/L	9/22/87		USTEST	
		11/13/87	H000DMG1	N	34	2.00 U		ug/L	12/03/87		USTEST	
			H000DMG1F	Y	34	2.00 U		ug/L	12/11/87		USTEST	
		5/10/88	H000DMG4	N	34	2.00 U		ug/L	5/13/88		USTEST	
			H000DMG4F	Y	34	2.00 U		ug/L	5/20/88		USTEST	
		8/18/88	H000DMG6	N	34	2.00 U		ug/L	9/14/88		USTEST	
			H000DMG6F	Y	34	2.00 U		ug/L	9/14/88		USTEST	
		12/09/88	H000DMG8	N	34	2.00 U		ug/L	12/22/88		USTEST	
			H000DMG8F	Y	34	2.00 U		ug/L	12/16/88		USTEST	
		6/13/89	H000DMG9	N	34	2.00 U	1.38	ug/L	6/26/89		USTEST	
			H000DMG9F	Y	34	2.00 U	1.38	ug/L	6/26/89		USTEST	
		12/18/91	B00KC6	N	34	U			2/26/92	0	DATACH	
		1/07/92	B01DY2	N	4	1.00		ug/L			SKINER	
		5/06/92	B062Y4	N	4	2.00		ug/L			SKINER	
			B062Y5	Y	4	2.00		ug/L			SKINER	
		9/10/92	B07615	N	4	1.50		ug/L			SKINER	
			B07616	Y	4	1.50		ug/L			SKINER	
Cesium-137	399-8-2	8/02/76	H000DM57	N	77	11.00		pCi/L			USTEST	
		1/26/77	H000DM58	N	77	.53		pCi/L			USTEST	
		10/31/77	H000DM69	N	77	20.00		pCi/L			USTEST	
		1/11/78	H000DM72	N	77	10.00		pCi/L			USTEST	
		6/20/78	H000DM74	N	77	31.00		pCi/L			USTEST	
		1/16/87	H000DMF1	N	77	.35 U	4.67	pCi/L	2/12/87		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Cesium-137	399-8-2	4/15/87	H000DMF5	N	77	2.67 U	6.80	pCi/L	5/06/87		USTEST	
		7/22/87	H000DMF8	N	77	0.00 U	6.42	pCi/L	8/10/87		USTEST	
		10/19/87	H000DMG0	N	77	-3.79 U	6.40	pCi/L	10/30/87		USTEST	
		1/07/92	B01DY2	N	232	9.02 U		pCi/L			TMA	
		5/06/92	B062Y4	N	232	11.00 U		pCi/L			TMA	
		9/10/92	B07615	N	232	10.00 UJ		pCi/L			TMA	
Chromium	399-8-2	6/18/85	H000DMB4	N	34	10.00 U		ug/L	7/15/85		USTEST	
		7/22/85	H000DMB5	N	34	10.00 U		ug/L	9/04/85		USTEST	
		8/19/85	H000DMB6	N	34	10.00 U		ug/L	9/30/85		USTEST	
		9/25/85	H000DMB8	N	34	10.00 U		ug/L	10/29/85		USTEST	
		10/23/85	H000DMB9	N	34	10.00 U		ug/L	11/21/85		USTEST	
		12/05/85	H000DMC2	N	34	10.00 U		ug/L	1/10/86		USTEST	
		1/20/86	H000DMC3	N	34	10.00 U		ug/L	2/05/86		USTEST	
		2/20/86	H000DMC5	N	34	10.00 U		ug/L	3/26/86		USTEST	
		3/20/86	H000DMC6	N	34	10.00 U		ug/L	4/11/86		USTEST	
		4/18/86	H000DMC8	N	34	10.00 U		ug/L	5/13/86		USTEST	
		5/20/86	H000DMC9	N	34	10.00 U		ug/L	6/20/86		USTEST	
		6/25/86	H000DMD0	N	34	10.00 U		ug/L	7/29/86		USTEST	
		7/16/86	H000DMD3	N	34	10.00 U		ug/L	8/20/86		USTEST	
		8/19/86	H000DMD4	N	34	10.00 U		ug/L	9/22/86		USTEST	
		9/22/86	H000DMD5	N	34	10.00 U		ug/L	10/28/86		USTEST	
			H000DMD5F	Y	34	10.00 U		ug/L	10/28/86		USTEST	
		10/22/86	H000DMD8	N	34	10.00 U		ug/L	11/04/86		USTEST	
			H000DMD8F	Y	34	10.00 U		ug/L	11/04/86		USTEST	
		11/13/86	H000DMD9	N	34	10.00 U		ug/L	11/20/86		USTEST	
			H000DMD9F	Y	34	10.00 U		ug/L	11/20/86		USTEST	
		12/08/86	H000DMF0	N	34	10.00 U		ug/L	12/16/86		USTEST	
			H000DMF0F	Y	34	10.00 U		ug/L	12/15/86		USTEST	
		1/16/87	H000DMF2	N	34	10.00 U		ug/L	1/28/87		USTEST	
			H000DMF2F	Y	34	10.00 U		ug/L	1/28/87		USTEST	
		2/20/87	H000DMF3	N	34	10.00 U		ug/L	2/27/87		USTEST	
			H000DMF3F	Y	34	10.00 U		ug/L	2/27/87		USTEST	
		3/29/87	H000DMF4	N	34	10.00 U		ug/L	4/23/87		USTEST	
			H000DMF4F	Y	34	10.00 U		ug/L	4/23/87		USTEST	
		4/15/87	H000DMF6	N	34	10.00 U		ug/L	5/11/87		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Chromium	399-8-2	4/15/87	H000DMF6F	Y	34	10.00 U		ug/L	5/11/87		USTEST	
		6/19/87	H000DMF7	N	34	10.00 U		ug/L	7/22/87		USTEST	
			H000DMF7F	Y	34	10.00 U		ug/L	7/22/87		USTEST	
		8/18/87	H000DMF9	N	34	10.00 U		ug/L	9/18/87		USTEST	
			H000DMF9F	Y	34	10.00 U		ug/L	9/22/87		USTEST	
		11/13/87	H000DMG1	N	34	10.00 U		ug/L	12/03/87		USTEST	
			H000DMG1F	Y	34	10.00 U		ug/L	12/11/87		USTEST	
		5/10/88	H000DMG4	N	34	10.00 U		ug/L	5/13/88		USTEST	
			H000DMG4F	Y	34	10.00 U		ug/L	5/20/88		USTEST	
		8/18/88	H000DMG6	N	34	10.00 U		ug/L	9/14/88		USTEST	
			H000DMG6F	Y	34	10.00 U		ug/L	9/14/88		USTEST	
		12/09/88	H000DMG8	N	34	10.00 U		ug/L	12/22/88		USTEST	
			H000DMG8F	Y	34	10.00 U		ug/L	12/16/88		USTEST	
		6/13/89	H000DMG9	N	34	10.00 U	5.13	ug/L	6/26/89		USTEST	
			H000DMG9F	Y	34	10.00 U	5.13	ug/L	6/26/89		USTEST	
		12/18/91	B00KC6	N	34	U			2/26/92	0	DATACH	
		1/07/92	B01DY2	N	4	26.40		ug/L			SKINER	
		5/06/92	B062Y4	N	4	11.90		ug/L			SKINER	
			B062Y5	Y	4	3.00		ug/L			SKINER	
		9/10/92	B07615	N	4	5.40		ug/L			SKINER	
			B07616	Y	4	2.60		ug/L			SKINER	
Lead	399-8-2	6/18/85	H000DMB4	N	34	45.00		ug/L	7/15/85		USTEST	
		7/22/85	H000DMB5	N	34	168.00		ug/L	9/04/85		USTEST	
		8/19/85	H000DMB6	N	34	30.00 U		ug/L	9/30/85		USTEST	
		9/25/85	H000DMB8	N	34	30.00 U		ug/L	10/29/85		USTEST	
		10/23/85	H000DMB9	N	34	30.00 U		ug/L	11/21/85		USTEST	
		12/05/85	H000DMC2	N	34	30.00 U		ug/L	1/10/86		USTEST	
		9/22/86	H000DM05	N	40	5.00 U		ug/L	10/17/86		USTEST	
		10/22/86	H000DM08	N	40	5.00 U		ug/L	11/24/86		USTEST	
		11/13/86	H000DM09	N	40	5.00 U		ug/L	12/12/86		USTEST	
		12/08/86	H000DM00	N	40	5.00 U		ug/L	1/07/87		USTEST	
		1/16/87	H000DMF2	N	40	5.00 U		ug/L	1/22/87		USTEST	
		2/20/87	H000DMF3	N	40	5.00		ug/L	3/04/87		USTEST	
		3/29/87	H000DMF4	N	40	5.00 U		ug/L	4/27/87		USTEST	
		4/15/87	H000DMF6	N	40	5.00 U		ug/L	5/12/87		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil-tered	Method ID	Result	Error	Analysis Units	Dilu-tion	Lab	Comment
Lead	399-8-2	6/19/87	H000DMF7	N	40	5.00 U		ug/L	8/11/87	UTEST	
		8/18/87	H000DMF9	N	40	5.00 U		ug/L	9/23/87	UTEST	
		11/13/87	H000DMG1	N	40	5.00 U		ug/L	11/27/87	UTEST	
		5/10/88	H000DMG4	N	40	5.00 U		ug/L	5/12/88	UTEST	
		8/18/88	H000DMG6	N	40	5.00 U		ug/L	9/06/88	UTEST	
		12/09/88	H000DMG8	N	40	5.00 U		ug/L	1/03/89	UTEST	
		6/13/89	H000DMG9	N	40	5.00 U	2.55	ug/L	7/06/89	UTEST	
		1/07/92	B01DY2	N	6	1.80		ug/L		SKINER	
		5/06/92	B062Y4	N	6	1.60		ug/L		SKINER	
			B062Y5	Y	6	2.30 *		ug/L		SKINER	
		9/10/92	B07615	N	6	2.30 *		ug/L		SKINER	
			B07616	Y	6	7.90		ug/L		SKINER	
Strontium-90	399-8-2	1/07/92	B01DY2	N	281	.06 UJ		pCi/L		TMA	
		5/06/92	B062Y4	N	281	.09 U		pCi/L		TMA	
		9/10/92	B07615	N	281	-1.20 UJ		pCi/L		TMA	
Uranium	399-8-2	2/01/59	H000DM14	N	77	10.00		pCi/L		UTEST	
		3/01/59	H000DM15	N	77	4.00		pCi/L		UTEST	
		4/01/59	H000DM16	N	77	3.00		pCi/L		UTEST	
		1/19/67	H000DM20	N	77	140.00		pCi/L		UTEST	
		7/17/67	H000DM21	N	77	14.00		pCi/L		UTEST	
		1/17/68	H000DM22	N	77	19.00		pCi/L		UTEST	
		1/26/77	H000DM58	N	77	2.40		pCi/L		UTEST	
		2/01/77	H000DM59	N	77	3.40		pCi/L		UTEST	
		3/02/77	H000DM60	N	77	2.50		pCi/L		UTEST	
		3/30/77	H000DM61	N	77	2.70		pCi/L		UTEST	
		4/25/77	H000DM62	N	77	21.00		pCi/L		UTEST	
		6/30/77	H000DM64	N	77	2.40		pCi/L		UTEST	
		9/01/77	H000DM66	N	77	1.60		pCi/L		UTEST	
		3/27/78	H000DM73	N	77	6.90		pCi/L		UTEST	
		6/20/78	H000DM74	N	77	6.90		pCi/L		UTEST	
		9/12/78	H000DM75	N	77	6.80		pCi/L		UTEST	
		1/08/79	H000DM76	N	77	6.90		pCi/L		UTEST	
		3/19/79	H000DM77	N	77	6.90		pCi/L		UTEST	
		6/13/79	H000DM78	N	77	6.90		pCi/L		UTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Uranium	399-8-2	9/04/79	H0000DM79	N	77	6.90		pCi/L			USTEST	
		1/11/80	H0000DM80	N	77	6.90		pCi/L			USTEST	
		4/09/80	H0000DM81	N	77	6.90		pCi/L			USTEST	
		6/25/80	H0000DM82	N	77	6.90		pCi/L			USTEST	
		1/09/81	H0000DM83	N	77	6.90		pCi/L			USTEST	
		3/26/81	H0000DM84	N	77	6.90		pCi/L			USTEST	
		6/25/81	H0000DM85	N	77	6.00		pCi/L			USTEST	
		9/14/81	H0000DM86	N	77	6.70		pCi/L			USTEST	
		1/07/82	H0000DM87	N	77	6.70		pCi/L			USTEST	
		3/19/82	H0000DM88	N	77	6.70		pCi/L			USTEST	
		6/15/82	H0000DM89	N	77	6.70		pCi/L			USTEST	
		9/16/82	H0000DM90	N	77	6.70		pCi/L			USTEST	
		11/24/82	H0000DM91	N	77	6.70		pCi/L			USTEST	
		3/22/83	H0000DM92	N	77	6.70		pCi/L			USTEST	
		6/21/83	H0000DM93	N	77	6.70		pCi/L			USTEST	
		9/21/83	H0000DM94	N	77	6.70		pCi/L			USTEST	
		12/02/83	H0000DM95	N	77	6.70		pCi/L			USTEST	
		3/29/84	H0000DM96	N	77	2.80		pCi/L			USTEST	
		6/29/84	H0000DM97	N	77	4.00		pCi/L			USTEST	
		10/12/84	H0000DM98	N	77	2.20		pCi/L			USTEST	
		12/28/84	H0000DM99	N	77	2.70		pCi/L			USTEST	
		1/29/85	H0000DMB0	N	77	14.00		pCi/L			USTEST	
		4/15/85	H0000DMB2	N	77	4.00		pCi/L			USTEST	
		9/12/85	H0000DMB7	N	77	2.20		pCi/L			USTEST	
		12/05/85	H0000DMC0	N	77	4.70		pCi/L			USTEST	
		1/30/86	H0000DMC4	N	77	4.00		pCi/L			PNL-KI	
		4/18/86	H0000DMC7	N	77	3.90		pCi/L			PNL-KI	
		7/16/86	H0000DM02	N	77	1.80 U		pCi/L			PNL-KI	
		10/22/86	H0000DM07	N	77	21.00		pCi/L			PNL-KI	
		1/16/87	H0000DMF1	N	77	4.49	1.48	pCi/L	2/13/87		USTEST	
		4/15/87	H0000DMF5	N	77	2.97	.89	pCi/L	5/12/87		USTEST	
		7/22/87	H0000DMF8	N	77	1.76	.56	pCi/L	11/06/87		USTEST	
		10/19/87	H0000DMG0	N	77	1.86	.59	pCi/L	11/03/87		USTEST	
		11/13/87	H0000DMG1	N	77	2.75	.82	ug/L	12/08/87		USTEST	
		2/04/88	H0000DMG2	N	77	1.91	.63	pCi/L	3/24/88		USTEST	
		5/10/88	H0000DMG3	N	77	1.84	.62	pCi/L	6/07/88		USTEST	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Uranium	399-8-2	7/07/88	H000DMG5	N	77	1.92	.65	pCi/L	8/11/88		USTEST	
		12/02/88	H000DMG7	N	77	1.38	.46	pCi/L	12/21/88		USTEST	
		12/09/88	H000DMG8	N	77	1.89	.62	pCi/L	12/29/88		USTEST	
		6/13/89	H000DMG9	N	77	2.32	.73	pCi/L	7/06/89		USTEST	
		12/18/91	B00MH6	N	145	2.37	.77	ug/L	1/15/92	1	ITASRL	

Results for upgradient well 399-1-18A

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Analysis Date	Dilu- tion	Lab	Comment
Barium	399-1-18A	2/27/87	H000BSS7	N	34	45.00		ug/L	3/20/87	USTEST	
			H000BSS7F	Y	34	45.00		ug/L	3/20/87	USTEST	
		3/31/87	H000BSS8	N	34	45.00		ug/L	4/27/87	USTEST	
			H000BSS8F	Y	34	44.00		ug/L	4/27/87	USTEST	
		4/22/87	H000BSS9	N	34	46.00		ug/L	5/13/87	USTEST	
			H000BSS9F	Y	34	46.00		ug/L	5/13/87	USTEST	
		6/18/87	H000BST0	N	34	50.00		ug/L	7/22/87	USTEST	
			H000BST0F	Y	34	48.00		ug/L	7/22/87	USTEST	
		8/24/87	H000BST1	N	34	48.00		ug/L	9/23/87	USTEST	
			H000BST1F	Y	34	48.00		ug/L	9/23/87	USTEST	
		11/17/87	H000BST2	N	34	46.00		ug/L	12/11/87	USTEST	
			H000BST2F	Y	34	49.00		ug/L	12/11/87	USTEST	
		5/23/88	H000BST3	N	34	50.00		ug/L	6/07/88	USTEST	
			H000BST3F	Y	34	48.00		ug/L	6/09/88	USTEST	
		8/16/88	H000BST4	N	34	56.00		ug/L	8/31/88	USTEST	
			H000BST4F	Y	34	52.00		ug/L	8/31/88	USTEST	
		12/07/88	H000BST9	N	34	46.00		ug/L	12/15/88	USTEST	
			H000BST9F	Y	34	43.00		ug/L	12/16/88	USTEST	
		6/08/89	H000BSV8	N	34	42.00	5.06	ug/L	6/21/89	USTEST	
			H000BSV8F	Y	34	43.00	5.15	ug/L	6/21/89	USTEST	
		12/18/89	H000BSW6	N	34	46.00	5.43	ug/L	1/15/90	USTEST	
			H000BSW6F	Y	34	46.00	5.43	ug/L	1/15/90	USTEST	
		12/18/90	H0007091	N	34	.04		mg/L	5/14/91	PNL2	
		7/15/91	H00071V8	N	34	47.00	Y	ug/L	2/05/92	0	DATACh
			H00071V8F	Y	34	46.00	6.35	ug/L	2/05/92	0	DATACh
		12/06/91	B01F01	N	4	44.10	E	ug/L			SKINER
			B01F02	Y	4	45.70		ug/L			SKINER
		12/13/91	B01FR8	N	34	44.00	P	ug/L	3/02/92	0	DATACh
			B01FR9	N	34	44.00	6.07	ug/L	3/02/92	0	DATACh
		4/30/92	B062S9	N	4	46.70		ug/L			SKINER
			B062T0	Y	4	45.30		ug/L			SKINER
		7/16/92	B07052	N	34	47.00	6.49	ug/L	8/07/92	0	DATACh
			B07054	N	34	46.00	6.35	ug/L	8/07/92	0	DATACh
			B07056	Y	34	47.00	6.49	ug/L	8/07/92	0	DATACh
			B07057	Y	34	46.00	6.35	ug/L	8/07/92	0	DATACh
		2/12/93	B085G6	N	34	50.00	6.90	ug/L	3/09/93		DATACh

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil-tered	Method ID	Result	Error	Units	Analysis Date	Dilu-tion	Lab	Comment
Barium	399-1-18A	2/12/93	B085G7	Y	34	50.00	6.90	ug/L	3/09/93			
		9/07/93	B09657	N	34	47.00	.14	ug/L	10/11/93			
			B09658	Y	34	46.00	.14	ug/L	10/11/93			
		6/22/94	B0BYL8	N	34	46.00	11.00	ug/L	7/20/94			
			B0BYL9	Y	34	46.00	11.00	ug/L	7/20/94			
		10/05/94	B0D378	N	34	44.00	21.10	ug/L	10/17/94			
			B0D379	Y	34	44.00	21.10	ug/L	10/17/94			
		6/01/95	B0FLS5	N	34	49.00	23.50	ug/L	7/08/95			
			B0FLS6	Y	34	49.00	23.50	ug/L	7/08/95			
		10/03/95	B0GM90	Y	34	47.00	22.60	ug/L	10/20/95	1		
		6/04/96	B0HV83	Y	34	49.00	23.50	ug/L	6/25/96	1		
		12/10/96	B0JSL2	Y	1139	64.50 Q		ug/L	12/31/96	1	QTESSL	
		6/19/97	B0L5R1	Y	1139	47.00 Q		ug/L	7/11/97	1	QTESSL	Added
Cadmium	399-1-18A	2/27/87	H000BSS7	N	34	2.00 U		ug/L	3/20/87			
			H000BSS7F	Y	34	2.00 U		ug/L	3/20/87			
		3/31/87	H000BSS8	N	34	2.00 U		ug/L	4/27/87			
			H000BSS8F	Y	34	2.00 U		ug/L	4/27/87			
		4/22/87	H000BSS9	N	34	2.00 U		ug/L	5/13/87			
			H000BSS9F	Y	34	2.00 U		ug/L	5/13/87			
		6/18/87	H000BST0	N	34	2.00 U		ug/L	7/22/87			
			H000BST0F	Y	34	2.00 U		ug/L	7/22/87			
		8/24/87	H000BST1	N	34	2.00 U		ug/L	9/23/87			
			H000BST1F	Y	34	2.00 U		ug/L	9/23/87			
		11/17/87	H000BST2	N	34	2.00 U		ug/L	12/11/87			
			H000BST2F	Y	34	2.00 U		ug/L	12/11/87			
		5/23/88	H000BST3	N	34	2.00 U		ug/L	6/07/88			
			H000BST3F	Y	34	2.00 U		ug/L	6/09/88			
		8/16/88	H000BST4	N	34	2.00 U		ug/L	8/31/88			
			H000BST4F	Y	34	2.00 U		ug/L	8/31/88			
		12/07/88	H000BST9	N	34	2.00 U		ug/L	12/15/88			
			H000BST9F	Y	34	2.00 U		ug/L	12/16/88			
		6/08/89	H000BSV8	N	34	2.00 U	1.38	ug/L	6/21/89			
			H000BSV8F	Y	34	2.00 U	1.38	ug/L	6/21/89			
		12/18/89	H000BSW6	N	34	2.00 U	1.38	ug/L	1/15/90			
			H000BSW6F	Y	34	2.00 U	1.38	ug/L	1/15/90			

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Cadmium	399-1-18A	12/18/90	H0007091	N	34	U			5/14/91			PNL2
		7/15/91	H00071V8	N	34	10.00	UY	ug/L	2/05/92	1		DATACH
			H00071V8F	Y	34	10.00	U	ug/L	2/05/92	1		DATACH
		12/06/91	B01F01	N	4	1.00		ug/L				SKINER
			B01F02	Y	4	1.00		ug/L				SKINER
		12/13/91	B01FR8	N	34	10.00	UP	ug/L	3/02/92	1		DATACH
			B01FR9	N	34	10.00	U	ug/L	3/02/92	1		DATACH
		4/30/92	B062S9	N	4	2.00		ug/L				SKINER
			B062T0	Y	4	2.00		ug/L				SKINER
		7/16/92	B07052	N	34	10.00	U	ug/L	8/07/92	1		DATACH
			B07054	N	34	10.00	U	ug/L	8/07/92	1		DATACH
			B07056	Y	34	10.00	U	ug/L	8/07/92	1		DATACH
			B07057	Y	34	10.00	U	ug/L	8/07/92	1		DATACH
		2/12/93	B085G6	N	34	10.00	U	ug/L	3/09/93			DATACH
			B085G7	Y	34	10.00	U	ug/L	3/09/93			DATACH
		9/07/93	B09657	N	34	4.70	U	ug/L	10/11/93			DATACH
			B09658	Y	34	4.70	U	ug/L	10/11/93			DATACH
		6/22/94	B0BYL8	N	34	3.00	U	ug/L	7/20/94			DATACH
			B0BYL9	Y	34	3.00	U	ug/L	7/20/94			DATACH
		10/05/94	B0D378	N	34	3.30	U	ug/L	10/17/94			DATACH
			B0D379	Y	34	3.30	U	ug/L	10/17/94			DATACH
		6/01/95	B0FLS5	N	34	1.60	L	.53 ug/L	7/08/95			DATACH
			B0FLS6	Y	34	1.50	L	.50 ug/L	7/08/95			DATACH
		10/03/95	B0GM90	Y	34	.98	U	ug/L	10/20/95	1		DATACH
		6/04/96	B0HV83	Y	34	3.20	U	ug/L	6/25/96	1		DATACH
		12/10/96	B0JSL2	Y	1139	3.00	U	ug/L	12/31/96	1		QTESSL
		6/19/97	B0L5R1	Y	1139	2.90	U	ug/L	7/11/97	1		QTESSL
Cesium-137	399-1-18A	12/06/91	B01F01	N	232	10.69	U	pCi/L				TMA
		4/30/92	B062S9	N	232	12.00	UJ	pCi/L				TMA
Chromium	399-1-18A	2/27/87	H000BSS7	N	34	10.00	U	ug/L	3/20/87			USTEST
			H000BSS7F	Y	34	10.00	U	ug/L	3/20/87			USTEST
		3/31/87	H000BSS8	N	34	10.00	U	ug/L	4/27/87			USTEST
			H000BSS8F	Y	34	10.00	U	ug/L	4/27/87			USTEST
		4/22/87	H000BSS9	N	34	10.00	U	ug/L	5/13/87			USTEST

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Chromium	399-1-18A	4/22/87	H000BSS9F	Y	34	10.00 U		ug/L	5/13/87		USTEST	
		6/18/87	H000BST0	N	34	10.00 U		ug/L	7/22/87		USTEST	
			H000BST0F	Y	34	10.00 U		ug/L	7/22/87		USTEST	
		8/24/87	H000BST1	N	34	10.00 U		ug/L	9/23/87		USTEST	
			H000BST1F	Y	34	10.00 U		ug/L	9/23/87		USTEST	
		11/17/87	H000BST2	N	34	17.00		ug/L	12/11/87		USTEST	
			H000BST2F	Y	34	10.00 U		ug/L	12/11/87		USTEST	
		5/23/88	H000BST3	N	34	10.00		ug/L	6/07/88		USTEST	
			H000BST3F	Y	34	10.00 U		ug/L	6/09/88		USTEST	
		8/16/88	H000BST4	N	34	10.00 U		ug/L	8/31/88		USTEST	
			H000BST4F	Y	34	10.00 U		ug/L	8/31/88		USTEST	
		12/07/88	H000BST9	N	34	10.00 U		ug/L	12/15/88		USTEST	
			H000BST9F	Y	34	10.00 U		ug/L	12/16/88		USTEST	
		6/08/89	H000BSV8	N	34	10.00 U	5.13	ug/L	6/21/89		USTEST	
			H000BSV8F	Y	34	10.00 U	5.13	ug/L	6/21/89		USTEST	
		12/18/89	H000BSW6	N	34	10.00 U	5.13	ug/L	1/15/90		USTEST	
			H000BSW6F	Y	34	10.00 U	5.13	ug/L	1/15/90		USTEST	
		12/18/90	H0007091	N	34	U			5/14/91		PNL2	
		7/15/91	H00071V8	N	34	43.00 Y	25.70	ug/L	2/05/92	0	DATA	CH
			H00071V8F	Y	34	20.00 U		ug/L	2/05/92	1	DATA	CH
		12/06/91	B01F01	N	4	13.20		ug/L			SKINER	
			B01F02	Y	4	4.50		ug/L			SKINER	
		12/13/91	B01FR8	N	34	30.00 P	17.90	ug/L	3/02/92	0	DATA	CH
			B01FR9	N	34	20.00 U		ug/L	3/02/92	1	DATA	CH
		4/30/92	B062S9	N	4	24.30		ug/L			SKINER	
			B062T0	Y	4	3.00		ug/L			SKINER	
		7/16/92	B07052	N	34	20.00 U		ug/L	8/07/92	1	DATA	CH
			B07054	N	34	20.00 U		ug/L	8/07/92	1	DATA	CH
			B07056	Y	34	20.00 U		ug/L	8/07/92	1	DATA	CH
			B07057	Y	34	20.00 U		ug/L	8/07/92	1	DATA	CH
		2/12/93	B085G6	N	34	20.00 U		ug/L	3/09/93		DATA	CH
			B085G7	Y	34	20.00 U		ug/L	3/09/93		DATA	CH
		9/07/93	B09657	N	34	81.00	21.10	ug/L	10/11/93		DATA	CH
			B09658	Y	34	5.42 U		ug/L	10/11/93		DATA	CH
		6/22/94	B0BYL8	N	34	120.00	57.60	ug/L	7/20/94		DATA	CH
			B0BYL9	Y	34	11.00 U		ug/L	7/20/94		DATA	CH

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Chromium	399-1-18A	10/05/94	B00378	N	34	65.00 B	27.30	ug/L	10/17/94		DATA	DATA
			B00379	Y	34	19.00 LB	7.98	ug/L	10/17/94		DATA	DATA
		6/01/95	B0FLS5	N	34	16.00 L	6.72	ug/L	7/08/95		DATA	DATA
			B0FLS6	Y	34	7.60 L	3.19	ug/L	7/08/95		DATA	DATA
		10/03/95	B0GM90	Y	34	3.70 U		ug/L	10/20/95	1	DATA	DATA
		6/04/96	B0HV83	Y	34	3.40 L	1.43	ug/L	6/25/96	1	DATA	DATA
		12/10/96	B0JSL2	Y	1139	6.00 B		ug/L	12/31/96	1	QTESSL	
		6/19/97	B0L5R1	Y	1139	2.70 U		ug/L	7/11/97	1	QTESSL	
Lead	399-1-18A	2/27/87	H000BSS7	N	40	5.00 U		ug/L	3/24/87		USTEST	
		3/31/87	H000BSS8	N	40	5.00 U		ug/L	4/27/87		USTEST	
		4/22/87	H000BSS9	N	40	5.00 U		ug/L	5/19/87		USTEST	
		6/18/87	H000BST0	N	40	5.00 U		ug/L	8/10/87		USTEST	
		8/24/87	H000BST1	N	40	5.00 U		ug/L	10/05/87		USTEST	
		11/17/87	H000BST2	N	40	5.00 U		ug/L	11/27/87		USTEST	
		5/23/88	H000BST3	N	40	5.00 U		ug/L	5/27/88		USTEST	
		8/16/88	H000BST4	N	40	5.00 U		ug/L	9/06/88		USTEST	
		12/07/88	H000BST9	N	40	5.00 U		ug/L	1/03/89		USTEST	
		6/08/89	H000BSV8	N	40	5.00 U	2.55	ug/L	6/27/89		USTEST	
		12/18/89	H000BSW6	N	40	5.00 U	2.55	ug/L	1/04/90		USTEST	
		12/18/90	H0007091	N	34	U			5/14/91		PNL2	
		7/15/91	H00071V8	N	40	5.00 U		ug/L	8/14/91	1	ITASSJ	MOL
			H00071V8F	Y	40	5.00 U		ug/L	8/14/91	1	ITASSJ	MOL
		12/06/91	B01F01	N	6	4.90		ug/L			SKINER	
			B01F02	Y	6	1.00		ug/L			SKINER	
		12/13/91	B01FR8	N	40	5.30 P	2.23	ug/L	2/12/92	0	DATA	
			B01FR9	N	40	5.00 U		ug/L	2/12/92	1	DATA	
		4/30/92	B062S9	N	6	2.00		ug/L			SKINER	
			B062T0	Y	6	2.00		ug/L			SKINER	
		7/16/92	B07052	N	40	5.00 U		ug/L	7/31/92	1	DATA	
			B07054	N	40	5.00 U		ug/L	7/31/92	1	DATA	
			B07056	Y	40	5.00 U		ug/L	7/31/92	1	DATA	
			B07057	Y	40	5.00 U		ug/L	7/31/92	1	DATA	
		2/12/93	B085G6	N	40	5.00 U		ug/L	3/09/93		DATA	
			B085G7	Y	40	5.00 U		ug/L	3/09/93		DATA	
		9/07/93	B09657	N	40	10.00 B	2.09	ug/L	9/22/93		DATA	

GeoDAT Report - 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil-tered	Method ID	Result	Error	Analysis Units	Analysis Date	Dilu-tion	Lab	Comment
Lead	399-1-18A	9/07/93	B09658	Y	40	.51 U		ug/L	9/22/93			DATACH
		6/22/94	B0BYL8	N	40	.60 L	.18	ug/L	7/19/94			DATACH
			B0BYL9	Y	40	.86 U		ug/L	7/19/94			DATACH
		10/05/94	B0D378	N	40	3.50 L	1.05	ug/L	10/18/94			DATACH
			B0D379	Y	40	1.70 L	.51	ug/L	10/18/94			DATACH
		6/01/95	B0FLS5	N	40	2.60 BL	.78	ug/L	7/02/95			DATACH
			B0FLS6	Y	40	1.50 U		ug/L	7/02/95			DATACH
		10/03/95	B0GM90	Y	40	.88 U		ug/L	10/18/95	1		DATACH
		6/04/96	B0HV83	Y	34	1.70 U		ug/L	7/31/96	1		DATACH
Strontium-90	399-1-18A	12/06/91	B01F01	N	281	.20 U		pCi/L				TMA
		4/30/92	B062S9	N	281	.73 UJ		pCi/L				TMA
Uranium	399-1-18A	11/17/87	H000BST2	N	77	4.28	1.20	ug/L	12/15/87			USTEST
		10/14/88	H000BST5	N	77	5.29	1.54	ug/L	11/07/88			USTEST
		10/25/88	H000BST6	N	77	3.32	1.03	ug/L	11/07/88			USTEST
		11/09/88	H000BST7	N	77	5.20	2.40	pCi/L	11/22/88			USTEST
		11/23/88	H000BST8	N	77	3.82	1.88	pCi/L	12/06/88			USTEST
		12/07/88	H000BST9	N	77	3.59	1.79	pCi/L	12/29/88			USTEST
		12/22/88	H000BSV0	N	77	4.69	2.05	pCi/L	1/11/89			USTEST
		1/05/89	H000BSV1	N	77	3.02	1.77	pCi/L	1/25/89			USTEST
		1/19/89	H000BSV2	N	77	3.22	1.64	pCi/L	2/01/89			USTEST
		2/01/89	H000BSV3	N	77	3.57	1.91	pCi/L	3/14/89			USTEST
		2/17/89	H000BSV4	N	77	3.20	1.64	pCi/L	3/14/89			USTEST
		3/01/89	H000BSV5	N	77	3.59	1.70	pCi/L	3/21/89			USTEST
		3/16/89	H000BSV6	N	77	3.82	2.00	pCi/L	3/29/89			USTEST
		5/10/89	H000BSV7	N	77	2.58	1.40	pCi/L	5/23/89			USTEST
		6/08/89	H000BSV8	N	77	3.74	1.13	pCi/L	6/20/89			USTEST
		8/03/89	H000BSW2	N	77	2.86	1.35	pCi/L	8/18/89			USTEST
		8/17/89	H000BSW3	N	77	3.27	1.00	pCi/L	9/08/89			USTEST
		8/28/89	H000BSW4	N	77	4.05	1.21	pCi/L	9/12/89			USTEST
		9/27/89	H000BSW5	N	77	4.03	1.21	pCi/L	10/09/89			USTEST
		12/18/89	H000BSW6	N	77	3.40	1.03	pCi/L	1/24/90			USTEST
		12/18/90	H0007091	N	145	4.49	1.37	ug/L	6/18/91	1		ITASRL
		7/15/91	H00071V8	N	145	5.29	1.59	ug/L	9/12/91	1		ITASRL
		12/13/91	B01FR8	N	145	4.30 P	1.32	ug/L	1/15/92	1		ITASRL

GeoDAT Report 2/05/98

Constituent Name	Well	Collect Date	Sample Number	Fil- tered	Method ID	Result	Error	Units	Analysis Date	Dilu- tion	Lab	Comment
Uranium	399-1-18A	7/16/92	B07052	N	145	3.85	1.18	ug/L	8/04/92	1	ITASRL	
			B07054	N	145	4.73	1.45	ug/L	8/04/92	1	ITASRL	
		2/12/93	B085G6	N	145	4.24	1.28	ug/L	3/09/93	1	ITASRL	
		9/07/93	B09657	N	145	5.04	1.51	ug/L	9/29/93	1	ITASRL	
		6/22/94	B0BYL8	N	145	5.60	1.74	ug/L	7/15/94	1	ITASRL	
		10/05/94	B0D378	N	145	3.97	1.25	ug/L	10/24/94	1	ITASRL	
		6/01/95	B0FLS5	N	145	5.40	1.66	ug/L	6/27/95	1	ITASRL	
		10/03/95	B0GM88	N	145	4.99	1.58	ug/L	10/30/95	1	ITASRL	
		6/04/96	B0HV82	N	145	5.43	1.69	ug/L	6/24/96	1	ITASRL	
		12/10/96	B0JSL1	N	1289	5.53	.74	ug/L	12/30/96	1	QTESRL	Incorr
		1/08/97	B0JTJ9	N	1289	5.60	.23	ug/L	1/29/97	1	QTESRL	/Samp
		2/10/97	B0K1Q3	N	1289	5.46	.73	ug/L	3/07/97	1	QTESRL	Incorr
		3/13/97	B0K334	N	1289	5.27	1.16	ug/L	4/18/97	1	QTESRL	Incorr
		6/19/97	B0L5R0	N	1289	7.28	.98	ug/L	7/25/97	1	QTESRL	
		7/17/97	B0LBC3	N	1289	6.92	.93	ug/L	8/24/97	1	QTESRL	
		8/18/97	B0LMX6	N	1289	5.68	1.25	ug/L	9/22/97	1	QTESRL	
		9/09/97	B0LX55	N	1289	5.81	.78	ug/L	9/22/97	1	QTESRL	
		12/11/97	B0MDX7	N	1289	5.61	1.23	ug/L	1/13/98	1	QTESRL	

ATTACHMENT 7

Data Results for the 18 Wells Within 305m of the 324 Building

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-1	2/01/59	H000BYY7	N	Uranium	440.00		pCi/L
	3/01/59	H000BYY8	N	Uranium	590.00		pCi/L
	4/01/59	H000BYY9	N	Uranium	440.00		pCi/L
	1/19/67	H000BYZ7	N	Uranium	4300.00		pCi/L
	7/17/67	H000BYZ8	N	Uranium	83.00		pCi/L
	1/17/69	H000BZ09	N	Uranium	440.00		pCi/L
	7/28/71	H000BZ35	N	Uranium	130.00		pCi/L
	12/12/74	H000BZ57	N	Uranium	22.00		pCi/L
	2/19/75	H000BZ59	N	Uranium	33.00		pCi/L
	4/18/75	H000BZ61	N	Uranium	110.00		pCi/L
	6/12/75	H000BZ63	N	Uranium	53.00		pCi/L
	12/11/75	H000BZ69	N	Uranium	23.00		pCi/L
	2/12/76	H000BZ72	N	Uranium	11.00		pCi/L
	4/05/76	H000BZ74	N	Uranium	19.00		pCi/L
	5/11/76	H000BZ75	N	Uranium	29.00		pCi/L
	6/09/76	H000BZ76	N	Uranium	33.00		pCi/L
	8/16/76	H000BZ78	N	Uranium	54.00		pCi/L
	9/02/76	H000BZ79	N	Uranium	64.00		pCi/L
	9/09/76	H000BZ80	N	Uranium	49.00		pCi/L
	9/15/76	H000BZ81	N	Cesium-137 Uranium	17.00 82.00		pCi/L pCi/L
	9/23/76	H000BZ82	N	Cesium-137 Uranium	15.00 75.00		pCi/L pCi/L
	10/14/76	H000BZ83	N	Uranium	50.00		pCi/L
	10/21/76	H000BZ84	N	Uranium	59.00		pCi/L
	10/26/76	H000BZ85	N	Uranium	52.00		pCi/L
	11/06/76	H000BZ86	N	Uranium	53.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-1	11/11/76	H000BZ87	N	Uranium	62.00		pCi/L
	11/18/76	H000BZ88	N	Uranium	53.00		pCi/L
	11/23/76	H000BZ89	N	Uranium	64.00		pCi/L
	12/02/76	H000BZ90	N	Uranium	52.00		pCi/L
	12/28/76	H000BZ91	N	Uranium	19.00		pCi/L
	1/05/77	H000BZ92	N	Uranium	41.00		pCi/L
	1/26/77	H000BZ93	N	Cesium-137 Uranium	.01 45.00		pCi/L pCi/L
	2/01/77	H000BZ94	N	Uranium	19.00		pCi/L
	3/01/77	H000BZ95	N	Uranium	36.00		pCi/L
	3/04/77	H000BZ96	N	Uranium	24.00		pCi/L
	3/30/77	H000BZ97 H000BZ98	N	Uranium Uranium	35.00 6900.00		pCi/L pCi/L
	4/29/77	H000BZ99	N	Uranium	42.00		pCi/L
	6/02/77	H000BZB1	N	Uranium	41.00		pCi/L
	3/01/78	H000BZC8	N	Cesium-137 Uranium	15.00 34.00		pCi/L pCi/L
	3/24/78	H000BZC9	N	Uranium	41.00		pCi/L
	4/26/78	H000BZD0	N	Uranium	43.00		pCi/L
	5/16/78	H000BZD2	N	Uranium	28.00		pCi/L
	6/20/78	H000BZD3	N	Uranium	24.00		pCi/L
	7/11/78	H000BZD4	N	Uranium	26.00		pCi/L
	8/07/78	H000BZD5	N	Uranium	22.00		pCi/L
	9/12/78	H000BZD6	N	Uranium	10.00		pCi/L
	10/13/78	H000BZD7	N	Uranium	17.00		pCi/L
	11/08/78	H000BZD8	N	Uranium	20.00		pCi/L
	11/28/78	H000BZD9	N	Uranium	14.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-1	1/08/79	H000BZF0	N	Uranium	12.00		pCi/L
	1/24/79	H000BZF1	N	Uranium	14.00		pCi/L
	2/22/79	H000BZF2	N	Uranium	14.00		pCi/L
	3/19/79	H000BZF3	N	Uranium	14.00		pCi/L
	4/18/79	H000BZF4	N	Uranium	23.00		pCi/L
	5/16/79	H000BZF5	N	Uranium	11.00		pCi/L
	6/15/79	H000BZF6	N	Uranium	27.00		pCi/L
	7/10/79	H000BZF7	N	Uranium	22.00		pCi/L
	8/07/79	H000BZF8	N	Uranium	10.00		pCi/L
	9/05/79	H000BZF9	N	Uranium	14.00		pCi/L
	10/11/79	H000BZG0	N	Uranium	6.90		pCi/L
	11/07/79	H000BZG1	N	Uranium	6.90		pCi/L
	12/03/79	H000BZG2	N	Uranium	6.90		pCi/L
	1/11/80	H000BZG3	N	Uranium	6.90		pCi/L
	1/30/80	H000BZG4	N	Uranium	11.00		pCi/L
	4/09/80	H000BZG5	N	Uranium	11.00		pCi/L
	4/23/80	H000BZG7	N	Uranium	16.00		pCi/L
	5/19/80	H000BZG8	N	Uranium	17.00		pCi/L
	6/13/80	H000BZG9	N	Uranium	6.90		pCi/L
	7/16/80	H000BZH0	N	Uranium	6.90		pCi/L
	8/13/80	H000BZH1	N	Uranium	6.90		pCi/L
	9/10/80	H000BZH2	N	Uranium	6.90		pCi/L
	10/07/80	H000BZH3	N	Uranium	18.00		pCi/L
	11/05/80	H000BZH4	N	Uranium	15.00		pCi/L
	1/09/81	H000BZH5	N	Uranium	6.90		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-3-1	4/08/81	H000BZH6	N	Uranium	6.90		pCi/L
	6/24/81	H000BZH7	N	Uranium	6.00		pCi/L
	9/16/81	H000BZH8	N	Uranium	13.00		pCi/L
	1/13/82	H000BZH9	N	Uranium	6.70		pCi/L
	4/06/82	H000BZJ0	N	Uranium	6.70		pCi/L
	6/14/82	H000BZJ1	N	Uranium	6.70		pCi/L
	9/20/82	H000BZJ2	N	Uranium	10.00		pCi/L
	11/29/82	H000BZJ3	N	Uranium	6.70		pCi/L
	3/21/83	H000BZJ4	N	Uranium	6.70		pCi/L
	6/20/83	H000BZJ5	N	Cesium-137 Uranium	-12.00 17.00		pCi/L pCi/L
	9/19/83	H000BZJ6	N	Uranium	6.70		pCi/L
	12/05/83	H000BZJ7	N	Uranium	6.70		pCi/L
	3/23/84	H000BZJ8	N	Uranium	14.00		pCi/L
	6/04/84	H000BZJ9	N	Uranium	11.00		pCi/L
	9/24/84	H000BZK0	N	Uranium	10.00		pCi/L
	1/03/85	H000BZK1	N	Uranium	2.50		pCi/L
	1/28/85	H000BZK3	N	Uranium	120.00		pCi/L
	4/08/85	H000BZK5	N	Uranium	9.60		pCi/L
	7/15/85	H000BZK7	N	Uranium	15.00		pCi/L
	12/27/85	H000BZK8	N	Uranium	13.00		pCi/L
	1/29/86	H000BZK9	N	Uranium	8.90		pCi/L
	4/28/86	H000BZL0	N	Uranium	11.00		pCi/L
	7/14/86	H000BZL2	N	Uranium	5.30		pCi/L
	10/10/86	H000BZL4	N	Uranium	8.30		pCi/L
	1/08/87	H000BZL5	N	Cesium-137 Uranium	.32 U 6.80	4.33 2.06	pCi/L pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil- tered	Constituent Name	Result	Error	Units
399-3-1	4/02/87	H000BZL6	N	Cesium-137	4.54	U	7.42 pCi/l
				Uranium	6.91		1.87 pCi/l
	7/21/87	H000BZL7	N	Cesium-137	-2.56	U	5.43 pCi/l
				Uranium	7.00		1.89 pCi/l
	10/15/87	H000BZL8	N	Cesium-137	-3.79	U	6.40 pCi/l
				Uranium	8.41		2.29 pCi/l
	7/22/94	B0C1X8	N	Uranium	53.30		16.34 ug/L
399-3-10	10/01/76	H000BZL9	N	Strontium-90	.00		pCi/l
	10/27/76	H000BZM0	N	Uranium	140.00		pCi/l
	12/02/76	H000BZM1	N	Uranium	36.00		pCi/l
	1/05/77	H000BZM2	N	Uranium	40.00		pCi/l
	1/25/77	H000BZM3	N	Cesium-137	.35		pCi/l
				Uranium	37.00		pCi/l
	2/09/77	H000BZM4	N	Uranium	16.00		pCi/l
399-3-10	3/04/77	H000BZM5	N	Uranium	14.00		pCi/l
	3/30/77	H000BZM6	N	Uranium	13.00		pCi/l
	4/29/77	H000BZM7	N	Uranium	28.00		pCi/l
	11/02/77	H000BZN7	N	Cesium-137	14.00		pCi/l
	1/04/78	H000BZP1	N	Strontium-90	2.90		pCi/l
	2/07/78	H000BZP2	N	Strontium-90	3.60		pCi/l
	3/01/78	H000BZP3	N	Cesium-137	15.00		pCi/l
399-3-10				Strontium-90	1.10		pCi/l
				Uranium	24.00		pCi/l
	3/24/78	H000BZP4	N	Uranium	23.00		pCi/l
	4/26/78	H000BZP5	N	Strontium-90	.45		pCi/l

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-10	4/26/78	H000BZP5	N	Uranium	26.00		pCi/L
	5/16/78	H000BZP6	N	Strontium-90	2300.00		pCi/L
				Uranium	26.00		pCi/L
		H000BZP7	N	Strontium-90	.29		pCi/L
	6/19/78	H000BZP8	N	Strontium-90	.15		pCi/L
				Uranium	27.00		pCi/L
	7/11/78	H000BZP9	N	Uranium	32.00		pCi/L
	8/07/78	H000BZQ0	N	Uranium	32.00		pCi/L
	9/14/78	H000BZQ1	N	Uranium	41.00		pCi/L
	10/13/78	H000BZQ2	N	Uranium	6.90		pCi/L
	11/08/78	H000BZQ3	N	Uranium	38.00		pCi/L
	11/28/78	H000BZQ4	N	Uranium	46.00		pCi/L
	1/08/79	H000BZQ5	N	Strontium-90	3.20		pCi/L
				Uranium	38.00		pCi/L
	1/24/79	H000BZQ6	N	Strontium-90	7.20		pCi/L
				Uranium	16.00		pCi/L
	2/22/79	H000BZQ7	N	Strontium-90	13.00		pCi/L
				Uranium	20.00		pCi/L
	3/19/79	H000BZQ8	N	Strontium-90	2.90		pCi/L
				Uranium	17.00		pCi/L
	4/17/79	H000BZQ9	N	Strontium-90	3.90		pCi/L
				Uranium	21.00		pCi/L
	5/16/79	H000BZR0	N	Strontium-90	3.00		pCi/L
				Uranium	38.00		pCi/L
	6/13/79	H000BZR1	N	Strontium-90	3.00		pCi/L
				Uranium	25.00		pCi/L
	7/10/79	H000BZR2	N	Strontium-90	3.70		pCi/L
				Uranium	28.00		pCi/L
	8/07/79	H000BZR3	N	Strontium-90	4.10		pCi/L
				Uranium	47.00		pCi/L
	9/04/79	H000BZR4	N	Strontium-90	4.20		pCi/L
				Uranium	40.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-10	10/11/79	H000BZR5	N	Strontium-90 Uranium	2.60 41.00		pCi/L pCi/L
	11/07/79	H000BZR6	N	Strontium-90 Uranium	6.60 29.00		pCi/L pCi/L
	12/03/79	H000BZR7	N	Strontium-90 Uranium	13.00 31.00		pCi/L pCi/L
	1/11/80	H000BZR8	N	Strontium-90 Uranium	2.20 14.00		pCi/L pCi/L
	1/30/80	H000BZR9	N	Strontium-90 Uranium	3.40 21.00		pCi/L pCi/L
	2/27/80	H000BZS0	N	Strontium-90	3.60		pCi/L
	4/09/80	H000BZS1	N	Strontium-90 Uranium	3.10 16.00		pCi/L pCi/L
	4/23/80	H000BZS2	N	Strontium-90 Uranium	3.20 12.00		pCi/L pCi/L
	6/13/80	H000BZS3	N	Strontium-90 Uranium	3.20 19.00		pCi/L pCi/L
	7/16/80	H000BZS4	N	Strontium-90 Uranium	5.30 18.00		pCi/L pCi/L
	8/13/80	H000BZS5	N	Strontium-90 Uranium	6.90 14.00		pCi/L pCi/L
	9/10/80	H000BZS6	N	Strontium-90 Uranium	2.30 31.00		pCi/L pCi/L
	10/07/80	H000BZS7	N	Strontium-90 Uranium	1.60 40.00		pCi/L pCi/L
	11/05/80	H000BZS8	N	Strontium-90 Uranium	5.00 40.00		pCi/L pCi/L
	1/09/81	H000BZT0	N	Strontium-90 Uranium	4.60 19.00		pCi/L pCi/L
	1/29/81	H000BZT1	N	Strontium-90 Uranium	5.80 16.00		pCi/L pCi/L
	3/11/81	H000BZT2	N	Strontium-90 Uranium	2.30 15.00		pCi/L pCi/L
	3/24/81	H000BZT3	N	Strontium-90	2.80		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-3-10	3/24/81	H000BZT3	N	Uranium	19.00		pCi/L
	4/24/81	H000BZT4	N	Strontium-90	11.00		pCi/L
				Uranium	12.00		pCi/L
	6/03/81	H000BZT5	N	Strontium-90	1.90		pCi/L
				Uranium	11.00		pCi/L
	6/22/81	H000BZT6	N	Strontium-90	5.30		pCi/L
				Uranium	17.00		pCi/L
	7/22/81	H000BZT7	N	Strontium-90	1.90		pCi/L
				Uranium	20.00		pCi/L
	8/25/81	H000BZT8	N	Strontium-90	3.00		pCi/L
				Uranium	24.00		pCi/L
	9/14/81	H000BZT9	N	Strontium-90	5.10		pCi/L
				Uranium	23.00		pCi/L
	10/14/81	H000BZV0	N	Strontium-90	12.00		pCi/L
				Uranium	30.00		pCi/L
	11/04/81	H000BZV1	N	Strontium-90	8.50		pCi/L
				Uranium	31.00		pCi/L
	1/07/82	H000BZV2	N	Strontium-90	11.00		pCi/L
				Uranium	16.00		pCi/L
	2/05/82	H000BZV3	N	Strontium-90	7.50		pCi/L
				Uranium	16.00		pCi/L
	4/23/82	H000BZV4	N	Strontium-90	2.60		pCi/L
				Uranium	6.70		pCi/L
	10/19/82	H000BZV5	N	Strontium-90	14.00		pCi/L
				Uranium	26.00		pCi/L
	3/21/83	H000BZV6	N	Strontium-90	1.60		pCi/L
				Uranium	6.70		pCi/L
	6/20/83	H000BZV7	N	Cesium-137	-11.00		pCi/L
				Strontium-90	1.50		pCi/L
				Uranium	13.00		pCi/L
	9/19/83	H000BZV8	N	Strontium-90	1.70		pCi/L
				Uranium	12.00		pCi/L
	12/05/83	H000BZV9	N	Strontium-90	1.20		pCi/L
				Uranium	20.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-10	3/23/84	H000BZW0	N	Strontium-90	.28		pCi/L
				Uranium	17.00		pCi/L
	6/04/84	H000BZW1	N	Strontium-90	1.20		pCi/L
				Uranium	12.00		pCi/L
	10/12/84	H000BZW2	N	Strontium-90	-3.60		pCi/L
				Uranium	22.00		pCi/L
	12/28/84	H000BZW3	N	Strontium-90	1.30		pCi/L
				Uranium	16.00		pCi/L
	1/24/85	H000BZW4	N	Uranium	31.00		pCi/L
		H000BZW5	N	Strontium-90	.190		pCi/L
	4/15/85	H000BZW6	N	Strontium-90	.27		pCi/L
				Uranium	18.00		pCi/L
	7/01/85	H000BZW8	N	Barium	37.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	77.00		ug/L
		H000BZW9	N	Barium	81.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	72.00		ug/L
		H000BZX0	N	Barium	48.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00		ug/L
				Lead	72.00		ug/L
		H000BZX1	N	Barium	54.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	89.00		ug/L
	7/15/85	H000BZX2	N	Strontium-90	5.20		pCi/L
				Uranium	21.00		pCi/L
	7/30/85	H000BZX3	N	Barium	43.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	38.00		ug/L
				Lead	71.00		ug/L
		H000BZX4	N	Barium	42.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	97.00		ug/L
		H000BZX5	N	Barium	183.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	71.00		ug/L
		H000BZX6	N	Barium	50.00		ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filter	Constituent Name	Result	Error	Units
399-3-10	7/30/85	H000BZX6	N	Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	55.00		ug/L
	8/22/85	H000BZX7	N	Barium	40.00		ug/L
				Cadmium	3.00		ug/L
				Chromium	10.00	U	ug/L
				Lead	30.00	U	ug/L
		H000BZX8	N	Barium	39.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	30.00	U	ug/L
		H000BZX9	N	Barium	40.00		ug/L
				Cadmium	2.00		ug/L
				Chromium	10.00	U	ug/L
				Lead	30.00	U	ug/L
		H000BZY0	N	Barium	39.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	30.00	U	ug/L
	9/30/85	H000BZY1	N	Barium	41.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	30.00	U	ug/L
	10/23/85	H000BZY2	N	Barium	44.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	30.00	U	ug/L
		H000BZY3	N	Barium	46.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	11/21/85	H000BZY4	N	Strontium-90	2.60		pCi/L
				Uranium	39.00		pCi/L
		H000BZY6	N	Barium	47.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	30.00	U	ug/L
	1/16/86	H000BZY7	N	Barium	42.00		ug/L
				Cadmium	2.00		ug/L
				Chromium	10.00	U	ug/L
	1/30/86	H000BZY8	N	Strontium-90	2.20		pCi/L
				Uranium	27.00		pCi/L
	2/19/86	H000BZY9	N	Barium	40.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-3-10	3/14/86	H000BZZ0	N	Barium	56.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	4/17/86	H000BZZ1	N	Strontium-90	.89 U		pCi/L
				Uranium	17.00		pCi/L
		H000BZZ2	N	Barium	51.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	5/22/86	H000BZZ3	N	Barium	51.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	6/23/86	H000BZZ4	N	Barium	40.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	7/14/86	H000BZZ6	N	Strontium-90	5.63		pCi/L
				Uranium	.42 U		pCi/L
	7/22/86	H000BZZ7	N	Barium	51.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	8/29/86	H000BZZ8	N	Barium	40.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	9/19/86	H000BZZ9	N	Barium	42.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
		H000BZZ9F	Y	Lead	5.00 U		ug/L
				Barium	44.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	10/22/86	H000C001	N	Strontium-90	3.90		pCi/L
				Uranium	19.00		pCi/L
		H000C002	N	Barium	40.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
		H000C002F	Y	Lead	5.00 U		ug/L
				Barium	41.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	11/11/86	H000C003	N	Barium	44.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L

Well	Collect Date	Sample Number	Filter	Constituent Name	Result	Error	Units
399-3-10	11/11/86	H000C003	N	Lead	5.00 U		ug/L
		H000C003F	Y	Barium	43.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	12/09/86	H000C004	N	Barium	40.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
		H000C004F	Y	Barium	40.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
1/22/87	H000C005	N	Cesium-137		6.20	4.18	pCi/L
			Strontium-90		.77 U	.88	pCi/L
			Uranium		27.30	7.22	pCi/L
	H000C006	N	Barium		53.00		ug/L
			Cadmium		2.00 U		ug/L
			Chromium		10.00 U		ug/L
	H000C006F		Lead		5.00 U		ug/L
		Y	Barium		53.00		ug/L
			Cadmium		2.00 U		ug/L
			Chromium		10.00 U		ug/L
2/03/87	H000C007	N	Barium		38.00		ug/L
			Cadmium		2.00 U		ug/L
			Chromium		10.00 U		ug/L
			Lead		5.00 U		ug/L
	H000C007F	Y	Barium		39.00		ug/L
			Cadmium		2.00 U		ug/L
			Chromium		10.00 U		ug/L
3/29/87	H000C008	N	Barium		44.00		ug/L
			Cadmium		2.00 U		ug/L
			Chromium		10.00 U		ug/L
			Lead		5.00 U		ug/L
	H000C008F	Y	Barium		48.00		ug/L
			Cadmium		2.00 U		ug/L
			Chromium		10.00 U		ug/L
4/14/87	H000C009	N	Cesium-137		-4.48 U	7.10	pCi/L
			Strontium-90		.20 U	.66	pCi/L
			Uranium		13.90	3.57	pCi/L
	H000C010	N	Barium		42.00		ug/L
			Cadmium		2.00 U		ug/L
			Chromium		10.00 U		ug/L
	H000C010F		Lead		5.00 U		ug/L
		Y	Barium		46.00		ug/L
			Cadmium		2.00 U		ug/L
			Chromium		10.00 U		ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt- ered	Constituent Name	Result	Error	Units
399-3-10	6/25/87	H000C011	N	Barium	42.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
		H000C011F	Y	Barium	45.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	7/21/87	H000C012	N	Cesium-137	-2.66 U	4.99	pCi/L
				Strontium-90	.13 U	65	pCi/L
				Uranium	17.40	4.58	pCi/L
	8/13/87	H000C013	N	Barium	44.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
		H000C013F	Y	Barium	49.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Cesium-137	-1.92 U	5.57	pCi/L
				Strontium-90	.43 U	.70	pCi/L
				Uranium	44.10	11.50	pCi/L
	10/19/87	H000C015	N	Barium	54.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
				Uranium	76.70	18.80	ug/L
		H000C015F	Y	Barium	60.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Strontium-90	.21 U	.77	pCi/L
				Uranium	27.80	7.76	pCi/L
	2/08/88	H000C017	N	Strontium-90	- .07 U	.62	pCi/L
				Uranium	12.70	3.63	pCi/L
				Barium	35.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
		H000C018F		Lead	5.00 U		ug/L
			Y	Barium	40.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Strontium-90	.08 U	.70	pCi/L
	8/17/88	H000C019	N	Uranium	20.50	5.90	pCi/L
				Barium	42.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
		H000C020	N				

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-10	8/17/88	H000C020	N	Lead	5.00 U		ug/L
		H000C020F	Y	Barium	39.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	12/02/88	H000C021	N	Strontium-90	.43 U	.53	pCi/L
				Uranium	25.70	6.91	pCi/L
	12/09/88	H000C022	N	Barium	46.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
				Uranium	27.70	7.61	pCi/L
		H000C022F	Y	Barium	50.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	6/02/89	H000C023	N	Barium	34.00	4.32	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	8.58	2.47	pCi/L
		H000C023F	Y	Barium	36.00	4.50	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
	6/12/89	H000C027	N	Strontium-90	.28 U	.56	pCi/L
	12/19/89	H000C028	N	Strontium-90	.30 U	.66	pCi/L
		H000C029	N	Barium	39.00	4.78	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	17.60	4.80	pCi/L
		H000C029F	Y	Barium	38.00	4.69	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
	7/12/91	H00071W2	N	Barium	46.00 Y	6.35	ug/L
				Cadmium	10.00 UY		ug/L
				Chromium	20.00 UY		ug/L
				Lead	5.00 U		ug/L
				Uranium	17.10	5.96	ug/L
		H00071W2F	Y	Barium	44.00	6.07	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	20.00 U		ug/L
				Lead	5.00 U		ug/L
	12/09/91	B01F07	N	Barium	43.00		ug/L
				Cadmium	3.00		ug/L
				Cesium-137	12.14 U		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-10	12/09/91	B01F07	N	Chromium	6.00		ug/L
				Lead	4.20		ug/L
				Strontium-90	.51 UJ		pCi/L
		B01F08	Y	Barium	45.10		ug/L
				Cadmium	1.00		ug/L
	12/18/91	B01FS4	N	Chromium	8.40		ug/L
				Lead	2.00		ug/L
				Barium	47.00	6.49	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	20.00 U		ug/L
5/13/92	B062W8	B062W8	N	Lead	5.00 U		ug/L
				Uranium	20.10	5.57	ug/L
				Barium	48.00	6.62	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	20.00 U		ug/L
	B062W9	B062W9	Y	Lead	5.00 U		ug/L
				Barium	52.60 E		ug/L
				Cadmium	2.00		ug/L
				Chromium	20.60		ug/L
				Lead	1.00		ug/L
7/14/92	B07070	B07070	N	Barium	46.60		ug/L
				Cadmium	1.00		ug/L
				Chromium	5.00		ug/L
				Lead	1.80 W		ug/L
				Barium	42.00 G	5.80	ug/L
	B07071	B07071	Y	Cadmium	10.00 UG		ug/L
				Chromium	20.00 UG		ug/L
				Lead	5.00 U		ug/L
				Uranium	14.40	4.13	ug/L
				Barium	43.00 G	5.93	ug/L
12/11/92	B07P90	B07P90	N	Cadmium	10.00 UG		ug/L
				Chromium	20.00 UG		ug/L
				Lead	5.00 UG		ug/L
				Uranium	24.00 U		ug/L
				Barium	24.00 U	60.00	ug/L
	B085H0	B085H0	N	Cadmium	50.00	6.90	ug/L
				Chromium	10.00 U		ug/L
				Lead	20.00 U		ug/L
				Uranium	5.00 U		ug/L
				Barium	9.68	2.71	ug/L
2/16/93	B085H1	B085H1	Y	Cadmium	50.00	6.90	ug/L
				Chromium	10.00 U		ug/L
				Lead	20.00 U		ug/L
				Uranium	5.00 U		ug/L
				Barium	52.00	.16	ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units			
399-3-10	9/03/93	B09659	N	Cadmium	4.70 U		ug/L			
				Chromium	6.40 L	1.66	ug/L			
		B09660	N	Lead	51 UQ		ug/L			
				Uranium	25.90	7.08	ug/L			
				Barium	53.00	.16	ug/L			
	B09661	B09661	Y	Cadmium	4.70 U		ug/L			
				Chromium	9.40 L	2.44	ug/L			
				Lead	.68 LQ	.14	ug/L			
				Uranium	23.20	6.35	ug/L			
				Barium	53.00	.16	ug/L			
6/23/94	B0BYM2	B0BYM2	N	Cadmium	4.70 U		ug/L			
				Chromium	5.42 U		ug/L			
				Lead	.51 UQ		ug/L			
				Barium	51.00	.15	ug/L			
				Cadmium	4.70 U		ug/L			
	B0BYM3	B0BYM3	Y	Chromium	5.42 U		ug/L			
				Lead	.73 LQ	.15	ug/L			
				Barium	67.00		ug/L			
				Cadmium	3.00 U		ug/L			
				Chromium	21.00	10.10	ug/L			
10/10/94	B0D384	B0D384	N	Lead	4.70 BL	1.41	ug/L			
				Uranium	20.30	5.81	ug/L			
				Barium	61.00	14.60	ug/L			
				Cadmium	3.00 U		ug/L			
				Chromium	11.00 U		ug/L			
	B0D385	B0D385	Y	Lead	2.60 BL	78	ug/L			
				Barium	62.00		ug/L			
				Cadmium	3.30 U		ug/L			
				Chromium	17.00 L	7.14	ug/L			
				Lead	2.70 LQ	.81	ug/L			
6/05/95	B0FLT9	B0FLT9	N	Uranium	17.60	4.98	ug/L			
				Barium	59.00	28.30	ug/L			
				Cadmium	3.30 U		ug/L			
				Chromium	4.50 U		ug/L			
				Lead	1.70 LQ	.51	ug/L			
	B0FLVO	B0FLVO	Y	Barium	57.00	27.40	ug/L			
				Cadmium	3.30 U		ug/L			
				Chromium	9.70 L	4.07	ug/L			
				Lead	1.50 U		ug/L			
				Uranium	27.80	7.83	ug/L			
10/04/95	B0GMB1	B0GMB1	N	Barium	58.00	27.80	ug/L			
				Cadmium	1.00 BL	.33	ug/L			
	B0GMB2	B0GMB2	Y	Chromium	4.50 U		ug/L			
				Lead	1.50 U		ug/L			
				Uranium	62.53	17.89	ug/L			
				Barium	56.00	26.90	ug/L			
				Cadmium	.98 U		ug/L			

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-3-10	10/04/95	B0GMB2	Y	Chromium Lead	3.70 U .88 U		ug/L ug/L
	6/05/96	B0HV88	N	Uranium	36.29	10.46	ug/L
		B0HV89	Y	Barium	33.00	15.80	ug/L
				Cadmium	3.20 U		ug/L
				Chromium	1.80 U		ug/L
				Lead	1.70 U		ug/L
	8/08/97	B0LN32	N	Uranium	74.20	16.30	ug/L
399-3-11	10/01/76	H000C031	N	Strontium-90	.01		pCi/L
	10/27/76	H000C032	N	Uranium	39.00		pCi/L
	12/02/76	H000C033	N	Uranium	48.00		pCi/L
	1/05/77	H000C034	N	Uranium	35.00		pCi/L
	1/25/77	H000C035	N	Cesium-137 Uranium	.18 44.00		pCi/L pCi/L
	2/09/77	H000C036	N	Uranium	36.00		pCi/L
	3/04/77	H000C038	N	Uranium	34.00		pCi/L
	3/30/77	H000C039	N	Uranium	18.00		pCi/L
	4/29/77	H000C041	N	Uranium	39.00		pCi/L
	11/02/77	H000C054	N	Cesium-137	15.00		pCi/L
	1/04/78	H000C058	N	Strontium-90	9.50		pCi/L
	2/07/78	H000C059	N	Strontium-90	7.00		pCi/L
	3/01/78	H000C060	N	Cesium-137 Strontium-90 Uranium	15.00 2.70 23.00		pCi/L pCi/L pCi/L
	3/24/78	H000C061	N	Uranium	26.00		pCi/L
	4/26/78	H000C062	N	Strontium-90 Uranium	5.30 26.00		pCi/L pCi/L
	5/16/78	H000C063	N	Strontium-90 Uranium	2.70 26.00		pCi/L pCi/L
		H000C064	N	Strontium-90	4700.00		pCi/L
	6/19/78	H000C065	N	Strontium-90	4.40		pCi/L

Collect	Sample	File	Date	Number	tered	Constituent Name	Result	Error	Units
399-3-11	6/19/78 H000C065	N	Uranium	19.00		Uranium	15.00		PCI/L
	8/07/78 H000C066	N	Uranium	15.00		Uranium	15.00		PCI/L
	6/19/79 H000C067	N	Strontium-90	9.10		Strontium-90	9.10		PCI/L
	7/11/79 H000C068	N	Strontium-90	7.70		Strontium-90	14.00		PCI/L
	8/07/79 H000C069	N	Uranium	7.50		Uranium	22.00		PCI/L
	9/04/79 H000C070	N	Strontium-90	5.80		Strontium-90	16.00		PCI/L
	10/11/79 H000C071	N	Uranium	9.60		Strontium-90	17.00		PCI/L
	11/07/79 H000C072	N	Strontium-90	7.00		Uranium	19.00		PCI/L
	12/03/79 H000C073	N	Strontium-90	18.00		Uranium	21.00		PCI/L
	1/11/80 H000C074	N	Uranium	4.90		Strontium-90	12.00		PCI/L
	1/30/80 H000C075	N	Strontium-90	4.80		Uranium	19.00		PCI/L
	2/27/80 H000C076	N	Strontium-90	5.20		Uranium	17.00		PCI/L
	3/31/80 H000C077	N	Strontium-90	17.00		Uranium	190.00		PCI/L
	4/23/80 H000C078	N	Strontium-90	5.50		Uranium	23.00		PCI/L
	5/19/80 H000C079	N	Uranium	41.00		Uranium	3.30		PCI/L
	6/13/80 H000C080	N	Strontium-90	4.60		Uranium	21.00		PCI/L
	7/16/80 H000C081	N	Strontium-90	3.30		Uranium	4.30		PCI/L
	9/11/80 H000C082	N	Uranium	23.00		Strontium-90	6.80		PCI/L
	10/07/80 H000C083	N	Uranium	27.00		Strontium-90	6.80		PCI/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt- ered	Constituent Name	Result	Error	Units
399-3-11	11/05/80	H000C084	N	Strontium-90 Uranium	2.20 28.00		pCi/L pCi/L
	1/14/81	H000C085	N	Strontium-90 Uranium	22.00 37.00		pCi/L pCi/L
	2/04/81	H000C086	N	Strontium-90 Uranium	1.70 25.00		pCi/L pCi/L
	3/11/81	H000C087	N	Uranium	18.00		pCi/L
	4/08/81	H000C088	N	Strontium-90 Uranium	2.20 20.00		pCi/L pCi/L
	4/24/81	H000C089	N	Strontium-90 Uranium	2.10 25.00		pCi/L pCi/L
	6/02/81	H000C090	N	Strontium-90 Uranium	2.10 27.00		pCi/L pCi/L
	6/22/81	H000C091	N	Strontium-90 Uranium	2.30 28.00		pCi/L pCi/L
	7/22/81	H000C092	N	Strontium-90 Uranium	6.20 35.00		pCi/L pCi/L
	8/25/81	H000C093	N	Strontium-90 Uranium	7.10 20.00		pCi/L pCi/L
	9/14/81	H000C094	N	Strontium-90 Uranium	9.50 27.00		pCi/L pCi/L
	10/14/81	H000C095	N	Strontium-90 Uranium	8.50 34.00		pCi/L pCi/L
	11/04/81	H000C096	N	Strontium-90 Uranium	8.80 28.00		pCi/L pCi/L
	1/13/82	H000C097	N	Strontium-90 Uranium	15.00 32.00		pCi/L pCi/L
	2/05/82	H000C098	N	Strontium-90 Uranium	12.00 29.00		pCi/L pCi/L
	4/23/82	H000C099	N	Strontium-90 Uranium	9.80 15.00		pCi/L pCi/L
	10/19/82	H000C0B0	N	Strontium-90 Uranium	8.20 24.00		pCi/L pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-3-11	3/22/83	H000COB1	N	Strontium-90 Uranium	7.30 20.00		pCi/L pCi/L
	6/20/83	H000COB2	N	Cesium-137 Strontium-90 Uranium	-7.50 5.50 19.00		pCi/L pCi/L pCi/L
	9/21/83	H000COB3	N	Strontium-90 Uranium	5.60 18.00		pCi/L pCi/L
	12/05/83	H000COB4	N	Strontium-90 Uranium	4.20 29.00		pCi/L pCi/L
	2/06/84	H000COB5	N	Strontium-90 Uranium	8.80 23.00		pCi/L pCi/L
	4/13/84	H000COB6	N	Strontium-90 Uranium	5.80 16.00		pCi/L pCi/L
	8/21/84	H000COB7	N	Strontium-90 Uranium	9.50 19.00		pCi/L pCi/L
	10/12/84	H000COB8	N	Strontium-90 Uranium	7.00 18.00		pCi/L pCi/L
	4/19/85	H000COB9 H000COC0	N	Strontium-90 Uranium	7.40 48.00		pCi/L pCi/L
	7/15/85	H000COC1	N	Strontium-90 Uranium	8.00 7.30		pCi/L pCi/L
	1/29/86	H000COC2	N	Strontium-90 Uranium	6.90 18.00		pCi/L pCi/L
	4/24/86	H000COC3	N	Strontium-90 Uranium	8.21 64.00		pCi/L pCi/L
	7/14/86	H000COC5	N	Strontium-90 Uranium	6.65 27.00		pCi/L pCi/L
	10/13/86	H000COC7	N	Strontium-90 Uranium	9.03 12.00		pCi/L pCi/L
	1/08/87	H000COC8	N	Cesium-137 Strontium-90 Uranium	1.13 U 6.97 28.90	8.88 2.28 7.78	pCi/L pCi/L pCi/L
	4/07/87	H000COC9	N	Cesium-137 Strontium-90 Uranium	-8.26 U 6.92 20.50	7.83 2.70 5.34	pCi/L pCi/L pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-11	7/23/87	H000C0D0	N	Cesium-137	2.56 U	7.84	pCi/L
				Strontium-90	6.24	2.15	pCi/L
				Uranium	26.30	6.96	pCi/L
	10/20/87	H000C0D1	N	Cesium-137	-3.89 U	7.43	pCi/L
				Strontium-90	6.72	2.20	pCi/L
				Uranium	22.10	5.71	pCi/L
	2/12/88	H000C0D2	N	Cesium-137	.32 U	4.31	pCi/L
				Strontium-90	6.43	2.22	pCi/L
				Uranium	22.40	6.27	pCi/L
	6/01/88	H000C0D3	N	Cesium-137	.85 U	3.74	pCi/L
				Strontium-90	5.70	1.76	pCi/L
				Uranium	32.50	9.05	pCi/L
	8/17/88	H000C0D4	N	Cesium-137	2.54 U	6.49	pCi/L
				Strontium-90	7.29	2.06	pCi/L
				Uranium	20.30	5.63	pCi/L
	11/29/88	H000C0D5	N	Cesium-137	1.06 U	4.58	pCi/L
				Strontium-90	3.95	1.38	pCi/L
				Uranium	16.00	4.45	pCi/L
	1/16/92	B01DL4	N	Barium	43.30		ug/L
				Cadmium	1.00		ug/l
				Cesium-137	12.04 U		pCi/L
				Chromium	2.00		ug/l
				Lead	5.80		ug/L
				Strontium-90	.25 U		pCi/L
		B01DL5	Y	Barium	43.30		ug/L
				Cadmium	1.00		ug/l
				Chromium	2.00		ug/l
				Lead	2.00		ug/l
	6/11/92	B062D6	N	Barium	43.40		ug/l
				Cadmium	1.40		ug/l
				Chromium	3.70		ug/L
				Lead	1.40 W		ug/l
		B062D7	Y	Barium	51.00		ug/L
				Cadmium	1.50		ug/l
				Chromium	4.90		ug/L
				Lead	1.00		ug/L
	9/16/92	B075Y7	N	Barium	41.60		ug/L
				Cadmium	1.50		ug/L
				Cesium-137	15.00 UJ		pCi/L
				Chromium	22.20		ug/l
				Lead	4.00		ug/L
				Strontium-90	.12 UJ		pCi/L
		B075Y8	Y	Barium	40.90		ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-11	9/16/92	B075Y8	Y	Cadmium	1.50		ug/L
				Chromium	2.60		ug/L
				Lead	1.90		ug/L
	11/12/92	B07P92	N	Uranium	24.00		ug/L
					24.00	4.40	ug/L
	3/03/93	B086Q8	N	Uranium	34.00		ug/L
		B086S3	N	Uranium	34.00	6.30	ug/L
					38.00		ug/L
					38.00	7.10	ug/L
	9/22/93	B095K7	N	Uranium	24.00		ug/L
		B095K8	N	Uranium	24.00	4.30	ug/L
					27.00		ug/L
					27.00	4.70	ug/L
	6/22/94	B0BZL0	N	Barium	44.20		ug/L
				Cadmium	2.20 N		ug/L
				Chromium	7.20		ug/L
				Uranium	96.50	14.50	ug/L
		B0BZL1	Y	Barium	45.60		ug/L
				Cadmium	2.20 N		ug/L
				Chromium	3.40		ug/L
		B0BZL2	N	Barium	44.20		ug/L
				Cadmium	2.20 N		ug/L
				Chromium	7.10		ug/L
		B0BZL3	Y	Barium	95.70	14.40	ug/L
				Cadmium	45.10		ug/L
				Chromium	2.20 N		ug/L
					3.00		ug/L
	9/30/94	B0C1Y5	N	Cesium-137	- .96 G	6.42	pCi/L
				Strontium-90	4.20 Y	1.02	pCi/L
				Uranium	25.20	7.11	ug/L
	10/06/94	B0D4W8	N	Uranium	27.00		ug/L
		B0D4X1	N	Uranium	27.00	4.10	ug/L
					30.00		ug/L
					30.00	4.60	ug/L
	12/20/95	B0GHX4	N	Cesium-137	.39 U	1.65	pCi/L
				Strontium-90	8.70 G	1.95	pCi/L
				Uranium	129.70 G	38.12	ug/l
	8/26/96	B0HX35	N	Cesium-137	- .11 U	1.36	pCi/L
				Strontium-90	2.97	.80	pCi/L
	9/02/97	B0LN33	N	Barium	46.80		ug/L
				Cadmium	3.00 U		ug/L
				Chromium	6.50 B		ug/L

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-3-11	9/02/97	BOLN33	N	Strontium-90	3.11	.78	pCi/L
				Uranium	65.90	14.50	ug/L
		BOLN34	Y	Barium	45.80	E	ug/L
	3/11/81			Cadmium	2.90	U	ug/L
				Chromium	6.00	B	ug/L
				Strontium-90	3.14	.80	pCi/L
399-3-12	2/04/81	H000C0D7	N	Cesium-137	.46	UJ	2.36 pCi/L
				Uranium	25.00		pCi/L
	3/11/81	H000C0D8	N	Strontium-90	1.90		pCi/L
				Uranium	30.00		pCi/L
	3/24/81	H000C0D9	N	Strontium-90	2.70		pCi/L
				Uranium	18.00		pCi/L
	4/24/81	H000C0F0	N	Cesium-137	2.10		pCi/L
				Strontium-90	3.00		pCi/L
				Uranium	43.00		pCi/L
	6/03/81	H000C0F1	N	Strontium-90	2.70		pCi/L
				Uranium	50.00		pCi/L
	1/07/82	H000C0F2	N	Strontium-90	15.00		pCi/L
				Uranium	36.00		pCi/L
	2/05/82	H000C0F3	N	Strontium-90	2.00		pCi/L
				Uranium	26.00		pCi/L
	3/10/82	H000C0F4	N	Strontium-90	2.90		pCi/L
				Uranium	34.00		pCi/L
	4/06/82	H000C0F5	N	Strontium-90	2.00		pCi/L
				Uranium	25.00		pCi/L
	4/23/82	H000C0F6	N	Strontium-90	2.50		pCi/L
				Uranium	14.00		pCi/L
	5/28/82	H000C0F7	N	Strontium-90	2.30		pCi/L
				Uranium	15.00		pCi/L
	6/15/82	H000C0F8	N	Strontium-90	63.00		pCi/L
				Uranium	16.00		pCi/L
	7/16/82	H000C0F9	N	Uranium	13.00		pCi/L
				Strontium-90	2.50		pCi/L
	9/20/82	H000C0G0	N	Uranium	49.00		pCi/L
				Strontium-90	4.20		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt- ered	Constituent Name	Result	Error	Units
399-3-12	10/19/82	H000C0G1	N	Uranium	44.00		pCi/L
	11/24/82	H000C0G2	N	Strontium-90	1.80		pCi/L
				Uranium	38.00		pCi/L
	1/31/83	H000C0G3	N	Strontium-90	2.90		pCi/L
				Uranium	27.00		pCi/L
	2/15/83	H000C0G4	N	Strontium-90	1.70		pCi/L
				Uranium	24.00		pCi/L
	3/21/83	H000C0G5	N	Strontium-90	3.50		pCi/L
				Uranium	23.00		pCi/L
	4/18/83	H000C0G6	N	Strontium-90	6.00		pCi/L
				Uranium	15.00		pCi/L
	5/19/83	H000C0G7	N	Strontium-90	1.70		pCi/L
				Uranium	14.00		pCi/L
	6/20/83	H000C0G8	N	Cesium-137	-3.80		pCi/L
				Strontium-90	3.10		pCi/L
				Uranium	17.00		pCi/L
	7/21/83	H000C0G9	N	Strontium-90	2.20		pCi/L
				Uranium	25.00		pCi/L
	8/17/83	H000C0H0	N	Strontium-90	2.00		pCi/L
				Uranium	34.00		pCi/L
	9/21/83	H000C0H1	N	Strontium-90	1.90		pCi/L
				Uranium	34.00		pCi/L
	9/30/83	H000C0H2	N	Strontium-90	1.50		pCi/L
				Uranium	32.00		pCi/L
	10/31/83	H000C0H3	N	Strontium-90	3.40		pCi/L
				Uranium	27.00		pCi/L
	12/02/83	H000C0H4	N	Strontium-90	1.60		pCi/L
				Uranium	30.00		pCi/L
	3/23/84	H000C0H5	N	Strontium-90	1.20		pCi/L
				Uranium	21.00		pCi/L
	10/12/84	H000C0H6	N	Strontium-90	-2.00		pCi/L
				Uranium	34.00		pCi/L
	12/28/84	H000C0H7	N	Strontium-90	1.00		pCi/L
				Uranium	66.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-12	1/28/85	H000COH8	N	Strontium-90	-1.20		pCi/L
				Uranium	66.00		pCi/L
		H000COH9	N	Strontium-90	1.20 U		pCi/L
	4/15/85	H000COJ1	N	Strontium-90	1.60		pCi/L
				Uranium	47.00		pCi/L
	9/12/85	H000COJ3	N	Strontium-90	3.40		pCi/L
				Uranium	36.00		pCi/L
	12/27/85	H000COJ4	N	Strontium-90	.61		pCi/L
				Uranium	21.00		pCi/L
	2/20/86	H000COJ5	N	Strontium-90	1.30		pCi/L
				Uranium	30.00		pCi/L
	4/24/86	H000COJ6	N	Strontium-90	2.50		pCi/L
				Uranium	27.00		pCi/L
	7/15/86	H000COJ9	N	Strontium-90	2.30		pCi/L
				Uranium	22.00		pCi/L
	10/10/86	H000COK1	N	Strontium-90	1.60		pCi/L
				Uranium	44.00		pCi/L
	1/08/87	H000COK2	N	Cesium-137	0.00 U	6.25	pCi/L
				Strontium-90	.21 U	.66	pCi/L
				Uranium	27.60	7.35	pCi/L
	4/07/87	H000COK3	N	Cesium-137			
				Strontium-90			
				Uranium			
	5/07/87	H000COK4	N	Cesium-137	1.72 U	5.06	pCi/L
				Strontium-90	-.06 U	.64	pCi/L
				Uranium	41.00	10.60	pCi/L
	7/21/87	H000COK5	N	Cesium-137	-1.51 U	8.82	pCi/L
				Strontium-90	-.04 U	.70	pCi/L
				Uranium	26.50	6.82	pCi/L
	10/19/87	H000COK6	N	Cesium-137	0.00 U	6.00	pCi/L
				Strontium-90	.67 U	.84	pCi/L
				Uranium	29.20	7.63	pCi/L
	2/11/88	H000COK7	N	Strontium-90	.11 U	.72	pCi/L
				Uranium	18.30	6.15	pCi/L
	6/01/88	H000COK8	N	Strontium-90	.05 U	.66	pCi/L
				Uranium	25.60	8.23	pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-12	8/18/88	H000COK9	N	Strontium-90	- .34 U	.67	pCi/L
				Uranium	24.90	6.86	pCi/L
	11/29/88	H000COLO	N	Strontium-90	- .24 U	.62	pCi/L
				Uranium	15.30	5.30	pCi/L
	12/09/91	B01DN5	N	Barium	45.00		ug/L
				Cadmium	3.00		ug/L
				Cesium-137	15.10 U		pCi/L
				Chromium	6.00		ug/L
				Lead	2.50 W		ug/L
				Strontium-90	- .11 UJ		pCi/L
		B01DN6	Y	Barium	50.20		ug/L
				Cadmium	1.00		ug/L
				Chromium	9.50		ug/L
				Lead	2.00		ug/L
	4/23/92	B062D9	N	Barium	45.80		ug/L
				Cadmium	2.00		ug/L
				Cesium-137	11.00 UJ		pCi/L
				Chromium	3.70		ug/L
				Lead	1.60		ug/L
				Strontium-90	-1.70 UJ		pCi/L
				Uranium	32.00		ug/L
					32.00	6.10	ug/L
		B062F0	Y	Barium	45.20		ug/L
				Cadmium	2.00		ug/L
				Chromium	3.00		ug/L
				Lead	1.00		ug/L
	9/10/92	B075Z1	N	Barium	45.40		ug/L
				Cadmium	1.50		ug/L
				Cesium-137	13.00 UJ		pCi/L
				Chromium	2.60		ug/L
				Lead	7.30 *		ug/L
				Strontium-90	.28 UJ		pCi/L
		B075Z2	Y	Barium	45.90		ug/L
				Cadmium	1.50		ug/L
				Chromium	2.60		ug/L
				Lead	1.90		ug/L
	11/14/92	B07P94	N	Uranium	29.00		ug/L
					29.00	5.40	ug/L
	2/25/93	B086Q9	N	Uranium	37.00		ug/L
					37.00	7.00	ug/L
	8/27/93	B08ZT1	N	Uranium	3.32		ug/L
	9/24/93	B095K9	N	Uranium	31.00		ug/L
					31.00	5.50	ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt- ered	Constituent Name	Result	Error	Units
399-3-12	6/22/94	B0BZL4	N	Barium	46.20		ug/L
				Cadmium	2.20	N	ug/L
				Chromium	5.30		ug/L
				Uranium	38.90	5.84	ug/L
		B0BZL5	Y	Barium	45.90		ug/L
				Cadmium	2.20	N	ug/L
				Chromium	3.00		ug/L
	9/30/94	B0C1Y0	N	Uranium	24.50	6.92	ug/L
	8/14/96	B0HYZ8	N	Uranium	76.00	16.70	ug/L
	8/20/97	B0LJR7	N	Uranium	77.60	17.00	ug/L
399-3-2	2/01/59	H000FZQ7	N	Uranium	160.00		pCi/L
	3/01/59	H000FZQ8	N	Uranium	170.00		pCi/L
	4/01/59	H000FZQ9	N	Uranium	120.00		pCi/L
	10/07/76	H000FZR2	N	Cesium-137	4.80		pCi/L
				Strontium-90	1.60		pCi/L
	10/26/76	H000FZR3	N	Uranium	14.00		pCi/L
	12/02/76	H000FZR4	N	Uranium	5.50		pCi/L
	1/26/77	H000FZR6	N	Cesium-137	.45		pCi/L
				Uranium	25.00		pCi/L
	2/09/77	H000FZR7	N	Uranium	10.00		pCi/L
	3/04/77	H000FZR9	N	Uranium	8.20		pCi/L
	3/30/77	H000FZS0	N	Uranium	3.40		pCi/L
	4/29/77	H000FZS2	N	Uranium	14.00		pCi/L
	3/01/78	H000FZT5	N	Cesium-137	20.00		pCi/L
				Uranium	15.00		pCi/L
	3/22/78	H000FZT7	N	Uranium	15.00		pCi/L
	4/26/78	H000FZT8	N	Uranium	16.00		pCi/L
	5/16/78	H000FZT9	N	Uranium	17.00		pCi/L
	6/20/78	H000FZV0	N	Uranium	18.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-3-2	7/11/78	H000FZV1	N	Uranium	12.00		pCi/L
	8/07/78	H000FZV2	N	Uranium	12.00		pCi/L
	9/14/78	H000FZV3	N	Uranium	10.00		pCi/L
	11/08/78	H000FZV4	N	Uranium	6.90		pCi/L
	11/28/78	H000FZV5	N	Uranium	6.90		pCi/L
	1/08/79	H000FZV6	N	Uranium	6.90		pCi/L
	1/24/79	H000FZV7	N	Uranium	6.90		pCi/L
	2/22/79	H000FZV8	N	Uranium	10.00		pCi/L
	3/19/79	H000FZV9	N	Uranium	10.00		pCi/L
	4/17/79	H000FZW0	N	Uranium	6.90		pCi/L
	5/16/79	H000FZW1	N	Uranium	10.00		pCi/L
	6/19/79	H000FZW2	N	Uranium	6.90		pCi/L
	7/10/79	H000FZW3	N	Uranium	14.00		pCi/L
	8/07/79	H000FZW4	N	Uranium	10.00		pCi/L
	9/04/79	H000FZW5	N	Uranium	6.90		pCi/L
	10/11/79	H000FZW6	N	Uranium	6.90		pCi/L
	11/07/79	H000FZW7	N	Uranium	9.60		pCi/L
	12/03/79	H000FZW8	N	Uranium	6.90		pCi/L
	1/11/80	H000FZW9	N	Uranium	6.90		pCi/L
	1/30/80	H000FZX0	N	Uranium	16.00		pCi/L
	4/09/80	H000FZX2	N	Uranium	11.00		pCi/L
	4/23/80	H000FZX3	N	Uranium	6.90		pCi/L
	5/19/80	H000FZX4	N	Uranium	14.00		pCi/L
	6/25/80	H000FZX5	N	Uranium	22.00		pCi/L
	7/16/80	H000FZX6	N	Uranium	9.60		pCi/L
	9/10/80	H000FZX7	N	Uranium	6.90		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-2	10/07/80	H000FZX8	N	Uranium	6.90		pCi/L
	11/05/80	H000FZX9	N	Uranium	11.00		pCi/L
	1/08/81	H000FZY0	N	Uranium	13.00		pCi/L
	1/29/81	H000FZY1	N	Uranium	18.00		pCi/L
	3/11/81	H000FZY2	N	Uranium	6.90		pCi/L
	4/08/81	H000FZY3	N	Uranium	11.00		pCi/L
	4/24/81	H000FZY4	N	Uranium	6.70		pCi/L
	6/03/81	H000FZY5	N	Uranium	17.00		pCi/L
	6/22/81	H000FZY6	N	Uranium	15.00		pCi/L
	7/22/81	H000FZY7	N	Uranium	26.00		pCi/L
	8/25/81	H000FZY8	N	Uranium	17.00		pCi/L
	9/14/81	H000FZY9	N	Uranium	12.00		pCi/L
	10/14/81	H000FZZ0	N	Uranium	6.70		pCi/L
	11/04/81	H000FZZ1	N	Uranium	6.70		pCi/L
	1/13/82	H000FZZ2	N	Uranium	15.00		pCi/L
	2/05/82	H000FZZ3	N	Uranium	16.00		pCi/L
	4/23/82	H000FZZ4	N	Uranium	14.00		pCi/L
	10/19/82	H000FZZ5	N	Uranium	6.70		pCi/L
	3/22/83	H000FZZ6	N	Uranium	6.70		pCi/L
	6/21/83	H000FZZ7	N	Uranium	11.00		pCi/L
	9/21/83	H000FZZ8	N	Uranium	6.70		pCi/L
	12/06/83	H000FZZ9	N	Uranium	6.70		pCi/L
	3/29/84	H000G000	N	Uranium	10.00		pCi/L
	6/04/84	H000G001	N	Uranium	12.00		pCi/L
	9/26/84	H000G002	N	Uranium	14.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-2	12/21/84	H000G003	N	Uranium	11.00		pCi/L
	1/28/85	H000G004	N	Uranium	15.00		pCi/L
	4/19/85	H000G006	N	Uranium	14.00		pCi/L
	9/12/85	H000G008	N	Uranium	7.10		pCi/L
	12/27/85	H000G009	N	Uranium	15.00		pCi/L
	1/30/86	H000G011	N	Uranium	9.00		pCi/L
	4/28/86	H000G012	N	Uranium	14.00		pCi/L
	7/15/86	H000G014	N	Uranium	13.00		pCi/L
	10/13/86	H000G016	N	Uranium	4.00		pCi/L
	1/08/87	H000G017	N	Cesium-137 Uranium	1.28 U 7.04	5.54 2.09	pCi/L
	4/02/87	H000G018	N	Cesium-137 Uranium	4.79 U .96	5.52 .33	pCi/L
	7/21/87	H000G019	N	Cesium-137 Uranium	2.65 U 8.94	7.33 2.39	pCi/L
	10/20/87	H000G020	N	Cesium-137 Uranium	.32 U 7.25	4.31 1.96	pCi/L
	12/09/91	B01DM9	N	Barium Cadmium Cesium-137 Chromium Lead Strontium-90	43.00 3.00 93.87 U 6.00 2.20 .05 UJ		ug/L ug/L pCi/L ug/L ug/L pCi/L
		B01DNO	Y	Barium Cadmium Chromium Lead	36.80 1.00 9.90 2.90		ug/L ug/L ug/L ug/L
	3/10/92	B06200	N	Barium Cadmium Cesium-137 Chromium Lead Strontium-90 Uranium	35.30 1.00 15.00 UJ 5.40 3.10 .12 UJ		ug/L ug/L pCi/L ug/L ug/L pCi/L
		B06201	N	Barium Cadmium Chromium	14.00 51.80 1.00 5.00		ug/L ug/L ug/L ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-3-2	3/10/92	B06201	N	Lead	2.40		ug/L
	9/02/92	B075X9	N	Barium	37.40		ug/L
				Cadmium	1.50		ug/L
				Cesium-137	11.00	UJ	pCi/L
				Chromium	2.60		ug/L
				Lead	3.60	*	ug/L
				Strontium-90	.19	UJ	pCi/L
		B075Y0	Y	Barium	36.70		ug/L
				Cadmium	1.50		ug/L
				Chromium	2.60		ug/L
				Lead	1.90		ug/L
	11/14/92	B07P82	N	Uranium	15.00		ug/L
					15.00	2.70	ug/L
	3/08/93	B086Q7	N	Uranium	21.00		ug/L
					21.00	6.60	ug/L
	9/13/93	B095K6	N	Uranium	26.00		ug/L
					26.00	4.60	ug/L
	6/22/94	B0BZK8	N	Barium	42.00		ug/L
				Cadmium	2.20	N	ug/L
				Chromium	4.80		ug/L
				Uranium	22.30	3.34	ug/L
		B0BZK9	Y	Barium	40.50		ug/L
				Cadmium	2.20	N	ug/L
				Chromium	4.50		ug/L
	6/24/94	B0C1W1	N	Uranium	19.00		6.43 ug/L
	9/17/95	B0GHX2	N	Uranium	25.00		7.14 ug/L
399-3-3	10/05/76	H000COX7	N	Cesium-137	4.90		pCi/L
				Strontium-90	2.30		pCi/L
	10/26/76	H000COX8	N	Uranium	19.00		pCi/L
	12/02/76	H000COX9	N	Uranium	14.00		pCi/L
	1/05/77	H000COY0	N	Uranium	23.00		pCi/L
	1/26/77	H000COY1	N	Cesium-137	.08		pCi/L
				Uranium	16.00		pCi/L
	2/09/77	H000COY2	N	Uranium	12.00		pCi/L
	3/04/77	H000COY3	N	Uranium	7.50		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil- tered	Constituent Name	Result	Error	Units
399-3-3	3/30/77	H000C0Y4	N	Uranium	5.50		pCi/L
	4/29/77	H000C0Y5	N	Uranium	22.00		pCi/L
	7/01/77	H000C0Y8	N	Uranium	15.00		pCi/L
	3/01/78	H000C0Z9	N	Cesium-137 Uranium	15.00 6.90		pCi/L pCi/L
	3/23/78	H000C100	N	Uranium	8.90		pCi/L
	4/26/78	H000C101	N	Uranium	12.00		pCi/L
	5/16/78	H000C102	N	Uranium	9.60		pCi/L
	6/20/78	H000C103	N	Uranium	10.00		pCi/L
	7/11/78	H000C104	N	Uranium	11.00		pCi/L
	8/07/78	H000C105	N	Uranium	10.00		pCi/L
	9/14/78	H000C106	N	Uranium	6.80		pCi/L
	11/08/78	H000C107	N	Uranium	6.90		pCi/L
	11/28/78	H000C108	N	Uranium	8.90		pCi/L
	1/08/79	H000C109	N	Uranium	6.90		pCi/L
	1/24/79	H000C116	N	Uranium	9.60		pCi/L
	2/22/79	H000C122	N	Uranium	9.60		pCi/L
	3/19/79	H000C126	N	Uranium	6.90		pCi/L
	6/21/79	H000C141	N	Uranium	6.90		pCi/L
	7/10/79	H000C146	N	Uranium	10.00		pCi/L
	8/09/79	H000C155	N	Uranium	6.90		pCi/L
	9/04/79	H000C161	N	Uranium	6.90		pCi/L
	10/11/79	H000C166	N	Uranium	6.90		pCi/L
	11/07/79	H000C167	N	Uranium	6.90		pCi/L
	1/30/80	H000C168	N	Uranium	8.20		pCi/L
	5/19/80	H000C169	N	Uranium	6.90		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-3	6/13/80	H000C170	N	Uranium	6.90		pCi/L
	7/16/80	H000C171	N	Uranium	9.60		pCi/L
	9/11/80	H000C172	N	Uranium	12.00		pCi/L
	10/07/80	H000C173	N	Strontium-90 Uranium	20.00 11.00		pCi/L pCi/L
	11/05/80	H000C174	N	Uranium	11.00		pCi/L
	1/14/81	H000C175	N	Uranium	11.00		pCi/L
	2/04/81	H000C176	N	Strontium-90 Uranium	4.00 6.90		pCi/L pCi/L
	3/11/81	H000C177	N	Uranium	12.00		pCi/L
	4/08/81	H000C178	N	Uranium	6.90		pCi/L
	4/24/81	H000C179	N	Uranium	6.70		pCi/L
	6/02/81	H000C180	N	Uranium	12.00		pCi/L
	6/22/81	H000C181	N	Uranium	6.00		pCi/L
	7/22/81	H000C182	N	Uranium	12.00		pCi/L
	8/25/81	H000C183	N	Uranium	17.00		pCi/L
	9/14/81	H000C184	N	Uranium	15.00		pCi/L
	10/14/81	H000C185	N	Uranium	12.00		pCi/L
	11/04/81	H000C186	N	Uranium	6.70		pCi/L
	1/13/82	H000C187	N	Uranium	6.70		pCi/L
	2/05/82	H000C188	N	Uranium	6.70		pCi/L
	4/23/82	H000C189	N	Uranium	6.70		pCi/L
	10/19/82	H000C190	N	Uranium	6.70		pCi/L
	3/21/83	H000C191	N	Uranium	6.70		pCi/L
	6/20/83	H000C192	N	Cesium-137 Uranium	-9.80 11.00		pCi/L pCi/L
	9/19/83	H000C193	N	Uranium	6.70		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-3-3	12/05/83	H000C194	N	Uranium	6.70		pCi/L
	4/05/84	H000C195	N	Uranium	12.00		pCi/L
	6/04/84	H000C196	N	Uranium	15.00		pCi/L
	10/12/84	H000C197	N	Uranium	12.00		pCi/L
	12/28/84	H000C198	N	Uranium	10.00		pCi/L
	1/29/85	H000C199	N	Uranium	26.00		pCi/L
	4/19/85	H000C1B1	N	Uranium	11.00		pCi/L
	7/15/85	H000C1B3	N	Uranium	12.00		pCi/L
	1/29/86	H000C1B4	N	Uranium	12.00		pCi/L
	4/28/86	H000C1B5	N	Uranium	17.00		pCi/L
	7/14/86	H000C1B8	N	Uranium	4.80		pCi/L
	10/13/86	H000C1C0	N	Uranium	10.00		pCi/L
	1/08/87	H000C1C1	N	Cesium-137 Uranium	6.80 8.70	4.58 2.56	pCi/L
	4/07/87	H000C1C2	N	Cesium-137 Uranium	-1.28 U 7.72	5.72 2.09	pCi/L
	7/23/87	H000C1C3	N	Cesium-137 Uranium	5.13 9.94	4.22 2.65	pCi/L
	10/20/87	H000C1C4	N	Cesium-137 Uranium	0.00 U 8.48	5.81 2.28	pCi/L
	2/12/88	H000C1C5	N	Uranium	7.15	2.09	pCi/L
	6/01/88	H000C1C6	N	Uranium	5.31	1.58	pCi/L
	8/17/88	H000C1C7	N	Uranium	6.01	1.80	pCi/L
	11/29/88	H000C1C8	N	Uranium	5.94	1.73	pCi/L
	12/12/91	B01F12	Y	Barium Cadmium Chromium Lead	24.30 1.00 4.00 1.60		ug/l ug/l ug/l ug/l
	1/16/92	B01DN2	N	Barium Cadmium	27.50 1.00		ug/l ug/l

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil- tered	Constituent Name	Result	Error	Units
399-3-3	1/16/92	B01DN2	N	Cesium-137	12.41	U	pCi/L
				Chromium	2.00		ug/L
		B01DN3	Y	Lead	7.50	M	ug/L
				Strontium-90	4.57		pCi/L
				Barium	23.00		ug/L
	5/13/92	B062D3	N	Cadmium	1.00		ug/L
				Chromium	2.00		ug/L
				Lead	2.00		ug/L
		B062D4	Y	Barium	27.00		ug/L
				Cadmium	1.00		ug/L
399-3-6	9/10/92	B075Y3	N	Chromium	5.00		ug/L
				Lead	1.30	W	ug/L
		B075Y4	Y	Barium	33.20		ug/L
				Cadmium	1.50		ug/L
				Cesium-137	10.00	UJ	pCi/L
	11/13/92	B07P84	N	Chromium	2.60		ug/L
				Lead	2.00	*	ug/L
		B0C1Y1	N	Strontium-90	-1.10	UJ	pCi/L
				Barium	31.90		ug/L
				Cadmium	1.50		ug/L
399-3-6	10/29/96	B0JJN9	N	Chromium	2.60		ug/L
				Lead	5.10		ug/L
		B0M3F1	N	Uranium	10.00		ug/L
				Uranium	10.00	1.90	ug/L
	10/30/97	B0M3F2	N	Uranium	16.10		5.58 ug/L
				Uranium	17.80		2.40 ug/L
		H000C1D1	N	Uranium	26.50		5.84 ug/L
				Uranium	24.40		3.30 ug/L
				Cesium-137	.01		pCi/L
	1/26/77	H000C1D2	N	Uranium	2.70		pCi/L
				Uranium	6.90		pCi/L
		H000C1D3	N	Uranium	6.90		pCi/L
				Uranium	6.90		pCi/L
		H000C1D4	N	Uranium	6.90		pCi/L
				Uranium	6.90		pCi/L
	3/30/78	H000C1D5	N	Uranium	6.90		pCi/L
				Uranium	6.90		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filter	Constituent Name	Result	Error	Units
399-3-6	4/24/81	H000C1D6	N	Uranium	12.00		pCi/L
	6/03/81	H000C1D7	N	Uranium	6.70		pCi/L
	6/22/81	H000C1D8	N	Uranium	6.00		pCi/L
	7/22/81	H000C1D9	N	Uranium	6.70		pCi/L
	8/25/81	H000C1F0	N	Uranium	22.00		pCi/L
	9/14/81	H000C1F1	N	Uranium	16.00		pCi/L
	10/14/81	H000C1F2	N	Uranium	10.00		pCi/L
	11/04/81	H000C1F3	N	Uranium	6.70		pCi/L
	1/13/82	H000C1F4	N	Uranium	6.70		pCi/L
	2/05/82	H000C1F5	N	Uranium	6.70		pCi/L
	3/10/82	H000C1F6	N	Uranium	13.00		pCi/L
	4/06/82	H000C1F7	N	Uranium	6.70		pCi/L
	4/23/82	H000C1F8	N	Uranium	6.70		pCi/L
	5/28/82	H000C1F9	N	Uranium	14.00		pCi/L
	6/14/82	H000C1G0	N	Uranium	17.00		pCi/L
	7/16/82	H000C1G1	N	Uranium	10.00		pCi/L
	9/20/82	H000C1G3	N	Uranium	11.00		pCi/L
	10/19/82	H000C1G4	N	Uranium	11.00		pCi/L
	11/24/82	H000C1G5	N	Uranium	11.00		pCi/L
	1/31/83	H000C1G6	N	Uranium	12.00		pCi/L
	2/15/83	H000C1G7	N	Uranium	6.70		pCi/L
	3/21/83	H000C1G8	N	Uranium	6.70		pCi/L
	4/18/83	H000C1G9	N	Uranium	12.00		pCi/L
	5/19/83	H000C1H0	N	Uranium	12.00		pCi/L
	6/20/83	H000C1H1	N	Cesium-137 Uranium	-7.90 12.00		pCi/L pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-6	7/21/83	H000C1H2	N	Uranium	6.70		pCi/L
	8/17/83	H000C1H3	N	Uranium	6.70		pCi/L
	9/19/83	H000C1H4	N	Uranium	6.70		pCi/L
	10/08/83	H000C1H5	N	Uranium	6.70		pCi/L
	11/14/83	H000C1H6	N	Uranium	6.70		pCi/L
	12/05/83	H000C1H7	N	Uranium	13.00		pCi/L
	3/29/84	H000C1H8	N	Uranium	10.00		pCi/L
	6/04/84	H000C1H9	N	Uranium	11.00		pCi/L
	10/12/84	H000C1J0	N	Uranium	14.00		pCi/L
	12/21/84	H000C1J1	N	Uranium	11.00		pCi/L
	1/28/85	H000C1J2	N	Uranium	32.00		pCi/L
	4/19/85	H000C1J4	N	Uranium	15.00		pCi/L
	7/15/85	H000C1J6	N	Uranium	20.00		pCi/L
	12/27/85	H000C1J7	N	Uranium	-1.60		pCi/L
	1/30/86	H000C1J9	N	Uranium	15.00		pCi/L
	4/28/86	H000C1K0	N	Uranium	13.00		pCi/L
	7/14/86	H000C1K3	N	Uranium	5.60		pCi/L
	10/13/86	H000C1K5	N	Uranium	17.00		pCi/L
	1/08/87	H000C1K6	N	Cesium-137 Uranium	-11.20 U 10.80	7.90 3.09	pCi/L pCi/L
	4/02/87	H000C1K7	N	Cesium-137 Uranium	-4.13 U 12.60	5.52 3.30	pCi/L pCi/L
	7/21/87	H000C1K8	N	Cesium-137 Uranium	3.42 U 13.80	3.44 3.59	pCi/L pCi/L
	10/20/87	H000C1K9	N	Cesium-137 Uranium	8.27 9.98	5.06 2.65	pCi/L pCi/L
	2/08/88	H000C1L0	N	Cesium-137 Uranium	.74 U 11.40	6.58 3.24	pCi/L pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-6	5/31/88	H000C1L1	N	Cesium-137	1.53 U	7.46	pCi/L
				Uranium	8.08	2.33	pCi/L
	7/07/88	H000C1L2	N	Cesium-137	1.59 U	4.68	pCi/L
				Uranium	10.80	3.13	pCi/L
	12/21/88	H000C1L3	N	Cesium-137	8.25	6.43	pCi/L
				Uranium	6.63	1.90	pCi/L
	9/29/94	B0D0B8	N	Uranium	16.60	4.75	ug/L
	7/19/95	B0G798	N	Uranium	32.90	10.60	ug/L
	5/31/96	B0HTR6	N	Uranium	45.60	13.13	ug/L
	8/27/97	B0LN40	N	Uranium	33.50 B	7.35	ug/L
		B0LN41	N	Uranium	33.50 B	7.36	ug/L
399-3-7	1/29/81	H000C1L6	N	Uranium	11.00		pCi/L
	3/11/81	H000C1L7	N	Uranium	6.90		pCi/L
	4/08/81	H000C1L8	N	Uranium	6.90		pCi/L
	4/24/81	H000C1L9	N	Cesium-137	24.00		pCi/L
				Uranium	6.70		pCi/L
	6/03/81	H000C1M0	N	Uranium	13.00		pCi/L
	6/22/81	H000C1M1	N	Uranium	6.00		pCi/L
	7/22/81	H000C1M2	N	Uranium	17.00		pCi/L
	8/25/81	H000C1M3	N	Uranium	21.00		pCi/L
	9/14/81	H000C1M4	N	Uranium	21.00		pCi/L
	10/14/81	H000C1M5	N	Uranium	19.00		pCi/L
	11/04/81	H000C1M6	N	Uranium	6.70		pCi/L
	1/13/82	H000C1M7	N	Uranium	10.00		pCi/L
	2/05/82	H000C1M8	N	Uranium	6.70		pCi/L
	3/10/82	H000C1M9	N	Uranium	6.70		pCi/L
	4/06/82	H000C1N0	N	Uranium	14.00		pCi/L
	4/23/82	H000C1N1	N	Uranium	6.70		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-7	5/28/82	H000C1N2	N	Uranium	11.00		pCi/L
	6/14/82	H000C1N3	N	Uranium	17.00		pCi/L
	7/16/82	H000C1N4	N	Uranium	13.00		pCi/L
	9/20/82	H000C1N6	N	Uranium	14.00		pCi/L
	10/19/82	H000C1N7	N	Uranium	11.00		pCi/L
	11/24/82	H000C1N8	N	Uranium	16.00		pCi/L
	1/31/83	H000C1N9	N	Uranium	10.00		pCi/L
	2/15/83	H000C1P0	N	Uranium	6.70		pCi/L
	3/22/83	H000C1P1	N	Uranium	23.00		pCi/L
	4/18/83	H000C1P2	N	Uranium	6.90		pCi/L
	5/19/83	H000C1P3	N	Uranium	12.00		pCi/L
	6/21/83	H000C1P4	N	Uranium	6.70		pCi/L
	7/21/83	H000C1P5	N	Uranium	19.00		pCi/L
	8/17/83	H000C1P6	N	Uranium	17.00		pCi/L
	9/21/83	H000C1P7	N	Uranium	11.00		pCi/L
	10/08/83	H000C1P8	N	Uranium	12.00		pCi/L
	11/14/83	H000C1P9	N	Uranium	6.70		pCi/L
	12/06/83	H000C1Q0	N	Uranium	14.00		pCi/L
	4/05/84	H000C1Q1	N	Uranium	10.00		pCi/L
	7/23/84	H000C1Q2	N	Uranium	.50		pCi/L
	10/12/84	H000C1Q3	N	Uranium	12.00		pCi/L
	12/21/84	H000C1Q4	N	Uranium	.50		pCi/L
	1/28/85	H000C1Q5	N	Uranium	19.00		pCi/L
	4/19/85	H000C1Q7	N	Uranium	4.50		pCi/L
	6/25/85	H000C1Q9	N	Barium Cadmium	50.00 2.00 U		ug/L ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt- ered	Constituent Name	Result	Error	Units
399-3-7	6/25/85	H000C1Q9	N	Chromium Lead	10.00 U 140.00		ug/L ug/L
	7/24/85	H000C1R0	N	Barium Cadmium Chromium Lead	48.00 2.00 U 10.00 U 31.00		ug/L ug/L ug/L ug/L
	8/20/85	H000C1R1	N	Barium Cadmium Chromium Lead	36.00 5.00 10.00 U 30.00 U		ug/L ug/L ug/L ug/L
	9/12/85	H000C1R2	N	Uranium	19.00		pCi/L
	9/25/85	H000C1R3	N	Barium Cadmium Chromium Lead	78.00 2.00 U 10.00 U 30.00 U		ug/L ug/L ug/L ug/L
	10/28/85	H000C1R4	N	Uranium	14.00		pCi/L
		H000C1R6	N	Barium Cadmium Chromium Lead	37.00 2.00 U 10.00 U 30.00 U		ug/L ug/L ug/L ug/L
	11/25/85	H000C1R7	N	Barium Cadmium Chromium Lead	35.00 2.00 U 10.00 U 30.00 U		ug/L ug/L ug/L ug/L
	1/17/86	H000C1R8	N	Barium Cadmium Chromium	30.00 2.00 U 10.00 U		ug/L ug/L ug/L
	1/30/86	H000C1R9	N	Uranium	7.20		pCi/L
	2/19/86	H000C1S0	N	Barium Cadmium Chromium	29.00 2.00 U 10.00 U		ug/L ug/L ug/L
	3/14/86	H000C1S1	N	Barium Cadmium Chromium	31.00 2.00 U 10.00 U		ug/L ug/L ug/L
	4/17/86	H000C1S2	N	Uranium	16.00		pCi/L
		H000C1S3	N	Barium Cadmium Chromium	30.00 2.00 U 10.00 U		ug/L ug/L ug/L
	5/19/86	H000C1S4	N	Barium	34.00		ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filter	Constituent Name	Result	Error	Units
399-3-7	5/19/86	H000C1S4	N	Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	6/20/86	H000C1S5	N	Barium	33.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	7/17/86	H000C1S7	N	Uranium	1.60	U	pCi/L
				Barium	38.00		ug/L
		H000C1S8	N	Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	8/19/86	H000C1S9	N	Barium	40.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	9/19/86	H000C1T1	N	Barium	38.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000C1T1F	Y	Barium	16.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	10/20/86	H000C1T3	N	Uranium	12.00		pCi/L
				Barium	38.00		ug/L
				Cadmium	2.00	U	ug/L
		H000C1T4	N	Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
				Barium	16.00		ug/L
	11/10/86	H000C1T5	N	Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000C1T5F	Y	Barium	20.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	12/04/86	H000C1T6	N	Barium	37.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000C1T6F	Y	Barium	36.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	1/19/87	H000C1T7	N	Cesium-137	-2.56	U	pCi/L
				Uranium	10.30		2.77 pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fill-tered	Constituent Name	Result	Error	Units
399-3-7	1/19/87	H000C1T8	N	Barium	34.00		ug/L
				Cadmium	2.00 U		ug/L
		H000C1T8F	Y	Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
				Barium	32.00		ug/L
	2/04/87	H000C1T9	N	Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
		H000C1T9F	Y	Barium	31.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
3/18/87	H000C1V0	N	N	Barium	30.00		ug/L
				Cadmium	2.00 U		ug/L
		H000C1V0F	Y	Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
				Barium	29.00		ug/L
	H000C1V1	N	N	Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
		H000C1V1F	Y	Barium	32.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
4/28/87	H000C1V2	N	N	Cesium-137	-2.41 U	7.48	pCi/L
				Uranium	7.36	2.09	pCi/L
		H000C1V2F	Y	Barium	34.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	H000C1V3	N	N	Lead	5.00 U		ug/L
				Barium	32.00		ug/L
		H000C1V3F	Y	Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
6/24/87	H000C1V4	N	N	Barium	42.00		ug/L
				Cadmium	2.00 U		ug/L
		H000C1V4F	Y	Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
				Barium	40.00		ug/L
	H000C1V5	N	N	Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
		H000C1V5F	Y	Barium	20.00		ug/L
				Cadmium	2.00 U		ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filter	Constituent Name	Result	Error	Units
399-3-7	8/13/87	H000C1V5F	Y	Chromium	10.00	U	ug/L
	10/20/87	H000C1V6	N	Cesium-137	10.30	5.40	pCi/L
				Uranium	10.70	2.82	pCi/L
	11/09/87	H000C1V7	N	Barium	42.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
				Uranium	12.10	3.06	ug/L
		H000C1V7F	Y	Barium	42.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	2/08/88	H000C1V8	N	Uranium	6.54		pCi/L
	5/27/88	H000C1V9	N	Uranium	14.70	4.15	pCi/L
		H000C1W0	N	Barium	43.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000C1W0F	Y	Barium	36.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	7/07/88	H000C1W1	N	Uranium	9.65	2.77	pCi/L
	8/19/88	H000C1W2	N	Barium	44.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000C1W2F	Y	Barium	16.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	11/29/88	H000C1W3	N	Uranium	9.75		pCi/L
	12/08/88	H000C1W4	N	Barium	31.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
				Uranium	8.67	2.46	pCi/l
		H000C1W4F	Y	Barium	31.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	8/16/89	H000C1W5	N	Barium	37.00	4.60	ug/L
				Cadmium	2.00	U	1.38 ug/L
				Chromium	10.00	U	5.13 ug/L
				Lead	5.00	U	2.55 ug/L
				Uranium	10.20	2.90	pCi/l

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil- tered	Constituent Name	Result	Error	Units
399-3-7	8/16/89	H000C1W5F	Y	Barium	44.00	5.24	ug/L
				Cadmium	2.00	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
		H000C1W6	N	Barium	37.00	4.60	ug/L
				Cadmium	2.00 U	1.38	ug/L
	12/19/89	H000C1W6F	Y	Chromium	10.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	8.33	2.37	pCi/L
		H000C1W8F	Y	Barium	39.00	4.78	ug/L
				Cadmium	2.00 U	1.38	ug/L
7/12/91	H00071W0	H00071W0	N	Chromium	10.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	5.55	1.59	pCi/L
		H00071W0F	Y	Barium	32.00	4.15	ug/L
				Cadmium	2.00 U	1.38	ug/L
	12/09/91	B01DL1	N	Chromium	10.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	27.70	8.97	ug/L
		B01DL2	Y	Barium	42.00	5.80	ug/L
				Cadmium	10.00 U	5.13	ug/L
12/17/91	B01FS6	B01FS6	N	Chromium	20.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	8.87	2.57	ug/L
		B01FS7	N	Barium	33.00	4.55	ug/L
				Cadmium	10.00 U	5.13	ug/L
	12/17/91	B01FS7	N	Chromium	20.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fill-tered	Constituent Name	Result	Error	Units
399-3-7	5/06/92	B062W1	N	Barium	37.80		ug/L
				Cadmium	2.00		ug/L
				Cesium-137	6.40 U		pCi/L
				Chromium	3.00		ug/L
				Lead	1.80		ug/L
	7/14/92	B062W2	Y	Strontium-90	-15 U		pCi/L
				Barium	37.50		ug/L
				Cadmium	2.00		ug/L
				Chromium	3.00		ug/L
				Lead	2.00 *		ug/L
399-3-8	11/14/92	B07074	N	Barium	40.00 G	5.52	ug/L
				Cadmium	10.00 UG		ug/L
				Chromium	20.00 UG		ug/L
				Lead	5.00 UG		ug/L
				Uranium	13.20	3.76	ug/L
	9/01/76	H000FXF1	N	Barium	41.00 G	5.66	ug/L
				Cadmium	10.00 UG		ug/L
				Chromium	20.00 UG		ug/L
				Lead	5.00 U		ug/L
				Uranium	13.00		ug/L
	9/09/76	H000FXF2	N	Uranium	13.00	2.50	ug/L
				Uranium	38.00		pCi/L
				Cesium-137	17.00		pCi/L
				Uranium	45.00		pCi/L
				Cesium-137	13.00		pCi/L
				Uranium	40.00		pCi/L
				Cesium-137	27.00		pCi/L
				Uranium	50.00		pCi/L
				Uranium	52.00		pCi/L
				Uranium	56.00		pCi/L
11/06/76	H000FXF8	N	N	Uranium	33.00		pCi/L
				Uranium	57.00		pCi/L
				Uranium	38.00		pCi/L
				Uranium	57.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filter	Constituent Name	Result	Error	Units
399-3-8	11/23/76	H000FXG1	N	Uranium	39.00		pCi/L
	12/02/76	H000FXG2	N	Uranium	48.00		pCi/L
	12/09/76	H000FXG3	N	Uranium	41.00		pCi/L
	12/15/76	H000FXG4	N	Uranium	36.00		pCi/L
	12/21/76	H000FXG5	N	Uranium	34.00		pCi/L
	12/28/76	H000FXG6	N	Uranium	25.00		pCi/L
	1/05/77	H000FXG7	N	Uranium	36.00		pCi/L
	1/17/77	H000FXG8	N	Uranium	50.00		pCi/L
	1/19/77	H000FXG9	N	Uranium	41.00		pCi/L
	1/25/77	H000FXH0	N	Uranium	51.00		pCi/L
	1/28/77	H000FXH1	N	Cesium-137 Uranium	2.40 34.00		pCi/L pCi/L
	3/01/77	H000FXH3	N	Uranium	35.00		pCi/L
	3/30/77	H000FXH4	N	Uranium	33.00		pCi/L
	4/29/77	H000FXH5	N	Uranium	29.00		pCi/L
	6/02/77	H000FXH6	N	Uranium	34.00		pCi/L
	7/01/77	H000FXH7	N	Uranium	37.00		pCi/L
	7/28/77	H000FXH8	N	Uranium	38.00		pCi/L
	9/01/77	H000FXJ0	N	Uranium	44.00		pCi/L
	12/14/77	H000FXJ4	N	Cesium-137 Strontium-90	19.00 69.00		pCi/L pCi/L
	12/16/77	H000FXJ5	N	Strontium-90	94.00		pCi/L
	12/19/77	H000FXJ6	N	Strontium-90	170.00		pCi/L
	1/04/78	H000FXJ8	N	Cesium-137 Strontium-90	15.00 62.00		pCi/L pCi/L
	2/07/78	H000FXJ9	N	Strontium-90	120.00		pCi/L
	3/01/78	H000FXK0	N	Cesium-137 Strontium-90	15.00 110.00		pCi/L pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-8	3/01/78	H000FXK0	N	Uranium	21.00		pCi/L
	4/05/78	H000FXK1	N	Uranium	15.00		pCi/L
	4/26/78	H000FXK2	N	Strontium-90	100.00		pCi/L
				Uranium	22.00		pCi/L
	5/16/78	H000FXL2	N	Strontium-90	670.00		pCi/L
				Uranium	19.00		pCi/L
		H000FXL3	N	Strontium-90	960.00		pCi/L
	6/12/78	H000FXL9	N	Uranium	17.00		pCi/L
	6/19/78	H000FXM1	N	Strontium-90	130.00		pCi/L
	7/11/78	H000FXM5	N	Uranium	15.00		pCi/L
	8/07/78	H000FXM6	N	Strontium-90	180.00		pCi/L
				Uranium	17.00		pCi/L
	9/14/78	H000FXM7	N	Strontium-90	140.00		pCi/L
				Uranium	2.50		pCi/L
	11/15/78	H000FXM8	N	Uranium	23.00		pCi/L
	11/28/78	H000FXM9	N	Uranium	16.00		pCi/L
	1/08/79	H000FXN0	N	Uranium	26.00		pCi/L
	1/24/79	H000FXN2	N	Uranium	25.00		pCi/L
	2/22/79	H000FXN3	N	Uranium	6.90		pCi/L
	3/20/79	H000FXN4	N	Strontium-90	89.00		pCi/L
				Uranium	19.00		pCi/L
399-3-9	10/01/76	H000FXN5	N	Strontium-90	.00		pCi/L
				Uranium	170.00		pCi/L
	10/27/76	H000FXN6	N	Uranium	120.00		pCi/L
	12/02/76	H000FXN7	N	Uranium	140.00		pCi/L
	1/05/77	H000FXN8	N	Uranium	40.00		pCi/L
	1/19/77	H000FXN9	N	Uranium	.11		pCi/L
				Cesium-137	38.00		pCi/L
	2/09/77	H000FXP1	N	Uranium	25.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil- tered	Constituent Name	Result	Error	Units
399-3-9	3/04/77	H000FXP3	N	Uranium	18.00		pCi/L
	3/30/77	H000FXP4	N	Uranium	29.00		pCi/L
	4/29/77	H000FXP6	N	Uranium	40.00		pCi/L
	11/02/77	H000FXQ6	N	Cesium-137	11.00		pCi/L
	1/04/78	H000FXR0	N	Strontium-90	2.10		pCi/L
	2/07/78	H000FXR1	N	Strontium-90	2.30		pCi/L
	3/01/78	H000FXR2	N	Cesium-137	15.00		pCi/L
				Strontium-90	.53		pCi/L
				Uranium	27.00		pCi/L
	3/24/78	H000FXR3	N	Uranium	25.00		pCi/L
	4/26/78	H000FXR4	N	Strontium-90	.92		pCi/L
				Uranium	26.00		pCi/L
	5/16/78	H000FXR5	N	Strontium-90	5100.00		pCi/L
				Uranium	31.00		pCi/L
		H000FXR6	N	Strontium-90	.61		pCi/L
	6/19/78	H000FXR7	N	Strontium-90	.24		pCi/L
				Uranium	30.00		pCi/L
	7/11/78	H000FXR8	N	Uranium	29.00		pCi/L
	8/07/78	H000FXR9	N	Uranium	26.00		pCi/L
	9/14/78	H000FXS0	N	Uranium	27.00		pCi/L
	10/13/78	H000FXS1	N	Uranium	17.00		pCi/L
	11/08/78	H000FXS2	N	Uranium	22.00		pCi/L
	11/28/78	H000FXS3	N	Uranium	20.00		pCi/L
	1/08/79	H000FXS4	N	Strontium-90	4.70		pCi/L
				Uranium	16.00		pCi/L
	1/24/79	H000FXS5	N	Strontium-90	8.10		pCi/L
				Uranium	16.00		pCi/L
	2/22/79	H000FXS6	N	Strontium-90	9.20		pCi/L
				Uranium	15.00		pCi/L
	3/19/79	H000FXS7	N	Strontium-90	2.30		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-9	3/19/79	H000FXS7	N	Uranium	19.00		pCi/L
	4/17/79	H000FXS8	N	Strontium-90	3.00		pCi/L
				Uranium	22.00		pCi/L
	5/16/79	H000FXS9	N	Strontium-90	2.00		pCi/L
				Uranium	32.00		pCi/L
	6/13/79	H000FXT0	N	Strontium-90	4.00		pCi/L
				Uranium	19.00		pCi/L
	7/10/79	H000FXT1	N	Strontium-90	2.40		pCi/L
				Uranium	34.00		pCi/L
	8/07/79	H000FXT2	N	Strontium-90	3.40		pCi/L
				Uranium	38.00		pCi/L
	9/04/79	H000FXT3	N	Strontium-90	2.60		pCi/L
				Uranium	25.00		pCi/L
	10/11/79	H000FXT4	N	Strontium-90	4.20		pCi/L
				Uranium	16.00		pCi/L
	11/07/79	H000FXT5	N	Strontium-90	8.00		pCi/L
				Uranium	18.00		pCi/L
	12/03/79	H000FXT6	N	Strontium-90	15.00		pCi/L
				Uranium	17.00		pCi/L
	1/11/80	H000FXT7	N	Strontium-90	2.30		pCi/L
				Uranium	19.00		pCi/L
	1/30/80	H000FXT8	N	Strontium-90	3.10		pCi/L
				Uranium	12.00		pCi/L
	2/27/80	H000FXT9	N	Strontium-90	2.40		pCi/L
	4/09/80	H000FXV0	N	Strontium-90	1.50		pCi/L
				Uranium	14.00		pCi/L
	4/23/80	H000FXV1	N	Strontium-90	1.70		pCi/L
				Uranium	12.00		pCi/L
	6/13/80	H000FXV2	N	Strontium-90	4.70		pCi/L
				Uranium	26.00		pCi/L
	7/16/80	H000FXV3	N	Strontium-90	3.40		pCi/L
				Uranium	17.00		pCi/L
	8/13/80	H000FXV4	N	Strontium-90	3.30		pCi/L
				Uranium	8.20		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-9	9/10/80	H000FXV5	N	Strontium-90 Uranium	2.50 17.00		pCi/L pCi/L
	10/07/80	H000FXV6	N	Strontium-90 Uranium	2.80 23.00		pCi/L pCi/L
	11/05/80	H000FXV7	N	Strontium-90 Uranium	12.00 19.00		pCi/L pCi/L
	1/09/81	H000FXV8	N	Strontium-90 Uranium	3.20 12.00		pCi/L pCi/L
	1/29/81	H000FXV9	N	Strontium-90 Uranium	4.30 13.00		pCi/L pCi/L
	3/11/81	H000FXW0	N	Strontium-90 Uranium	2.10 6.90		pCi/L pCi/L
	3/24/81	H000FXW1	N	Strontium-90 Uranium	2.50 15.00		pCi/L pCi/L
	4/24/81	H000FXW2	N	Strontium-90 Uranium	3.20 13.00		pCi/L pCi/L
	6/02/81	H000FXW3	N	Strontium-90 Uranium	1.90 24.00		pCi/L pCi/L
	6/22/81	H000FXW4	N	Strontium-90 Uranium	2.10 14.00		pCi/L pCi/L
	7/22/81	H000FXW5	N	Strontium-90 Uranium	2.50 18.00		pCi/L pCi/L
	8/25/81	H000FXW6	N	Strontium-90 Uranium	4.50 23.00		pCi/L pCi/L
	9/14/81	H000FXW7	N	Strontium-90 Uranium	2.70 25.00		pCi/L pCi/L
	10/14/81	H000FXW8	N	Strontium-90 Uranium	2.00 22.00		pCi/L pCi/L
	11/04/81	H000FXW9	N	Strontium-90 Uranium	4.40 19.00		pCi/L pCi/L
	1/07/82	H000FXX0	N	Strontium-90 Uranium	2.00 18.00		pCi/L pCi/L
	2/05/82	H000FXX1	N	Strontium-90 Uranium	20.00 6.70		pCi/L pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-9	4/23/82	H000FXX2	N	Strontium-90 Uranium	3.90 10.00		pCi/L pCi/L
	10/19/82	H000FXX3	N	Strontium-90 Uranium	3.00 20.00		pCi/L pCi/L
	3/21/83	H000FXX4	N	Strontium-90 Uranium	1.40 6.70		pCi/L pCi/L
	6/20/83	H000FXX5	N	Cesium-137 Strontium-90 Uranium	-8.10 .82 13.00		pCi/L pCi/L pCi/L
	9/21/83	H000FXX6	N	Strontium-90 Uranium	2.10 19.00		pCi/L pCi/L
	12/02/83	H000FXX7	N	Strontium-90 Uranium	2.80 6.70		pCi/L pCi/L
	2/06/84	H000FXX8	N	Strontium-90 Uranium	-.53 13.00		pCi/L pCi/L
	4/13/84	H000FXX9	N	Strontium-90 Uranium	2.30 1.20		pCi/L pCi/L
	7/23/84	H000FXY0	N	Strontium-90 Uranium	-.68 12.00		pCi/L pCi/L
	10/12/84	H000FXY1	N	Strontium-90 Uranium	3.90 18.00		pCi/L pCi/L
	1/24/85	H000FXY2	N	Uranium	10.00		pCi/L
		H000FXY3	N	Strontium-90	5.60		pCi/L
	4/15/85	H000FXY4	N	Strontium-90 Uranium	.84 19.00		pCi/L pCi/L
	9/12/85	H000FXY6	N	Strontium-90 Uranium	2.20 5.20		pCi/L pCi/L
	12/27/85	H000FXY7	N	Strontium-90 Uranium	2.30 12.00		pCi/L pCi/L
	2/20/86	H000FXY8	N	Strontium-90 Uranium	1.90 7.70		pCi/L pCi/L
	4/24/86	H000FXY9	N	Strontium-90 Uranium	1.20 14.00		pCi/L pCi/L
	7/15/86	H000FXZ1	N	Strontium-90	5.12		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil- tered	Constituent Name	Result	Error	Units
399-3-9	7/15/86	H000FXZ1	N	Uranium	31.00		pCi/L
	10/10/86	H000FXZ3	N	Strontium-90	3.10		pCi/L
				Uranium	20.00		pCi/L
	1/08/87	H000FXZ4	N	Cesium-137	6.42 U	6.70	pCi/L
				Strontium-90	.55 U	.72	pCi/L
				Uranium	18.70	5.25	pCi/L
	4/07/87	H000FXZ5	N	Cesium-137	-3.02 U	5.66	pCi/L
				Strontium-90	.38 U	.95	pCi/L
				Uranium	10.20	2.71	pCi/L
	7/21/87	H000FXZ6	N	Cesium-137	.76 U	6.59	pCi/L
				Strontium-90	.53 U	.90	pCi/L
				Uranium	13.30	3.42	pCi/L
	10/19/87	H000FXZ7	N	Cesium-137	-8.66 U	8.57	pCi/L
				Strontium-90	.06 U	.62	pCi/L
				Uranium	17.40	4.55	pCi/L
	2/08/88	H000FXZ8	N	Strontium-90	.09 U	.69	pCi/L
				Uranium	8.84	2.52	pCi/L
	5/31/88	H000FXZ9	N	Strontium-90	-.29 U	.64	pCi/L
				Uranium	12.20	3.49	pCi/L
	8/16/88	H000FY00	N	Strontium-90	-.15 U	.67	pCi/L
				Uranium	16.10	4.45	pCi/L
	11/29/88	H000FY01	N	Strontium-90	-.09 U	.58	pCi/L
				Uranium	8.63	2.45	pCi/L
	12/11/88	H000FY02	N	Barium	33.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
				Uranium	19.90	5.48	pCi/L
	H000FY02F		Y	Barium	55.00		ug/L
				Cadmium	2.00		ug/L
				Chromium	10.00 U		ug/L
	6/12/89	H000FY03	N	Barium	49.00	5.72	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	17.90	4.97	pCi/L
	H000FY03F		Y	Barium	43.00	5.15	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-3-9	12/19/89	H000FY07	N	Strontium-90	.04 U	.64	pCi/L
		H000FY08	N	Barium	41.00	4.96	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	11.60	3.22	pCi/L
		H000FY08F	Y	Barium	42.00	5.06	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
	5/22/90	H000FY09	N	Lead	5.00 U	2.55	ug/L
	7/15/91	H00071W1	N	Barium	42.00	5.80	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	20.00 U		ug/L
				Lead	5.00 U		ug/L
				Uranium	18.60	5.17	ug/L
			Y	Barium	39.00	5.38	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	20.00 U		ug/L
				Lead	5.00 U		ug/L
	12/12/91	B01F05	N	Barium	48.40		ug/L
				Cadmium	1.00		ug/L
				Cesium-137	11.88 U		pCi/L
				Chromium	2.00		ug/L
				Lead	2.00		ug/L
				Strontium-90	.12 U		pCi/L
			Y	Barium	40.50		ug/L
				Cadmium	1.00		ug/L
				Chromium	4.00		ug/L
				Lead	1.30 W		ug/L
	12/17/91	B01FS8	N	Barium	48.00	6.62	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	20.00 U		ug/L
				Lead	5.00 U		ug/L
				Uranium	16.40	4.59	ug/L
			N	Barium	47.00	6.49	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	20.00 U		ug/L
				Lead	5.90	2.49	ug/L
	5/13/92	B062W4	N	Barium	52.80 E		ug/L
				Cadmium	2.00		ug/L
				Chromium	3.00		ug/L
				Lead	1.20		ug/L
			Y	Barium	49.60		ug/L
				Cadmium	1.00		ug/L
				Chromium	5.00		ug/L
				Lead	1.00		ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filter	Constituent Name	Result	Error	Units
399-3-9	5/13/92	B062W6	N	Barium	47.40		ug/L
				Cadmium	4.00		ug/L
				Chromium	7.00		ug/L
	7/14/92	B07078	N	Barium	59.00 G	8.14	ug/L
				Cadmium	10.00 UG		ug/L
				Chromium	20.00 UG		ug/L
				Lead	5.00 UG		ug/L
		B07080	Y	Uranium	24.30	6.88	ug/L
				Barium	60.00 G	8.28	ug/L
				Cadmium	10.00 UG		ug/L
				Chromium	20.00 UG		ug/L
				Lead	5.00 UG		ug/L
	11/14/92	B07P88	N	Uranium	27.00		ug/L
					27.00	4.90	ug/L
	6/27/94	B0C1V9	N	Uranium	21.80	7.28	ug/L
399-4-1	2/01/59	H000FY31	N	Uranium	320.00		pCi/L
	3/01/59	H000FY32	N	Uranium	370.00		pCi/L
	4/01/59	H000FY33	N	Uranium	180.00		pCi/L
	1/19/67	H000FY38	N	Uranium	4600.00		pCi/L
	7/17/67	H000FY39	N	Uranium	160.00		pCi/L
	1/17/68	H000FY40	N	Uranium	460.00		pCi/L
	10/26/76	H000FY98	N	Uranium	25.00		pCi/L
	1/26/77	H000FY99	N	Cesium-137	.02		pCi/L
				Uranium	28.00		pCi/L
	2/01/77	H000FYB0	N	Uranium	9.60		pCi/L
	3/01/77	H000FYB2	N	Uranium	27.00		pCi/L
	3/30/77	H000FYB3	N	Uranium	23.00		pCi/L
	4/25/77	H000FYB4	N	Uranium	28.00		pCi/L
	6/03/77	H000FYB6	N	Uranium	34.00		pCi/L
	6/30/77	H000FYB7	N	Uranium	23.00		pCi/L
	9/01/77	H000FYC0	N	Uranium	25.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-4-1	1/11/78	H000FYC6	N	Cesium-137	12.00		pCi/L
	3/08/78	H000FYC7	N	Uranium	6.90		pCi/L
	3/23/78	H000FYC8	N	Uranium	6.90		pCi/L
	4/26/78	H000FYC9	N	Uranium	8.90		pCi/L
	5/16/78	H000FYD0	N	Uranium	6.90		pCi/L
	6/19/78	H000FYD1	N	Uranium	6.90		pCi/L
	7/11/78	H000FYD2	N	Uranium	7.50		pCi/L
	8/07/78	H000FYD3	N	Uranium	14.00		pCi/L
	9/14/78	H000FYD4	N	Uranium	12.00		pCi/L
	10/13/78	H000FYD5	N	Uranium	15.00		pCi/L
	11/08/78	H000FYD6	N	Uranium	13.00		pCi/L
	11/28/78	H000FYD7	N	Uranium	13.00		pCi/L
	1/08/79	H000FYD8	N	Uranium	13.00		pCi/L
	1/24/79	H000FYD9	N	Uranium	15.00		pCi/L
	2/22/79	H000FYF0	N	Uranium	12.00		pCi/L
	3/19/79	H000FYF1	N	Uranium	14.00		pCi/L
	4/17/79	H000FYF2	N	Uranium	12.00		pCi/L
	5/16/79	H000FYF3	N	Uranium	14.00		pCi/L
	6/13/79	H000FYF4	N	Uranium	12.00		pCi/L
	7/10/79	H000FYF5	N	Uranium	14.00		pCi/L
	8/07/79	H000FYF6	N	Uranium	16.00		pCi/L
	9/04/79	H000FYF7	N	Uranium	12.00		pCi/L
	10/11/79	H000FYF8	N	Uranium	11.00		pCi/L
	11/07/79	H000FYF9	N	Uranium	12.00		pCi/L
	12/03/79	H000FYG0	N	Uranium	9.60		pCi/L
	1/11/80	H000FYG1	N	Uranium	11.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-1	1/30/80	H000FYG2	N	Uranium	12.00		pCi/L
	3/31/80	H000FYG4	N	Uranium	40.00		pCi/L
	4/23/80	H000FYG5	N	Uranium	8.90		pCi/L
	5/19/80	H000FYG6	N	Uranium	6.90		pCi/L
	8/13/80	H000FYG7	N	Uranium	16.00		pCi/L
	11/13/80	H000FYG8	N	Uranium	14.00		pCi/L
	12/31/80	H000FYH0	N	Uranium	19.00		pCi/L
	3/24/81	H000FYH1	N	Uranium	11.00		pCi/L
	8/31/81	H000FYH2	N	Uranium	16.00		pCi/L
	1/07/82	H000FYH3	N	Uranium	18.00		pCi/L
	3/19/82	H000FYH4	N	Uranium	18.00		pCi/L
	6/14/82	H000FYH5	N	Uranium	14.00		pCi/L
	9/20/82	H000FYH6	N	Uranium	15.00		pCi/L
	11/29/82	H000FYH7	N	Uranium	6.70		pCi/L
	3/21/83	H000FYH8	N	Uranium	16.00		pCi/L
	6/20/83	H000FYH9	N	Cesium-137 Uranium	-7.30 16.00		pCi/L pCi/L
	9/19/83	H000FYJ0	N	Uranium	6.70		pCi/L
	12/05/83	H000FYJ1	N	Uranium	11.00		pCi/L
	4/05/84	H000FYJ2	N	Uranium	11.00		pCi/L
	6/04/84	H000FYJ3	N	Uranium	11.00		pCi/L
	12/28/84	H000FYJ4	N	Uranium	15.00		pCi/L
	1/24/85	H000FYJ5	N	Uranium	14.00		pCi/L
	4/15/85	H000FYJ7	N	Uranium	25.00		pCi/L
	7/02/85	H000FYJ9	N	Barium Cadmium Chromium	46.00 2.00 U 10.00 U		ug/L ug/L ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-1	7/02/85	H000FYJ9	N	Lead	99.00		ug/L
	7/15/85	H000FYK0	N	Uranium	20.00		pCi/L
	7/23/85	H000FYK1	N	Barium Cadmium Chromium Lead	33.00 2.00 U 10.00 U 81.00		ug/L ug/L ug/L ug/L
	8/23/85	H000FYK2	N	Barium Cadmium Chromium Lead	30.00 2.00 U 15.00 30.00 U		ug/L ug/L ug/L ug/L
	9/24/85	H000FYK3	N	Barium Cadmium Chromium Lead	33.00 2.00 U 10.00 U 30.00 U		ug/L ug/L ug/L ug/L
	10/28/85	H000FYK4	N	Uranium	13.00		pCi/L
		H000FYK6	N	Barium Cadmium Chromium Lead	34.00 2.00 U 10.00 U 30.00 U		ug/L ug/L ug/L ug/L
	12/06/85	H000FYK7	N	Barium Cadmium Chromium Lead	29.00 2.00 U 10.00 U 30.00 U		ug/L ug/L ug/L ug/L
	1/17/86	H000FYK8	N	Barium Cadmium Chromium	32.00 2.00 U 10.00 U		ug/L ug/L ug/L
	1/29/86	H000FYK9	N	Uranium	19.00		pCi/L
	2/18/86	H000FYL0	N	Barium Cadmium Chromium	32.00 2.00 U 10.00 U		ug/L ug/L ug/L
	3/13/86	H000FYL1	N	Barium Cadmium Chromium	124.00 2.00 U 23.00		ug/L ug/L ug/L
	4/18/86	H000FYL2	N	Uranium	18.00		pCi/L
		H000FYL3	N	Barium Cadmium Chromium	43.00 2.00 U 10.00 U		ug/L ug/L ug/L
	5/22/86	H000FYL4	N	Barium Cadmium	32.00 2.00 U		ug/L ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-1	5/22/86	H000FYL4	N	Chromium	10.00	U	ug/L
	6/23/86	H000FYL5	N	Barium	34.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	7/14/86	H000FYL7	N	Uranium	18.00		pCi/L
	7/22/86	H000FYL8	N	Barium	34.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	8/27/86	H000FYL9	N	Barium	36.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	9/23/86	H000FYMO	N	Barium	35.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000FYMOF	Y	Barium	33.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	10/23/86	H000FYM2	N	Uranium	21.00		pCi/L
		H000FYM3	N	Barium	34.00		ug/L
				Cadmium	4.00		ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000FYM3F	Y	Barium	30.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	11/11/86	H000FYM4	N	Barium	34.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000FYM4F	Y	Barium	34.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	12/09/86	H000FYM5	N	Barium	30.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000FYM5F	Y	Barium	31.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	1/15/87	H000FYM6	N	Barium	33.00		ug/L
				Cadmium	2.00	U	ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-4-1	1/15/87	H000FYM6	N	Chromium	10.00	U	ug/L
				Lead	10.70		ug/L
		H000FYM6F	Y	Barium	32.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	2/23/87	H000FYM7	N	Cesium-137	-4.13	U	8.50 pCi/L
				Uranium	16.10		4.48 pCi/L
		H000FYM8	N	Barium	31.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	3/26/87	H000FYM8F	Y	Lead	5.00	U	ug/L
				Barium	29.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
		H000FYM9	N	Barium	36.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	4/21/87	H000FYN9F	Y	Lead	5.00	U	ug/L
				Barium	34.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
		H000FYN0	N	Cesium-137	3.44		3.10 pCi/L
				Uranium	11.40		2.99 pCi/L
				Barium	32.00		ug/L
	6/25/87	H000FYN1	N	Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000FYN1F	Y	Barium	32.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	7/23/87	H000FYN2	N	Barium	39.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
		H000FYN2F	Y	Lead	5.00	U	ug/L
				Barium	42.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	8/13/87	H000FYN3	N	Cesium-137	8.55		5.47 pCi/L
				Uranium	14.20		3.75 pCi/L
				Barium	43.00		ug/L
		H000FYN4	N	Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000FYN4F	Y	Barium	41.00		ug/L
				Cadmium	2.00	U	ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-1	8/13/87	H000FYN4F	Y	Chromium	10.00	U	ug/L
	10/19/87	H000FYN5	N	Cesium-137	-1.13	U	pCi/L
				Uranium	13.20		3.47 pCi/L
	11/12/87	H000FYN6	N	Barium	38.00		ug/l
				Cadmium	2.00	U	ug/l
				Chromium	10.00	U	ug/l
				Lead	5.00	U	ug/l
				Uranium	16.00		ug/l
		H000FYN6F	Y	Barium	36.00		ug/l
				Cadmium	2.00	U	ug/l
				Chromium	10.00	U	ug/l
	2/11/88	H000FYN7	N	Cesium-137	-1.27	U	pCi/L
				Uranium	9.13		2.59 pCi/L
	5/27/88	H000FYN8	N	Cesium-137	.95	U	pCi/L
				Uranium	13.20		3.81 pCi/L
		H000FYN9	N	Barium	34.00		ug/l
				Cadmium	2.00	U	ug/l
				Chromium	10.00	U	ug/l
				Lead	5.00	U	ug/l
		H000FYN9F	Y	Barium	34.00		ug/l
				Cadmium	2.00		ug/l
				Chromium	10.00	U	ug/l
	7/07/88	H000FYP0	N	Cesium-137	-2.63	U	pCi/L
				Uranium	10.00		2.90 pCi/L
	8/19/88	H000FYP1	N	Barium	35.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
		H000FYP1F	Y	Lead	5.00	U	ug/L
				Barium	36.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	12/21/88	H000FYP2	N	Cesium-137	6.39		pCi/L
				Uranium	8.86		2.51 pCi/L
		H000FYP3	N	Barium	32.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
				Lead	5.00	U	ug/L
		H000FYP3F	Y	Uranium	8.54		2.43 pCi/L
				Barium	33.00		ug/L
				Cadmium	2.00	U	ug/L
				Chromium	10.00	U	ug/L
	7/12/89	H000FYP4	N	Barium	36.00		ug/L
				Cadmium	2.00	U	1.38 ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filter	Constituent Name	Result	Error	Units
399-4-1	7/12/89	H000FYP4	N	Chromium	10.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	15.10	4.53	pCi/L
		H000FYP4F	Y	Barium	39.00	4.78	ug/L
				Cadmium	2.00 U	1.38	ug/L
	12/20/89	H000FYP6	N	Chromium	10.00 U	5.13	ug/L
				Barium	33.00	4.23	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
399-4-1	7/10/91	H00071W3	N	Uranium	8.75	2.43	pCi/L
				Barium	32.00	4.15	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
		H00071W3F	Y	Barium	39.00	5.38	ug/L
				Cadmium	10.00 U	ug/L	
				Chromium	20.00 U	ug/L	
				Lead	5.00 U	ug/L	
				Uranium	17.10	4.80	ug/L
399-4-1	12/03/91	B01DY9	N	Barium	36.00	4.97	ug/L
				Cadmium	10.00 U	ug/L	
				Cesium-137	20.00 U	ug/L	
				Chromium	5.00 U	ug/L	
				Lead	19.50	5.46	ug/L
	12/03/91	B01DZ0	Y	Barium	31.90	ug/L	
				Cadmium	3.00	ug/L	
				Cesium-137	13.79 U	pCi/L	
				Chromium	6.00	ug/L	
				Lead	2.10	ug/L	
399-4-1	12/10/91	B01FT0	N	Strontium-90	-2.29 UJ	pCi/L	
				Barium	35.40	ug/L	
				Cadmium	1.00	ug/L	
				Chromium	2.00	ug/L	
				Lead	1.90	ug/L	
	B01FT1	N	N	Barium	32.00	4.42	ug/L
				Cadmium	10.00 U	ug/L	
				Chromium	20.00 U	ug/L	
				Lead	5.00 U	ug/L	
				Uranium	13.50	3.81	ug/L
5/06/92	B062X1	N	N	Barium	32.00	4.42	ug/L
				Cadmium	10.00 U	ug/L	
				Cesium-137	20.00 U	ug/L	
				Lead	5.00 U	ug/L	
5/06/92	B062X1	N	N	Barium	34.20	ug/L	
				Cadmium	2.00	ug/L	
				Cesium-137	10.00 U	pCi/L	

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units	
399-4-1	5/06/92	B062X1	N	Chromium	3.00		ug/L	
				Lead	2.50		ug/L	
				Strontium-90	0.00 U		pCi/L	
	B062X2		Y	Barium	32.70		ug/L	
				Cadmium	2.00		ug/L	
				Chromium	3.00		ug/L	
				Lead	2.00 *		ug/L	
		B06311	N	Barium	34.90		ug/L	
	B06312			Cadmium	2.00		ug/L	
				Cesium-137	10.00 U		pCi/L	
				Chromium	3.00		ug/L	
				Lead	1.40		ug/L	
				Strontium-90	.01 U		pCi/L	
			Y	Barium	33.20		ug/L	
				Cadmium	2.00		ug/L	
				Chromium	3.40		ug/L	
				Lead	4.10 *		ug/L	
		7/14/92	B07083	N	Barium	35.00 G	4.83	ug/L
				Cadmium	10.00 UG		ug/L	
				Chromium	20.00 UG		ug/L	
				Lead	5.00 UG		ug/L	
				Uranium	13.00	3.73	ug/L	
		B07085	Y	Barium	35.00 G	4.83	ug/L	
				Cadmium	10.00 UG		ug/L	
				Chromium	20.00 UG		ug/L	
				Lead	5.00 UG		ug/L	
		11/10/92	B07P96	N	Uranium	16.00		ug/l
					16.00	3.00	ug/L	
	3/12/93	B086R0	N	Uranium	14.00		ug/L	
					14.00	3.40	ug/L	
	3/10/94	B0BGT8	N	Uranium	16.80	4.69	ug/l	
	7/19/95	B0G794	N	Uranium	17.10	4.91	ug/L	
	8/15/95	B0GCD9	N	Uranium	20.20	5.77	ug/L	
	8/14/96	B0HYZ9	N	Uranium	37.20	8.20	ug/L	
	8/20/97	B0LJR8	N	Uranium	53.70	11.80	ug/L	
	399-4-10	10/01/76	H000FYP8	N	Strontium-90	.00		pCi/L
		10/27/76	H000FYP9	N	Uranium	82.00		pCi/L
		12/02/76	H000FYQ0	N	Uranium	49.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-10	1/05/77	H000FYQ1	N	Uranium	52.00		pCi/l
	1/25/77	H000FYQ2	N	Cesium-137	.01		pCi/l
				Uranium	40.00		pCi/l
	2/09/77	H000FYQ3	N	Uranium	40.00		pCi/l
	3/04/77	H000FYQ4	N	Uranium	68.00		pCi/l
	3/30/77	H000FYQ5	N	Uranium	25.00		pCi/l
	4/29/77	H000FYQ6	N	Uranium	38.00		pCi/l
	1/04/78	H000FYS1	N	Strontium-90	1.50		pCi/l
	2/07/78	H000FYS2	N	Strontium-90	2.90		pCi/l
	3/01/78	H000FYS3	N	Cesium-137	15.00		pCi/l
				Strontium-90	.72		pCi/l
				Uranium	24.00		pCi/l
	3/24/78	H000FYS4	N	Uranium	24.00		pCi/l
	4/26/78	H000FYS5	N	Strontium-90	.83		pCi/l
				Uranium	33.00		pCi/l
	5/16/78	H000FYS6	N	Cesium-137	-1.06		pCi/l
				Strontium-90	2.50		pCi/l
		H000FYS7	N	Strontium-90	.77		pCi/l
	6/19/78	H000FYS8	N	Strontium-90	.39		pCi/l
				Uranium	30.00		pCi/l
	7/11/78	H000FYS9	N	Uranium	26.00		pCi/l
	8/07/78	H000FYT0	N	Uranium	20.00		pCi/l
	9/14/78	H000FYT1	N	Uranium	19.00		pCi/l
	11/08/78	H000FYT2	N	Uranium	36.00		pCi/l
	11/28/78	H000FYT3	N	Uranium	39.00		pCi/l
	1/08/79	H000FYT4	N	Strontium-90	2.10		pCi/l
				Uranium	23.00		pCi/l
	1/24/79	H000FYT5	N	Strontium-90	2.20		pCi/l
				Uranium	22.00		pCi/l
	2/22/79	H000FYT6	N	Strontium-90	2.00		pCi/l
				Uranium	19.00		pCi/l

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-10	3/19/79	H000FYT7	N	Strontium-90 Uranium	2.00 27.00		pCi/L pCi/L
	4/17/79	H000FYT8	N	Strontium-90 Uranium	2.00 26.00		pCi/L pCi/L
	5/16/79	H000FYT9	N	Strontium-90 Uranium	2.00 24.00		pCi/L pCi/L
	6/13/79	H000FYV0	N	Strontium-90 Uranium	4.00 24.00		pCi/L pCi/L
	7/10/79	H000FYV1	N	Strontium-90 Uranium	2.50 24.00		pCi/L pCi/L
	8/07/79	H000FYV2	N	Strontium-90 Uranium	2.30 22.00		pCi/L pCi/L
	9/04/79	H000FYV3	N	Strontium-90 Uranium	5.90 23.00		pCi/L pCi/L
	10/11/79	H000FYV4	N	Strontium-90 Uranium	3.20 29.00		pCi/L pCi/L
	11/07/79	H000FYV5	N	Strontium-90 Uranium	6.80 24.00		pCi/L pCi/L
	1/30/80	H000FYV6	N	Strontium-90 Uranium	4.10 19.00		pCi/L pCi/L
	4/09/80	H000FYV7	N	Strontium-90 Uranium	2.30 19.00		pCi/L pCi/L
	4/23/80	H000FYV8	N	Strontium-90 Uranium	2.10 24.00		pCi/L pCi/L
	6/13/80	H000FYV9	N	Strontium-90 Uranium	2.00 24.00		pCi/L pCi/L
	8/13/80	H000FYW0	N	Strontium-90 Uranium	5.40 22.00		pCi/L pCi/L
	9/10/80	H000FYW1	N	Strontium-90 Uranium	4.10 27.00		pCi/L pCi/L
	11/05/80	H000FYW2	N	Strontium-90 Uranium	6.10 29.00		pCi/L pCi/L
	1/09/81	H000FYW3	N	Strontium-90 Uranium	3.50 27.00		pCi/L pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-10	3/24/81	H000FYW4	N	Uranium	6.90		pCi/L
	6/22/81	H000FYW5	N	Uranium	19.00		pCi/L
	9/14/81	H000FYW6	N	Uranium	25.00		pCi/L
	1/07/82	H000FYW7	N	Uranium	21.00		pCi/L
	4/06/82	H000FYW8	N	Uranium	16.00		pCi/L
	6/14/82	H000FYW9	N	Uranium	17.00		pCi/L
	9/20/82	H000FYX0	N	Uranium	14.00		pCi/L
	11/29/82	H000FYX1	N	Uranium	6.70		pCi/L
	3/21/83	H000FYX2	N	Strontium-90 Uranium	5.30 6.70		pCi/L pCi/L
	6/20/83	H000FYX3	N	Cesium-137 Strontium-90 Uranium	-8.60 6.70 15.00		pCi/L pCi/L pCi/L
	9/19/83	H000FYX4	N	Strontium-90 Uranium	1.50 24.00		pCi/L pCi/L
	12/05/83	H000FYX5	N	Strontium-90 Uranium	2.00 20.00		pCi/L pCi/L
	3/23/84	H000FYX6	N	Strontium-90 Uranium	-19 16.00		pCi/L pCi/L
	6/04/84	H000FYX7	N	Strontium-90 Uranium	1.00 17.00		pCi/L pCi/L
	10/12/84	H000FYX8	N	Strontium-90 Uranium	5.00 25.00		pCi/L pCi/L
	12/28/84	H000FYX9	N	Strontium-90 Uranium	2.60 25.00		pCi/L pCi/L
	1/24/85	H000FYY0	N	Strontium-90 Uranium	2.00 28.00		pCi/L pCi/L
	4/08/85	H000FYY2	N	Strontium-90 Uranium	-25 29.00		pCi/L pCi/L
	7/15/85	H000FYY4	N	Strontium-90 Uranium	2.60 31.00		pCi/L pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-4-10	12/27/85	H000FY5	N	Strontium-90 Uranium	2.90 37.00		pCi/L pCi/L
	2/20/86	H000FY7	N	Strontium-90 Uranium	1.80 32.00		pCi/L pCi/L
	4/24/86	H000FY8	N	Strontium-90 Uranium	.14 U 38.00		pCi/L pCi/L
	7/14/86	H000FY20	N	Strontium-90 Uranium	2.80 19.00		pCi/L pCi/L
	10/10/86	H000FY22	N	Strontium-90 Uranium	3.30 32.00		pCi/L pCi/L
	1/08/87	H000FY23	N	Cesium-137 Strontium-90 Uranium	-7.57 U .27 U 27.70	7.94 .64 7.34	pCi/L pCi/L pCi/L
	5/07/87	H000FY24	N	Cesium-137 Strontium-90 Uranium	4.33 U .26 U 17.60	5.26 .53 -4.60	pCi/L pCi/L pCi/L
	7/21/87	H000FY25	N	Cesium-137 Strontium-90 Uranium	-.69 U .03 U 30.70	6.31 .69 7.86	pCi/L pCi/L pCi/L
	10/19/87	H000FY26	N	Cesium-137 Strontium-90 Uranium	3.10 U .30 U 38.30	5.07 .56 10.00	pCi/L pCi/L pCi/L
	2/08/88	H000FY27	N	Cesium-137 Strontium-90 Uranium	3.35 U .43 U 30.40	5.49 .62 8.38	pCi/L pCi/L pCi/L
	5/31/88	H000FY28	N	Cesium-137 Strontium-90 Uranium	6.01 U .24 U 26.70	6.75 .59 7.39	pCi/L pCi/L pCi/L
	7/07/88	H000FY29	N	Cesium-137 Strontium-90 Uranium	2.98 U .26 U 29.70	4.89 .68 8.34	pCi/L pCi/L pCi/L
	11/29/88	H000FZ00	N	Cesium-137 Strontium-90 Uranium	1.76 U .04 U 21.70	4.70 .64 6.00	pCi/L pCi/L pCi/L
	12/03/91	B01DL8	Y	Barium Cadmium Chromium Lead	50.70 1.00 2.00 5.80		ug/L ug/l ug/l ug/l

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filter	Constituent Name	Result	Error	Units
399-4-10	1/08/92	B01DL7	N	Barium	50.60		ug/L
				Cadmium	3.00		ug/L
				Cesium-137	7.58 U		pCi/l
				Chromium	6.00		ug/L
				Lead	2.00		ug/L
				Strontium-90	26 J		pCi/l
	5/13/92	B062F5	N	Barium	52.60 E		ug/L
				Cadmium	2.00		ug/L
				Chromium	3.50		ug/L
				Lead	1.10		ug/L
		B062F6	Y	Barium	52.50		ug/L
				Cadmium	1.00		ug/L
				Chromium	5.00		ug/L
				Lead	1.00		ug/L
	9/14/92	B075Z9	N	Barium	53.70 E		ug/L
				Cadmium	1.50		ug/L
				Cesium-137	12.00 U		pCi/l
				Chromium	16.90		ug/L
				Lead	1.90		ug/L
				Strontium-90	.07 U		pCi/l
		B07600	Y	Barium	50.80		ug/L
				Cadmium	1.00		ug/L
				Chromium	4.50		ug/L
				Lead	1.70		ug/L
	11/12/92	B07PB2	N	Uranium	56.00		ug/L
					56.00	10.00	ug/L
	3/03/93	B086R2	N	Uranium	43.00		ug/L
		B086S4	N	Uranium	43.00	8.10	ug/L
					43.00	8.10	ug/L
					43.00	8.10	ug/L
	8/31/93	B08ZT5	N	Uranium	.35	.19	ug/L
	9/22/93	B095L4	N	Uranium	70.00		ug/L
					70.00	12.00	ug/L
		B095L5	N	Uranium	70.00		ug/L
					70.00	12.00	ug/L
		B095L6	N	Uranium	52.00		ug/L
					52.00	9.10	ug/L
		B095L7	N	Uranium	61.00		ug/L
					61.00	11.00	ug/L
		B095L8	N	Uranium	70.00		ug/L
					70.00	12.00	ug/L
	9/28/93	B098W0	N	Uranium	4.32	1.29	ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-10	6/23/94	B0BZM0	N	Barium	53.20		ug/L
				Cadmium	1.80		ug/L
				Chromium	2.80		ug/L
				Uranium	42.40	6.36	ug/L
		B0BZM1	Y	Barium	52.20		ug/L
				Cadmium	1.80		ug/L
				Chromium	2.80		ug/L
		B0BZM3	Y	Barium	53.70		ug/L
				Cadmium	1.80		ug/L
				Chromium	2.80		ug/L
	6/24/94	B0BZM2	Y	Barium	53.40		ug/L
				Cadmium	1.80		ug/L
				Chromium	2.80		ug/L
				Uranium	41.50	6.22	ug/L
	10/06/94	B0C1Y2	N	Uranium	32.40	10.28	ug/L
					55.00		ug/L
	8/05/95	B0GF75	N	Uranium	55.00	8.40	ug/L
					37.50	10.60	ug/L
399-4-11	2/24/87	H000FZ02	N	Barium	28.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	17.00		ug/L
				Lead	5.00 U		ug/L
		H000FZ02F	Y	Barium	28.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	4/01/87	H000FZ03	N	Barium	28.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
		H000FZ03F	Y	Barium	28.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	4/23/87	H000FZ04	N	Barium	32.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
		H000FZ04F	Y	Barium	31.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	6/25/87	H000FZ05	N	Barium	41.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	14.00		ug/L
				Lead	5.00 U		ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-4-11	6/25/87	H000FZ05F	Y	Barium	43.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
	8/26/87	H000FZ06	N	Barium	40.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
		H000FZ06F	Y	Barium	41.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
11/11/87	H000FZ07	H000FZ07	N	Barium	43.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	23.00		ug/L
				Lead	5.00 U		ug/L
				Uranium	16.80	4.20	pCi/L
	H000FZ07F	H000FZ07F	Y	Barium	39.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
2/12/88	H000FZ08	H000FZ08	N	Uranium	9.38	-2.70	pCi/L
	H000FZ09	H000FZ10	N	Uranium	8.57	2.48	pCi/L
				Barium	33.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
	H000FZ10F	H000FZ10F	Y	Barium	33.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
8/11/88	H000FZ11	H000FZ11	N	Uranium	13.20	3.71	pCi/L
	H000FZ12	H000FZ12F	N	Barium	35.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
				Barium	38.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
12/05/88	H000FZ13	H000FZ13	N	Uranium	6.28	1.82	pCi/L
	H000FZ14	H000FZ14F	N	Barium	30.00		ug/L
				Cadmium	2.00 U		ug/L
				Chromium	10.00 U		ug/L
				Lead	5.00 U		ug/L
				Uranium	6.89	1.99	pCi/L
				Barium	31.00		ug/L
				Cadmium	2.00 U		ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt- ered	Constituent Name	Result	Error	Units
399-4-11	12/15/88	H000FZ14F	Y	Chromium	10.00 U		ug/L
	6/06/89	H000FZ15	N	Barium	30.00	3.97	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	8.75	2.49	pCi/L
		H000FZ15F	Y	Barium	38.00	4.69	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
	12/20/89	H000FZ20	N	Barium	33.00	4.23	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
				Lead	5.00 U	2.55	ug/L
				Uranium	7.04	1.98	pCi/L
		H000FZ20F	Y	Barium	31.00	4.06	ug/L
				Cadmium	2.00 U	1.38	ug/L
				Chromium	10.00 U	5.13	ug/L
	5/21/90	H000FZ21	N	Lead	5.00 U	2.55	ug/L
	7/15/91	H00071W5	N	Barium	38.00	5.24	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	22.00	13.10	ug/L
				Lead	5.00 U		ug/L
				Uranium	13.70	3.91	ug/L
		H00071W5F	Y	Barium	38.00	5.24	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	20.00 U		ug/L
				Lead	5.00 U		ug/L
	12/03/91	B01DZ1	N	Barium	39.40		ug/L
				Cadmium	3.00		ug/L
				Cesium-137	8.15 U		pCi/L
				Chromium	28.10		ug/L
				Lead	2.10		ug/L
				Strontium-90	.28 UJ		pCi/L
		B01DZ2	Y	Barium	34.80		ug/L
				Cadmium	1.00		ug/L
				Chromium	2.00		ug/L
				Lead	1.00		ug/L
	12/11/91	B01FT2	N	Barium	36.00	4.97	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	22.00	13.10	ug/L
				Lead	5.00 U		ug/L
				Uranium	14.90	4.18	ug/L
		B01FT3	N	Barium	36.00	4.97	ug/L
				Cadmium	10.00 U		ug/L
				Chromium	20.00 U		ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units	
399-4-11	12/11/91	B01FT3	N	Lead	5.00	U	ug/L	
	5/06/92	B062X8	N	Barium	34.20		ug/L	
				Cadmium	2.00		ug/L	
				Cesium-137	5.90	U	pCi/L	
				Chromium	363.00		ug/L	
				Lead	1.40		ug/L	
				Strontium-90	.05	U	pCi/L	
	B062X9		Y	Barium	34.00		ug/L	
				Cadmium	2.00		ug/L	
				Chromium	3.40		ug/L	
				Lead	4.30	*	ug/L	
	7/14/92	B07088	N	Barium	35.00	G	4.83	ug/L
				Cadmium	10.00	UG		ug/L
				Chromium	20.00	UG		ug/L
				Lead	5.00	UG		ug/L
	B07089		Y	Uranium	12.80		3.68	ug/L
				Barium	35.00	G	4.83	ug/L
				Cadmium	10.00	UG		ug/L
				Chromium	20.00	UG		ug/L
				Lead	5.00	UG		ug/L
	11/13/92	B07PB4	N	Uranium	13.00			ug/L
					13.00		2.50	ug/L
	3/09/93	B086R3	N	Uranium	17.00			ug/L
					17.00		5.30	ug/L
	6/27/94	B0C1W2	N	Strontium-90	.23		.27	pCi/l
	10/06/95	BOGHW9	N	Cesium-137	.66	U	1.05	pCi/L
				Uranium	23.57		6.70	ug/L
	6/17/96	B0HX36	N	Cesium-137	-1.17	U	2.06	pCi/L
				Strontium-90	-.15		.28	pCi/L
				Uranium	40.38		11.53	ug/L
	8/11/97	B0LN42	N	Uranium	50.70		11.10	ug/L
399-4-5	6/20/78	H000FZ23	N	Uranium	12.00			pCi/l
	8/07/78	H000FZ24	N	Uranium	10.00			pCi/l
399-4-9	10/01/76	H000DK83	N	Strontium-90	.00			pCi/l
	10/27/76	H000DK84	N	Uranium	28.00			pCi/l
	12/02/76	H000DK85	N	Uranium	16.00			pCi/l

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-9	1/05/77	H000DK86	N	Uranium	60.00		pCi/L
	1/25/77	H000DK87	N	Cesium-137 Uranium	.01 34.00		pCi/L pCi/L
	2/09/77	H000DK88	N	Uranium	29.00		pCi/L
	3/30/77	H000DK91	N	Uranium	27.00		pCi/L
	4/29/77	H000DK93	N	Uranium	64.00		pCi/L
	11/02/77	H000DKB5	N	Cesium-137	16.00		pCi/L
	1/04/78	H000DKB9	N	Cesium-137 Strontium-90	12.00 1.80		pCi/L pCi/L
	2/07/78	H000DKC0	N	Strontium-90	2.10		pCi/L
	3/01/78	H000DKC1	N	Cesium-137 Strontium-90 Uranium	15.00 .45 26.00		pCi/L pCi/L pCi/L
	3/24/78	H000DKC2	N	Uranium	27.00		pCi/L
	4/26/78	H000DKC3	N	Strontium-90 Uranium	.66 34.00		pCi/L pCi/L
	5/16/78	H000DKC4	N	Strontium-90 Uranium	4100.00 37.00		pCi/L pCi/L
		H000DKC5	N	Strontium-90	1.10		pCi/L
	6/19/78	H000DKC6	N	Strontium-90 Uranium	.52 37.00		pCi/L pCi/L
	7/11/78	H000DKC7	N	Uranium	24.00		pCi/L
	8/07/78	H000DKC8	N	Uranium	24.00		pCi/L
	9/14/78	H000DKC9	N	Uranium	11.00		pCi/L
	10/13/78	H000DKD0	N	Uranium	9.60		pCi/L
	11/08/78	H000DKD1	N	Uranium	31.00		pCi/L
	11/28/78	H000DKD2	N	Uranium	23.00		pCi/L
	1/08/79	H000DKD3	N	Strontium-90 Uranium	3.10 21.00		pCi/L pCi/L
	1/24/79	H000DKD4	N	Strontium-90	3.80		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-4-9	1/24/79	H000DKD4	N	Uranium	16.00		pCi/L
	2/22/79	H000DKD5	N	Strontium-90	4.40		pCi/L
				Uranium	16.00		pCi/L
	3/19/79	H000DKD6	N	Strontium-90	2.00		pCi/L
				Uranium	21.00		pCi/L
	4/17/79	H000DKD7	N	Strontium-90	3.60		pCi/L
				Uranium	24.00		pCi/L
	5/16/79	H000DKD8	N	Strontium-90	2.00		pCi/L
				Uranium	25.00		pCi/L
	6/13/79	H000DKD9	N	Strontium-90	2.00		pCi/L
				Uranium	24.00		pCi/L
	7/10/79	H000DKF0	N	Strontium-90	2.80		pCi/L
				Uranium	22.00		pCi/L
	8/07/79	H000DKF1	N	Strontium-90	1.70		pCi/L
				Uranium	24.00		pCi/L
	9/04/79	H000DKF2	N	Strontium-90	4.90		pCi/L
				Uranium	21.00		pCi/L
	10/11/79	H000DKF3	N	Strontium-90	2.50		pCi/L
				Uranium	19.00		pCi/L
	11/07/79	H000DKF4	N	Strontium-90	4.20		pCi/L
				Uranium	16.00		pCi/L
	12/03/79	H000DKF5	N	Strontium-90	8.20		pCi/L
				Uranium	14.00		pCi/L
	1/11/80	H000DKF6	N	Strontium-90	1.70		pCi/L
				Uranium	10.00		pCi/L
	1/30/80	H000DKF7	N	Strontium-90	2.60		pCi/L
				Uranium	17.00		pCi/L
	2/27/80	H000DKF8	N	Strontium-90	1.60		pCi/L
	4/09/80	H000DKF9	N	Strontium-90	1.40		pCi/L
				Uranium	27.00		pCi/L
	4/23/80	H000DKG0	N	Strontium-90	2.00		pCi/L
				Uranium	18.00		pCi/L
	6/13/80	H000DKG1	N	Strontium-90	2.30		pCi/L
				Uranium	18.00		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil- tered	Constituent Name	Result	Error	Units
399-4-9	7/16/80	H000DKG2	N	Strontium-90 Uranium	9.30 18.00		pCi/L pCi/L
	8/13/80	H000DKG3	N	Strontium-90 Uranium	4.00 23.00		pCi/L pCi/L
	1/09/81	H000DKG4	N	Strontium-90 Uranium	1.90 12.00		pCi/L pCi/L
	1/29/81	H000DKG5	N	Strontium-90 Uranium	2.50 13.00		pCi/L pCi/L
	3/11/81	H000DKG6	N	Strontium-90 Uranium	6.90 6.90		pCi/L pCi/L
	3/24/81	H000DKG7	N	Strontium-90 Uranium	3.20 13.00		pCi/L pCi/L
	4/24/81	H000DKG8	N	Cesium-137 Strontium-90 Uranium	30.00 3.20 18.00		pCi/L pCi/L pCi/L
	6/02/81	H000DKG9	N	Strontium-90 Uranium	2.30 11.00		pCi/L pCi/L
	6/22/81	H000DKH0	N	Strontium-90 Uranium	2.20 6.00		pCi/L pCi/L
	7/22/81	H000DKH1	N	Strontium-90 Uranium	3.20 24.00		pCi/L pCi/L
	8/25/81	H000DKH2	N	Strontium-90 Uranium	7.00 22.00		pCi/L pCi/L
	9/14/81	H000DKH3	N	Strontium-90 Uranium	3.10 24.00		pCi/L pCi/L
	10/14/81	H000DKH4	N	Strontium-90 Uranium	3.10 24.00		pCi/L pCi/L
	11/04/81	H000DKH5	N	Strontium-90 Uranium	2.50 6.70		pCi/L pCi/L
	1/07/82	H000DKH6	N	Strontium-90 Uranium	3.00 19.00		pCi/L pCi/L
	2/05/82	H000DKH7	N	Strontium-90 Uranium	13.00 24.00		pCi/L pCi/L
	4/23/82	H000DKH8	N	Strontium-90	6.70		pCi/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-9	4/23/82	H000DKH8	N	Uranium	17.00		pCi/l
	10/19/82	H000DKH9	N	Strontium-90	3.80		pCi/l
				Uranium	27.00		pCi/l
	3/21/83	H000DKJ0	N	Strontium-90	2.20		pCi/l
				Uranium	6.70		pCi/l
	6/20/83	H000DKJ1	N	Cesium-137	-4.90		pCi/L
				Strontium-90	.94		pCi/L
				Uranium	14.00		pCi/L
	9/21/83	H000DKJ2	N	Strontium-90	2.30		pCi/l
				Uranium	18.00		pCi/l
	12/02/83	H000DKJ3	N	Strontium-90	2.40		pCi/l
				Uranium	16.00		pCi/l
	2/06/84	H000DKJ4	N	Strontium-90	3.60		pCi/l
				Uranium	11.00		pCi/l
	4/13/84	H000DKJ5	N	Strontium-90	.87		pCi/l
				Uranium	16.00		pCi/l
	7/19/84	H000DKJ6	N	Strontium-90	1.30		pCi/l
				Uranium	4.90		pCi/l
	10/12/84	H000DKJ7	N	Strontium-90	-4.20		pCi/l
				Uranium	21.00		pCi/l
	1/24/85	H000DKJ8	N	Strontium-90	1.60		pCi/l
				Uranium	-.80		pCi/l
	4/15/85	H000DKK0	N	Strontium-90	-.12		pCi/l
				Uranium	21.00		pCi/l
	9/12/85	H000DKK2	N	Strontium-90	4.10		pCi/l
				Uranium	45.00		pCi/l
	12/27/85	H000DKK3	N	Strontium-90	5.50		pCi/l
				Uranium	24.00		pCi/l
	1/30/86	H000DKK4	N	Strontium-90	1.90		pCi/l
				Uranium	8.80		pCi/l
	4/24/86	H000DKK5	N	Strontium-90	1.90		pCi/l
				Uranium	33.00		pCi/l
	7/15/86	H000DKK7	N	Strontium-90	.96 U		pCi/l
				Uranium	33.00		pCi/l

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Filt-tered	Constituent Name	Result	Error	Units
399-4-9	10/10/86	H000DKK9	N	Strontium-90 Uranium	3.40 30.00		pCi/L pCi/L
	1/08/87	H000DKL0	N	Cesium-137 Strontium-90 Uranium			pCi/L
	3/18/87	H000DKL1	N	Cesium-137 Strontium-90 Uranium	1.33 U .26 U 24.30	.95 .73 6.12	pCi/L pCi/L pCi/L
	4/07/87	H000DKL2	N	Cesium-137 Strontium-90 Uranium	5.33 .78 U 25.80	3.80 1.05 6.66	pCi/L pCi/L pCi/L
	7/21/87	H000DKL3	N	Cesium-137 Strontium-90 Uranium	3.85 U .27 U 25.90	6.74 .73 6.64	pCi/L pCi/L pCi/L
	10/19/87	H000DKL4	N	Cesium-137 Strontium-90 Uranium	.34 U .12 U 29.80	4.01 .66 7.74	pCi/L pCi/L pCi/L
	2/08/88	H000DKL5	N	Cesium-137 Strontium-90 Uranium	3.39 U .05 U 22.80	4.54 .70 6.32	pCi/L pCi/L pCi/L
	5/31/88	H000DKL6	N	Cesium-137 Strontium-90 Uranium	0.00 U .45 U 24.10	6.38 .68 6.67	pCi/L pCi/L pCi/L
	7/07/88	H000DKL7	N	Cesium-137 Strontium-90 Uranium	-1.27 U .32 U 28.60	5.69 .63 8.00	pCi/L pCi/L pCi/L
	11/29/88	H000DKL8	N	Cesium-137 Strontium-90 Uranium	2.25 U .40 U 14.30	5.82 .60 3.99	pCi/L pCi/L pCi/L
	12/03/91	B01DY5	N	Barium Cadmium Cesium-137 Chromium Lead Strontium-90	50.60 3.00 6.58 U 6.00 3.10 .25 UJ		ug/L ug/L pCi/L ug/L ug/L pCi/L
		B01DY6	Y	Barium Cadmium Chromium Lead	50.40 1.50 2.00 1.00		ug/l ug/L ug/L ug/L
	4/21/92	B062F2	N	Barium	59.80		ug/L

GeoDAT Report - 2/05/98

Well	Collect Date	Sample Number	Fil-tered	Constituent Name	Result	Error	Units
399-4-9	4/21/92	B062F2	N	Cadmium	1.30		ug/L
				Cesium-137	9.50 UJ		pCi/L
				Chromium	5.00		ug/L
				Lead	2.40		ug/L
				Strontium-90	.16 UJ		pCi/L
				Uranium	50.00		ug/L
	9/09/92	B062F3	Y		50.00	9.50	ug/L
				Barium	55.20		ug/L
				Cadmium	1.00		ug/L
				Chromium	5.00		ug/L
				Lead	1.60		ug/L
9/14/92	B075Z5	N	Barium	48.30		ug/L	
			Cadmium	1.00		ug/L	
			Cesium-137	14.00 UJ		pCi/L	
			Chromium	4.50		ug/L	
			Lead	2.10		ug/L	
			Strontium-90	.04 UJ		pCi/l	
11/10/92	B075Z6	Y	Barium	53.40		ug/L	
			Cadmium	1.00		ug/L	
			Chromium	4.50		ug/L	
			Lead	2.40		ug/L	
	8/31/93	B01323	N	Barium	52.80		ug/L
				Cadmium	1.50		ug/L
				Cesium-137	11.00 U		pCi/L
				Chromium	2.60		ug/L
				Lead	1.00		ug/L
				Strontium-90	.12 UJ		pCi/L
	6/27/94	B076G2	N	Barium	54.60		ug/L
				Cadmium	1.50		ug/L
				Chromium	2.60		ug/L
				Lead	2.00		ug/L
	8/13/96	B07P80	N	Uranium	45.00		ug/L
					45.00	8.40	ug/L
	8/20/97	B08ZT6	N	Uranium	.38	.18	ug/L
	8/20/97	B0C1Y3	N	Uranium	38.90	12.19	ug/L
	8/20/97	B0HZ00	N	Uranium	74.10	16.30	ug/L
	8/20/97	B0LJT0	N	Uranium	128.00	28.50	ug/L